

HURCO®



WINMAX MILL DOCUMENTATION

WinMax Mill Dual Screen and Max Consoles for Hurco Machining Centers

The information in this document is subject to change without notice and does not represent a commitment on the part of Hurco Companies, Inc. (Hurco). The software described in this document is furnished under the License Agreement to customers. It is against the law to copy the software on any medium except as specifically allowed in the license agreement. The purchaser may make copies of the software for backup purposes. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, for any purpose without the express written permission of the Hurco machine tool owner.

Hurco Manufacturing Company reserves the right to incorporate any modification or improvements in machines and machine specifications which it considers necessary, and does not assume any obligation to make any said changes in machines or equipment previously sold.

Hurco products and services are subject to Hurco's then current prices, terms, and conditions, which are subject to change without notice.

© 2008 Hurco Companies, Inc. All rights reserved.

Patents: U.S. Patents B14,477,754; 5,453,933; Canadian Patent 1,102,434;
Japanese Patents 1,649,006 and 1,375,124; other Patents pending.

Hurco, Max, Ultimax, and WinMax are Registered Trademarks of Hurco Companies, Inc.

AutoCAD, Autodesk, and DXF are registered trademarks of Autodesk, Inc.

MS-DOS, Microsoft, and Windows are registered trademarks of Microsoft Corporation.

Many of the designations used by manufacturers and sellers to distinguish their products are claimed as trademarks. Hurco has listed here all trademarks of which it is aware. For more information about Hurco products and services, contact:

Hurco Companies, Inc.
One Technology Way
P.O. Box 68180
Indianapolis, IN 46268-0180
Tel (317) 293-5309 (products)
(317) 298-2635 (service)
Fax (317) 328-2812 (service)

For Hurco subsidiary contact information, go to Hurco's Web site:

www.hurco.com

TABLE OF CONTENTS

Table of Contents	-	iii
Using This Manual		xiii
Using the Touch Screen		xiii
Icons		xiii
Machine and Console Basics	1 -	1
Machine Components	1 -	1
Consoles	1 -	2
Control Panel Function Groups	1 -	3
Emergency Stop Buttons	1 -	5
Programming Keyboard	1 -	5
Axis, Spindle, and Machine Control	1 -	7
Communications Panel	1 -	11
Automatic Tool Changers	1 -	13
Loading a Tool into the Spindle	1 -	13
Unloading a Tool from the Spindle	1 -	14
Loading Tools into the ATC Magazine	1 -	14
Removing Tools from the ATC Magazine	1 -	15
Large Tools in the ATC Magazine	1 -	15
Machine Start Up and Shut Down	1 -	16
Calibrate Machine	1 -	16
Warm Up Machine	1 -	16
Reset Master	1 -	17
Recovery and Restart	1 -	17
Shut Down Techniques	1 -	18
WinMax Interface Environment	1 -	19
Softkeys	1 -	20
Drop-down Lists	1 -	20
Expand and Collapse Files	1 -	20
Pop-ups	1 -	21
Status Bar	1 -	21
On-screen Help	1 -	23
Program Manager	1 -	25
Program Properties	1 -	28
Disk Operations	1 -	28
FTP Manager	1 -	30
FTP Host List	1 -	30
FTP Host Properties	1 -	31
Utilities	1 -	32
Auxiliary Screen	1 -	32
System Configuration	1 -	32
Display WinMax Configuration	1 -	33
Display Machine Specifications	1 -	33
Backup Config & Machine Files	1 -	34
Restore Config & Machine Files	1 -	34
User Preferences	1 -	34
User Interface Settings	1 -	34

Conversational Settings	1 - 35
NC Settings	1 - 36
Autosave Settings	1 - 36
Tool Utilities and Settings	1 - 36
Machine Parameters	1 - 40
Serial Port Settings	1 - 44
FTP Server Settings	1 - 44
WinMax Uptime	1 - 45
Select Language	1 - 45
Data Logging Filters	1 - 45
Additional Utilities Softkeys	1 - 45
Printing Setup	1 - 46
Part Program Printing	1 - 46
Probing Data Printing	1 - 46
Integrator Support Services	1 - 47
Serial I/O	1 - 47
Log Files	1 - 47
Active Error Listing	1 - 48
Active Status Listing	1 - 48
Error History	1 - 48
Status History	1 - 49
Retrieve Log and Diagnostic Files	1 - 49
Export Log	1 - 50
Programming Basics	1 - 51
Input Mode	1 - 51
Erase Functions	1 - 51
Part Setup	1 - 52
Part Setup Fields	1 - 53
Part Setup Softkeys	1 - 54
Part Fixturing and Tool Loading	1 - 55
Work Offsets	1 - 55
Stock Geometry	1 - 56
Tool Setup	1 - 58
Tool Setup Softkeys	1 - 58
Tool Setup Fields	1 - 59
Advanced Tool Settings	1 - 62
Creating Tool Setup Templates	1 - 68
Zero Calibration	1 - 69
Part Program Tool Review	1 - 70
Tool Matching	1 - 71
Tool Management	1 - 73
Spindle	1 - 73
Auto	1 - 73
Manual	1 - 73
Tool and Material Database	1 - 74
Program Parameters	1 - 75
General Parameters 1	1 - 76
General Parameters 2	1 - 77
Milling Parameters 1	1 - 78
Milling Parameters 2	1 - 81
Holes Parameters	1 - 81
Probing Parameters	1 - 82
Performance Parameters	1 - 82
Import Functions	1 - 83

Conversational Components	1 - 83
NC States	1 - 83
Importing NC States into Conversational Programs	1 - 84
Copy and Change Blocks	1 - 85
Copy, Move, or Delete Blocks	1 - 86
Modify Dimensions	1 - 86
Changing Feeds, Speeds, and Tools	1 - 87
Change Surface Finish Quality	1 - 87
Review Mode	1 - 88
Auto Mode	1 - 89
Auto Mode Monitoring	1 - 90
Manual Mode	1 - 92
Graphics	1 - 93
Graphics Settings	1 - 93
Toolpath and Solid Graphics	1 - 94
Hurco Conversational Overview	2 - 1
Part Programming	1
Cutter Compensation	10
Lead In/Out Moves	16
Milling Operations	2 - 18
Creating a Milling Data Block	18
Mill Face	19
Circle Data Block	21
Ellipse Data Block	23
Frame Data Block	24
Finish Tool for a Mill Frame, Mill Circle or Mill Contour	27
Mill Triangle Data Block	28
Mill Diamond Data Block	30
Mill Hexagon Data Block	33
Lettering Data Block	35
Swept Surface	38
Lines/Arcs Data Blocks	43
Mill Contour	43
Contour Line	45
Contour Arc	45
Contour Blend Arc	46
Helix	48
3D Arc	49
Contour End	51
Holes Operations	2 - 52
Holes Data Block	52
Drill Overview	53
Tap Operations	60
Back Spotface	62
Bolt Circle	63
Locations	64
Holes End Block	65
Patterns Operations	2 - 66
Loop Rectangular	66
Loop Linear	67

Loop Angular	69
Loop Rotate	70
Pattern Locations	71
Scale	71
Mirror Image	72
Pattern End	73
Special Operations 2 -	74
Position Data Block	74
Graphics On/Off	75
Change Parameters	75
Change Part Setup	78
Machine Function	79
Lube Cycle	79
Comment Block	79
Insert Block	80
NC/Conversational Merge 2 -	81
NC Part Programming 3 -	1
NC Part Programming Principles 3 -	1
NC Part Programming 3 -	1
NC Editor 3 -	6
Editor Menus 3 -	6
Edit Screen Fields 3 -	6
Starting a New NC Program 3 -	9
NC Programming Rules 3 -	9
NC Editor Menus 3 -	10
Basic Programming Menu 3 -	10
Search and Edit Menu 3 -	11
Jump and Search Functions Menu 3 -	12
Wireframe Graphics Markers and Syntax Errors Menu 3 -	16
Program Execution and Verification Menu 3 -	16
NC Parameters 3 -	17
NC Configuration Parameters (Screen 1) 3 -	17
NC Configuration Parameters (Screen 2) 3 -	17
NC M and G Code Program Numbers 3 -	18
NC Variables 3 -	19
Macro Mode A Subprogram Variables 3 -	21
Macro Mode A G Code Group Status 3 -	22
NC Probing Part Setup 3 -	23
Preparatory Functions - G Codes 3 -	25
G Code Groups 3 -	25
G Code Table 3 -	26
Rapid Traverse (G00) 3 -	32
Linear Interpolation (G01) 3 -	33
Circular and Helical Interpolation (G02 and G03) 3 -	34
3D Circular Interpolation (G02.4 and G03.4) 3 -	38
Dwell Mode (G04) 3 -	39
Surface Finish (G05.1) 3 -	40
Data Smoothing (G05.2) 3 -	40

Surface Finish Quality (G05.3)	3 - 40
Precision Cornering (G09)	3 - 40
Setting Work Coordinate Systems with G10	3 - 41
Setting External Work Zero Offsets (G10 with L2)	3 - 41
Setting Tool Offsets with G10	3 - 41
Initializing Tool Length Offsets (G10 with P, R)	3 - 41
Initializing Tool Offsets (G10 with T, H, D)	3 - 41
Assigning Tool Offsets (G10 with L3)	3 - 42
Polar Coordinates Command (G16)	3 - 42
Plane Selection	3 - 43
XY Plane Selection (G17)	3 - 43
XZ Plane Selection (G18)	3 - 44
YZ Plane Selection (G19)	3 - 46
Units of Measure ISNC G20, G21	3 - 47
Automatic Return To and From Reference Point (G28 and G29)	3 - 48
Skip (Probing) Function (G31)	3 - 49
Tool Offsets (G40–G49)	3 - 51
Cutter Compensation (G40–G42)	3 - 52
Cutter Compensation – ISNC and Basic NC Programming Differences	3 - 53
Cutter Compensation Off (G40)	3 - 54
Cutter Compensation Left (G41)	3 - 54
Cutter Compensation Right (G42)	3 - 55
Cutter Compensation Programming	3 - 55
Tool Length Offset (G43, G44, G49)	3 - 57
Tool Radius Offset Increase (G45)	3 - 60
Tool Radius Offset Decrease (G46)	3 - 60
Tool Radius Offset Double Increase (G47)	3 - 60
Tool Radius Offset Double Decrease (G48)	3 - 60
Scaling (G50 and G51)	3 - 62
Mirror Image (G50.1 and G51.1)	3 - 64
Local Coordinate System Setting (G52)	3 - 66
Machine Coordinates (G53)	3 - 68
Multiple Work Coordinate Systems (G54–G59)	3 - 69
Aux Work Coordinate Systems (G54.1)	3 - 70
Precision Cornering On (G61) and Off (G64)	3 - 71
Special Program Support	3 - 72
Rotation (G68 and G69)	3 - 72
Units of Measure (BNC G70, G71)	3 - 74
Peck Drilling (G73)	3 - 75
Left-Handed Tapping Cycle (ISNC G74)	3 - 75
Single-Quadrant Circular Interpolation (BNC G74)	3 - 76
Multi-Quadrant Circular Interpolation (BNC G75)	3 - 76
Bore Orient (G76)	3 - 77
Canned Cycle Cancel (G80)	3 - 78
Drill, Spot Boring (G81)	3 - 78
Drill with Dwell, Counter Boring (G82)	3 - 79
Deep Hole Drilling (G83)	3 - 80
Tapping (G84)	3 - 82
Boring (G85)	3 - 84
Bore Rapid Out Cycle (ISNC G86)	3 - 85
Chip Breaker (BNC G87)	3 - 86
Back Boring (ISNC G87)	3 - 86
Rigid Tapping (BNC G88; ISNC G84.2; ISNC G84.3)	3 - 87
Canned Boring with Manual Feed Out and Dwell (ISNC G88)	3 - 88
Bore with Dwell (G89)	3 - 89

Absolute and Incremental (G90, G91)	3 - 90
Coordinate System Setting	3 - 91
Part Zero Setting (G92)	3 - 91
Feed Functions	3 - 93
Inverse Time Feedrate (G93) and Feed Per Minute Feedrate (G94)	3 - 93
Canned Cycle Descriptions	3 - 94
Return to Initial Point in Canned Cycles (G98)	3 - 94
Return to R Level in Canned Cycles (G99)	3 - 96
Canned Cycles	3 - 97
Canned Cycle Parameters	3 - 99
Depth (Z Parameter)	3 - 100
Dwell (P Parameter)	3 - 100
Feedrate (F Parameter)	3 - 101
Canceling or Replacing Canned Cycles	3 - 101
Spindle Speed - S Codes	3 - 102
Tool Functions	3 - 103
D Codes	3 - 103
L Codes (BNC)	3 - 103
T Codes	3 - 103
Miscellaneous Functions - M Codes	3 - 104
M Code Table	3 - 104
M Code Table —Laser Operation	3 - 105
Program Functions	3 - 106
Program Stop (M00)	3 - 106
Planned Stop (M01)	3 - 106
End of Program (M02)	3 - 107
Start Spindle Clockwise (M03)	3 - 107
Start Spindle Counterclockwise (M04)	3 - 107
Spindle Off (M05)	3 - 107
M6 Initiates Tool Change	3 - 108
Change Tool (M06)	3 - 108
Secondary Coolant On (M07)	3 - 109
Primary Coolant On (M08)	3 - 109
Both Coolant Systems Off (M09)	3 - 109
Both Coolant Systems On (M10)	3 - 109
Clamp C-axis (M12)	3 - 109
Unclamp C-axis (M13)	3 - 109
Oriented Spindle Stop (M19)	3 - 109
Pulse Indexer One Increment (M20)	3 - 110
Z Axis to Home Position (M25) - Basic NC Programming only	3 - 110
Select Part Probe Signal (M26)	3 - 110
Select Tool Probe Signal (M27)	3 - 110
Enable Rigid Tapping (ISNC M29)	3 - 110
End Program (M30)	3 - 110
Clamp A-axis (M32)	3 - 111
Unclamp A-axis (M33)	3 - 111
Clamp B-axis (M34)	3 - 111
Unclamp B-axis (M35)	3 - 111
Servo Off Code (M36)	3 - 111
Laser Input Update (M38-M40)	3 - 111
Single-Touch Probing (M41)	3 - 111
Double-Touch Probing (M42)	3 - 112

Barrier Air Control (M43 and M44)	3 - 112
Shutter Probe Control (M45 and M46)	3 - 112
Laser Emitter On/Off Control (M47 and M48)	3 - 112
Laser Receiver On/Off (M49 and M50)	3 - 112
Enable Auxiliary Output 1through 4 (M52 – M55)	3 - 112
Nonconfirmation Pallet Change (M56 – M58)	3 - 112
Chip Conveyor Fwd/Reverse/Stop (M59, M60, M61)	3 - 113
Disable Auxiliary Output 1 through 4 (M62 – M65)	3 - 113
Washdown Coolant System (M68, M69)	3 - 113
Right Handed C Axis (M80)	3 - 113
Left Handed C Axis (M81)	3 - 113
Subprogram Call (M98)	3 - 113
Jump; Return from Subprogram (M99)	3 - 114
3D Mold	4 - 1
3D Mold Parameters	4 - 1
3D Mold Contour	4 - 6
3D Mold Line	4 - 7
3D Mold Arc	4 - 8
3D Mold Blend Arc	4 - 9
Roughing and Finishing Tools	4 - 10
Roughing and Finishing Passes	4 - 13
UltiPockets Option	4 - 14
Pocket Boundary	4 - 14
Spiral Outward - No Islands	4 - 15
Spiral Inward	4 - 15
Programming Islands	4 - 15
Mill Contours	4 - 15
Mill Frame	4 - 16
Mill Circle	4 - 16
Pattern	4 - 16
Helical Plunge with UltiPocket Option	4 - 16
Helical Plunge Using Operator Specify Pocket Start	4 - 17
DXF Option	4 - 18
DXF Build Data Block	4 - 19
DXF Parameters	4 - 20
DXF Zoom Window	4 - 20
DXF Edit Drawing	4 - 21
DXF Layers	4 - 22
DXF Edit Modify - Arc	4 - 23
DXF Edit Modify - Line	4 - 23
DXF Edit Modify - Point	4 - 23
Rotary	4 - 24
Rotary A Axis Part Programs	4 - 24
Axis Diagram	4 - 25
Program Definition	4 - 25
Rotary Part Setup	4 - 26
Rotary A Axis	4 - 26
Rotary C Axis	4 - 26
Rotary Part Programming	4 - 27
Rotary Parameters	4 - 27
Rotary Position Block	4 - 28

Rotary Milling Operations	4 - 29
Rotary Lines and Arcs	4 - 29
Calculating Unknown Rotary Dimensions	4 - 29
Rotary A Axis	4 - 30
Rotary C Axis	4 - 30
Rotary Circle and Frame	4 - 30
Rotary A Axis	4 - 30
Rotary C Axis	4 - 30
Rotary Patterns	4 - 30
Rotary Pattern Loop	4 - 31
Rotary Pattern Locations	4 - 31
Rotary Holes	4 - 32
Rotary A Axis	4 - 32
Rotary C Axis	4 - 32
Probing Option	4 - 33
Part Probe Deflection	4 - 33
Part Probe Working Envelope	4 - 33
Tool Probe Setup Parameters	4 - 34
Part Probing Parameters	4 - 35
Tool Probe Calibration	4 - 37
Touch Tool Probe Calibration	4 - 37
Touch Tool and Part Probe Calibration	4 - 38
Laser Beam Calibration	4 - 39
Tool Probe Deflection Offset Calibration	4 - 41
Part Probe Calibration	4 - 43
Part Probe Deflection Offset Calibration	4 - 43
Tool Setup Probing Softkeys	4 - 45
Tool Setup Probing Fields	4 - 46
Probe Part Setup	4 - 47
Conversational Part Probing Cycles	4 - 48
Part Setup Screen	4 - 49
Part Zero Storage Cycle	4 - 49
Manual Mode Part Setup Probing Cycles	4 - 50
Manual Mode Part Skew Probing Cycles	4 - 50
Automatic Mode	4 - 52
Probe Part Setup Data Block	4 - 52
Probe Part Setup Fields	4 - 52
Automatic Part Zero Cycles	4 - 52
Automatic Skew Cycles	4 - 56
Probe Part Setup Data Block Execution	4 - 60
Part Inspection Cycles	4 - 60
Part Inspection Programming	4 - 64
Probe Tool Monitoring	4 - 64
Manual Tool Probing Cycles	4 - 65
Probe a Single Tool	4 - 66
Probe Multiple Tools	4 - 66
Tool Wear Detection Data Block	4 - 67
Probing Cycles	4 - 67
Part Setup Probing Cycles	4 - 67
Part Skew Probing Cycles	4 - 68
Edge Cycle	4 - 69
Hole or Circle Pocket Cycle	4 - 71
Cylinder Cycle	4 - 73
Rectangular Pocket Inside Cycle	4 - 75

Rectangular Solid Outside Cycle	4 - 76
Plane Intersection (Non-Rectangular Corner) Cycle	4 - 78
Edge Skew Cycle	4 - 80
Hole or Circle Pocket Skew Cycle	4 - 81
Cylinder Skew Cycle	4 - 81
Rectangular Pocket Skew Cycle	4 - 82
Rectangular Solid Skew Cycle	4 - 83
NCPP Option	4 - 84
Modal Subprograms	4 - 84
Modal Subprogram Call (G66)	4 - 84
Modal User Defined G Code	4 - 84
Modal Subprogram Cancel (G67)	4 - 85
Modal Subprogram Call (G66) Example	4 - 85
Macro Modes	4 - 86
Macro Instruction (G65)	4 - 86
NCPP Variable Summary	4 - 91
Variables_Option	4 - 106
Addresses with Variables	4 - 106
Alarm 3000 Messages	4 - 106
Vacant Variables	4 - 107
Variable Expressions	4 - 109
Indirect Variables	4 - 109
Saving Variable Values to a File on the Control	4 - 109
Variable Example	4 - 109
Program Control Statements	4 - 110
Subprograms	4 - 112
G65 Subprogram Call	4 - 112
Passing Argument Lists to Subprograms in Macro Mode B	4 - 113
Layering of Local Variables Within Subprogram Calls	4 - 114
Specifying Subprogram Iterations	4 - 115
Macro Instruction (G65)	4 - 115
User Defined Codes	4 - 118
M Codes	4 - 118
G Codes	4 - 118
S, B, and T Codes	4 - 119
Passing Single Dedicated Parameters to Subprograms	4 - 119
User Defined G Code Example	4 - 124
User Defined G and M Code Example	4 - 124
User Defined S, B and T Code Example	4 - 126
Global Variables	4 - 127
System Variables	4 - 127
Macro Mode A Local Variables	4 - 127
Macro Mode A Arguments	4 - 127
Macro Mode A G Code Groups	4 - 129
Read/Write Restrictions	4 - 129
Expression Symbols	4 - 134
Expression Keywords	4 - 134
Operation Priorities	4 - 138
GOTO Statements	4 - 139
Positive GOTO Statement	4 - 139
Negative GOTO Statement	4 - 139
IF Statements	4 - 139
WHILE Loops	4 - 139

DO Loops	4 - 140
Stop Program Execution	4 - 141
NC Part Programming Example	4 - 142
NCPP Example - Bolt Hole Circle	4 - 143
NCPP Example - Gear Pattern	4 - 144
Tool Fixture (TPS) Option	4 - 146
Tool Removal	4 - 146
Automatic Tool Change Using TPS	4 - 147
Bypass TPS in an Automatic Tool Change	4 - 148
Helical Plunge Option	4 - 149
Helical Plunge Milling Parameter Fields	4 - 149
Helical Plunge (Inside/Outside) for Mill Frames, Mill Circles and Ellipses	4 - 150
Helical Plunge with UltiPocket	4 - 151
Helical Plunge with Operator Specified Location	4 - 151
Helical Plunge in the Center of a Pocket	4 - 151
Helical Plunge with Outward Pocketing	4 - 151
Helical Plunge of Mill Frame Inside with No Pecking and Blend Offset	4 - 152
Helical Plunging of Mill Frame Inside with Pecking and Straight Plunge Finish Pass and Blend Offset	4 - 153
Helical Plunge with Lines and Arcs	4 - 155
Helical Plunge with 3-D Part Programming Option	4 - 155
UltiNet	4 - 156
UltiNet FTP Client	4 - 156
UltiNet FTP Server	4 - 156
FTP Server Settings	4 - 157
Index	IX - 1

USING THIS MANUAL

This manual uses several conventions to explain the safety features and emphasize key concepts. These conventions are described in this section.

Additional information is available on the machine's Documentation CD.

Using the Touch Screen

The console has a touch screen for entering programming data. Tap the screen on a softkey, field, or drop-down list using the stylus attached to the side of the console or another suitable pointing device to make a selection.

Icons

This manual may contain the following icons:

Caution/Warning



The operator may be injured and the center severely damaged if the described procedure is not followed.

Hints and Tricks



Useful suggestions that show creative uses of the WinMax features.

Important



Ensures proper operation of the machine and control.

Troubleshooting



Steps that can be taken to solve potential problems.

Where can we go from here?



Lists several possible options the operator can take.

Table of Contents




To assist with onscreen viewing, this icon is located on the cover page. Click the icon to access the Table of Contents (TOC).

You can also access many of the same TOC entries from the Adobe Reader bookmarks located on the left side of the PDF page.

MACHINE AND CONSOLE BASICS

Machine Components

Before using the machine, you should become familiar with its components. Because of European Committee (CE) requirements, Hurco machines sold in Europe differ somewhat from those sold elsewhere. The figure below identifies some of the easily recognized components of a machine. The console is in front of the machine, facing the operator's area.



1	Console
2	Way Cover
3	Table
4	Spindle
5	Power Drawbar
6	Spindle Motor
7	Z-Axis Servo
8	Column
9	Base

Figure 1–1. Hurco Machine with the Dual-Screen Console

Hurco machines are available with several hardware and software options. Information about these options is available from Hurco or your Hurco Distributor.

Consoles

The dual-screen and single-screen consoles use WinMax software:




Figure 1-2. Dual-Screen and Single-Screen Console

The console, and the electrical components required to operate it, are called the “control” or the “CNC” (Computer Numeric Control). Some of the electrical components are built into a separate enclosure kept in the machine’s electrical cabinet.


Some of the control’s internal components, such as disk drives and memory, are like those in a PC. Disk operations, such as copying, deleting and storing files, are also similar.

The floppy drive is located on the console’s right side panel. To protect the drive from debris, the protective floppy drive cover should be closed, except when inserting or removing a diskette.

Information about options is available from Hurco or your Hurco distributor.

Control Panel Function Groups

The buttons, keys, and knobs on the dual- and single-screen consoles are grouped by their functions. Here are the control panel groups on an dual-screen console:




1	Touchscreen softkeys
2	Text screen
3	Graphics screen
4	Brightness control
5	Machine operations
6	Emergency stop
7	Trackball
8	Programming keyboard
9	Remote jog
10	Emergency stop
11	Axis, spindle, and machine control
12	Power on button

Figure 1–3. Dual-Screen Console Panel Groups

The dual-screen console also has a power on button, emergency stop button, and brightness control thumbwheels for the Text screen and Graphics screen. Some consoles are also equipped with contrast control thumbwheels.

Here are the control panel groups on a single-screen console:



1	Power On Button
2	Emergency Stop Button
3	Programming Keyboard
4	Axis, Spindle, and Machine Control Dials
5	Machine Operation Keys
6	Console Jog Unit

Figure 1-4. Single-Screen Console Panel Groups

Emergency Stop Buttons

There is an Emergency Stop button located on each console and one on the Remote Jog Unit. Press the Emergency Stop button to stop all spindle and table motion. This button locks down when pressed. To release it, twist the button in the direction indicated by the arrows.



Learn the location of all Emergency Stop buttons on the machining center *before* operating.



If the Emergency Stop button is pressed during execution of a part program, the tool must be jogged clear of the part before resuming operation.

Programming Keyboard

Program a job at the machine while reading from a blueprint or program worksheet. The prompts on the Text screen lead you through each element of a part program. Enter machine operations, part dimensions, and other parameters by selecting the appropriate screen softkeys and console buttons.

Set up and run part programs, and manage part program files using the following data entry keys:

- Text Screen Data Entry
- Softkeys
- Numeric Keypad
- Pop-up Text Entry Window
- Graphics Screen Data Entry

Text Screen Data Entry

Text screen data entry keys are used for entering programming information into the Text screen's fields. These keys are located in the center of the console's Programming Keypad.

Programming Mode

Programming Mode console keys are named for the screens they activate:

- **Input** – displays the main programming screen used to create and edit part programs. From this screen, access Part Setup, Tool Setup, Part Programming, Program Parameters, Copy and Change Blocks, and Restore and Erase menus.
- **Auxiliary** – accesses program storage management, system configuration settings, DXF files, reset master, and the upgrade system files menus.
- **Review** – for Conversational programs, provides an outline view of the blocks currently programmed, including type of block and tool used. Jump to a desired block by typing the block number and pressing Enter. For Numerical Control (NC) programs, the Review key displays or re-displays the NC part program.

- **Help** – displays help text. Place the cursor on a field in question and press the Help key. If help text is available, it will appear in a pop-up window. Help is not available for all screens.

These keys function as they would on a standard PC keyboard:

- **Insert** - type over and replace current text.
- **Delete** - delete the character to the right of the cursor.
- **Home** - position the cursor before a line of text.
- **End** - position the cursor at the end of a line of text.
- **Page Up** - position the cursor at the beginning of the previous page.
- **Page Down** - position the cursor at the beginning of the next page.

Text Screen Cursor Control Keys

These keys control cursor movement and perform programming operations:

- **Arrow keys** - move the cursor from one field to the next, or advance a part program to the next data block.
- **Enter key** (↵) - accept the information typed in a text field, or move to the next field.
- **Special Function keys**
- **C console key** - Use the *C* console and *Clear* keys to delete the value at the current cursor position.
- **Delete console key** - Use the *F* console and *Delete* keys together to delete the character to the left of the cursor.
- **Arrow console key** - Use the *F* console key in combination with the arrow keys to quickly move the graphics cursor on the graphics screen.

Softkeys

Softkeys have a three-dimensional look on the touch screen of the console. Each softkey is labeled with an operation. Touching the softkey selects its operation.

If a softkey appears “grayed out,” the operation is not available because the cursor is not in a specific field, or the machine does not support the option.



Another way to activate a softkey is to press and hold the *F* console key while you simultaneously press the number key that corresponds to the softkey number (F1, F2, . . . F8).

Numeric Keypad

The numeric keypad allows you to enter numbers and calculate values in the Text screen. Perform the following operations with this keypad:

- Enter numeric data into fields on the screen.
- Perform calculations using the mathematical symbols (\div , \times , $-$, $+$) on the keypad.

Optional Computer Keyboard

If the console is equipped with an optional computer keyboard, use it to enter data into a field. Press the Enter key to update a field and advance the cursor.

Axis, Spindle, and Machine Control

The following keys and knobs are used to control machine movement and adjust the spindle and axes.

Override Knobs


Three knobs on the upper console allow you to override the programmed axis feedrate, rapid, and spindle speed.

The Override knobs function as follows:

- **Axis Feed Rate** - controls the programmed axis feedrate during an auto run program. Turning the dial to counterclockwise slows the feedrate; turning the dial to clockwise speeds the feedrate. Selecting *Min* slows the spindle to 10% of the nominal value. Selecting *Max* increases the feedrate to 150% of the nominal value.
- **Spindle Speed** - controls the spindle speed. Turning the dial counterclockwise slows the spindle; turning the dial clockwise increases spindle speed. Selecting *Min* slows spindle speed to 640 RPM slower than the nominal value. Selecting *Max* increases spindle speed to 640 RPM faster than the nominal value.
- **Rapid Override** - overrides the programmed rapid traverse; the speed at which the table moves from one point to another. Selecting *Min* slows the table speed to 10% of the nominal value. Selecting *Max* increases the table speed to 150% of the nominal value.

Jog Unit

Use the Jog Unit to manually jog the axes. The Console Jog Unit is on the Max console. The hand-held Remote Jog Unit can be removed from the console and carried closer to the work piece.



1	Emergency Stop Button
2	Store Position Key
3	Hand Wheel Multiplier Keys
4	Jog Hand Wheel
5	Jog Feed Keys
6	Jog Feed Override
7	Axis Select Switch


Figure 1-5. Remote Jog Unit

Both the Console Jog Unit and the Remote Jog Unit function the same:


1. Select an axis with the Axis Select Switch.
2. Use the Jog Feed Keys:

- a. Select either the + or – Jog Feed Keys.
- b. Adjust Jog Feed Override to override the programmed axis feedrate.

OR

3. Use the Hand Wheel Multiplier:
 - a. Select a hand wheel resolution with one of the Hand Wheel Multiplier Keys.
 - b. Rotate the Jog Hand Wheel.
 Other than the Emergency Stop button, the Jog Unit does not affect running programs.

The dials on a Jog Unit are defined as follows:

- **Axis Select Switch** – select the axis to jog (O, X, Y, Z, A, B).
- **Jog Feed Override** – control the jog speed (10% to 150%) of the nominal value. Use this dial to touch off the tool and move the X and Y axes to touch off the part for Tool and Part Setup.
- **Jog Feed Keys** - select minus (-) or plus (+) jog direction.
- **Jog Hand Wheel** - select minus (-) or plus (+) jog direction.
- **Hand Wheel Multiplier Keys** - define the hand wheel resolution.
 - **x1** - defines a one-to-one ratio (each click equals .0001 inch, or .00254 mm).
 - **x10** - defines a 10-to-one ratio (each click equals .001 inch, or .0254 mm).
 - **x100** - defines a 100-to-one ratio (each click equals 0.01 inch, or .254 mm. One full turn equals 1 inch, or 25.4 mm).
- **Store Position Key** - record the axis' current position in the part program's setup screens.
 See the "Setting Jog Unit Parameters " section for instructions on setting the Jog Unit parameters.

Use a Jog Unit to manually jog the axes:

1. Select an axis with the Axis Select Switch.
2. Use the Jog Feed Keys:
 - a. Jog axis direction by select either + or – .
 - b. Use the Jog Feed Override to override the programmed axis feedrate.

OR

Use the Hand Wheel Multiplier:

- a. Select a hand wheel resolution with one of the Hand Wheel Multiplier Keys
- b. Rotate the Jog Hand Wheel to jog axis direction.

Setting Jog Unit Parameters

To access the parameters :

1. Press the Manual Mode console key to display the Manual screen.
2. Press the Manual Function (F2) softkey. The Jog Unit parameters are displayed:

- **Manual Jog Feed** - enter the desired manual jog axis feedrate. The range is from 0.0 to the machine's maximum feedrate.

An axis may have a maximum jog feedrate slower than other axes. This slower axis can only move at its maximum jog feedrate (and not the higher feedrate of other axes).

For example, the X and Y axes on a machine each have a maximum jog feedrate of 787 inches per minute (ipm). The Z axis has a maximum jog feedrate of 100 ipm. Without using the jog feedrate override, the X and Y axes can jog at 787 ipm , but the Z axis is limited at 100 ipm.

- **Manual Spindle Speed** - enter the spindle speed when the Spindle On console key is pressed. This value can not be greater than the machine's maximum spindle speed. Entering a negative value (e.g., -500) causes the spindle to reverse (turn counterclockwise) at that speed.

Machine Control

Machine Control buttons start and stop machine operation. The buttons function as follows:

- **Power On** - enables the relay control system. This button must be illuminated to operate the machine, but may be switched off while creating or editing a part program.
- **Start Cycle** - activates machine operation. When the machine is in an active mode, the Start Cycle flashes to indicate the machine is ready. When this button is pressed again, the light switches off.

To turn Control Power On:

1. Press the Power On console button.
2. Press the Manual Mode console key.
3. Press the Start Cycle console button.



Never press the Start Cycle button without knowing exactly what the machine will do.

- **Stop Cycle** - stops axes movement, then stops the spindle.
- **Feed Hold (Motion Hold on Max console)** - stops all axes movement, except a tap operation, when the tool is in the programmed feedrate region. Pressing the button a second time allows machine positioning to resume.

To Stop an Automatic Machine Operation:

Press the Stop Cycle button to stop the axis, then the spindle.

⇒ Or


1. Press the Feed Hold (or Motion Hold) console button to stop axis motion.
2. Press the Spindle Off console key to stop the spindle.
3. Press the Feed Hold (or Motion Hold) console button again.

Communications Panel

All communication ports are located on the Comm Port panel assembly on machine control cabinet. The following connectors are available:

Port	Connector Type	Use
10-base T	RJ45	Network (Ethernet)
Indexer	8-pin military	Indexer
PORT 1 and Port 2	9-pin	RS-232C Serial Communications
USB	USB jump drive	Not available for use.

The communication ports are typically arranged as follows:




Communications Panel

RS-232C Serial Port

The RS-232C serial ports can be used to connect peripherals to the machine. These ports may be addressed separately. The standard baud rates are software-selectable. The ports can be used as an output or input, depending upon the software.

The connector pin designated for the RS-232C signal is shown below:



Male 9-Pin D-Type Connector

While the signals present at the serial port conforms to the RS-232C standard, not all standard RS-232C signals are available. Some peripheral devices may provide RS-232C control signals that are not available at the port described here. However, such devices can usually be adapted to the port. In some cases, it may be necessary to add jumpers to the connector. Signals available at the serial port are:

Pin	Signal Name	Signal on the Pin
1	Data Carrier Detect (DCD)	Not used by the control.
2	Receive Data (RXD)	Data received (by machine) in serial format from peripheral device.
3	Transmit Data (TXD)	Data transmitted (by machine) to peripheral device in serial format.
4	Data Terminal Ready (DTR)	Not used by the control.
5	Signal Ground (SG)	Line establishing the common ground reference potential for all interface lines.
6	Data Set Ready (DSR)	Signal to notify printer that transmitter is ready for transmission.
7	Request to Send (RTS)	Line used by control to instruct peripheral device to get ready to receive data. Data can be transmitted after the Clear-To-Send signal is received from connected peripheral device.
8	Clear to Send (CTS)	Control line used by peripheral device to indicate that it is ready to receive data from machine.
9	Ring Indicator (RI)	Signal indicates modem has received the ring of an incoming call.

To connect a peripheral to the machine, fabricate an adapter cable. If a properly shielded low capacitance cable is used, cable lengths of up to 100 feet are permissible.

Be certain that you use the correct cabling before connecting the device to the machine. Consult the peripheral manual to determine whether the peripheral is a Data Terminal Equipment (DTE) or Data Communication Equipment (DCE) device. The Hurco machine is a DTE device, and in most cases, so is a personal computer. A printer may be either a DTE or DCE device.

Indexer Port

Indexing signals are always present at the Indexer port, so there is no need to turn it on. It is the customer's responsibility to provide a harness from the Indexer to the Indexer port. Before making this harness, see the *Parts Listing and Diagrams Manual* for the correct pin-outs.

Network Port

The 10baseT (RJ45) connector is used with the Ultinet option. This option requires an ethernet card, cabling from the ethernet card to the communications panel, and an optikey diskette to enable the option.

USB Port

The USB Port (Universal Serial Bus) is a high-speed port that allows you to connect devices, such as printers and jump drives to the panel. You can use a jump drive to transfer files.

Automatic Tool Changers

Hurco machining centers use either a Swing-Arm Random Pocket Automatic Tool Changer (ATC) or a Horizontal Chain Type ATC. Both types of ATCs function essentially the same.

Each tool is inserted into a tool holder before being loaded into the spindle. The *orientation hole* in the tool holder must always line up with the *orientation key* in the tool changer. Tool changer stations are numbered to identify and locate each tool.

⇒ Only use tools that are dimensioned for the maximum spindle speed.

Loading a Tool into the Spindle

Use this procedure to manually load a tool into the spindle:

1. Press the Machine Mode Manual console key to prevent the ATC from moving while you insert a tool. The Manual screen appears.
2. Touch the Orient Spindle softkey to position the spindle for tool insertion. If there is a tool in the spindle, refer to [Removing Tools from the ATC Magazine](#).
3. Insert the tool holder into the spindle. Make sure the tool holder slots align with the spindle head guides.
4. Release the Spindle Unclamp button to secure the tool in the spindle. Be certain that the tool is firmly seated.
5. Touch the Tool In Spindle softkey. The Tool In Spindle field appears.
6. Make sure the tool number in the Tool In Spindle field matches the number of the tool in the spindle. If the numbers do not match, enter the correct tool number.
7. To load a tool into the ATC magazine, see the "Loading Tools into the ATC Magazine" section.

Unloading a Tool from the Spindle

To manually remove a tool from the spindle, follow these steps:

1. Press the Manual Mode console key. The Manual screen appears.
2. Hold the tool to prevent it from dropping.
3. Press the Spindle Unclamp button. The spindle unclamp button is either on the side of the spindle, or the front of the spindle. Refer to *Parts Listing and Wiring Diagrams Manual* for your machine for a drawing showing the Spindle Unclamp button location.
4. The tool disengages. Pull the tool out of the spindle.
5. Release the Spindle Unclamp button when the tool is free.

Loading Tools into the ATC Magazine

The ATC takes a tool from the spindle and automatically loads it into the magazine, if space allows. The tool's location in the magazine is recorded in the ATC Map (the Horizontal Chain Type ATC does not use an ATC Map). Before loading a tool into the ATC magazine, the Servo power must be On, and the machine must be calibrated.



Do not manually load tools directly into the magazine.

To load the tool currently in the spindle into the ATC magazine:

1. Press the Manual Mode console key.
2. Touch the Tool In Spindle softkey. The Tool In Spindle, Next Tool, and ATC Map (Swing-Arm Random Pocket ATC only) fields appear. For more information about the ATC Map, see "The ATC Map" section.
3. Verify that the Tool In Spindle value matches the tool currently in the spindle. If the numbers do not match, enter the correct tool number.
4. Enter the same tool number into the Next Tool field.
5. Press the Tool Changer Auto console key.
6. Enter a new tool number into the Next Tool field. The ATC Map field must be Auto.
7. Press the Tool Changer Auto console key. The Start Cycle light begins flashing.
8. Clear the tool changer and shut the enclosure door. Press the Start Cycle button. The Tool In Spindle field will be updated to the next tool value.
 - If the Next Tool is an Auto tool, it was placed into the magazine when the previous tool was removed from the spindle.
 - If the Next Tool is a Manual tool, you will be prompted to insert it into the spindle.

Removing Tools from the ATC Magazine

Remove tools from the ATC magazine by following these steps:

1. Press the Manual Mode console key.
2. Touch the Tool In Spindle softkey to access the Tool In Spindle screen. If there is no tool in the spindle, set the Tool In Spindle field to 0 (zero).
 - ⇒ The ATC Map field will indicate if the tool selected is in the magazine, and its location.
3. Enter the tool number (of the tool you want to remove in the magazine) into the Next Tool field.
4. Press the Tool Changer Auto console key to move the Next Tool into the spindle.
5. Clear the tool changer area and shut the enclosure door. Press the Start Cycle button to initiate the tool change.
6. Press the Spindle Unclamp button and manually remove the tool from the spindle.
7. Repeat steps 2 through 6, as needed, to remove additional tools from the ATC magazine.

Large Tools in the ATC Magazine

A part program may require tools with large diameters. These tools can be manually loaded by the operator, or automatically loaded.

- ⇒ The ATC magazine capacity is reduced by half for tools larger than 80 mm (125 mm for some machines).

Follow these steps to load large tools into the ATC magazine:

1. Touch the ATC Map softkey from the Tool In Spindle screen. The ATC Map appears. See "The ATC Map" section for more information.
2. Touch the Max. Tool Dia. More than XX mm softkey.
3. An "ATC Map will be cleared! Are you sure you want to change Max. Tool Diameter to more than XX mm?" message appears.
 - ⇒ Each time you switch between large and small tools, the entire ATC Map will be cleared and the magazine must be reloaded.
4. Select the Yes softkey. The ATC Map will clear, then reappear. Only the odd numbered tool pockets will be available.
5. Reload tools into the magazine using the "Loading a Tool into the Spindle" section.
6. Return to the default setting of Maximum Tool Diameter XX mm or Less by using the previous procedure and touching the Max. Tool Dia. XX mm or Less softkey.

Machine Start Up and Shut Down

Calibrate Machine

Calibrating establishes the machine reference point (absolute zero) for each axis. Absolute zero is the location on the table, usually a corner or near a corner, where the X and Y axes intersect. This value does not change.

To calibrate the machine, press the Manual Mode console button. "Uncalibrated" will be in the Cal Status field.

Establishing Servo Power

Perform the following steps to establish servo power:

1. If necessary, release all Emergency Stop buttons. Twist the button in the direction indicated by the arrows to release it.
2. Press the Manual Mode console button.
3. Press the console Power On button to turn on the machine. The Power On button lights up.
4. If there is a servo or spindle error, press the Reset Servos and Spindle softkey to clear it. The Start Cycle button begins flashing.
5. Press the Start Cycle button to turn on the machine servos. The Start Cycle button stops flashing.

Axes Calibration

To calibrate all axes, follow these steps:

1. Press the Calibrate Machine softkey. The Start Cycle button begins to flash off and on.
2. Press the flashing Start Cycle button. The Axis Limit Switches field indicates the current status of the machining center's limit switches as each axis calibrates.
3. The machine position display (at the top of the text screen) shows zero (0) for all axes when the calibration process is complete.

Warm Up Machine

If the machine has been idle for an hour or more, it is recommended that the warm up cycle be run. Warming up an idle machine before part cutting improves component reliability and machine performance. You must be in Manual mode to run a warm up cycle.

Follow these steps to warm up the machining center:

1. The control power must be on and the axes must be calibrated. There must not be any tool in the spindle, and the Tool in Spindle field on the Manual screen must be 0.

2. Select the Warm Up Machine softkey. The Start Cycle button begins flashing.
3. Press the Start Cycle button (to cancel the warm up cycle, press any Mode console button or softkey before pressing the Start Cycle button). The axes slowly move from one end of the machine to the other. The spindle moves at a low RPM for five minutes.
4. The warm up cycle completes in 15 minutes. The Manual screen reappears and axis movement stops.

Follow these steps to *cancel* the warm-up cycle:

1. Press the Feed Hold console button.
2. Press the Spindle Off button.
3. Press the Feed Hold button a second time, or press the Stop Cycle button.

Reset Master

To restart the control (*reboot* the system) without switching the power to the machine tool off and back on again, follow these steps:

1. Press the Auxiliary console button. The Auxiliary screen appears.
2. Press the More softkey.
3. Press the Reset Master softkey. The Yes and No softkeys appear. When the Yes softkey is pressed, the system will reboot. Pressing the No softkey aborts the reset process.



Be sure to save any part program you're working on before resetting the master. In NC Programming, an unsaved part program will be permanently erased. In Conversational Programming, the part program will be saved, but any changes made after the last autosave will be lost.

Recovery and Restart

Restart a part program at almost any point within the program - typically, the point at which the running program was interrupted.

If the Emergency Stop button was used to stop machining, machine power must be restored before restarting the program.

To restart the program, follow these steps:

1. Select the console Auto button. The Start Block default is 1, and the End Block default is the last block of the program.
2. Enter the proper *Start Block* and, optionally, an *End Block* if other than the end of the program.
3. Touch the Recovery Restart softkey.
4. If the Start Block contains multiple choices for restart, then prompts are displayed to select the proper point of restart.

Shut Down Techniques

At the end of a work day, most shops leave their machine tools powered up to simplify start-up the next day. There are three methods used to shut down a machine without turning off the power:

- Using the Emergency Stop button.
- Park the machine.
- Using the Control Power Off Timer.



If machine power will be left on overnight, either park the machine or press the Emergency Stop button to turn off the power to the servos and stop the machine from pumping lubrication onto the ways.

Emergency Stop

To shut down the machining center quickly, press the Emergency Stop button. All motion stops and power is shut off to the spindle, relay control, way lubrication pumps, and servo systems.



Do not use Emergency Stop shut down if the machine has a long table with heavy equipment attached to one end. Instead, park the machine so that the weight of the table and any attached equipment will be evenly distributed.



Before hitting the Emergency Stop button, park the machine or center the table.

Park Machine

Parking the machine centers the table and places the spindle at the home position. Table and attached equipment weight is distributed evenly when the machine is parked. Before parking the machine, the servo power must be on, the machine must be calibrated and the Tool in Spindle must be 0.

Follow this procedure to park the machine:

1. Press the Manual Mode console button.
2. Select the PARK MACHINE softkey. The Start Cycle button flashes.
3. Press the Start Cycle button. The machine moves to its park position.
4. A message with instructions to return to the power-up condition is displayed.

Control Power Off Timer

Set the Control Power Off Timer on the System Parameters screen. All motion stops and power is shut off to the spindle, relay control, way lubrication pumps, and servo systems.



Where can we go from here?

To restart the machine after the Emergency Stop was pressed, follow this sequence:

1. Twist the Emergency Stop button to release it.
2. Press the Manual Machine Mode button.
3. Press the Power On button.
4. Press the Start Cycle button.

Or...

To restart the machine after it was parked, follow this sequence:

1. Press the Manual Machine Mode button.
2. Press the Power On button.
3. Press the Start Cycle button.

Or...

If machine will not be used for several days or power surges and blackouts are common, switch off the machine's power. After restarting, calibrate and warm up the machine.

WinMax Interface Environment

There are three ways to navigate and enter data for programming:

- Ultimax classic edit mode—use the console keys; for example, the arrow keys for navigation and the enter key to accept data typed into a field
- Touchscreen—use the stylus or other pointing device to select softkeys and drop-down lists for data entry and programming
- Keyboard—use the function (F1-F12) keys and other keyboard shortcuts for navigation and to call up screens


Softkeys

Softkeys appear as buttons on the screen; their default location is the right side of the screen, but they can also be positioned on the left by changing the setting in **User Preferences** (see [Utilities](#) for more information). Select a softkey using one of these methods:

- On the screen, touch the softkey
- On the console, simultaneously press the **F** key and the number that corresponds to the softkey (for example, **F + 1** will select the **F1** softkey). For dual-console machines, **ALT +** the softkey number will select softkeys on the graphics screen.
- On the keyboard (if using), press the corresponding function key (F1, F2, F3)

Drop-down Lists


Many fields contain a choice of items that are viewed by pulling down a list:



Example of a drop-down list

Expand and Collapse Files


In the Program Manager, files can be expanded or collapsed as follows:



Example of Expand and Collapse Files


Pop-ups

During machine operation and programming, pop-up boxes may be displayed in place of error or status messages that were previously displayed in the prompt or status area in Ultimax. These pop-up boxes can be closed by selecting the appropriate button (i.e., YES or NO or OK). Some pop-up boxes may only provide informational messages and will be displayed for a few seconds before they automatically close.



Pop-up message example

Certain pop-ups, such as the calculator and virtual keyboard, can be minimized by touching the "—" in the upper right corner. These pop-ups will remain open but are "hidden" in the taskbar, and can be viewed again by touching the taskbar button. These pop-ups can also be closed by touching the "X" in the upper right corner:



Pop-up showing minimize and close icons

Status Bar

The Status Bar appears at the bottom of every WinMax screen. It displays the program name of the current active part program, a calculator icon, the current unit of measure (inch or mm), the keyboard icon, and the current time. When viewed on a single screen console, all icons appear in the same status bar; when viewed on a dual-screen console, the program name and calculator icon appear on the left screen status bar, and the unit of measure, keyboard icon and time appear on the right screen status bar.


- To use the calculator function, touch the calculator icon.
- To use the on-screen keyboard, touch the keyboard icon.
- To change the unit of measure, touch the unit of measure abbreviation.



Status Bar and other areas

Calculator

Select the calculator icon in the Status Bar to open the calculator. The calculator appears on screen and is operated using the stylus to select the calculator keys on screen.



Calculator pop-up

When the calculator is minimized (with the "—" in the upper right corner), the last calculation is retained, but when it is closed (with the "X" in the upper right corner), the last calculation is erased.

On-screen Help

On-screen Help provides information about using WinMax. The Help is context-sensitive to the screen level. Press the console Help button to display the Help topic for the current screen. The following list describes Help functions:

- Buttons in the upper left-hand corner of the Help screen are used to move through Help topics and print screens.
 - Use the **Hide** button to hide the navigation pane.
 - Use the **Back** button to return to the previous Help screen.
 - Use the **Print** button to print the current Help topic, if a printer attached and configured. See [Accessing the WinMax Help in PDF format](#) for more information.
- Use the arrow buttons to move between pages within a Help topic and to move through topics.
- Use the **Contents** tab for a list of information sorted by subject:
 1. Select the "+" to expand the topic and view sub-topics.
 2. Select the topic to display it.
- Use the **Index** tab to show the Help index:
 1. Quickly scroll to an index topic by typing the topic in the box at the top of the index.
 2. Select a topic and the Display button to view the topic.
- Use the **Search** tab to search the Help for a word or phrase:
 1. Type the search word(s) into the text box at the top of the pane.
 2. Select the List Topics button. A list of topics that contain the search word(s) is displayed.
 3. Select a topic and the Display button to view that topic.
- Use the **Favorites** tab to save Help topics for quick access:
 1. Select the Add button at the bottom of the pane to add the current topic.
 2. Select a topic from the Favorites list, and select the Display button to view it.
 3. Select a topic from the Favorites list, and select the Remove button to remove it from the list.

Accessing the WinMax Help in PDF format

The WinMax On-screen Help is also provided as a PDF file for easy printing. The information contained in the PDF file is identical to the on-screen Help. The PDF file may be copied to a floppy disk or USB memory device to be transferred to a PC for viewing or printing. Here are the steps to access the PDF file:

1. From the Input screen, select the PROGRAM MANAGER *F8* softkey.
2. Select the DISK OPERATIONS *F7* softkey.
3. In the left-hand pane, navigate through the folders:
 - For WinMax Mill on a machine, the path is D:\Hurco\Winmax Mill\hlp
 - For WinMax Desktop on a PC, the path is C:\Program Files\Winmax Mill\hlp.

The PDF file will appear in the right-hand pane.

4. Highlight the **WinMax Mill Documentation.pdf** file in the right-hand pane, and select the COPY *F2* softkey.
5. Ensure that your media is loaded (either a floppy disk in the disk drive or a USB memory device in the USB port), and navigate to the proper location in the left-hand pane of the DISK OPERATIONS screen (either the floppy drive A: or the USB port E:). Highlight the desired location.
6. Place the cursor in the right-hand pane, and select the PASTE *F3* softkey to paste the PDF file to the desired location.
7. You may now remove your media and load the PDF file onto a PC for viewing and printing.

PROGRAM MANAGER

Program Manager shows all part programs that are in the control's memory to edit or run. Use the Program Manager menu to create, open, save, and close programs. Features of the Program Manager include:

- Ability to load more than one program at a time
- Ability to load Conversational and NC programs at the same time
- Ability to copy blocks from one program into another (blocks are copied in Program Review; Program Manager is used to switch between programs to facilitate copy and paste)




Figure 2. WinMax Program Manager



Sort the program list by Program Name or Path by selecting the corresponding header. Select the Program Name header once to sort the list alphabetically. Select the Program Name header again and sort the list in reverse alphabetical order.


Program Manager softkeys are:

- **NEW F1**—creates a new part program. Choose the program type by selecting one of these softkeys:
- **CONVERSATIONAL PROGRAM F1**—creates a new conversational part program.

- **NC PROGRAM F2**—creates a new NC part program (extensions for NC part programs are determined by the NC dialect set in User Preferences, .FNC for Industry Standard and .HNC for Basic NC.).

⇒ WinMax gives new programs the default name NONAME (for example, NONAME1.HWM). When new programs are created, they should be renamed with a suitable name and be saved to the hard drive or other media.

- **OPEN F2**—opens a part program that is saved to the hard drive, network drive, floppy disk, or USB memory device. The Load Program screen opens, where you can locate the program from the list, as in the following example:



Load Program screen

To find a program, navigate through the folders in the left pane by selecting "+" or "-" to expand or collapse. Select a folder to view its contents in the right pane.

- **Load F1**—opens an HWM file or an XML1 file.
- **Import F2**—opens an HD3 file.

⇒ HD3 and XML1 files will be listed with .HWM extension in Program Manager. HWM is Hurco's conversational program file type. **SAVE AS** must be used to resave the program as HD3. Using **SAVE** will save the program with the HWM extension. Programs cannot be saved with the XML1 extension.



Sort the program list by File, Size, or Date by selecting the corresponding header. Programs with the same date will be sorted alphabetically.

Select the File header once to sort the list alphabetically. Select the File header again to sort the list in reverse alphabetical order.

- **SAVE F3**—saves the current part program to a hard drive, network drive, floppy disk, or USB memory device. If the program has a path indicated in Program Manager, it will be saved to the same location.



Hurco recommends the following storage areas in My Computer:

- 3½ Floppy (A:)
 - PART_PROGS (D:)
 - USB Device (E:)
 - My Network Places (if the UltiNet option is installed)
- **SAVE AS F4**—allows the current part program to be saved with a different name, as a different file type, or in a different location. Also used to save files with the default NONAME program name. Type the program name in the File Name box and select the file type, as in the following example:

FILE NAME: 6SWITCHPLATE.HWM
SAVE AS TYPE: HWM Files (*.hwm)

To rename a program, highlight the entire name in the FILE NAME field and type or use alpha/numeric console keys to replace the name. To modify character(s) in the name, highlight the name, select again in the field, and use the cursor keys, delete, and the alpha/numeric keys to change the name. When the filename is completely highlighted, the filename extension does not have to be re-entered; the extension selected in the SAVE AS TYPE field will be added to the name entered in the FILE NAME field.

For Conversational programs, the following file types are available from the Save As Type drop-down list:

- .HWM—WinMax Mill conversational format
- .HD5—WinMax Desktop conversational format (desktop only)
- .HD3—Ultimax conversational format

To save as an HWM file, select the **SAVE F1** softkey.

To save as an HD3 (or HD5) file, select the **EXPORT F2** softkey.

For NC programs, SAVE AS will default extensions to the selected NC dialect, either FNC or HNC. If another extension is desired, include the extension with the filename in the FILE NAME field. For example, SAMPLE. NC.

- **CLOSE F5**—opens a menu to close selected program or all programs.
- **Program Properties F6**—stores properties for the selected part program.
- **Disk Operations F7**—opens the Disk Operations screen to browse available folders and files, and cut, copy, paste, rename, and delete files.
- **FTP Manager F8**—displays external network connections (with the Ultinet option)

Program Properties

Program properties stores and manages properties for the selected part program.

Fields are:

- **DISPLAY UNITS**—the unit of measurement (inches or millimeters) used throughout part programming (this field does not apply to NC programs). These units will be used when the part program is loaded into memory but the display value can be changed using the unit (IN or MM) icon in the status bar.
- **NAME**—the file name of the part program. This field appears as read-only.
- **PATH**—the media and directory path to the saved program. This field appears as read-only.
- **MATERIAL**—the material to be used, if specified (optional). This field appears as read-only; however, the material can be changed with the CHANGE MATERIAL *F3* softkey. See [Tool and Material Database](#) for more information.
- **DESCRIPTION**—a short text description of the part program.
- **PROGRAM TYPE**—specifies the type of program. This field appears as read-only. See [Utilities](#) for more information about changing the program type.
- **WRITE PROTECTION**—prevents changes to the program from being saved when set to ON. Changes can be made if set to OFF.



A write-protected program can be saved with a different program name. The user will be prompted to do this when attempting to save.

Disk Operations

Disk Operations displays available directories and files. Cut, copy, paste, rename, and delete program files from Disk Operations.

See also:

[Part Setup](#)


[NC States](#)

[Load Program screen](#)

[Save Program screen](#)

[DXF Option](#)

[Retrieve Log and Diagnostic Files](#)



Disk Operations

When a directory is highlighted in the Directory window, the softkeys are:

- **CUT DIRECTORY F1**—deletes the directory from one location to be pasted into another location
- **COPY DIRECTORY F2**—makes a copy of the directory (but does not delete) to be pasted into another location
- **PASTE INTO DIRECTORY F3**—pastes the directory or file that has been cut or copied. For example, to copy a directory and paste it into a new location:
 1. Highlight the directory you wish to copy.
 2. Select the COPY DIRECTORY F2 softkey.
 3. Highlight the folder in which you wish to place the copied directory.
 4. Select the PASTE INTO DIRECTORY F3 softkey.
- **CREATE DIRECTORY F4**—creates a new directory
- **RENAME DIRECTORY F5**—renames a directory
- **DELETE DIRECTORY F6**—removes the directory
- **FTP MANAGER F7**—displays the external network connections (with Ultinet option)

When a file is highlighted in the Files window, the softkeys are:

- **CUT F1**—deletes the file from one location to be pasted into another location
- **COPY F2**—makes a copy of the file (but does not delete) to be pasted into another location

- **PASTE F3**—pastes the file that has been cut or copied. For example, to copy a file and paste it into a new location:
 1. Highlight the file you wish to copy.
 2. Select the COPY F2 softkey.
 3. Highlight the folder in which you wish to place the copied file.
 4. Select the PASTE F3 softkey.
- **RENAME F4**—renames the file
- **DELETE F5**—removes the file
- **LOAD F6**—loads the file into the Program Manager
- **FTP MANAGER F7**—displays the external network connections (with Ultinet option)

FTP Manager

FTP Manager allows you to transfer programs from a remote location (host), such as a PC or machine, to a local PC or another machine. To use FTP Manager follow these steps:

1. Set up a connection between your machine and a host.
2. Connect to the remote location.
3. Manipulate files/folders between your machine and the host.
4. Disconnect from the host.
5. Use [Program Manager](#) to access the copied file.

After you've connected to a host:

- Select the FTP Manager softkey to cut, copy, create and delete files/folders to which you have access on the host computer.
- Select the File Manager softkey to cut, copy, create and delete files/folders on the local PC or machine.

FTP Host List

This screen displays all the remote locations (hosts) to which you can connect. The following softkeys are available:

- **CONNECT**—connect to the selected host. This softkey will be grayed out if you are already connected.
- **DISCONNECT**— disconnect from the selected host. This softkey will be grayed out if you are not connected.
- **[Add Host](#)**—selecting this softkey takes you to the FTP Host Properties screen and allows you to add a host.
- **[Edit Host](#)**—edit the properties of the selected host.
- **DELETE HOST**—remove the selected host from the FTP Host List.

FTP Host Properties

This screen displays the properties of the remote location (host). The following fields are available:

- **ALIAS**—the name you want displayed in the host list. Choose a meaningful name to distinguish the host.
- **IP ADDRESS**—the IP address of the host.
- **USERNAME**—the name of the user. Access is determined by the FTP server's settings. Usually, access to the data drive is given to the "anonymous" login. Most servers assume a password is not needed for an anonymous login, but that may not be always be the case.
- **PASSWORD**—the password required when connecting to the host. The password must be a minimum of 0 characters and a maximum of 10 characters. If you do not want to require a password, the username should be anonymous.
- **DEFAULT REMOTE DIRECTORY**—the directory on the host you want to access. You can only enter the part of the path to which the server allows you access (e.g., you won't be able to access C:\Payroll if the server only allows you access to the D drive. Also, the default remote directory **MUST** exist.




Leave this field empty. It will automatically populate with the root directory on the server to which you have access.

- **FILENAME FORMAT**—choose the format of file names sent from the host computer:
 - **8.3**—file names with eight characters before the period (.) and three characters for an extension after the period are allowed.
 - **Long**—the complete path to the file, including the drive letter, server name, folder path, and file name and extension can contain up to 255 characters – however, it will be truncated to the 8.3 format. For example, LongFilename.txt will be truncated to LongFil_.txt.

UTILITIES

Utilities is accessed with the Auxiliary button on the console. Select the Utility Screen icon.

Auxiliary Screen



Auxiliary Screen

System Configuration

The SYSTEM CONFIGURATION *F1* softkey on the Utilities screen displays machine, control, and software information. Softkeys on the System Configuration submenu are:

- [Display WinMax Configuration](#) *F3*—changes WinMax configuration settings.
- [Display Machine Specifications](#) *F4*—changes machine specifications.
- **Upgrade Motion Control Firmware** *F5*—upgrades firmware.
- [Backup Config & Machine Files](#) *F6*—copy Configuration and Machine files to a directory or to a USB memory device or floppy disk.

- [Restore Config & Machine Files](#) *F7*—use saved files to overwrite existing Configuration and Machine files.

Display WinMax Configuration

The WinMax Configuration screen displays the current full version number of WinMax. This information is also displayed when you select the DISPLAY SOFTWARE VERSION softkey. The following softkeys are also available:

- **Display Software Options** *F2*—displays the current software options available for the machining center.
- **Display Motion Configuration** *F3*—displays information about the motion controller configuration.
- **Display Ladder Configuration** *F4*—Ladder files bridge communication between the machine and the software. The current version of the Ladder files on the machining center, the total number of Ladder files, and any mismatched Ladder files that may cause a software conflict are displayed.
- **Display WRC File Configuration** *F5*—WRC files contain the screen images. The total number of WRC files and any mismatched WRC files that may cause a software conflict are displayed.
- **Display WinMax IP Address** *F7*—Displays the current IP address of the CNC.

Display Machine Specifications

Displays specific information about the machining center that was entered during software/machine installation.

- **Machine Class**—The physical orientation of the spindle, relative to the table surface. The possible machine classes are vertical, horizontal, and universal.
- **Vertical/Horizontal**—The current orientation of the machine. This field will be vertical for vertical machines and horizontal for horizontal machines. For universal machines, this field can be either vertical or horizontal.
- **Number of Axes Present**—The number of axes present on the machining center.
- **Machine Hour Meter**—The total number of machine hours expended to date.
- **Maximum Spindle Motor Speed**—The maximum acceptable speed for the spindle.
- **Maximum Spindle Tool Speed**—The maximum acceptable speed for a tool in the spindle.
- **Maximum Rapid Traverse Rate**—The maximum rapid traverse rate.
- **Maximum Contouring Rate**—The maximum feedrate for contouring.
- **Minus/Plus X Direction Travel Limit**—The maximum and minimum travel limits for the X axis.
- **Minus/Plus Y Direction Travel Limit**—The maximum and minimum travel limits for the Y axis.

- **Minus/Plus Z Direction Travel Limit**—The maximum and minimum travel limits for the Z axis.

Backup Config & Machine Files

Backup files can be used to restore corrupted Configuration and Machine files on the hard drive. Select this softkey and choose the location to copy the files. Backup files can be copied to any directory on the hard drive or to a USB memory device or floppy diskette.

Restore Config & Machine Files

Select this softkey to use saved Configuration and Machine files to overwrite existing files stored on the hard drive.

User Preferences

The USER PREFERENCES *F2* softkey on the Utilities screen provides access to the following:

- [User Interface Settings](#)
- [Conversational Settings](#)
- [NC Settings](#)
- [Autosave Settings](#)
- [Tool Utilities and Settings](#)
- [Machine Parameters](#)
- [Serial Port Settings](#)
- [FTP Server Settings](#)
- [WinMax Uptime](#)
- [Select Language](#)
- [Data Logging Filters](#)

User Interface Settings

User Interface Settings change the screen display. Fields are:

- **APPLICATION FONT SIZE**—size of text displayed by the application in lists (for example, in Program Manager); default is Large. This field is inactive in WinMax Mill (active in WinMax desktop).
- **SOFTKEY MENU POSITION**—positions the softkey menu to the right or left of the screen; default is Right.
- **EDIT MODE**—select either Ultimax Classic (default) or Windows Dialog. For example, Ultimax Classic requires the Enter key to change the value of a data field, while Windows Dialog will accept a number by pressing the Down arrow.

- **ENABLE PROGRAM RESTORE**—resets previously loaded programs when the application is started after a shutdown; default is No.
- **SHOW ALL FILE TYPES**—view all file extensions when opening files; default is No (only displays HWM, HD3, HD5, FNC, HNC, and NC file types).
- **SCREENSAVER TIMEOUT**—set screensaver timeout in minutes (range is 1-30 minutes); default is 10.
- **LIST CONTROL ROWS**—select the appearance of list controls; default is Lines.
- **LIST ICON SIZE**—changes the size of icons in lists; default is Small.
- **WARN BEFORE SAVING IN OLD FORMAT**—specify if WinMax should warn that information may be lost when saving a program as HD3.
- **MAX MEMORY LOAD**—controls the amount of system memory that graphics generation uses. The range is 50% to 100%; default is 85%. Graphics generation that uses more than the specified memory will be aborted by the system and an error message will be displayed. Raising the maximum memory load allows large programs to be drawn.



If Max Memory Load is set to 100%, graphics generation will not abort even if all system memory is being used to draw a graphic.

Conversational Settings

Conversational Settings fields are:

- **MATH ASSIST STYLE**—select either Ultimax Classic or Standard Calculator interface to be used when editing data fields.
 - Ultimax Classic Math Assist—select operation (=, -, *, /), then number, and then Enter. For example, if the number 5 is displayed as a value, pressing “+” and the number 3 will change the value to 8.
 - Standard Calculator—select number, then operation (=, -, *, /), then Enter. For example, if the number 5 is displayed as a value, pressing 3 and “+” will change the value to 8.
- **DEFAULT CONVERSATIONAL PROGRAM TYPE**—select the default program type when creating new Conversational programs.
- **HD3 SAVE PROGRAM TYPE**—select the program type used when exporting conversational programs to the HD3 file format.



Choices for HWM and HD3 Program Types are:

Standard = 3-axis

Rotary A or Rotary B = 4-axis

Rotary A, Tilt B, or Tilt A, Rotary C = 5-axis

NC Settings

NC Settings fields are:

- **NC DIALECT**—select Basic or Industry Standard NC.
- **NC DISPLAY TYPE**—select axes data:
 - Standard = 3-axis
 - Rotary A or Rotary B = 4-axis
 - Rotary A, Tilt B or Tilt A, Rotary C = 5-axis
- **EXPORTED NC DECIMAL PLACES**—indicate the number of decimal places expressed when exporting a conversational program as NC (range is 1-8); desktop version only
- **BPRNT/DPRNT OUTPUT DEVICE**—select where to output BPRINT and DPRNT formatted data; desktop version only.
- **BPRNT/DPRNT OUTPUT FILE**—specify the file path if BPRINT and DPRNT data will be output to a file; desktop version only.
- **CUSTOM NC FILE EXTENSION**—provide a custom filename extension to enable loading of NC files that use the extension.

Autosave Settings

Autosave Settings fields are:

- **ENABLE AUTOMATIC SAVE**—turn Autosave on or off; if Yes, programs are saved to memory at the time interval specified—it will not save to the source location of the program.
- **SAVE FREQUENCY**—specify number of minutes between each autosave; range is 1-255.
- **SAVE ACTIVE PROGRAM ONLY**—specify Yes to save only the current program; specify No to save all loaded programs; default is No.

Tool Utilities and Settings

See also [Import and Export](#)

The Tool Utilities and Settings screen displays different fields with and without the Tool and Material Library option.

With the Tool & Material Library option, fields are:

- **AUTOMATICALLY LOAD UNMATCHED TOOLS AS MANUAL**—automatically loads unmatched tools from newly-loaded conversational part programs:
 - YES—new tools from the newly loaded program (that are not in the Tool & Material Library) are automatically added to Manual.

- NO—requires new tools to be matched (see “Part Program Tool Review” section for more information about matching tools.)
- **USE TOOL TYPE CHECKING**—only allow the selection of tool types that are valid for the operation in conversational mode:
 - YES—only the tools that are valid for the data block can be selected (i.e., drills and taps displayed for hole operations)
 - NO—allows any tool to be selected for any data block
- **UPDATE DATA BLOCKS WITH TOOL CHANGES**—Update feeds and speeds in conversational data blocks when tool feeds and speeds are changed.
- **OVERWRITE EXISTING ZERO CALIBRATION**—when matching tools during a program load, the zero calibration from the program replaces the calibration for the tool on the machine. Default is YES.



The OVERWRITE EXISTING ZERO CALIBRATION setting applies both to tools that are automatically matched (during a program load), as well as tools that are manually matched.

- **REPLACE IN FILES**—specify if new tool feeds and speeds should be updated in current editing file only or in all open files
- **TOOL MATCHING: MAXIMUM DIAMETER DIFFERENCE**—the maximum diameter difference for a tool to be considered a match

Softkeys are:

- **Tool Information Printing F6**—allows the Tool Library to be printed or saved to a file
- **Import and Export F7**—import and export tools to and from the Tool Library. To move the Tool Library from one machine to another, select EXPORT.

Without the Tool & Material Library option, fields are:


- **USE TOOL TYPE CHECKING**—only allow the selection of tool types that are valid for the operation in conversational mode
 - YES—only the tools that are valid for the data block can be selected (i.e., drills and taps displayed for hole operations)
 - NO—allows any tool to be selected for any data block
- **UPDATE DATA BLOCKS WITH TOOL CHANGES**—Update feeds and speeds in conversational data blocks when tool feeds and speeds are changed.

Tool Information Printing



Tool Information Printing is available only with the Tool and Material Library option.

The TOOL INFORMATION PRINTING F6 softkey on the Tool Utilities and Settings screen allows you to view and print tool information for all tools saved in the Tool Library:



Tool Information and Printing

Select the PRINT button on the Tool Information pop-up to print a list of tools and settings, as in the following example:

ATC

Tool Number: 23

Tool Type: Ball End Mill

Tool Diameter is 0.0938 inches.

Tool length is 0.5625 inches.

Length of cut is 0.4688 inches.

Number of flutes is 0 inches.

Direction of Spindle Rotation is Clockwise.

Helix Angle is 0°.

Shank Diameter is 0.0938 inches.

Apt Gear Ratio is 1.

Apt Tool Number is 1.

Apt Diameter Offset is 1.

Apt Length offset is 1.

Simulation Color is SEQUENTIAL.

MTC

Tool Number: 1

Tool Type: Drill

Tool Diameter is 0.031 inches.

Tool length is 5 inches.

Length of cut is 5 inches.

Number of flutes is 0 inches.

Direction of Spindle Rotation is Clockwise.

Drill Angle is 118.000000°.

Helix Angle is 0°.
Shank Diameter is 0.031 inches.
Apt Gear Ratio is 1.
Apt Tool Number is 1.
Apt Diameter Offset is 1.
Apt Length offset is 1.
Simulation Color is SEQUENTIAL.

Tool Number: 20
Tool Type: Cutting Tap
Tool Diameter is 0.216 inches.
Tool length is 1.296 inches.
Length of cut is 1.08 inches.
Tap Direction: Right Hand.
Tap Chamfer: Bottoming.
Thread Pitch is 0.0417 inches.
Thread Diameter is 0.216 inches.
Helix Angle is 0°.
Flute Style: Spiral Flute.
Shank Diameter is 0.216 inches.
Apt Gear Ratio is 1.
Apt Tool Number is 1.
Apt Diameter Offset is 1.
Apt Length offset is 1.
Simulation Color is SEQUENTIAL.

Import and Export



Import and Export functions are available only with the Tool and Material Library option.

The IMPORT AND EXPORT *F7* softkey in Tool Utilities and Settings allows you to move tool information from the WinMax control to other locations and vice versa.

Import and Export submenu softkeys are:

- **EXPORT AUTO AND MANUAL TOOLS *F1***—save Auto and Manual tools to a different directory
- **EXPORT MANUAL TOOLS *F2***—save Manual tools only to a different directory
- **IMPORT MANUAL TOOLS *F3***—load Manual tools into the control from a directory

Machine Parameters

The following tables provide information about the machine parameters. For more detailed information, refer to the "Machine Parameters" section of your machine's *Maintenance and Safety Manual*.

Machine Parameters - Page 1

Parameter	Description	Range	Default
Coolant Delay Time	Sets the time the program pauses when the coolant is enabled.	0-60 seconds	0
Pulsating or Delay Washdown Enable	Sets the Washdown Coolant pump run cycle; used in conjunction with other washdown coolant parameters.	0 (continuous) 1 (pulsating) 2 (delay)	0 or 1 (depends on machine)
Alt Washdown Dwell	Controls washdown coolant flow on the right side of the machine enclosure on certain machines. Used in conjunction with other washdown coolant parameters.	0-32767 (.01 sec)	500 or 1000 (depends on machine)
Alt Dwell Left Side	Controls washdown coolant flow on the left side of the machine enclosure on certain machines. Used in conjunction with other washdown coolant parameters.	0-32767 (.01 sec)	200
Alt Washdown Off Time	Sets the time the washdown coolant flow cycle is paused, on certain machines.	0-32767 (.01 sec)	0 or 200 (depends on machine)
Washdown On Delay Timer	Defines the time the washdown coolant pump is on; used with Washdown Off Delay Timer.	0-9999 seconds	0
Washdown Off Delay Timer	Defines the time the washdown coolant pump is off; used with Washdown On Delay Timer.	0-9999 seconds	0
Control Power Off Time	Turns the control off after the specified period of inactivity.	0-255 minutes	120
Disable Tool Picker Option	Turns off the Tool Picker option.	0 (enable) 1 (disable)	0



Refer to your machine's *Maintenance and Safety Manual* for more information about these Machine Parameters.

Machine Parameters - Page 2

Parameter	Description	Range	Default
CAL to LS Velocity X	Sets the feedrate for the X axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 MMPM	1270
CAL to LS Velocity Y	Sets the feedrate for the Y axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 MMPM	1270
CAL to LS Velocity Z	Sets the feedrate for the Z axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 MMPM	1270
CAL to LS Velocity A	Sets the feedrate for the A axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 DPM	0
CAL to LS Velocity B	Sets the feedrate for the B axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 DPM	0
CAL to LS Velocity C	Sets the feedrate for the C axis as it moves toward the calibration limit switch during a machine calibration cycle.	100-2540 DPM	0
Auto Balance Enable	Adjusts the balance between the motion card and the servo drives at the start of calibration and run program.	0 (disable) 1 (enable)	1
ATC Disable	Disables all automatic tool changer functions.	0 (enable) 1 (disable)	0
Rapid Override Disable	Enables or disables the Rapid Override potentiometer on the console.	0 (enable) 1 (disable)	0
Tilt Axis Safety Position	Sets the position for the tilt axis during an automatic tool change when the Table Safety Move parameter is set to Yes for an Automatic Tool Change.	0-360 degrees	0
X-Axis Safety Position	Sets the absolute X axis machine location to which the table will move when the Table Safety Move parameter is set to Yes for an Automatic Tool Change.	Travel Limits (mm)	0
Y-Axis Safety Position	Sets the absolute Y axis machine location to which the table will move when the Table Safety Move parameter is set to Yes for an Automatic Tool Change.	Travel Limits (mm)	0
ATC Z-Axis Move to Zero	On HTX500 only, moves the Z-axis to zero position at the end of a tool change.	0 (disable) 1 (enable)	0



Refer to your machine's *Maintenance and Safety Manual* for more information about these Machine Parameters.

Machine Parameter - Page 3

Parameter	Description	Range	Default
Aux Output 1 Confirmation Enable	Enables a confirmation signal for completion of each Auxiliary M-code Output.	0 (disable) 1 (enable)	0
Aux Output 2 Confirmation Enable	Enables a confirmation signal for completion of each Auxiliary M-code Output.	0 (disable) 1 (enable)	0
Aux Output 3 Confirmation Enable	Enables a confirmation signal for completion of each Auxiliary M-code Output.	0 (disable) 1 (enable)	0
Aux Output 4 Confirmation Enable	Enables a confirmation signal for completion of each Auxiliary M-code Output.	0 (disable) 1 (enable)	0
Disable Aux Out 1 During Interrupt	Disables the specified Auxiliary M-code Output when an Interrupt cycle is selected during Auto Run mode.	0 (enable) 1 (disable)	0
Disable Aux Out 2 During Interrupt	Disables the specified Auxiliary M-code Output when an Interrupt cycle is selected during Auto Run mode.	0 (enable) 1 (disable)	0
Disable Aux Out 3 During Interrupt	Disables the specified Auxiliary M-code Output when an Interrupt cycle is selected during Auto Run mode.	0 (enable) 1 (disable)	0
Disable Aux Out 4 During Interrupt	Disables the specified Auxiliary M-code Output when an Interrupt cycle is selected during Auto Run mode.	0 (enable) 1 (disable)	0
Move to Safety Pos Manual Mode ATC	Manual Mode ATC operations are performed at Safety Position when enabled.	0 (disable) 1 (enable)	0
Chip Conveyor On/Off Delay Enable	Enables the Chip Conveyor Delay.	0 (disable) 1 (enable)	0
Chip Conveyor On Delay Time	Sets the time the Chip Conveyor cycles on, when Chip Conveyor On/Off Delay is enabled.	0-9999 seconds	0
Chip Conveyor Off Delay Time	Sets the time the Chip Conveyor cycles off, when Chip Conveyor On/Off Delay is enabled.	0-9999 seconds	0



Refer to your machine's *Maintenance and Safety Manual* for more information about these Machine Parameters.

Machine Parameters - Page 4

Parameter	Description	Range	Default
Warm-Up Cycle Time Per Pass	Sets the time for each step of the warm-up cycle.	60-600	120
Warm-Up Starting Speed	Sets the spindle speed for the initial step of the warm-up cycle.	0-25% Max RPM	1000
Warm-Up Speed Steps	Sets spindle speed increments for each step of the warm-up cycle.	0-25% Max RPM	2000
Warm-Up Max Spindle Speed	Sets the spindle speed for the final step of the warm-up cycle.	0-Max RPM	Machine's maximum spindle RPM
Warm-Up Axis Feed Rate	Sets the axis feed rate for each step of the warm-up cycle.	0-Max Rapid	2920



Refer to your machine's *Maintenance and Safety Manual* for more information about these Machine Parameters.

Serial Port Settings

Serial Port Settings allows you to set Port 1 and Port 2 settings for protocol, baud rate, character length, stop bits, and parity. The following fields appear on the Serial Port Settings screen. Refer to your hardware documentation for your equipment's specific settings.

- **Protocol**—The format in which the data is communicated. Choose from CTS/RTS (hardware flow control), Xon/Xoff (software flow control), and Full Handshake
- **Baud Rate**—The communication speed rate. Choose a baud rate that is appropriate for your network from the drop-down list.
- **Character Length**—The maximum number of bits sent back and forth at one time.
- **Stop Bits**—Stop bits signal the end of the transmission of data. Choose the size for the Stop Bit.
- **Parity**—Provides simple error checking for the transmitted data.

Select Even if the data bits plus the parity bit result in an even number of 1's

Select Odd if the data bits plus the parity bit result in an odd number of 1's.

Select None if there is no parity bit included in the transmission. When No is selected, its assumed that there are other forms of checking that will detect any errors in transmission.

For example, suppose the data bits 01110001 are transmitted to your computer. If even parity is selected, then the parity bit is set to 0 by the transmitting device to produce an even number of 1's. If odd parity is selected, then the parity bit is set to 1 by the transmitting device to produce an odd number of 1's.

FTP Server Settings

The WinMax console can serve as an FTP Server. The following fields appear on the FTP Server Settings screen. For more information refer to the [UltiNet](#) section.

- **Enable FTP Server**—Enable the WinMax Control to act as an FTP Server.
- **FTP Server Port**—The port number for FTP access.
- **Maximum Idle Time (Mins)**—Maximum amount of time before connection is dropped.
- **User Name**—The log in name that will allow users access to the FTP Server.
- **Password**—The password that corresponds to the user name and allows access to the FTP Server.
- **Path**—The file path that the users will be allowed access to.

WinMax Uptime

The WinMax Uptime screen displays the start date time and runtime for the current session of Winmax.

Select Language

Select and register a language on the Language Selection screen:

1. Select an installed language. Languages that have not been installed and registered are grayed out on the list.
2. Press the SELECT/LOAD *F1* softkey to install the Language files. You can also press the F1 key to perform this function.

Language Registration

To register a new language:

1. Press the REGISTRATION *F3* softkey on the Language Selection screen to register alternate languages and enter map and hlp filenames.
 - Define the language to appear on the screen by using the drop-down list or select a softkey.
 - Select the Map filename and HLP filename for the language. WinMax requires the HLP file for the online Help.
 - Select the Register button so the software registers the language selection.
2. Select EXIT to return to the Language Selection screen.

Data Logging Filters

Used for diagnostic purposes only.

Additional Utilities Softkeys

- **Printing Setup *F3***—set printing preferences for program blocks, range of program blocks, program parameters, part setup, and tool setup.
- **Integrator Support Services *F4***—for diagnostics and machine configuration; password required for access.
- **RESTART CONTROL *F5***—exits all control operations, powers down, then restarts machine and control.
- **SHUTDOWN CONTROL *F6***—exits all control operations and powers down machine.
- **Serial I/O *F1***—to begin read/write program operations using screenport 1 or 2.

- [Log Files F2](#)—displays error and status messages that have occurred during normal operation.

Printing Setup

The PRINTING SETUP F3 softkey on the main Utilities screen provides access to the following printing functions:

- [Part Program Printing F1](#)—print part program elements.
- [Tool Information Printing F2](#)—print the Tool Library or save it to file.
- [Probing Data Printing F3](#)—print probing part inspection files.

Part Program Printing

In the Part Program Printing screen you can choose to print some or all of the following elements:

- Program Blocks (all or a range)
- Program Parameters
- Part Setup
- Tool Setup

After checking the desired elements, select the PRINTING F3 softkey. A pop-up window appears that contains the selected data. The information can be viewed by selecting the heading to expand the section; select the heading again to hide the information. The following softkeys appear in the pop-up window:

- Print Preview—displays the part program information as it will appear when printed.
- Print—sends the information to the printer.
- Save As—saves the information as a text file to an external drive.
- Close—closes the pop-up window.

Probing Data Printing

When Probing Part Inspection files are generated, they are saved to the same location and with the same filename as the part program with a .TXT filename extension. For example, the Part Inspection file for the program SAMPLE.HWM is SAMPLE.TXT. Part Inspection files are printed from the control using the PROBING DATA PRINTING softkey:

1. Select the PRINTING SETUP F3 softkey from Utilities.
2. Select the PROBING DATA PRINTING F3 softkey.
3. Locate the Part Inspection file from the Locate Probing Data Files screen.
4. Select the PRINT F1 softkey to print the file.

- ⇒ Subsequent Part Inspection data from the same part program is appended to the existing Part Inspection file for that program.

Integrator Support Services



The Integrator Support Services screen requires a password to access and is for Hurco Certified Technicians' use in configuring and setting up the machine.

Serial I/O

Two serial ports are available on the control. The Serial I/O screen contains Status and Bytes Transferred fields for both ports. In addition, there are read, write, and abort softkeys for both ports.

These are the fields on the Serial I/O screen:

- **Status**—status of serial port.
- **Bytes Transferred**—number of bytes transferred.

These softkeys are available on the Serial I/O screen. Duplicate sets of fields and softkeys are available on the Serial I/O screen for Port 1 and Port 2.

- **Begin Reading from Port**—brings up 2 softkey choices: READ NC FROM PORT and READ CONV FROM PORT to identify the program format to read.
- **Begin Writing to Port**—writes the program to the port.
- **Abort Port Operation**—halts the read or write operation for the port.

Log Files

WinMax provides two log files that are accessed with the **Log Files** softkey, as well as status and error listings:

- [Active Error Listing](#)
- [Active Status Listing](#)
- [Error History](#)
- [Status History](#)
- [Retrieve Log and Diagnostic Files](#)
- [Export Log](#)

Active Error Listing

WinMax provides a list of the most recent error messages displayed, up to a maximum of 200 messages. Review messages when troubleshooting or to determine if a problem recurs.

These are the softkeys on the Active Error Listing screen:

- **Previous Page F1**—displays the error messages on the previous page of the Active Error Listing.
- **Next Page F2**—displays the error messages on the next page of the Active Error Listing.
- **Clear All F4**—clears all error messages from the Active Error Listing.

Active Status Listing

The Active Status Listing screen displays current machine status messages. Each item will include time/date stamp, language file, language file index and the machine status message currently active in the system. Examples are messages such as "MOTION HOLD HAS BEEN DEPRESSED," or "LOW LUBE LEVEL." As each status changes back to a normal state, it will be removed from the list (see [Status History](#)).

Example:

10:53:39, STATUS.WRC, 32
CHIP DOOR(S) OPEN.

These are the softkeys on the Active Status Listing screen:

- **Previous Page F1**—displays the status messages on the previous page of the Active Error Listing.
- **Next Page F2**—displays the status messages on the next page of the Active Error Listing.
- **Clear All F4**—clears all status messages from the Active Status Listing.

Error History

The Error History screen displays a list of all system errors since the last power up (see [Active Error Listing](#)). A plus sign "+" indicates when the error occurred and a minus sign "-" indicates when the error was cleared.

Examples:

Error occurred:
10:53:40, ERROR.WRC, 110, +
SERVO FAULT – Z AXIS.

Error cleared:

10:57:32, ERROR.WRC, 110, -

SERVO FAULT – Z AXIS.

The history will also display part program errors generated during programming (interpreter errors). These errors will not display in the Active Error Listing since they are transient.

Example:

11:39:21, COMPILER.WRC, 3, +

ERROR IN BLOCK 1: TOOL 1 IS AN INVALID TOOL NUMBER.

Status History

The Status History screen displays a list of all system messages since the last power up (see [Active Status Listing](#)). A plus sign "+" indicates when the status went active and a minus sign "-" indicates when the status returned to normal.

Examples:

Status went active:

10:53:39, STATUS.WRC, 32, +

CHIP DOOR(S) OPEN.

Status returned to normal: Log F


10:54:27, STATUS.WRC, 32, -

CHIP DOOR(S) OPEN.

Retrieve Log and Diagnostic Files

When the Retrieve Log and Diagnostic Files softkey is selected, a file manager screen opens with access to Log and Diagnostic files. Directories are displayed in the left pane; these include AtcMapLog, Communications, DumpFiles, NavErr, NavTap, Profiles, ScreenCaptures, and ThreadMonitor. Select a directory to see its contents (the files) displayed in the right pane. To help distinguish between files, view the date and time they were created, which is displayed in the Date column.

When it is necessary to copy certain files for service purposes, follow these steps:

 Due to the large size of some of the files, it is recommended to copy them from the Hurco machine to a USB flash memory device (128M or larger).

1. Attach the USB flash memory device to the external connector on the communications port on the machine.
2. Select the appropriate directory from the left-hand pane and select the file(s) you wish to copy from the right-hand pane.

3. Select the COPY softkey.
4. In the left-hand pane, select the USB flash memory device (will probably indicate it is E drive in parentheses).
5. Select the PASTE softkey. The files are now on the USB flash memory device, and can be transferred to a PC to be emailed.

Export Log

The Export Log displays data that is lost or changed when a program is exported from WinMax (.HWM) to another format (.HD3, .FNC, etc.). Each time a program is exported from .HWM to another format, the data from the most recent export is displayed and the older data is erased.

These are the softkeys on the Export Log screen:

- **Previous Page F1**—displays the previous page if log is longer than one page.
- **Next Page F2**—displays the next page if log is longer than one page.
- **Clear All F4**—erases all information from the Export Log.

PROGRAMMING BASICS

The following sections explain basic programming information for Conversational and NC programming, such as required setup, program checking, editing, and running of the program.

Input Mode

Input mode is used for part and tool setup, part programming, setting parameters, and other information entry. Press the Input key on the console to access the Input screen.

The following softkeys appear on the Input screen:

- **[Part Setup F1](#)**—access the Part Setup screen to establish part zero, centerline, offset Z, safety work region, and other parameters.
- **[Tool Review F2](#)**—access the Tool Review screen for a summary listing of all tools used in active program (see [Part Program Tool Review](#) for more information).
- **[Part Programming F3](#)**—access and create data blocks of a part program. The current program's data blocks appear on screen when this softkey is used. Delete, add, edit, and navigate through the data blocks. The NC editor is displayed for NC programs.
- **[Program Parameters F4](#)**—access General, Milling, Holes, Probing, and Performance parameters. NC parameters are accessible for NC programs.
- **[Import Functions F5](#)**—import sections of a previously saved program.
- **[Copy and Change Blocks F6](#)**—make changes to several blocks at one time and/or copy and change blocks within the active program.
- **[Erase Functions F7](#)**—erase sections of the current program.
- **[Program Manager F8](#)**—access and manage other part programs.

Erase Functions

Erase functions erases (deletes) programs or components (part setup, tool setup, and program parameters).

New WinMax features are:

- **ERASE PART SETUP F1**—resets Part Setup to the default values.
- **ERASE TOOL SETUP F2**—deletes tools in Manual Tools, Auto Tools, and spindle.



ERASE TOOL SETUP deletes ALL tools from the control, and cannot be undone.


- **RESET PROGRAM PARAMETERS F3**—resets Program Parameters to the default values.
- **ERASE PROGRAM F4**—deletes the part program data blocks but retains the program name.
- **UNLOAD PROGRAM F5**—removes program from the Program Manager, including the filename. This does the same function as CLOSE PROGRAM in the Program Manager.

Part Setup

[Part Setup Fields](#)


[Part Setup Softkeys](#)

Part setup establishes the locations of part zero in X, Y, and Z relative to the machine's absolute zero. Part Zero may be located anywhere on the fixturing or the part. During machine calibration, each axis moves to its + or - travel limits. Machine zero, identified during machine calibration, is the location to which each axis moves to determine a fixed point where the X, Y, and Z axes become tangent. This value does not change after calibration.




Part Zero Relative to Machine Zero Viewed Looking Down at Table

Program the axes to move within the coordinate system as shown below:



Axis Motion

The location of part zero in Z is established during tool calibration. During setup, the tool zero calibration plane is established for each tool. The program dimensions for a part are relative to these points, viewed facing the machine, as shown below:




Part Zero in Z (Tool Zero Calibration Plane)

Select the **Toggle Units** softkey to change between inch and metric units of measurement.

Part Setup Fields

The Part Setup screen contains these fields:

- **Part Zero X / Y**—defines the X and Y locations in machine coordinates for part zero.
- **Part Zero A / B**—defines the A and B locations in machine coordinates for part zero. A and B refers to fourth and fifth axes (Rotary A/Tilt B).
- **A Centerline Y / Z**—defines incremental distances from true part zero. Program these values in order to draw the program properly on the Graphics screen.
- **B Centerline X / Z**—defines incremental distances from true part zero. Program these values in order to draw the program properly on the Graphics screen.
- **Offset Z**—defines the Z dimension offset for part zero. This field is usually left at 0 and the Tool Calibration field in [Tool Setup](#) is used to determine each tool's part zero. Offsets range from 1 to 6.



Offset Z

- **Safety Work Region**—defines a part-relative safety area to prevent the cutting tool from colliding with fixtures or other equipment. The Safety Work

Region created in Part Setup is saved with a conversational part program; the Safety Work Region is not saved with NC programs.

Use the Safety Work Region fields on the Part Setup screen to enter values to define the safety region. Type the value in the field, or jog each axis to the desired safety region, and press the Store Position button on the jog unit.

Out of range entries in the Safety Work Region appear in red. See Machine Specifications for ranges.




Always enter the Z(-) parameter (Z Bottom) to prevent the tool from drilling through the part and into the table.

Use the Z(+) field (Z Top) to define the clearance above the part and fixture.

Use the Z(+) field with a Position block. The Z Top value reduces rapid Z motion for Position blocks. The spindle retracts to the Z Top value above the tool zero calibration for Position blocks.

The figure below translates these fields into the Safety Work Region:



Safety Work Region

Part Setup Softkeys

Part Setup contains these softkeys:

- **Work Offsets**—Accesses the work coordinates G54-G59 and a set of shift values for NC programs. These are used to set multiple part zeroes for multiple parts fixtured to the table and milled consecutively using the same program.
- **Tool Setup**—Accesses Tool Setup screen to enter the descriptions of tools that will be used in the part program.
- **Part Programming**—Accesses fields to enter the exact description of how the part will be cut.
- **Program Parameters**—Accesses the Program Parameters screen to specify data common to all program data blocks.
- **Part Probing**—Accesses the Probing parameters screen (available only with the Probing option).
- **Store Machine Position**—Sets the current axis position as a Part Zero location. The cursor location determines which axis (X or Y) will be set.

These are the softkeys on the second Part Setup screen, accessed with the **MORE** → softkey:

- [Stock Geometry](#)—Accesses fields to specify the dimensions of the stock material so it displays properly in graphics.
- **Calculate Rotary Offsets**—Calculates centerline offsets for rotary programs.
- **Orient Spindle**—Allows the spindle to be positioned for tool insertion or removal.
- **Toggle Units**—Changes units from metric to imperial and vice versa.

Part Fixturing and Tool Loading

Before entering data into the part and tool setup screens for a part program, first fixture the work piece to the table and load a tool into the spindle.

In order to determine the starting point (part zero) in the part, first fixture the work piece (raw material or stock) to the machine tool table. This process, called fixturing, can be accomplished using a variety of clamping devices, such as vises and toe clamps. Select the fixturing device that will hold the work piece securely without getting in the way of the cutting tool while the part is being made.

You may want to insert a tool in the spindle to use as an edge finder when identifying part zero. Press the Manual button in the Machine Mode grouping to display the Manual screen. Use the Tool in Spindle field and softkey to enter the tool number for the edge finder tool.

Insert this tool as described in the [Loading a Tool into the Spindle](#). The tool will need to be calibrated as described in [Tool Setup](#).

Work Offsets

When in NC mode, the **Work Offsets** softkey displays up to six work coordinates (G54-G59) and a set of shift offset values. These are used to set multiple part zeroes for multiple parts fixtured to the table and milled consecutively using the same program.

The X, Y, Z, and optional Rotary A and B work offset values can be entered for G54 to G59 codes. The coordinates defining G54 are the part zero coordinates for the original part defined on the Part Setup screen. When the G54 coordinates are changed on this screen, the part setup is also changed.

These work offsets are stored in memory, but not with the part program. They are not saved to a disk file and need to be re-entered.

The shift offset coordinates, which follow the six work coordinates on the screen, move all of the part zero coordinates as a group. This incremental value is useful when you place part fixtures on the table in a different location and want to shift all of the work offsets to the newly fixtured location. The G54-G59 offset values do not change on the screen when shift offset values are entered.

Auxiliary Work Offsets

There are 93 additional X, Y, Z, and optional Rotary A and B work offsets available on the AUX WORK OFFSETS screen. These are accessed with the **Aux Work Offsets F6** softkey on the WORK OFFSETS screen.

To access any of these offsets call G code **G54.1 Pn**, where **n** is 1 thru 93. For example, to change to auxiliary work offset 46 you would call **G54.1 P46** in your NC program.

To update work offset values, use data setting G code **G10 L20 Pn** to set the Auxiliary work offsets values. For example, to update work offset 46 value call **G10 L20 P46 X12.5 Y3.0 Z-0.5**

Following is a sample NC program that uses Auxiliary Work Offsets:

```
%  
G90G80  
T1M6F100  
G10 L20 P1 X1 Y1 Z-.1  
G10 L20 P93 X10 Y10 Z-.1  
G54.1 P1 (change work part setup to 1)  
G1X0.Y0.Z0.  
X1.  
Y1.  
X0.  
Y0.  
G54.1 P93 (change work part setup to 93)  
G1X0.Y0.Z0.  
X1.  
Y1.  
X0.  
Y0.  
M02
```

Stock Geometry

STOCK GEOMETRY *F1* allows you to specify the dimensions of the stock material so it displays properly in graphics (when STOCK OUTLINE is enabled in **Graphics Settings**).

Fields on the Stock Geometry screen are:

- **MANUAL STOCK SIZING**—specify if you will manually set the stock dimensions
 - **NO**—software will automatically size and position the stock. To calculate this, WinMax takes the diameter of the largest tool in the program and adds 7/10ths of that size to the stock diameter X and Y fields (with a minimum addition of .05).
 - **YES**—enter the dimensions manually

- **STOCK TYPE**—specify BOX or CYLINDER
 - **BOX**—enables settings for X length, Y length, Z length of stock box or cube
 - **CYLINDER**—enables direction, length, and radius of cylinder
- **MANUAL BORDER SIZING**—specify if you will manually size the border (available only when MANUAL STOCK SIZING is set to NO)
- **BORDER SIZE**—specify stock border dimension (available only when MANUAL BORDER SIZING is set to YES)
- **ZERO REF**—coordinate system zero from which to reference the stock zero position
- **X REF POSITION**—locate the stock on X axis relative to the ZERO REF; can use Store Position or can be set to Part Zero with softkey
- **Y REF POSITION**—locate the stock on Y axis relative to the ZERO REF; can use Store Position or can be set to Part Zero with softkey
- **Z REF POSITION**—locate the stock on Z axis relative to the ZERO REF; can use Store Position or can be set to Part Zero with softkey
- **BOX LENGTH (X, Y, Z)**—specify lengths when MANUAL STOCK SIZING is YES and STOCK TYPE is BOX
- **CYLINDER**—set dimensions when MANUAL STOCK SIZING is YES and STOCK TYPE is CYLINDER
 - **DIRECTION**—specify POS X, NEG X, POS Y, NEG Y, POS Z, or NEG Z
 - **LENGTH**—specify length along axis from reference position
 - **RADIUS**—specify stock radius

Tool Setup

Tools for a part program must be described in Tool Setup, or WinMax cannot run the program.

You can [create tool setup templates](#) to make new part programming easier.

To review all tools currently programmed in the system, go to the [Tool Review](#) screen. The Tool Review screen also allows you to cut, copy, and paste tools between programs.



When running a previously created part program, Tool Setup must be carefully checked to be certain the tools described for the old program match the tools planned for the new program. If a tool breaks or is not available when running a previously created part program, the Tool Setup information must be changed.

[Tool Setup Softkeys](#)

[Tool Setup Fields](#)

Tool Setup Softkeys

The Tool Setup Softkeys are as follows:

- **Delete Tool**—Deletes all program settings for the tool number entered in the Tool Field, for a Manual tool. If the tool is in Spindle or Auto, this softkey is not active.
- **Part Setup**—Accesses Part Setup.
- **Part Programming**—Accesses fields to enter the exact description of how the part will be cut.
- **Tool Offsets**—Available only for NC programs. The tool length offsets appear on the screen. Tool offsets are used to compensate tool length without altering the NC program.
 - Use the Positive Tool Length Compensation (G43) or Negative Tool Length Compensation (G44) codes. A G49 code specifies tool offset cancel. An H00 also cancels an offset.
 - The G43 and G44 codes set a mode of operation within the program that is in effect until a G49 or H00 is used. If an H code is used without a G43 or G44, in effect, the value stored in the tool length offset table is used as the calibrated tool length.
 - The four keyboard arrows, Page Up, and Page Down keys scroll through the 01 to 200 offsets.
 - When the Store Machine Position softkey is pressed, a negative Z value reflecting the Z axis machine position is entered on the screen.

Tool offsets are not saved with the NC program.

- **Tool Home**—Allows you to move the tool quickly away from the part. Using

this softkey after Tool Calibration is much faster than pressing the axis jog buttons on the jog unit. Press this softkey and then press the Start Cycle button to move the spindle to the change height.

- **Set Tool Zero**—To use this softkey, carefully jog the tool in the spindle down to the top of the part or to the fixture defined at the Tool Calibration point and then press the softkey. The system stores the position of the tool into the current part program and the number appears in the Zero Calibration field on the Tool Setup screen. This can also be accomplished by pressing the Store Position button on the jog unit. On the screen the part display for "Z" changes to zero.

⇒ A warning message is displayed if the edited tool is not the tool in spindle. Select OK to continue, or Cancel if you do not want to set tool zero for that tool.

- **More** →—Accesses second set of Tool Setup softkeys.
- **Exit**—Exits the tool setup process and allows return to the Input screen.

Second set of Tool Setup softkeys:

- [Advanced Tool Settings](#)—set Tool Geometry, Feed and Speed, Surface Finish Quality, and other tool information.
- **Change Tool Number**—Allows you to change the tool number for the current tool displayed.
- **Tool Probing**—Accesses the [Probing Parameters](#). Probing is available only with BMCs.
- **Program Parameters**—Accesses the program parameters.
- **Part Program Tool Review**—Accesses the tool review screen.
- **Validate Zero Calibration**—Confirms tool zero.
- **More** →—Access first set of Tool Setup Softkeys.
- **Exit**—Exits the tool setup process and allows return to the Input screen.

Tool Setup Fields

The Tool Setup fields are defined as follows (note that not all fields appear on the screen for all tools):

- **Tool Number**—Identify the number of the programmed tool. If no tool should be in the spindle, enter a zero (0) for the tool number.

There are several ways to add a tool:

- Enter a new number in the Tool field and move to another field.
- With the cursor in the Tool field, press the PAGE DOWN key to display the New Tool field. Enter a new tool number and press the ENTER key. The remaining Tool Setup fields appear.
- With the cursor in the Tool field, press CTRL + → (the right arrow key). Enter a new tool number and press the ENTER key. The remaining Tool Setup fields appear.

- The Tool Review screen displays a list of programmed tools.
- The range of possible tool numbers is 0 through 65,535 and is set in the Tool Changer Specifications function in the Machine Specifications screen in Utilities.
- The **Next Tool** and **Previous Tool** softkeys become available when more than one tool has been programmed. Use these softkeys as appropriate to access tool setup screens within a program.

⇒ Tool numbers do not necessarily correspond exactly to tool pot numbers on the magazine of your ATC.


- **Location**—Identify the location of the tool: Spindle, Manual, or Auto.
- **Tool Type**—Identify the type of tool. Use the appropriate softkey or drop-down list to select a tool type. If you do not see the type of tool that you wish to use, select the **More →** softkey to display more Type softkeys.
- **Diameter**—Identify the nominal diameter of the tool's cutting surface (i.e., the diameter before the tool suffers from normal wear).

The diameter range is 0 through 9.9999 inches. The Diameter also appears on the Tool Geometry screen.

The system uses the programmed diameter to automatically determine cutter compensation during milling operations. The software calculates the radius of the cutting tool and automatically allows for this distance when performing milling operations. This means it is not necessary to remember the size of the cutting tool or manually calculate tool offsets when programming the part.

For Back Spotface operations, the Diameter field changes to **Cutter Diameter**.

- **Zero Calibration**—Identify a valid calibrated Z axis position (i.e., the distance between the tool tip and the top of the part).
- **Shank Diameter**—Appears when the tool type is Back Spotface and represents the diameter of the tool shank.
- **Thread Diameter**—Appears when the tool type is Tap. Select the Tap icon, located to the right of the field. Choose the appropriate diameter from the pop-up box, as shown below:



- **TPI (or PITCH)**—Appears when the tool type is Tap. Taps per Inch (TPI) appears when the program's unit of measurement is inch. Pitch appears when millimeter is the selected unit of measurement. The range is 0.0 through 99.99.

If you enter a value for TPI, WinMax automatically calculates the Pitch. If you enter a value for Pitch, WinMax calculates TPI.

- **Speed (RPM)**—Define the correct speed to be used for this tool, if known. This value will be copied into each new data block in the part program that uses this tool. If necessary, this parameter can be changed within the new data block when programming the part.

The system uses the Speed (RPM) value to [automatically calculate](#) spindle speeds for the tool.

You can manually change feed and speed values calculated by the control.

The range is set in the [Display Machine Specifications](#) screen in Utilities.

- **Coolant**—Define the coolant, if any, to be used for the tool. Coolant is programmable on a tool-by-tool basis. The softkey and drop-down list choices change to **Off**, **Primary**, **Secondary**, or **Both** when the cursor is at the Coolant field. Select **Primary** for machines equipped with a coolant system, **Secondary** for machines equipped with a secondary coolant system (i.e. through spindle coolant), and **Both** for machines with two coolant systems.
- **Surface Speed (FPM)**—Use for milling tools (drill, end mill, face mill, or ball nosed end mill). The Surface Speed, Flutes, and Feed/Flute fields appear. Enter a Surface Speed in feet per minute (or millimeters per minute), and the Flutes and Feed/Flute fields appear. Enter values that indicate the number of the flutes (teeth) on the tool and the feedrate per flute.

The system uses the values entered in Surface Speed, Flutes, and Feed/Flute to [automatically calculate](#) the feeds and speeds for the tool.

You can manually change all feed and speed values calculated by the control.

- **Flutes**—Enter the number of cutting flutes for the tool. This entry will be

used to [automatically calculate](#) the Mill Feed in all data blocks for this part program using this tool.

You can manually change all feed and speed values calculated by the control .

- **Feed**—Displays the value typically calculated from the tool's Speed, Feed/Flute and Flutes (this field is not used for drill type tools) values.

You can manually change all feed and speed values calculated by the control .

- **Feed/Flute (Tooth)**—Enter the tool's chipload. This entry will be used to [automatically calculate](#) the Mill Feed in all data blocks for this part program using this tool.

You can manually change all feed and speed values calculated by the control.

- **Cutting Time**—displays the number of minutes a tool has been running in the spindle (seconds are rounded up to the nearest minute). Starts at zero unless a time is pre-set by the user (if there is already time on the tool).
- **Diameter Wear**—enter a number to compensate for tool wear.

$$\text{Diameter Wear} = (\text{program tool diameter}) - (\text{actual tool diameter})$$

For example, to adjust a 0.5 inch diameter tool for .001 inch of wear, enter .001 in the Diameter Wear field to set cutter comp diameter to 0.499 inches.



Compensate for tool wear in this field rather than the Tool Diameter field. This will maintain the tool diameter and ensure accurate tool matching with other part programs that use the same tool.

The Diameter Wear value alters the toolpath for cutter compensation. For example, when milling a circle with Milling Type set to Outside, a positive number in the Diameter Wear field will result in a smaller diameter cut, and a negative number will result in a larger diameter cut.

If a probe is used to determine diameter, the Diameter Wear field will contain the compensated value based on the probed diameter. A (P) appears next to the Diameter Wear field to indicate that the value was derived from the probed diameter.

Advanced Tool Settings

See also:

[Tool Geometry](#)

[Feed and Speed](#)

[NC SFO](#)

[Supplier](#)

[Notes](#)


[Edit Apt Parameters](#)

Basic tool information is stored in Tool Setup and additional information can be set in the Advanced Tool Settings screens. Tool Geometry, Feed and Speed information, SFQ, and other tool information are set in the Advanced Tool Settings screen.

⇒ Advanced Tool Settings are optional; it is not necessary to adjust these settings in order to run part programs. They are available to simplify programming and increase program efficiency.

Tool Geometry

Tool dimensions are set in the Geometry tab. Fields denoted with a * are required in order to draw a tool in Solid Graphics; however, these fields are automatically populated with information from Tool Setup, as ratio of entered diameter. A picture of the tool is displayed, and when a field is selected, that area on the picture is denoted.



Most fields on the Geometry screen correspond to tool type, see the table on the following page for information about these fields. Additional Geometry fields are:

- **DIRECTION**—spindle direction
- **COLOR**—the color of the path left by the tool in Solid Graphics. The default selection is Sequential, where tools are represented in the following order by color:
 - Yellow—1st tool
 - Orange—2nd tool
 - Violet—3rd tool
 - Green—4th tool
 - Gray—5th tool
 - Blue—6th tool
 - Cyan—7th tool
 - Magenta—8th tool

- Tan—9th tool
- Lime—10th tool

Alternatively, a specific color can be assigned to a specific tool by changing the selection in the field.

The following table provides the tool-type specific fields:

	Diameter	Shank Diameter	Length of Cut	Tool Length	Flutes	Drill Angle	Thread Diameter	Threads per inch	Radius	Chamfer Angle	Cutting Edges	Stylus length	Drill Angle	Angle	Tip Angle	Tip Length	Tip Diameter	Ream Chamfer	Neck Diameter
Drill	X	X	X	X	X	X													
Tap (cutting)			X	X			X	X											
Boring head	X	X	X	X					X										
End Mill	X	x	x	x															
Face Mill	x	x		x					X	X	X								
Ball End Mill	X	X	X	X	X														
Back Spot-face Drill	X	X	X	X	X														
Probe	X	X		X								X							
Gun Drill	X	X	X	X	X								X						
Center Drill	X	X		X	X								X	X	X	X	X		
Chamfer Mill	X	X		X	X					X							X		
Bull Nose Mill	X	X	X	X	X				X										
Ream	X	X	X	X	X													X	
Spot Drill	X	X		X	X									X					
Forming Tap		X	X	X			X	X											
Counter Bore	X	X	X	X	X											X	X		
Counter Sink	X	X		X	X									X			X		
Keyseat Mill	X	X	X	X	X														X
Thread Mill	X	X	X	X			X	X											
Taper Radius End Mill	X		X	X	X				X					X			X		
Corner Round Mill	X	X	X	X	X				X								X		
Dove Tail Mill	X	X	X	X	X									X					X
Engraving Mill	X	X		X										X			X		

Table 1. Geometry Fields

Feed and Speed



Feed and Speed in Advanced Tool Settings is available only with the Tool and Material Library option.

Feed and Speed settings are carried over from Tool Setup or can be specified in the Feed and Speed tab for specific tool and material combinations in a part program. Choose one of the materials from the work material list for a specific tool and enter the feeds and speeds for both roughing and finishing for that tool and work material combination. This information is saved in the Tool and Material Library and can be utilized in future part programs without re-entering the speeds and feeds: When the Program Parameters for a part program specify a work material, the tool number will recall the feed and speed for that material.



Regardless of the material set in the Feed and Speed tab, the main Tool Setup screen will always display feeds and speeds for "Unspecified" material.

Advanced Tool Settings: Feed and Speed

Roughing and finishing tool parameters can be specified. Fields are:

- **SURFACE SPEED**—set in Tool Setup, or calculated from speed and diameter
- **CHIPLOAD**—set in Tool Setup, or calculated based on feeds and flutes
- **MAX DEPTH**—set maximum depth of cut (optional)
- **COOLANT**—select coolant type: none, primary, secondary, or both
- **SPEED**—calculated value or may be user-defined
- **FEED**—calculated value or may be user-defined
- **PECK DEPTH**—set peck depth
- **PLUNGE FEED**—set plunge feed, or calculated based on Feed Per Rev for

hole-making tools



Feed Per Rev is used for hole-making tools instead of chipload, independent of the number of flutes.

Feed and Speed Calculations

The WinMax software automatically performs tool feed and speed calculations for each tool programmed in the [Tool Setup](#) screens. The calculations are carried over to each data block in the part program using the programmed tool.

The software uses data to perform the calculations from these Tool Setup fields: Diameter, Speed (RPM), Surface Speed (FPM) or (MPM), Flutes, and Feed/Flute (Tooth). Feeds and speeds are related using the following formulas:

Speed Formulas

Feed Formulas

Calculated values are carried forward to the Mill Feed field and Speed (RPM) field for milling and holes data blocks. You can override automatically calculated values in a data block by inserting a user defined value. If you manually change a calculated value in Tool Setup, you will be prompted to update feeds and speeds for the part program data blocks.



For fields that display truncated decimal point values, you may view the non-truncated value by pressing and holding the CTRL key and pressing the period (.) key.

Speed Formulas

The WinMax software uses these formulas to automatically calculate the spindle speeds:

Metric Mode:

$$\frac{\text{Surface Speed} \times 1000}{\text{Tool Diameter} \times \pi} = \text{RPM}$$

English Units:

$$\frac{\text{Surface Speed} \times 12}{\text{Tool Diameter} \times \pi} = \text{RPM}$$



If the calculated RPM exceeds the maximum spindle RPM entered in Machine Specifications, the value appears in red font color.



If you enter the Surface Speed (fpm) value, the Speed (RPM) value will be calculated for you.

If you enter the Speed (RPM) value, the Surface Speed (fpm) value will be calculated for you.

In some cases, calculation rounding may slightly alter a calculated value.

For example, if you enter a value of 7000 RPM for the Speed field in Tool Setup for a Drill operation, the calculated value for Surface Speed is 458 fpm.

However, if you enter a Surface Speed of 458 fpm in the Surface Speed field, the calculated value for Speed is 6997 RPM.

Feed Formulas

For Milling data blocks, specify the number of flutes for the tool in the [Flutes](#) field.

The software uses the following formula to calculate the Mill Feed:

$$\text{Feed} = \text{Chipload} \times \text{Flute} \times \text{RPM}$$

For Holes operations, flutes are not specified for the tool.

The software uses this formula to calculate the Mill Feed:

$$\text{Feed} = \text{Chipload} \times \text{RPM}$$



If the calculated feedrate exceeds the maximum contouring feedrate entered in Machine Specifications, the value appears in red font color.

NC SFQ



NC SFQ in Advanced Tool Settings is available only with the NC/ Conversational Merge option.

Surface finish quality in NC programming is set in the NC SFQ tab of Advanced Tool Settings. Change Enable Tool SFQ to "YES" and adjust the Tool SFQ. This automatically sets the SFQ value whenever the tool is used in NC programming and will override the SFQ value set in Program Parameters or with the G5.3P setting.

Supplier



Supplier in Advanced Tool Settings is available only with the Tool and Material Library option.

The Supplier tab is optionally used to store information about tool supplier and orders in memo-type fields.

Notes



Notes in Advanced Tool Settings is available only with the Tool and Material Library option.

The Notes tab is used to store notes and miscellaneous information about a tool in a memo-type field.

Edit Apt Parameters

The Edit Apt Parameters fields are defined as follows:

- **Tool**—displays the tool number and type entered on the Tool Setup screen. This field cannot be edited. To change tools, go to the [Tool Setup](#) screen.
- **NC Gear Range**—define the spindle gear range. 0 = Low; 9 = High.
- **NC Tool Number**—indicate the starting tool in the tool changer. The range is 0 to 999.
- **NC Diameter Offset**—indicate the tool diameter to be used for cutter compensation. This field is used for posting only. This will not affect a file that is saved as an ISNC file.



If Cutter Comp is selected from the Output Tool Path As field on the Post Processor Configuration screen, the value in the NC Diameter Offset field will be put into the APT file. This value will refer to the tool diameter offset on the target machine. If Centerline is selected from the Output Tool Path As field, then the value entered in the NC Diameter Offset field will not affect the APT file.

- **NC Length Offset**—indicate the length offset at the machine tool.

Creating Tool Setup Templates

To create tool setup templates, save information for each tool block as a file. Recall the tool block file, make any necessary changes for the new part program, and save the changes under a new name. Renaming preserves the original template file for later use.

Create a Tool Template

Follow these steps:

1. Create a new HD5 file.
2. Fill in the Tool Setup screen information for the tool template.
3. Save the HD5 file. Choose an appropriate name for the template (i.e., MyFlatEndMill.hd5).

Rename an Existing Tool Template

Follow these steps:

1. Load the tool template file (i.e., MyFlatEndMill.hd5).
2. Add the necessary data blocks to the HD5 file.
3. Save the HD5 file with a new name (i.e., MyOtherFlatEndMill.hd5). This preserves the original tool template.

Use the Restore Function to Add an Existing Template's Tool Setup

This procedure replaces pre-programmed tools with new tools using the original tool's numbers.

Follow these steps:

1. Create a new HD5 program.
2. Program any necessary changes in the data blocks.
3. From the Input screen, select the **Restore Functions** and **Restore Tool Setup** softkeys.
4. Select **Yes** to continue with the Restore operation.
5. Select and load the tool template to use (i.e., MyFlatEndMill.hd5).

Zero Calibration

When you run the part on a control, use jog functions to calibrate the tool to the part or reference surface.

1. Move the tool in the spindle down until the tool touches part zero.
2. Press the **Store Position** button on the Hurco control's jog unit and the position of the Z axis appears in the Zero Calibration field.
3. The position of the Z axis can also be stored using the **Set Tool Zero** softkey on a Hurco control.



A confirmation (warning) message is displayed if the current tool number shown in Tool Setup is not listed as the tool in spindle.

Part Program Tool Review

Use the PART PROGRAM TOOL REVIEW softkey on the Program Review screen to review the tools used in a specific part program. This screen lists all tools used in a program, and in what program block they are used. The location column indicates if the tool is in Manual, Auto, or Spindle.

List of tools used in program

TOOL	LOCATION	DESCRIPTION
11	Manual	BALL END MILL, dia. 0.2500
	Unmatched	END MILL, dia. 0.5000

Program blocks in which highlighted tool is used (highlight block and select the EDIT BLOCK F1 softkey to jump to the program block)

BLOCK	TYPE
2	SWEPT SURFACE (ISLAND & POCKET BOUNDARY)-Finishin

Selected tool is used in:

Toggle between showing all tools, or only tools that are used in current part program.

SweptSurfaceExample.HHM

Part Program Tool Review



Jump to a program block by highlighting the block and selecting the EDIT BLOCK *F1* softkey.

Softkeys on the Part Program Tool Review screen are:

- **Part Setup *F1***—access the Part Setup screen to establish part zero, centerline, offset Z, safety work region, and other parameters.
- **Tool Setup *F2***—access Tool Setup.
- **Part Programming *F3***—access and create data blocks of a part program. The current program's data blocks appear on screen when this softkey is used. Delete, add, edit, and navigate through the data blocks. The NC editor is displayed for NC programs.
- **Program Parameters *F4***—accesses the Program Parameters screen to specify data common to all program data blocks.
- **Match Tools *F6***—access tool matching results (shown below).
- **Add As Manual Tool *F7***—adds the highlighted unmatched tool as a Manual tool in the Tool & Material Library and assigns it the next available tool number.

Tool Matching



Tool Matching is available only with the Tool and Material Library option.

When a program is loaded and the Tool & Material Library option is enabled, WinMax checks to see if the new program's tools match tools in the Tool & Material Library. Each tool of the program and each tool in the Tool & Material Library are scanned to identify a match by tool type and diameter.



The diameter is set in the Tool Matching: Maximum Diameter Difference field in [Tool Utilities and Settings](#).

1. If only one tool match is found, the program will use that tool number, including the Zero Calibration, from the Tool & Material Library. Note that Feed and Speed data will not be replaced in the program.
2. If more than one match by exists, WinMax then looks at tool number. If it finds the same tool number, type, and diameter, it will match the tool.
3. If there are no matches, tools are either loaded into the Tool & Material Library as Manual, or users can select from a list of tools in the Tool & Material Library that are similar to the unmatched tool. The AUTOMATICALLY LOAD UNMATCHED TOOLS AS MANUAL field in [Tool Utilities and Settings](#) controls this:
 - When the field is set to Yes, any unmatched tools from the new part program will be added to the Tool & Material Library and will be assigned to the first available tool number.
 - When the field is set to NO, a prompt to match tools appears. Answer YES to the prompt to review the unmatched tools.

Tools that are unmatched are displayed in Tool Matching Results.

Tool Matching Results

When tools from the part program cannot find a matching tool in the Tool & Material Library, these unmatched tools are listed in the Tool Matching Results screen, accessed with the Match Tools softkey from the Tool Review screen. Unmatched tools from the current part program are listed in the upper "Tools to be matched" section; as each unmatched tool is highlighted, a list of tools from the Tool & Material Library with the same tool type are listed in the lower, "Closest matches" section.

Tools to be matched:

Tool Description
END MILL, dia. 0.3750
BALL END MILL, dia. 0.1590
END MILL, dia. 3.0100
FACE MILL, dia. 1.0200

Closest matches:

Difference	Location	No.	Description
0.9800	Manual	1	FACE MILL, dia. 2.0000
0.9800	Manual	31	FACE MILL, dia. 2.0000

1861-11.HMM

Unmatched tools

Difference in tool diameter from unmatched tool

List of similar tools in Tool Library (list corresponds to the highlighted tool)

SAVE TO DATABASE

EXIT

Tool Matching Results

The CHOOSE AS REPLACEMENT *F4* softkey appears when you select a tool from the Closest matches list. Use this softkey to replace an unmatched tool with the selected tool from the Tool & Material Library.

If there is not a match in "Closest matches," use the EXIT softkey to return to the Part Program Tool Review screen, and use the ADD AS MANUAL TOOL *F4* softkey to add the tool to the Tool & Material Library. Use the TOOL SETUP *F1* softkey to see the tool details.

The SAVE TO DATABASE *F6* softkey appears when you select an unmatched tool from the list. Select the softkey to save the tool to the Tool and Material Database.

⇒ Saving a tool to the Tool and Material Database will not match a tool with an existing tool in the Tool & Material Library. The program will still consider the tool unmatched and will not run until a match is selected or a new tool is added to the Tool & Material Library.

Tool Management

Tool Management screens are accessed in Manual Mode with the TOOL MANAGEMENT *F1* softkey. They provide the following information:

- Spindle—shows the tool located in the machine's spindle.
- Auto—lists the tools that are in the machine's tool magazine.
- Manual—lists the tools that may be utilized on the machine but are not currently in the machine's magazine or spindle. The Manual tab is active only with the Tool & Material Library option.

Spindle

The Spindle tab displays information about the tool in spindle and allows you to set the next tool to execute a tool change, or to change the current tool in spindle.

Fields are:

- **NEXT TOOL**—lists the next tool to call into the spindle
- **TOOL IN SPINDLE**—lists the current tool in the spindle

Auto

The Auto tab lists the tools in the ATC (automatic tool changer) magazine. Tools are listed by pocket number. The view can be customized to show only occupied pockets or to disable even-numbered pockets (for large tools), using the checkboxes at the top of the screen.

Softkeys on the Tool Library Auto screen are:

- **MOVE TOOL TO SPINDLE *F1***—when spindle is empty, highlighting a tool on the Auto or Manual lists will enable this softkey. Select to confirm and the tool will appear on the SPINDLE tab. The control will prompt to insert the tool into the spindle.
- **SELECT TOOL *F2***—highlight a tool in the list and touch this softkey to select the tool
- **CLEAR POCKET *F3***—removes the selected tool from the pocket
- **CLEAR ALL POCKETS *F4***—removes all tools from the Auto list

Manual

The Manual tab shows tools available for use that are resident on the control, but are not currently in the spindle or ATC. The Manual tab is active only with the Tool & Material Library option:

Softkeys are:

- **MOVE TOOL TO SPINDLE *F1***—when spindle is empty, highlighting a tool on the Auto or Manual lists will enable this softkey. Select to confirm and the tool

will appear on the SPINDLE tab. The control will prompt to insert the tool into the spindle.

- **INSERT TOOL F3**—moves a tool from Manual to Auto:
- **Tool Setup F4**—accesses the Tool Setup screen
- **CHANGE TOOL NUMBER F5**—allows you to change the number of a tool in the list
- **CLEAR TOOLS F6**—clears (removes) tools from the list:
 - **CLEAR SELECTED TOOL F1**—removes highlighted tool from the Tool Library
 - **CLEAR AUTO AND MANUAL TOOLS F2**—removes all tools from the Tool Library
 - **CLEAR AUTO TOOLS F3**—removes all tools in Auto from the Tool Library
 - **CLEAR MANUAL TOOLS F4**—removes all tools in Manual from the Tool Library

Tool and Material Database

The Tool and Material Database is available when the Tool & Material Library option is enabled. It is accessed in Auxiliary Mode. Tool and material information can be entered and stored in the database. The materials entered into the database are available in the work material list located on the Feed and Speed tab in Tool Type Setup/Advanced Tool Settings. This information is saved in the material database and can be utilized in future part programs without re-entering the speeds and feeds.

To add a tool to the database:

1. Select the TOOLS tab.
2. Select ADD TOOL F1 softkey.
3. Enter the tool information in the fields. See the “Advanced Tool Settings” section for more information about these fields.

Softkeys on the TOOLS tab are:

- **ADD TOOL F1**—accesses Tool Type Setup screen to add a tool to the database
- **EDIT TOOL F2**—accesses Tool Setup to edit tool
- **REMOVE TOOL F3**—deletes the selected tool from the database
- **RELOAD DATABASE F4**—TBD
- **DATABASE SOURCE F7**—TBD

To add a material to the database:

1. Select the MATERIALS tab.
2. Select the ADD MATERIAL F1 softkey.
3. Type the name of the material in the NAME field.

4. Add any notes in the NOTES field.
5. Select the SAVE *F1* softkey.

Softkeys on the MATERIALS tab are:

- **ADD MATERIAL *F1***—add a new material to the database
- **EDIT MATERIAL *F2***—change the specifications of a material in the database
- **DELETE MATERIAL *F3***—delete a material from the database
- **RELOAD DATABASE *F4***—TBD
- **SELECT MATERIAL FOR PART PROGRAM *F5***—uses the highlighted material in the current part program
- **DATABASE SOURCE *F7***—TBD

Program Parameters

Program parameters are displayed on tabs for General 1, General 2, Milling 1, Milling 2, Holes, Probing, and Performance. The Performance tab in WinMax is active when the SelectSurface Finish Quality option is enabled. The programmer has the option to make changes to any or all of the program parameters and save them as user defaults. The user defaults and original WinMax defaults can be restored by using the appropriate softkey. Parameters can be altered with the [Change Parameters](#) data block during program execution.

[General Parameters 1](#)

[General Parameters 2](#)

[Milling Parameters 1](#)

[Milling Parameters 2](#)

[Holes Parameters](#)

[Probing Parameters](#)

[Performance Parameters](#)

[NC Parameters](#)

Softkeys on the Program Parameters screen are:

- **SAVE AS USER DEFAULTS *F4***—saves the selected field's value as the user-defined default value
- **RESTORE USER DEFAULTS *F5***—restores the user-defined values to a field that has been populated with other values
- **RESTORE WINMAX DEFAULTS *F6***—restores the WinMax-defined values to a field that has been populated with other values.



Change Parameters program blocks load the user-defined parameters set in Program Parameters.

- **NC Parameters F7**—accesses NC Configuration Parameters. These parameters are available only with NC Part Programming.

General Parameters 1

These are the fields on the General 1 tab:

- **Retract Clearance**—Determines the Z coordinate to which the Z axis positions before rapid table positioning. This includes a tool moving from one drilled hole to another, or from one milling operation to another (programmed in separate data blocks or generated as a patterns operation).
 - The default is the maximum programmable Z travel. This is the difference between the Z-Axis MAX Travel and the Z-Axis MIN Travel as indicated on the Machine Specifications screen.
 - The range is 0 through 99.9999 inches (0 through 2514.6 mm).

If the next operation has a different Z Start value, the CNC always retracts to the highest dimension. When a Position block is programmed, the tool always retracts to The safety plane programmed as Z Top of the Safety Work Region.
- **Rapid Traverse**—Determines the feedrate that the table (X and Y axes) moves between one point in the part program to the next point in the program (rapid table positioning).
 - The default is 400 ipm (10160.0 mm/min).
 - The Range MAX value is user-defined in the Maximum Rapid Traverse Rate field on the Machine Specifications screen. The Range MIN value is 0.1 ipm (2.54 mm/min).
- **Peck Clearance Plane**—Determines the relative distance to the previous peck level. In conversational programming, the tool retracts to Z Start after each peck. The tool then rapids down to a position which is the Peck Clearance distance above the previous peck level before plunging to the next peck level at plunge feedrate.

Peck Clearance Plane only applies to conversational programs.

 - The default is 0.05 inches (1.27 mm).
 - The range is 0 through 99.9999 inches (0 through 2514.6 mm).
- **Chord Error**—Determines the maximum distance the cutter deviates from the true arc path.
- **Override Lockout**—Disables the Axis Feed dial on the jog unit of Hurco controls when set to On. The default is Off.

General Parameters 2

These are the fields on the General 2 tab:

- **Depletion Retract**—Specifies the dimension above the part surface to which the Z axis retracts. The Z axis retracts while waiting for additional data to be transmitted into the current program during execution of an NC part program.
 - The default is 0.005 inches (.127 mm).
 - The range is 0 through 99.9999 inches (0 through 2514.6 mm).Depletion Retract only applies to NC programs.

- **Interrupt Cycle Z Retract**—Retracts the Z axis to Retract Clearance when you press the Interrupt Cycle console button on a Hurco control.
 - Select No to keep the spindle in its current position when the button is pressed.
 - The default is Yes.

- **First Peck Offset**—Permits modifying the depth of the first peck in milling and hole operations. Use this feature whenever a first peck needs to be deeper or shallower than subsequent pecks.

The permitted range is -10.0000 to $+10.0000$ inches or -254.00 to $+254.000$ millimeters.

The First Peck Offset value is added to the operation's peck depth in calculating the first peck only. Use a positive First Peck Offset value for deeper peck and negative value for shallower peck. A First Peck Offset of 0.000 will run the pecks normally, without any First Peck Offset.

For example, if the peck depth in a drill operation is set to 0.2000 inches and First Peck Offset is set to +0.0500 inches, then the first peck will be 0.2500 inches down from Z start plane and all subsequent pecks will be 0.2000 inches deep. If the First Peck Offset is set to -0.0500 inches, the result is a first peck only 0.1500 inches down from Z start plane and every subsequent peck will be 0.2000 inches deep.


- **Move to Safe Pos During TC**—Indicates whether or not the table will move to the right/front of the machine when the operator is changing a tool. If this field is set to Yes when a part program block calls for a tool change, the table will move out of the way.
- **Include Offset Z in Tool Zero Cal**—Indicates whether or not the Offset Z value in Part Setup is added to the zero calibration value when tool lengths are adjusted. Default is Yes.

Milling Parameters 1

Milling parameters apply to cutter motions during conversational milling operations only.

Milling 1 Parameters fields are defined as follows:

- **Blend Offset**—Determines the distance from the entry point of the part surface and the Z plunge point where the tool enters the work piece. This field is used in milling circles, frames, and ellipses.
 - The default is 0.1250 inches (3.175 mm).
 - The range is 0 through 1.0 inch (0 through 25.4 mm).
- **Blend Overlap**—Determines the distance the tool travels past the entry point before it is withdrawn from the part. This field is used in milling circles, frames, and ellipses.
 - The default is 0.1250 inches (3.175 mm).
 - The range is 0 through 1.0 inch (0 through 25.4 mm).



Blend Offset and Blend Overlap

- **Finish Feed (%)**—Allows you to specify a different feed for finishing operations without changing the tool. The specified percentage is a multiplier of the feed entered in Tool Setup. This multiplier is applied whenever the tool is entered for the finishing operation of a milling block. (See example below.)

⇒ If this parameter is changed in either Program Parameters or with a Change Parameters block, all existing data blocks that are affected by the multiplier will be updated.

- **Finish Speed (%)**—Allows you to specify a different speed for finishing operations without changing the tool. The specified percentage is a multiplier of the speed entered in Tool Setup. This multiplier is applied whenever the tool is entered for the finishing operation of a milling block. (See example below.)

- ⇒ If this parameter is changed in either Program Parameters or with a Change Parameters block, all existing data blocks that are affected by the multiplier will be updated.

Finish Feed / Finish Speed example:

Program Parameters: Finish Speed %=120, Finish Feed %=80

Tool Setup: Speed=5000, Feed=100

When a program block is created, the speed is automatically set to 5000 and the feed is set to 100. When the tool is entered into the finishing operation, the multipliers are applied, and finish speed is set to 6000 (5000 x 120%), finish feed is set to 80 (100 x 80%).

- ⇒ The Finish Feed and Finish Speed parameters are not applied if the roughing feed or speed in a data block is changed.

Values entered manually into the Finish Feed or Finish Speed fields in the data block take precedence over these parameters.


If the Tool & Material Library option is enabled, separate roughing and finishing defaults can be set for each tool. If finishing defaults are defined for a tool, those values take precedence over the Finish Feed and Finish Speed multiplier parameters.

- **Finish XY**—Determines the amount of material in the X-Y axis direction to be removed by the finish pass.
 - The default is 0.2 mm (0.007874 inches).
 - The range is 0 through 1.0 inches (0 through 25.4 mm).

- ⇒ Stock is removed up to a maximum of 90% of tool diameter.


- **Finish Z**—Determines the amount of material in the Z axis dimension to be removed by the finish pass.
 - The default is 0.1 mm (0.003937inches).
 - The range is 0 through 1.0 inch (0 through 25.4 mm).
- **Milling Direction**—Determines the milling type. Select Conventional or Climb milling for canned milling cycles (e.g., frame, circle, and ellipse) and for contours (e.g., line, arc).
 - The default is Climb.
 - The choices are Conventional or Climb.
- **Default Pocket Overlap**—Determines the cutter step-over movement in a pocket milling operation. After the first pass, the tool follows a path produced by offsetting the boundary by the tool radius, plus the pocket overlap for each pass while avoiding islands inside the boundary.
 - The default is 50%.

- The range is 0 through 99%.
- **Cutter Comp Param**—Determines the programmed tool automatically follows the finished contour of the part with cutter compensation. Without cutter compensation, the center line of the programmed tool follows the print line.
- **Insert Arc**—Inserts a tangent arc to connect two line segments, or a line segment and an arc segment (when the two cutter compensated segments are offset and do not intersect).



Cutter Compensation using the Insert Arc parameter

- **Insert Line**—Joins the cutter compensated lines and arcs as described below:
 - Two line segments are extended until they intersect (provided they form a 90° or greater angle). If the lines form an angle of less than 90° , a line is inserted to connect them.
 - Line and arc segments have the line segment extended, and a tangent line to the arc segment inserted and extended until the lines intersect (provided they form a 90° or greater angle). If the segments form an angle of less than 90° , a line is inserted to connect them.
 - Two arc segments have tangent lines (to the arcs) inserted and extended until the lines intersect (provided the extended tangent lines form a 90° or greater angle). If the extended tangent lines form an angle of less than 90° , a line or arc is inserted to connect them.



Cutter Compensation using the Insert Line parameter

Milling Parameters 2

The Milling 2 Parameters fields are related to the Helical Plunge Option and are defined as follows:

[Mill Plunge Type](#)

[Mill Plunge Ramp Slope](#)

[Mill Plunge Helix Radius](#)

[Finish Plunge Type](#)

[Finish Plunge Ramp Slope](#)

[Finish Plunge Helix Radius](#)

[Operator Specify Pocket Start](#)

[Inward Pocket Plunge Near Center](#)

Holes Parameters

The Holes Parameters fields are defined below:

- **Bore Orient Retract**—Determines the distance the boring tool moves away from the part surface at the end of the boring cycle. Used only when a Bore Orient data block is included in the part program.
 - The default is 0.05 mm (0.019685 inches).
 - The range is 0 through 99.9999 inches (0 through 2514.6 mm).
- **Drill Dwell**—Determines the pause (dwell) in seconds before the tool retracts at the bottom of a drill operation. The most often changed Holes Parameter is Drill Dwell. This parameter controls the length of time the drill stays at the bottom of a hole after it has drilled the hole. This parameter is not used for NC programs.
 - The default is 0.5 seconds.
 - The range is 0 through 20 seconds. (Set this to 0.0 seconds, and the drill immediately pulls out of the hole after it is drilled.)
- **Bore Dwell**—Determines the pause in seconds before the tool retracts at the bottom of a Bore operation. This parameter is not used for NC programs.
 - The default is 1.0 seconds.
 - The range is 0 through 20 seconds.

Probing Parameters

The Probing Parameters are:

- **Automatic Tool Monitoring**—indicate if tools that were calibrated with the probe should be automatically checked with each tool change.
- **Zero Cal (Length) Tolerance**—indicate the zero calibration (tool length) used when checking for a defective tool.
- **Diameter Tolerance**—indicate the diameter tolerance used when checking for a defective tool.
- **Retain Probed Part Setup**—allows the probed part setup and/or tool calibrations to be retained for new program runs. Choices are:
 - Do Not Retain—no updates will be made to part zero or tool lengths.
 - Retain All—retains part setup and tool calibrations.
 - Retain Part Setup—retains all part setup information.
 - Retain Tool Calibrations—retains tool calibrations.

Performance Parameters

Surface Finish Quality (SFQ) is enabled with the SelectSurface Finish Quality option. SFQ parameters can be modified in either Conversational or NC programming. The default SFQ for roughing is 80 and finishing is 20. Recommended SFQ values are:

SFQ	Desired Result
1-20	High precision parts /finishing
21-79	Good surface quality / finishing, semi-finishing
80-100	High throughput / roughing

Table 2. Recommended SFQ values

⇒ If SelectSurface Finish Quality is not enabled, conversational roughing tools use SFQ of 80 and conversational finishing tools use SFQ of 20; NC default is 50.

Import Functions

Import Functions imports Part Setup, Tool Setup, Program Parameters, Part Program information, and/or NC states from an existing Conversational program or NC State file into the active part program, as follows:

1. Select the IMPORT FUNCTIONS *F5* softkey from the Input screen.
2. Select the appropriate softkey for a Conversational or NC program.
3. Choose the file from which components will be imported and select the LOAD *F1* softkey.
4. Choose one or more components from the list and select the BEGIN OPERATION *F2* softkey.
5. Select OK to continue the import operation.

Conversational Components

These are the Conversational components that can be imported from an existing part program into a new part program:

- **Part Setup**—imports the Part Setup from the selected program into the current part program.
- **Tool Setup**—imports tools from the Tool Setup of the selected part program to the current tool setup on the machine. If the Tool & Material Library option is enabled, unique tools are added as Manual and other tools may be matched (see [Tool Matching](#)).
- **Program Parameters**—imports the Program Parameters from the selected program into the current part program.
- **Part Program**—imports the part program from the selected program into the current part program.

NC States

NC components are stored in the NC States file on the control. Only one NC States file exists on a control, and it is updated as changes are made to current or new NC programs. When an NC States file is saved, a corresponding NC Tools file (.nct) is also created with the same name in the same directory. For example, the NC States file Program Name.ncs. will have a corresponding tool file named Program Name.nct. The .nct file must remain in the same directory with the same name as the associated .ncs file. The .nct file can be imported into a program the same way a .ncs file is.

When transferring an NC program from one machine to another the NC States file from the original machine can be imported to another machine using the IMPORT NC STATES softkey. These are the components that can be imported from an NC States file into a new program:

- **Program Parameters**—imports the Program Parameters.
- **Part Setup**—imports the Part Setup.
- **Tool Setup**—imports tools from the Tool Setup of the selected part program

to the current tool setup on the machine. If the Tool & Material Library option is enabled, unique tools are added as Manual and other tools may be matched (see [Tool Matching](#)).

- **Tool Offsets**—imports Tool Offsets.
- **Work Offsets**—imports Work Offsets.
- **NC Parameters**—imports the NC parameters.
- **NC Variables**—imports NC variables.



The imported components will replace the current components from the open program; they are not merged together.



Either the .ncs or the .nct file can be selected to import any NC component(s); when either file is selected both are used.

NC States are saved as follows:

1. Select the IMPORT FUNCTIONS *F5* softkey from the Input screen.
2. Select the SAVE NC STATE TO FILE *F6* softkey.
3. Choose the location to which the file will be saved in the SAVE STATE FILE screen.
4. Type the name of the file in the FILE NAME field, or use the default, **ncstate.ncs**, which appears automatically in this field.



It is recommended to rename the NC States file to match the active part program. When renaming, you must retain the .ncs extension at the end of the file name. For example, **Program Name.ncs**.

5. Select the SAVE *F7* softkey to save the NC States file. A message that the file saved successfully will briefly appear on screen.

Importing NC States into Conversational Programs

NC States information that is valid for Conversational programs (the Part Setup, Tool Setup, and Program Parameters) can be imported into a Conversational program.

1. Make sure the current part program is Conversational.
2. Select the IMPORT FUNCTIONS *F5* softkey from the Input screen.
3. Select the IMPORT NC STATE FROM FILE *F4* softkey.
4. Choose the .ncs or .nct file from which components will be imported and select the LOAD *F1* softkey. Either file may be used to import any component.
5. Choose one or more components from the list and select the BEGIN OPERATION *F2* softkey.
6. Select OK to continue the import operation.

Copy and Change Blocks

To make changes to several data blocks at one time, use the Copy and Change Blocks softkey to access the Block Editor.

These are the softkeys:

- **Copy Blocks**—Duplicate the specified data blocks in another location in the part program.
- **Move Blocks**—Remove the specified data blocks from their current location and transfer them to another location in the part program.
- **Delete Blocks**—Remove the specified data blocks from the part program.
- **Modify Dimensions**—Add offsets to the axes' coordinate dimensions currently stored in the part program for a range of blocks.
- **Change All Feeds, Speeds, and Tools**—Substitutes new feeds and speeds for all tools within the specified range of data blocks.
- **Change Feeds and Speeds by Tool**—Substitutes new speeds and feedrates for a specified tool within a range of data blocks.

The following fields appear when you select either softkey, except where noted otherwise:

- **Start Block**—Enter the number of the first block in the program to be changed.
- **End Block**—Enter the number of the last block in the program to be changed.
- **Put Block Before**—Move a block in the program before the indicated block.
- **Change Tool Number**—Identify the tool number. Blocks using this tool number will be changed. (This field appears only for the Change Feeds and Speeds by Tools screen.)
- **New Speed (RPM)**—Enter a new Speed (RPM).
- **New Feed**—Enter a new Feed.
- **New Plunge Feed**—Enter a new Plunge Feed.
- **New Tool**—Enter a new Tool.
- **New Finish Tool**—Enter a new Speed (RPM).

Enter the changes in the fields and select the **Make the Change** softkey.



The **Copy Blocks**, **Move Blocks**, and **Delete Blocks** softkeys are also available for editing a current program.

Copy, Move, or Delete Blocks

The COPY BLOCKS screen is used to duplicate the specified data blocks in another location in the part program.

The MOVE BLOCKS screen is used to remove the specified data blocks from their current location and transfer them to another location in the part program.

The DELETE BLOCKS screen is used to remove specified data blocks from the part program.

Fields on the screens are:

- **Start Block**—Enter the number of the first block in the program to be changed.
- **End Block**—Enter the number of the last block in the program to be changed.
- **Put Block Before**—Move a block in the program before the indicated block.

Modify Dimensions

Modify Dimensions allows you to add offsets to the axes' coordinate dimensions currently stored in the part program for a range of blocks.

These softkey choices appear when you select the Modify Dimensions softkey:

- **Start Block** - enter the number of the first block in the program to be modified.
- **End Block** - enter the number of the last block in the program to be modified.
- **X Offset** - enter the offset for the X axis.
- **Y Offset** - enter the offset for the Y axis.
- **Z Offset** - enter the offset for the Z axis.
- **Change Z-Start** - enter the new Z-Start position.
- **A Offset** - enter the offset for the A axis.
- **B Offset** - enter the offset for the B axis.

Enter the modifications in the fields and select the **MAKE THE CHANGE** softkey to modify the programmed dimensions.

Changing Feeds, Speeds, and Tools

Feeds, Speeds, and Tools can be changed for a range of blocks in a part program with the following softkeys from the Block Editor screen:

- **Change All Feeds Speeds & Tools**—change Feed, Speed, and Tool for specified program blocks. Fields are:
 - **Start Block**—Enter the number of the first block in the program to be changed.
 - **End Block**—Enter the number of the last block in the program to be changed.
 - **New Speed (RPM)**—Enter a new Speed (RPM).
 - **New Feed**—Enter a new Feed.
 - **New Plunge Feed**—Enter a new Plunge Feed.
 - **New Tool**—Enter a new Tool.
 - **New Finish Tool**—Enter a new Speed (RPM).
- **Change Feeds & Speeds By Tool**—Make changes to feeds and speeds for blocks using a specified tool. Fields are:
 - **Start Block**—Enter the number of the first block in the program to be changed.
 - **End Block**—Enter the number of the last block in the program to be changed.
 - **Change Tool**—Enter tool; changes will be made only to blocks using this tool.
 - **New Speed (RPM)**—Enter a new Speed (RPM).
 - **New Feed**—Enter a new Feed.
 - **New Plunge Feed**—Enter a new Plunge Feed.
 - **New Tool**—Enter a new Tool.


Change Surface Finish Quality

The surface finish quality can be changed for a range of blocks in a part program. Fields are:

- **Start Block**—Enter the number of the first block in the program to be changed.
- **End Block**—Enter the number of the last block in the program to be changed.
- **Change Rough SFQ**—Specify Yes or No.
- **Rough SFQ**—Enter the Rough SFQ for the range of blocks.
- **Change Finish SFQ**—Specify Yes or No.
- **Finish SFQ**—Enter the Finish SFQ for the range of blocks.

Review Mode

The Program Review screen is accessed with the console Review key. Data blocks and sub blocks of the active part program are displayed in a list, and the tools used in each data block are displayed in the Tool Data list. Program blocks can be moved and added in the Program Review screen.



Program Review Screen

Program Review softkeys are:

- **Multiple Block Functions F1**—allows multiple blocks to be cut, copied, or pasted between programs:
 - **Cut F1**—highlight data block(s) and touch this softkey to delete from the current program. Block(s) can then be pasted into the same or a different program.
 - **Copy F2**—highlight data block(s) and select this softkey to make a copy that can be pasted into the same or a different program.
 - **Paste F3**—places previously cut or copied data block(s) above the highlighted data block.
 - **Delete F4**—highlight data block(s) and touch this softkey to permanently remove the block from the program.



Multiple blocks can be selected simultaneously by holding the **F** and **Alt** keys while pressing the up or down arrow keys.

- **Convert to Rotary F6**—converts linear dimensions to rotary dimensions; a flat geometry can be wrapped around a cylinder, given a radius. Blocks that can be wrapped are: contour, circle, frame, and TrueType lettering

holes (locations).

- **Convert to Linear F7**—converts rotary dimensions to linear dimensions.



For WinMax Desktop and WinMax Mill on machines not equipped with rotary, the **Default Conversational Program Type** must be changed to a rotary type in order to convert the program to rotary. This is changed in Conversational Settings in Utilities.

- **Delete Block / Delete Sub Block F2**—deletes the highlighted data block or sub-block.
- **Part Programming F3**—allows you to edit the selected data block or sub-block.
- **Program Parameters F4**—access General, Milling, Holes, Probing, and Performance parameters. NC parameters are accessible for NC programs.
- **Part Setup F5**—access the Part Setup screen to establish part zero, centerline, offset Z, safety work region, and other parameters.
- **Part Program Tool Review F6**—review the tools used in the part program.
- **Insert Block / Sub Block Before F7**—inserts a new program block or sub-block before the selected block or sub-block.

Auto Mode

Programs are run in Auto Mode. Press the Auto button on the console to access Auto Mode to check for errors, compute estimated run time, recovery/restart, perform a dry run, or run a part program.

The following softkeys are available in Auto Mode:

- **Use Editing File F1**—selects the active program file to run. If this softkey is not selected, WinMax defaults to the last program run. If the last program run does not match the program that is being edited (as indicated in status bar), the operator will be prompted to select which program to run.
- **Feed & Speed Optimization F2**—fine tunes program execution, using the Axis Feed Rate and Spindle Speed dials to adjust values.
- **Check for Errors F4**—checks the program from the Start Block through the End Block and displays error status. The number of the data block containing the error is included in the error message.

The time required for error checking depends upon the program's length and complexity. Select the Abort Operation softkey to stop error checking at any time.

- **Compute Estimated Run Time F5**—a pop-up window displays an estimate of time it takes to run the program. Pressing any console key will remove the pop-up window. Select the Abort Operation softkey to stop computing estimated run time.


Error checking automatically occurs during Compute Estimated Run Time.

- **Recovery Restart F6**—restarts a conversational or NC part program; typically the point at which the program was interrupted.
 - For Conversational Programs—if necessary, Conversational Start and End blocks can be changed from the default.

For a Mill Contour data block, Recovery Restart can occur at segment 0 of a Mill Contour data block, not at a segment within a data block.

If a Pattern data block is selected as the Start Block, the number of the starting location must be entered. The End Block for a Pattern Start Block must either be at or after the Pattern End, or the end of the program.
 - For NC Programs—use the Set Restart Marker, Auto Set Restart Marker, or Reset Restart Marker softkeys to restart an NC program after it was aborted either by the machine or the operator.
- **Dry Run F7**—active in Test Run mode only, performs a program test run to identify potential problems before cutting the part. Specify all or a portion of the part program that will be tested in the Start and End blocks.

Trace the tool over the part at the programmed minimum Z level with the Spindle Off. Peck cycles and roughing passes are skipped.

 If the Z-Start value is set below the stock surface, the minimum Z value must be programmed so the tool does not plunge into the part.
- **Run Program F8**—initiates program execution and displays monitoring information. If the machine is not calibrated, the Manual screen immediately displays.

Auto Mode Monitoring


The Auto Mode Monitoring screen appears when the RUN PROGRAM softkey is selected and program execution begins. The upper part of the screen displays the current positions of all axes, the Tool in Spindle, Spindle RPM, and the axes feedrates. The lower area of the screen displays the Spindle Load Monitor, the data block executed, the type of operation, and the part count. For NC programs, five lines of NC code are shown; to view more NC code as the program runs, select the NC MONITOR F6 softkey. The bottom portion of the screen is reserved for program status and error messages.

These are the fields on the Auto Mode Monitoring screen:

- **Machine and Part Axes**—displays the current position of all axes.
- **Opt Stop On (Off)**—displays the status (on or off) of the Optional Stop for NC programs.
- **Chip Removal**—displays the status of the chip auger.
- **Tool in Spindle**—displays the tool number of the tool in the spindle.
- **Spindle**—displays the current spindle speed.
- **Feed**—displays the current feed rate.
- **Program Run Time**—displays the time the program has been running.
- **F(%)**—displays the current Feedrate per Minute percentage set on the axis

Feed Rate knob.

- **R(%)**—displays the current Rapid Traverse Feedrate percentage set on the Rapid override knob.
- **S(%)**—displays the current spindle RPM percentage set on the Spindle Speed override knob.
- **Axis Limit Switches**—displays the status of the machine's limit switches as each axis calibrates.
- **Spindle Load Monitor**—displays the percentage of full load on each axis as the program runs. The load is displayed in a bar graph format, with colors progressing from green to yellow to red to indicate the percentage of load from 0 to 150%.
- **Block**—displays the current program block.
- **Part Count**—displays the number of times the program was executed.



Auto Mode Monitoring screen

These are the monitoring softkeys that may be available for Auto Cycle mode:

- **Reset Part Count F1**—the number of times a program was executed. To return this value to zero when a new program starts, touch the Reset Part Count softkey.
- **Chip Removal Forward On/Off F2**— turn the chip auger in the forward (clockwise) direction on or off. This selection is saved when the Interrupt button is pressed or after the program has finished running. If a stop condition or mode change is made before restarting a new part program or exiting the interrupt cycle, the saved information is cleared. This softkey is only available if your machining center uses a chip auger.
- **Optional Stop On/Off F3**—pauses the program and shuts off the spindle. This softkey functions only with NC programs. When Optional Stop is On, the M01 code in the NC program will be processed; when Optional Stop is Off, the M01 code is ignored.

- **Select DRO F4**—change the size of the digital read out (DRO) on the screen. From the Select DRO screen you can see machine information displayed in either Full Status or Full DRO. Full Status displays the current location of machine and part axes, as well as other machine information. Full DRO displays the current location of machine and part axes, Distance to Go and other machine information (with abbreviated categories).
- **Coolant Washdown On/Off F5**—turn the coolant washdown on or off for washing chips from the enclosure.
- **NC Monitor F6**—displays a pop-up window containing the current NC code. This feature allows you to view the code as the program runs; the program name appears in the Current Program Name box at the bottom of the monitor. The line of code that is currently being machined is identified in red. When the “Show Modals” box is checked, the current active modals are shown. As machining progresses, the monitor will scroll through the lines of code. Select the “Close” button at the bottom of the window to close the NC Monitor.
- **Toggle Rapid Override Enable F7**—enable or disable the ability to override the programmed rapid traverse using the Rapid Override console knob.
- **Worklight On/Off F8**—turn the enclosure worklight on or off. This softkey is only available if your machining center is equipped with an enclosure worklight.

Manual Mode

Manual mode controls machine settings and operations.

These are the softkeys for Manual mode:

- **[Tool Management F1](#)**—Access tool information for Spindle, Auto Tools, and Manual Tools.
- **Manual Function Setup F2**—Access the CE Status & Diagnostics screen.
- **Diagnostics F3**—View machine diagnostics.
- **[Park Machine F4](#)**—Center the table and leave the spindle at the home position.
- **[Warm Up Machine F5](#)**—Warm up an idle machine.
- **Orient Spindle F6**—Ensures that the Z axis is at the correct height for a tool to be inserted in the spindle.
 - ⇒ The ORIENT SPINDLE softkey will not function unless the enclosure doors are completely closed.
- **Reset Servos and Spindle F7**—Activates only to enable recovery from certain types of electronic hardware faults such as overloads.
- **[Calibrate Machine F8](#)**—Establish absolute zero for each axis on the machining center.

GRAPHICS

WinMax graphics include [Toolpath and Solid Graphics](#). Real-time graphic animation is available with the new Runtime tool, which shows a simulated tool cutting the part on screen while the machine is cutting the actual part.

⇒ Solid graphics and Runtime tool are only available with the Advanced Verification Graphics option.

Graphics Settings

Graphics preferences are set in the Graphics Settings screen, which is accessed with the GRAPHICS SETTINGS *F8* softkey. Fields on the Graphics Settings screen are:

- **DEFAULT VIEW**—set the default view when WinMax is started, either XY plane, XZ plane, Isometric, or All Views.
- **SHOW GRAPHICS**—set the type, either Show All, Toolpath, or Solids.
- **TOOL PATH**—specify Yes or No to show the tool path (appears as red dashed line).
- **PART SURFACE**—specify Yes or No to show the part surface (appears as solid cyan line).
- **RAPIDS**—specify Yes or No to show rapid moves (appears as yellow solid lines).
- **STOCK OUTLINE**—specify Yes or No to show the stock outline, which is set in the stock geometry screen (appears as green solid line). Refer to the “Stock Geometry” section in *Part Setup* for more information.
- **PLUNGES**—specify Yes or No to show plunge moves (appears as purple lines).
- **SHOW PECKS OF CONTOURS**—specify Yes or No to show all the roughing tool path, applies only to Toolpath graphics.
- **SHOW PECKS OF 3D SURFACES**—specify Yes or No to show all the pecks during milling of 3D mold and swept surface blocks.
- **ENABLE RUNTIME TOOL DISPLAY**—specify Yes or No to see simulated tool move around the part while the machine is running; tool also shown when jogging tool near part.
- **SHOW SFQ**—specify Yes or No to show surface quality indicator while the machine is running; only in Auto mode (appears as horizontal bar).
- **SHOW F-ERROR**—specify Yes or No to show following error (difference between commanded position and actual position) while machine is running; only in Auto mode.
- **USE CHORD ERROR FROM PROGRAM?**—specify Yes or No to use the chord error value programmed in general parameters when rendering curves in NC.
- **GRAPHICS CHORD ERROR**—enter the chord error to be used when drawing

curves in graphics.


- **BACKGROUND COLOR**—choose Black or White background color.
- **SCREEN REFRESH RATE**—choose how often the screen refreshes when displaying the runtime tool, based on machining feedrate:
 - EVERY 20 SECONDS
 - EVERY 10 SECONDS
 - EVERY 5 SECONDS
 - ONCE PER SECOND
 - 5 TIMES PER SECONDS
 - 10 TIMES PER SECOND
 - 20 TIMES PER SECOND

⇒ The faster refresh rate will represent more uniform motion but will consume more system memory and processing speed.

Toolpath and Solid Graphics

Toolpath graphics displays a wireframe view of the part. Toolpath is also animated to show the tool in motion if the runtime tool is displayed (only available with the Advanced Verification Graphics option).

Solid graphics displays a solid 3-dimensional part; only available with the Advanced Verification Graphics option.



Solid graphic display

The console Draw button initiates drawing. The Draw Options menu is displayed (for both Toolpath and Solid) to control drawing and animation:

- **DRAW OPTIONS F1**—displays the following draw options:
 - **DRAW (PAUSE) F1**—starts drawing the part. When drawing is in progress, the softkey displays PAUSE—select it to pause the drawing. When paused, the softkey displays DRAW—select it to resume drawing.
 - **ACCELERATED DRAW F2**—displays only the completed drawing without showing each block as it is drawn. There may be a delay before the completed drawing appears on screen; selecting the SHOW PROGRESS F2 softkey displays the drawing at the current point each time the softkey is selected.
 - **SINGLE STEP F3**—displays only one step or program block at a time. Subsequent selection of SINGLE STEP will execute the next step or block.
 - **NEXT TOOL CHANGE F4**—displays cutting from one tool change to the next.
- **SELECT VIEW F2**—choose XY plane, XZ plane, YZ plane, Isometric, or All Views.
- **ZOOM F3**—magnifies an area of the graphic. Select the softkey and choose one of the following:
 - **ZOOM IN F1**—magnify incrementally by 20% each time the softkey is selected.
 - **ZOOM OUT F2**—shrink view incrementally by 10% each time the softkey is selected.
 - **FIT TO VIEW F3**—returns drawing to full view.
 - “Touch-and-drag”—place stylus at a point on the screen and drag it to expand the box over the area you wish to magnify. When stylus is lifted from screen the area will be magnified.
- **PAN F4**—moves the graphic up, down, left, or right. Use the softkeys or touch the screen and drag the graphic.
- **ROTATE F5**—changes the rotation of the graphic.
- **DB SEARCH F6**—jumps to a selected data block. Select the softkey, touch an area on the graphic touchscreen, and select the JUMP TO BLOCK softkey.
- **SNAPSHOT F7**—creates an image of the solid that is stored with the HWM file. The image is displayed on the Program Manager screen when the program is highlighted.
- **GRAPHICS SETTINGS F8**—displays the Graphics Settings screen.

HURCO CONVERSATIONAL OVERVIEW

Conversational programming allows you to create a part program from a blueprint or program worksheet while working at the machine. Operating selections and prompts on the screen lead you through the steps necessary to enter the data for a part program. Machining operation information is stored within data blocks describing each operation to be performed.

Create and access the data blocks through the **Part Programming** softkey or the Part Programming icon.

- [Part Programming](#)
- [Cutter Compensation](#)
- [Milling Operations](#)
- [Holes Operations](#)
- [Patterns Operations](#)
- [Special Operations](#)
- [NC/Conversational Merge](#)

Part Programming

Use part programming to communicate plans from a blueprint to the CNC using data blocks. Data blocks appear in numerical order as they are created. To create a Conversational Part Program:

1. Press the Input console key to display the Input screen. The Input screen allows you to access setup functions including [Part Setup](#), [Tool Setup](#), and [Program Parameters](#).
2. Enter machining operation information in the Part Setup and Tool Setup functions. This information is stored within data blocks describing each operation to be performed. Create and access the data blocks through the Input screen.
3. Select the Part Programming softkey to begin programming. The system displays either the first block of an existing program or a *New Block* screen for new programs.

Data blocks can be managed with the following programming operations:

- Access softkeys to create a new data block or edit an existing data block in the Input screen.
- View a list summarizing a part program's data blocks on the Program Review screen. See [Review Mode](#) for more information.
- View the current program's tool list on the [Part Program Tool Review](#) screen.

- Use the Insert Block Before softkey to Insert a new data block between two sequentially numbered blocks. The data blocks following the inserted block automatically renumber.
- Holes blocks contain operations, and Mill Contour blocks contain segments.

Part Programming softkeys access the following options:

- **Position**—Insert instructions to move the tool away from the part (or fixture), or to stop a program. A [Position](#) block is most often used to move the table to an X-Y location and is normally used at the end of the program and at any time the tool must be moved to the Z Top position of the Safety Work Region.
- **Holes**—Select Drill, Tap, Bore and Ream drilling operations, and Back Spotface and Bolt Circle hole drilling. The locations of these holes on the part can be specified using the Locations operation, and the holes can also be programmed in a Bolt Circle pattern.
- **Milling**—Program [Lines and Arcs](#), [Circle](#), [Frame](#), [Facing](#), [Ellipse](#), [3D Mold](#), [HD3 Lettering](#), [Mill True-Type Lettering](#), and [Swept Surface](#) milling operations. Special milling blocks Triangle, Diamond 1 Face, Diamond 2 Faces, and Hexagon are accessed with the Special → softkey.
- **Patterns**—Repeat or modify a sequence of one or more data blocks. A program sequence can be repeated in a rectangular, linear, angular, or rotated [pattern](#) or at specified locations. This operation is also used to scale or mirror a programmed part.
- **Miscellaneous**—Access these softkey functions. Refer to [Temporary Parameter Change](#) for details.
 - Graphics Off
 - Graphics On
 - Change Parameters
 - Change Part Setup
 - Machine Function
 - Probe Part Setup
 - Lube Cycle
 - Comment
 - Insert
 - Tool Monitoring (Probing)
 - Part Inspection
- **NC Program Call**—Access an NC program from within the conversational program with this softkey.
- **Rotary**—Select [Rotary](#) parameters and programming of position blocks, lines and arcs, circles, frames, loops, locations and patterns.
- **Exit**—Returns to the previous screen.

Data Blocks

Use the following basic programming operations when creating data blocks:

- Create a new data block or edit an existing data block through the Input screen.
- Insert a new data block between two sequentially numbered blocks. Data blocks following the inserted block will be automatically renumbered.
- Delete an existing data block. The data blocks following the deleted block renumber automatically.
- View a list of the part program's data blocks on the Review Program screen.
- Copy, edit, or delete information in a data block using the Block Editor screen.
- Data blocks within a part program contain specific machining information:
 - Operation type (position, holes, milling, patterns).
 - Tool number to be used for the operation.
 - Dimension coordinates relative to X, Y, and Z axes.
 - Feedrate at which the axes move.
 - Locations of operations on the part.

Segments

Mill Contours, 3D Mold Contours, and Rotary Mill Contours are composed of a combination of segments. A segment is a line, arc, blend arc, helix, or 3D arc with programmed single or combined X, Y, Z axis movement at a programmed feedrate. A new segment begins where a different motion from the previous segment is programmed. Segments appear in a numbered list in the Program Review Screen under the data blocks to which they apply.

The order in which segments are programmed determines the direction the tool moves from the start point.

Setting Right (conventional milling) or Left (climb milling) in the Milling Parameters overrides the direction of the programmed path.

Data Block Creation and Navigation

These basic concepts are helpful to know when creating and editing data blocks:

- To move through the fields on a data block screen, press the ENTER key, use the up and down console arrows, the up and down arrows on the optional keyboard, or the optional mouse.
- When the cursor is on the Block field in a data block, these softkeys appear: **Previous Block**, **Next Block**, **Delete Block**, and **Insert Block Before**.
- If a block should not be used in the program, move the cursor to the Block field and select the **Delete Block** softkey to remove it from the program.
- To insert a data block before an existing block, select the **Insert Block Before** softkey at the beginning of this block. The New Block screen appears with softkey choices.

- To create a data block after the last block in a program, select the **Insert Block Before** softkey from the End of Program screen.
- When the cursor is on the Operation field in a Holes data block, these softkeys appear: **Previous Hole Operation**, **Next Hole Operation**, **Insert Hole Operation**, and **Delete Hole Operation**.
- When the cursor is on the Segment field in a Mill Contour data block, these softkeys appear: **Previous Segment**, **Next Segment**, **Delete Segment**, and **Insert Segment Before**.
- In Ultimax Classic Edit Mode, to tell the system to read and remember new data that is typed into a field, press the ENTER key. Pressing ENTER also automatically advances the cursor to the next field.
- A field can be skipped (allowed to remain unchanged) by pressing the ENTER key when the cursor is positioned on the field or by using the up and down console or keyboard arrows.
- Use the Page Up or Page Down console keys to move through data blocks and tool setup screens, or press and hold the CTRL key and press the right and left arrow keys.
- Use the optional keyboard's ALT + SHIFT + left arrow keys to navigate to the previous data block. On the virtual keyboard, sequentially touch the ALT, SHIFT and left arrow keys to move to the previous data block.
- Use the CTRL + ALT + left arrow console keys to navigate to the previous data block.
- Use the optional keyboard's ALT + SHIFT + right arrow keys to navigate to the next data block. On the virtual keyboard, sequentially touch the ALT, SHIFT and right arrow keys to move to the next data block.
- Use the CTRL + ALT + right arrow console keys to navigate to the next data block.
- Page Down (or CTRL + right arrow) on the last data block adds a new data block.
- Page Down (or CTRL + right arrow) on the last tool adds a new tool.
- While programming a Holes data block, select the **Previous Hole Operation** or the **Next Hole Operation** softkeys to move between the operations within the data block, or use the PAGE UP (CTRL + left arrow) or PAGE DOWN keys (or CTRL + right arrow). These operations describe separate portions of the holes operation.
- Use either the PAGE DOWN key, CTRL + right arrow, or the **Next Hole Operation** softkey to add a new operation when positioned on the last Hole Operation screen.
- When programming a Mill Contour data block, select the **Previous Segment** or **Next Segment** softkeys, or use the PAGE UP (CTRL + left arrow) or PAGE DOWN (or CTRL + right arrow) keys to move between the segments within the data block. These segments describe separate portions of the contour.
- Use either the PAGE DOWN key, CTRL + right arrow, or the **Next Segment** softkey to add a new segment when positioned on the last Mill Contour screen.

- When positioned on the End of Contour, Holes End Block, or End of Program screen, use the PAGE DOWN key or CTRL + right arrow to add a new contour segment, holes operation, or data block.

See [WinMax Interface Environment](#) for more details about navigation.

Select Tool from List

Use the following steps to select a tool using the SELECT TOOL FROM LIST *F3* softkey:

1. In a program block screen, touch in the TOOL field and choose the SELECT TOOL FROM LIST *F3* softkey.
2. Locate the desired tool and select to highlight.
3. Touch the SELECT TOOL *F1* softkey, which enters the tool into the data block or segment.



If Tool Type Checking is enabled, only tools that are suitable for the programmed operation can be selected.

Temporary Parameter Change

For some programs, you may want to insert a temporary parameter change block between data blocks.

1. Display the data block for which the parameter change will first be used.
2. Select the **Insert Block Before** softkey. The New Block screen appears.
3. Select the **Miscellaneous** softkey. Choose the [Change Parameter Softkey](#).

See [Change Parameters](#) and [Change Part Setup](#) for more information.

Automatic Calculations

The WinMax AutoCalc feature enables the system to calculate certain dimensions automatically after sufficient data has been programmed. If the system is to calculate a given dimension, leave that data field blank. After sufficient data is entered, the system automatically fills in the blank data field(s).

The screen displays a **Store Calculated Value** softkey for editing a field with a calculated value (indicated by "CAL" preceding the value). Select this softkey or the ENTER key to store the displayed value into the part program. Do not re-enter the data (i.e., 8.9199 Enter); the data is truly 8.9199xxx and will be calculated as such when entered with the softkey or the ENTER key.

To let the system calculate previously entered data clear the old value by following these steps:


1. Use the arrow keys to move the cursor to the field where the automatic calculation is needed.
2. Press the BACKSPACE key. The defined value is cleared from the program and the system-calculated dimension is displayed (or the field is blank waiting for additional data to be entered).

3. In some cases, if you need the system to recalculate the field, you may need to clear other fields that were automatically calculated. This is usually the case if the system calculates erroneous data indicated by "ERR" preceding the value.

Line Segments

The software uses data in the Line Segment fields as described below to perform automatic calculations:


- If the X End and Y End coordinates are entered, the system calculates the XY length and the XY angle values.
- The XY Angle is the angle of the line segment (from the start point to the end point), measured counterclockwise from the 3 o'clock position.



Length, Angle, and End Point Relationship

- If both end points are unknown but the XY Length and XY Angle fields are programmed, the system calculates the values for the X End and Y End fields.
- If one end point coordinate and the XY Angle field are programmed, the system calculates the values for the unknown end point and the XY Length fields.
- If one end point coordinate and the XY Length field are programmed, the system calculates the values for the unknown end point and the XY Angle fields. However, unless the XY Angle is known, there are two possible solutions for the unknown end point, and the correct one must be determined for the program.

- When two possible solutions exist, the "Another end point exists" message appears and one of the two possible solutions appears in the unknown field.




1	Known Start Point
2	Solution #1
3	Solution #2
4	X Known
5	XY Length Known
6	Y Unknown
7	XY Angle Unknown

Line Segment with Unknown Y End and XY Angle

Arc Segments


The software uses data in the Arc Segment fields as described below to perform automatic calculations:

- The center points plus the start points or end points provide the arc radius.
- The start points and end points plus the radius provide the two possible center points.
- Either of the end points and the center point provide the value of the other end point and the radius.
- When a known center point, start point, or end point and radius are provided, an unknown center point is provided.



1	Start Point
2	End Point
3	Center Point

Coordinates of a Clockwise Arc



1	Known Y End and Y Center
2	Unknown X End and X Center
3	Known X Start and Y Start
4	Known Radius
5	Solution #1
6	Center Point #1
7	End Point #1
8	Solution #2
9	Center Point #2
10	End Point #2

Arc Segment with Unknown X End and X Center

Helix


The software uses data in the Helix fields as described below to perform automatic calculations:

- The Z End and Sweep Angle provide data to calculate the Lead.
- The Sweep Angle is used to calculate the Z End.
- The X End, Y End, and Lead values provide the Z End.
- The Z End and Lead values provide the X End, Y End, and Sweep Angle values.
- The X End, Y End, X Center, and Y Center values supply the Radius.
- The Sweep Angle and either the X or Y end point provide the unknown X End or Y End.

Cutter Compensation

Cutter Compensation is set in the **Milling Type** field in a milling program block.


Cutter Compensation allows you to choose on which side of the contour the tool should begin cutting. The programmed tool automatically follows the finished contour of the part when cutter compensation is selected. Without cutter compensation, the centerline of the programmed tool follows the print line.



1	Programmed path
2	Cutting tool
3	Path compensating for cutter radius
4	Cutter radius = amount of cutter compensation offset

Cutter Compensation

The following diagram shows tool paths using no cutter compensation compared to tool paths using left and right compensation. When either right or left cutter compensation is selected, the tool is offset from the cutting path a distance equal to the tool's radius. The tool begins cutting at the offset and moves in the selected direction.



Tool Paths for Cutter Compensation

The following are the types of cutter compensation used for Mill Contours such as Lines, Arcs, Blend Arcs, Helices, True-Type Lettering, and 3D Blend Arcs:

- **On**—Locates the center of the tool on the programmed contour of the frame.
- **Left**—Performs [climb milling](#).
- **Right**—Performs [conventional milling](#).
- **Profile Left** [Removes material](#) from a contour for climb milling.
- **Profile Right**—[Removes material](#) from a contour for conventional milling.

The following are the types of cutter compensation used for milling Circles, Frames, and Ellipses:

- **On**—Locates the center of the tool on the programmed contour.
- **Inside**—Causes the tool to enter the part inside the contour and blend into the programmed contour using a 180° arc. [Cutter compensation](#) is automatically employed, and the edge of the tool remains inside a programmed contour.
- **Outside**—Causes the tool to enter the part outside the programmed contour and follow the outside contour. [Cutter compensation](#) is automatically employed, and the edge of the tool remains outside the programmed contour.
- **Inside Tangent**—Causes the tool to enter the part inside and tangent to the programmed contour. [Cutter compensation](#) is automatically employed, and the edge of the tool remains inside and tangent to the programmed contour. The direction the tool travels depends upon the Milling Direction. The tool is withdrawn from the part inside and tangent to the programmed contour.

- **Outside Tangent**—Causes the tool to enter the part outside and tangent to the programmed contour. [Cutter compensation](#) is automatically employed, and the edge of the tool remains outside and tangent to the programmed contour. The direction the tool travels depends upon the Milling Direction. The tool is withdrawn from the part outside and tangent to the programmed contour.
- **Pocket Boundary**—Causes the tool to cut the part around the programmed boundary and avoid any programmed islands or pockets.
- **Pocket Island**—Defines islands within pockets on a part. As many islands as desired may be defined (subject to available memory), but all must fit within the defined boundary and must allow the tool to completely define the island. A Pocket Island cannot follow an Outward Pocket Boundary.
- **Pocket Type**—The Pocket Type field appears with Inward and Outward softkey and drop-down list box choices when Pocket Boundary or Pocket Island is chosen for Milling Type. The choices define whether spindle movement spirals from inside the pocket or outside the pocket.
 - **Outward**—Causes the tool to begin cutting operations in the center region of the pocket and cut outward to the edge of the programmed boundary. Outward is used only for Circle and Frame data blocks without islands.
 - **Inward**—Causes the tool to cut in from the outside of the defined boundary, avoiding the defined islands.

The order in which segments are programmed determines the direction the tool moves from the start point. Setting Right (conventional milling) or Left (climb milling) in the Milling Parameters overrides the direction of the programmed path.

Unless the Blend Offset is set for 0.0 in Milling Parameters, the system automatically creates [Lead In and Lead Out](#) arcs for closed contours.

Climb Milling (Left)

Climb milling is preferred method of cutter compensation, except when the fixturing is not rigid. In climb milling, the tool cuts in the same direction as the feeding motion. This is also known as "in-cut" or "down milling."

During climb milling, the spindle turns in a clockwise direction. The tool is on the left-hand side of the cut as it travels away from the operator.

The advantages of using climb milling are as follows:

- The chip starts thick and allows easy penetration into the surface of the part, causing less tool wear and less power consumption.
- The tool force cuts in and down on the part, helping to hold the part in the fixture. The more rigid the fixture, the better the hold on the part.
- Chip removal is greater, and there is less re-cutting of chips or marring of the part surface.
- The cutting fluid is more accessible to the cutting surface.

Conventional Milling (Right)

During conventional milling, the cutting teeth move in the opposite direction to the feeding motion. This is known as "out-cut" or "up milling." When using conventional milling with a clockwise spindle direction, the tool moves away from the operator on the right-hand side of the cut.

The advantages of using conventional milling are as follows:

- The chip thickness starts at zero, causing less impact on the cutting teeth. This is ideal for setups that are not very rigid.
 - The backlash in older machines is greatly diminished.
- ⇒ The programming sequence of Lines and Arcs segments determines the cutting direction. However, when programming Mill Frames, Circles and Ellipses, the cutting direction is determined by the values entered in Program Parameters.

Profile Left and Right

Profile Left removes material inside a closed contour. A mill contour with the same X-Y coordinates for both the end point and start point is called a closed contour. When climb milling a closed contour, select Profile Left. Selecting Profile Left allows Ultimac to compute the start and end points of the tool path so the tool does not cut into the last or first segments of the contour.

Profile Right removes material from outside of a programmed closed contour. When conventional milling a closed contour, select Profile Right.

⇒ All contours must be closed when using Profile Left and Profile Right. If contours are not closed, the tool moves in a direct line from the end point to the start point at the current feedrate.

Do not program the start point in a corner of a closed contour.

Cutter Compensation Lookahead

The Cutcomp Lookahead field appears when the MILLING TYPE field is set to Left, Right, Profile Left, or Profile Right. It identifies the number of segments in a contour that are checked to determine if the contour crosses itself and if the tool will fit into the contour. The default value is calculated based on the number of segments and whether the contour is opened or closed:

⇒ Whether a contour is closed or open is based on the programmed part surface and not the tool path. The contour is closed if the start segment and the last segment have the same X and Y position. If the start and last segments do not have the same X and Y position, the contour is open.

- **Open contours** - Cutcomp Lookahead value = number of segments - 3
(If the number of segments is less than 5, the value is set to 2; if the number of segments is greater than 11, the value is set to 8.)
- **Closed contours** - Cutcomp Lookahead value = number of segments - 1
(If the number of segments is less than 4, the value is set to 3; if the number of segments is greater than 9, the value is set to 8.)

To override the calculated value, type a user-defined value in the Cutcomp Lookahead field.

Select the RECALCULATE LOOKAHEAD softkey to restore the calculated Cutcomp Lookahead value.

⇒ *CAL* to the left of the data field indicates a calculated value;
USR indicates a user-defined value.


Maximum Offset

The Maximum Offset field appears when either [Profile Left](#) or [Profile Right](#) is selected. Maximum Offset is the radius of the largest inscribed circle minus the tool radius. Manually calculate the value and enter it into this field.



Drawing the part on the graphics screen is the key to determining an optimum Maximum Offset value.

If a .500" diameter (.25" radius) End Mill is used to machine the part illustrated below (a circle with a 1" radius), the value for the Maximum Offset field is 0.75".



1	Starting point for the tool
2	Largest inscribed circle in this contour
3	Radius

Determining Maximum Offset


If the tool diameter is changed (i.e., the cutter is sharpened to a smaller diameter), the Maximum Offset value must be manually re-calculated and this new value programmed into [Segment 0](#) of the Mill Contour's Start block. The Tool diameter is programmed in [Tool Setup](#) and cannot be changed in [Part Programming](#).

Lead In/Out Moves

With posted NC programs, use Lead In and Lead Out moves to control the tool path before the tool moves into position to cut the part.

A positive Lead Angle starts the tool path away from the programmed path when performing a Lead In move and ends away from the programmed path when performing a Lead Out move. A negative Lead Angle has the opposite effect.

Toolpath Graphics will not draw the Lead Angle or Lead Length motion.



A	Lead In move
B	Lead Out move
1	Programmed paths
2	Offset tool path
3	(-) Lead Angle
4	(+) Lead Angle
5	Lead Length

Lead In/Out Moves

When you select Milling Type Left, Right, Inside, or Outside, and enable the Display APT fields in Editor field on the Utilities—Post Processor screen, Lead Angle and Lead Length fields appear on the Milling data block.

Lead In/Out moves are determined by the lead angle and lead length values. With the exception of open contours, perform a 90° arc Lead In and Lead Out move.

These NC Programming fields operate similarly to Conversational Blend In/Blend Out moves (Blend Offset and Blend Overlap values).

Lead Angle

Lead Angle is used with Lead Length to define Lead In and Lead Out moves. Lead Angle is an angle relative to the direction of the cut, measured 180° from the end of the first segment.

If starting a contour in the middle of a line or arc, set the Lead Angle at 45° or 90° to prevent gouging the contour.

Use caution with Lead Angle, because the tool could gouge the part if left at the default of 0.

Lead Length

Lead Length is used with Lead Angle to define Lead In and Lead Out moves. Lead Length is the length of the Lead In move.

The Lead Length must be larger than the tool's radius. For example, using a 1" diameter End Mill, the Lead Length would be 0.505".

MILLING OPERATIONS

Creating a Milling Data Block

1. Begin a [Mill Frame](#) block by displaying the Input screen and selecting the **Part Programming** softkey or icon.
2. Select the **Insert Block Before** softkey.
3. When the New Block screen appears, select the **Milling** softkey to display the milling options shown in the seven softkey selections.
4. Select the milling operation and the first data block screen appears. Use **Frame** for this example.
5. Type in the number of the tool that will be used to mill the frame and press the ENTER key to tell the system to read and remember the information in the field.
 - The tool numbers and their descriptions were entered in the [Tool Setup](#). If the tool information has not been entered or another tool should be added to the program, select the **Tool Setup** softkey to update the tool descriptions for this program.
 - Entering a number in the Tool field pulls information from the tool setup and automatically loads it into fields on this screen. Note that the Mill Feed and Speed (RPM) fields are filled in based on the information about the tool. For additional assistance to the operator, the system also displays the selected tool's diameter and type as read-only fields.

The fields describe how and where the frame will be milled on the work piece. For a machine equipped with the UltiPocket feature, select a pocket boundary with an inward cutter motion. The Pocket Type field appears when a pocket operation is selected. Many WinMax screens have fields that appear based on selections made in other fields. These are **conditional fields** because they only appear on a screen under certain conditions.

The X and Y Corner fields define a **reference corner** from which the rectangular frame will be milled. The X and Y Length fields define the lengths of the sides of the rectangle.


The fields on the Mill Frame screen are described in detail in [Frame](#).

Mill Face

Face milling directs the cutter path so the tool moves over the rectangular face area of the part, removing material using 60% of the tool diameter from the previous pass (but the last pass may be less).

Axis positioning places the tool over the next cutting path, and cutting resumes in the opposite direction.

The starting point is either the lower left or right corner of the rectangular area, depending on the milling direction defined in [Program Parameters](#) or [Change Parameters](#).



1	Blend Offset
2	X Unidirectional
3	Y Unidirectional
4	X Bidirectional
5	Y Bidirectional

Face Milling

To access the Mill Face screen, on the New Block screen, select the **Milling** softkey then select the **Face** softkey that appears.

The Face Milling fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—Identifies the tool number for this data block and enters that tool's Diameter and Tool Type on this screen.
- **Milling Type**—Defines the type of cutting operation. There are four types of face milling:
 - **X Unidirectional**—Directs the tool to cut in one direction, parallel to the X axis, and then move the spindle to the retract clearance value. Axis movement occurs at rapid traverse to return the tool to the start point of the next cutting path, which is determined by the system. The start point for each cut is the tool radius plus blend offset away from the starting edge corner.
 - **X Bi-directional**—Directs the tool to cut in one direction from the start point, parallel to the X axis. Axis positioning occurs to place the tool over the next cutting path, and cutting resumes in the opposite direction. The new cutting path for the tool is automatically determined by the system.
 - **Y Unidirectional**—Directs the tool to cut in one direction, parallel to the Y axis, and then move the spindle to the retract clearance value. Axis movement occurs at rapid traverse to return the tool to the start point of the next cutting path, which is determined by the system. The start point for each cut is the tool radius plus blend offset away from the starting edge corner.
 - **Y Bi-directional**—Directs the tool to cut in one direction from the start point, parallel to the Y axis. Axis positioning occurs to place the tool over the next cutting path and cutting is in the opposite direction. The new cutting path for the tool is automatically determined by the system.
- **X Corner** and **Y Corner**—Identify the X and Y coordinates of any one of the four corners of the face which then becomes the reference corner.
- **X Length** and **Y Length**—Identify the X and Y length coordinates as measured from the reference corner.
 - If the reference corner is at the left side of the rectangle, the X Length is a positive (+) dimension. If the reference corner is at the right side, the X Length is negative (-).
 - The Y Length value is positive (+) if the reference corner is at the lower left or lower right of the rectangular area. It is negative (-) if the reference corner is at the top left or top right of the rectangle.
- **Z Start**—Identifies the point where spindle begins to rotate.
- **Z Bottom**—Identifies the point where the mill feed rate begins.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Defines the rate at which the tool initially enters the part.

- **Mill Feed**—Defines the X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value. See also [Feed and Speed](#).
- **Speed (RPM)**—Determines the spindle speed for the tool calculated in Tool Setup. Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Tool Diameter**—Contains the diameter entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).
- **Finish Diameter**—Contains the diameter entered during [Tool Setup](#).
- **Finish Type**—Contains the type entered during [Tool Setup](#).

Circle Data Block

Use the Circle data block to mill circles.

To create a Circle data block:

- From the Input screen, select the **Part Programming** softkey or icon.
- Select the **Insert Block Before** softkey.
- When the New Block screen appears, select the **Milling** softkey.

From the Milling softkeys, select **Circle**.

The Mill Circle fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Finish Tool**—Identifies the tool number used for finish pass and enters that tool's Tool Diameter and Tool Type on this screen. If a finish tool is selected, the first tool leaves an amount of material selected in the Finish Z field in Milling Parameters. The finish tool removes the remaining stock down to the programmed dimension.
- **Milling Type**—Identifies whether the system should automatically compensate for the diameter of the tool when determining the tool path. With the cursor on the Milling Type field, select different types of [Cutter Compensation](#) and pocket type with the softkeys and pull down menu choice.
- **Pocket Type**—Appears when Pocket Boundary or Pocket Island is chosen for Milling Type and defines whether spindle movement is from inside the pocket or outside the pocket.
- **X Center** and **Y Center**—Identify the X and Y coordinates for the center point of the circle.
- **Radius**—Defines (in conjunction with the X and Y center coordinates) the location and size of the circle.

- **Lead Length**—Identifies the [Lead Length](#) for this Mill Circle. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Inside or Outside. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **Lead Angle**—Identifies the [Lead Angle](#) for this Mill Circle. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Inside or Outside. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Z Bottom**—Identifies the point where the mill feed rate begins.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Identifies the rate at which the tool initially enters the part.
- **Mill Feed**—Identifies the X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value. See also [Feed and Speed](#).
- **Speed (RPM)**—Identifies the spindle speed for the tool calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Pocket Overlap**—Appears when Pocket Boundary Milling Type is selected. Pocket Overlap is the percentage of tool diameter that overlaps for each pass in a pocket milling operation.
 - ⇒ If you change the Pocket Overlap using this field and save the file as an HD3 file, a Change Parameters data block will be inserted into the HD3 file to make the Pocket Overlap change. The Change Parameters block changes only the Pocket Overlap, leaving all other parameters as they were.
- **Tool Diameter**—Contains the diameter entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).
- **Finish Diameter**—Contains the diameter entered during [Tool Setup](#).
- **Finish Type**—Contains the type entered during [Tool Setup](#).

Ellipse Data Block

To access the Mill Ellipse screen on the New Block screen, select the **Milling** softkey then select the **Ellipse** softkey that appears. Use this function to mill an ellipse.

The Ellipse fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen. If a finish tool is selected, the first tool leaves an amount of material selected in the Finish Z field in Milling Parameters. The finish tool removes the remaining stock down to the programmed dimension.
- **Finish Tool**—Identifies the finish tool number and enters that tool's diameter and type on this screen.
- **Milling Type**—Identifies whether the system should automatically compensate for the diameter of the tool when determining the tool path. With the cursor in the Milling Type field, select different types of [Cutter Compensation](#) and pocket type with the softkeys and pull down menu.
- **Pocket Type**—Appears when Pocket Boundary or Pocket Island is chosen for Milling Type and defines whether spindle movement is from inside the pocket or outside the pocket.
- **X Center** and **Y Center**—Identify the X and Y coordinates for the center point of the ellipse.
- **X Radius** and **Y Radius**—Identify the X and Y axes for the ellipse. Ellipse axes must be programmed parallel to the respective axes of the machine. Program an ellipse with the major and minor axes non-parallel to the machine using a [Pattern Loop Rotate](#) routine and rotating the ellipse after it has been programmed.
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Z Bottom**—Identifies the point where the mill feed rate begins.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Identifies the rate at which the tool initially enters the part.
- **Mill Feed**—Identifies the X-Y feedrate. The value initially displayed has been calculated by the system and can be retained or changed to a different value. See also [Feed and Speed](#).
- **Speed (RPM)**—Identifies the spindle speed for the tool calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).


- **Pocket Overlap**—Appears when Pocket Boundary Milling Type is selected. Pocket Overlap is the percentage of tool diameter that overlaps for each pass in a pocket milling operation.
 - ⇒ If you change the Pocket Overlap using this field and save the file as an HD3 file, a Change Parameters data block will be inserted into the HD3 file to make the Pocket Overlap change. The Change Parameters block changes only the Pocket Overlap, leaving all other parameters as they were.
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).
- **Finish Diameter**—Contains the value entered during [Tool Setup](#).
- **Finish Type**—Contains the type entered during [Tool Setup](#).

Frame Data Block

Use the Frame function to create frames to surround geometry. The Frame fields describe how and where the frame will be milled on the workpiece. To access the Mill Frame screen, on the New Block screen select the **Milling** softkey then select the **Frame** softkey that appears.

Here are the definitions for these fields:


- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Finish Tool**—Identifies the tool number used for this block's finish pass and enters that tool's diameter and type on this screen. If a finish tool is selected, the first tool leaves the amount of material selected in Milling Parameters. The finish tool removes the remaining stock down to the programmed dimension.
- **Milling Type**—Identifies whether the system should automatically compensate for the diameter of the tool when determining the tool path. With the cursor in the Milling Type field, select different types of [Cutter Compensation](#) or pocket type with the softkeys and pull-down menu.
- **Pocket Type**—Appears when Pocket Boundary or Pocket Island is chosen for Milling Type and defines whether spindle movement is from inside the pocket or outside the pocket.



1	Reference Corner
2	Cutter Entry Position

Inside Mill Frame Operation

- **X Corner** and **Y Corner**—Identify the X and Y coordinates of any one of the four corners of the frame which then becomes the reference corner.
- **X Length** and **Y Length**—Identify the X and Y coordinates for this dimension as measured from the reference corner. This value is positive or negative relative to the reference corner. If the reference corner is at the left side of the rectangle, the X or Y Length is a positive (+) dimension. If the reference corner is at the right side, this field's value is negative (-).



1	Reference Corner
2	X Length
3	Y Length

X and Y Length Directional Measurement

- **Corner Radius**—Identifies the radius of the reference corner. It is the same for all four corners.
- **Lead Length**—Identifies the [Lead Length](#) for this Mill Frame. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Inside or Outside. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.

- **Lead Angle**—Identifies the [Lead Angle](#) for this Mill Frame. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Inside or Outside. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **Z Start**—Identifies the point where the spindle begins rotating.
- **Z Bottom**—Identifies the point where the mill feed rate begins.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Identifies the rate at which the tool initially enters the part.
- **Mill Feed**—The X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value. See also [Feed and Speed](#).
- **Speed (RPM)**—The spindle speed for the tool calculated in Tool Setup. Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Pocket Overlap**—Appears when Pocket Boundary Milling Type is selected. Pocket Overlap is the percentage of tool diameter that overlaps for each pass in a pocket milling operation.
 - ⇒ If you change the Pocket Overlap using this field and save the file as an HD3 file, a Change Parameters data block will be inserted into the HD3 file to make the Pocket Overlap change. The Change Parameters block changes only the Pocket Overlap, leaving all other parameters as they were.
- **Tool Diameter**—Contains the value entered in [Tool Setup](#).
- **Tool Type**—Contains the type entered in [Tool Setup](#).
- **Finish Diameter**—Contains the value entered in [Tool Setup](#).
- **Finish Type**—Contains the type entered in [Tool Setup](#).

Finish Tool for a Mill Frame, Mill Circle or Mill Contour

When a finish tool is used in a Mill Frame data block, and its Speed (on the Tool Setup screen) and Surface Speed (on the Milling Parameters screen) values are zero (0):

1. If the finish tool is the same as the Tool specified in Part Setup, the *finish speed* and *finish feed* is calculated as a percentage of the Speed (RPM) and Feed (IPM or MPPM) values in the Part Program data block. The new values used are determined by percentages set for the Finish Speed (%) and Finish Feed (%) in the Milling Parameters screen.

For example, if the Speed (RPM) value for the data block is 2000 and the Finish Speed (%) value is 130, the *calculated finish speed* is: $2000 \times .130 = 2600$.


2. If the finish tool is different from the Tool specified in Part Setup:
 - If the finish tool is a ball end mill, face mill, or flat end mill, the Spindle speed value entered on the Tool Setup screen will be used as the finish speed.
 - If the finish tool is a ball end mill, face mill or flat end mill, and a Spindle speed value was not entered on the Tool Setup screen, Ultimax attempts to calculate the finish speed based on the tool's diameter, surface speed, number of flutes and chip load. If the calculation can not be made, the finish speed is calculated as a percentage of the Speed RPM value (same as "1" above).
3. If the finish tool is a ball end mill, face mill or flat end mill, WinMax will attempt to calculate the *finish feed* using the tool's diameter, surface speed, number of flutes and chip load. If the calculation can not be made, the finish feed is calculated by multiplying the Mill Feed and the Finish Feed (%) values on the Milling Parameters screen.



When importing an older part program into WinMax, you may need to clear the Speed (RPM) and/or Surface Speed values for the data block to run as anticipated.

Mill Triangle Data Block

The triangle pocket shape has three equal 60° angles with one open face as shown below. A relief cut can be programmed in the corner at point 1.



1	Open Face
2	Orientation = 0
3	Relief Corner
4	Radius
5	Centerpoint
6	Point 1
7	Point 2
8	Point 3

Triangle Programming Diagram

Fields in the Mill Triangle Data Block are:


- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Center**—identifies the X-axis coordinate for the center of the triangle.
- **Y Center**—identifies the Y-axis coordinate for the center of the triangle.
- **Radius**—identifies the value for the radius of the inscribed circle.
- **Orientation**—identifies the angle to rotate the pocket about the center.
- **Z Start**—identifies the point above the part where the spindle will be at speed and the plunge feed will begin.
- **Z Bottom**—identifies the point at which the mill feed rate begins. The value initially displayed has been calculated by the control and can be retained or changed to a different value.
- **Relief 1**—identifies the direction of corner relief cut and the depth past the corner of the two walls. Provides the option of a right, center, or left relief cut (or none) in the corner at point 1.

- **Tool**—identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Milling Type**—defines cutter motion using these options:
 - **Inside** - cuts just the non-open faces of the pocket, including the relief cuts.
 - **Inside 2 Passes** - cuts the same as Inside, except this selection uses a roughing pass and a finishing pass. During roughing, material is left for the finish pass.
 - **Pocket Outside In** - cuts along the faces of the insert, including the relief cuts and then steps inward and cleans out the entire insert by executing smaller versions of the shape until the center point is reached.
 - **Pocket 2 Passes Outside In** - cuts in the same manner as Pocket Outside In, except this selection uses a roughing and a finishing pass.
 - **Pocket Inside Out** - plunges tool at X-Y center of the insert and cuts outward, executing larger versions of the shape until the faces and relief cuts are milled.
 - **Pocket 2 Passes Inside Out** - cuts the same as Pocket Inside Out, except this selection uses a roughing and a finishing pass.
- **Mill Feed**—defines the X-Y feedrate.
- **Speed (RPM)**—identifies the speed at which the spindle rotates to machine the part.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—identifies the rate at which the tool initially enters the part in Z-axis. Also used when plunging down in Z between peck depth passes.

Mill Diamond Data Block

The diamond pocket shapes have four sides with opposite angles equal.


The Diamond 1 Face has one open face and the option of a right, center, or left relief cut in the corners at point 1 and point 2 as shown below:



1	Open Face
2	Orientation = 0
3	Relief Corners
4	Angle
5	Radius
6	Centerpoint
7	Point 1
8	Point 2
9	Point 3
10	Point 4

Diamond 1 Face Diagram

The Diamond 2 Faces pocket has two open faces and the option of a right, center, or left relief cut in the corner at point 1 as shown below:



1	Open Face
2	Open Face
3	Orientation = 0
4	Relief Corners
5	Angle
6	Radius
7	Centerpoint
8	Point 1
9	Point 2
10	Point 3
11	Point 4

Diamond 2 Faces Diagram


Fields are:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Center**—identifies the X-axis coordinate for the center of the triangle.
- **Y Center**—identifies the Y-axis coordinate for the center of the triangle.
- **Radius**—identifies the value for the radius of the inscribed circle of the diamond.
- **Orientation**—identifies the angle to rotate the pocket about the center.

- **Shape Angle**—identifies the angle formed by points 1 and 3 defining the shape with a range from 20° to 160°.
- **Z Start**—identifies the point above the part where the spindle will be at speed and the plunge feed will begin.
- **Z Bottom**—identifies the point at which the mill feedrate begins.
- **Relief 1**—identifies the direction of corner relief cut and the depth past the corner of the two walls. Provides the option of a right, center, or left relief cut (or none) in the corner at point 1.
- **Relief 2**—for Diamond 1 Face only, provides the option of a right, center, or left relief cut (or none) in the corner at point 2.
- **Tool**—identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Milling Type**—defines cutter motion using these options:
 - **Inside** - cuts just the non-open faces of the pocket, including the relief cuts.
 - **Inside 2 Passes** - cuts the same as Inside, except this selection uses a roughing pass and a finishing pass. During roughing, material is left for the finish pass.
 - **Pocket Outside In** - cuts along the faces of the insert, including the relief cuts and then steps inward and cleans out the entire insert by executing smaller versions of the shape until the center point is reached.
 - **Pocket 2 Passes Outside In** - cuts in the same manner as Pocket Outside In, except this selection uses a roughing and a finishing pass.
 - **Pocket Inside Out** - plunges tool at X-Y center of the insert and cuts outward, executing larger versions of the shape until the faces and relief cuts are milled.
 - **Pocket 2 Passes Inside Out** - cuts the same as Pocket Inside Out, except this selection uses a roughing and a finishing pass.
- **Mill Feed**—defines the X-Y feedrate.
- **Speed (RPM)**—identifies the speed at which the spindle rotates to machine the part.
- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—identifies the rate at which the tool initially enters the part in Z-axis. Also used when plunging down in Z between peck depth passes.

Mill Hexagon Data Block

This pocket shape has six sides and every other angle equal. In the diagram below, the shape has two open faces and the option of a relief cut in the corners at point 1, point 2, and point 3, and the option of a face relief distance between points 0 and 1 and points 3 and 4.



1	Orientation = 0
2	Radius
3	Shape Angle
4	X and Y Centerpoint
5	Tool Path
6	Relief Distance
P-0	Point 0
P-1	Point 1
P-2	Point 2
P-3	Point 3
P-4	Point 4
P-5	Point 5
R-1	Relief 1
R-2	Relief 2
R-3	Relief 3

Hexagon Diagram

Fields are:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Center**—identifies the X-axis coordinate for the center of the triangle.
- **Y Center**—identifies the Y-axis coordinate for the center of the triangle.
- **Radius**—identifies the value for the radius of the inscribed circle.
- **Orientation**—identifies the angle to rotate the pocket about the center.
- **Shape Angle**—identifies the angle formed by points 1 and 3 defining the shape with a range from 20° to 160°.
- **Z Start**—identifies the point above the part where the spindle will be at speed and the plunge feed will begin.
- **Z Bottom**—identifies the point at which the mill feedrate begins.
- **Relief 1**—identifies the direction of corner relief cut and the depth past the corner of the two walls. Provides the option of a right, center, or left relief cut (or none) in the corner at point 1, or face relief distance between points 0 and 1.
- **Relief 2**—provides the option of a right, center, or left relief cut (or none) in the corner at point 2.
- **Relief 3**—provides the option of a right, center, or left relief cut (or none) in the corner at point 3 or the option of a face relief distance between points 3 and 4.
- **Tool**—identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Milling Type**—defines cutter motion using these options:
 - **Inside** - cuts just the non-open faces of the pocket, including the relief cuts.
 - **Inside 2 Passes** - cuts the same as Inside, except this selection uses a roughing pass and a finishing pass. During roughing, material is left for the finish pass.
 - **Pocket Outside In** - cuts along the faces of the insert, including the relief cuts and then steps inward and cleans out the entire insert by executing smaller versions of the shape until the center point is reached.
 - **Pocket 2 Passes Outside In** - cuts in the same manner as Pocket Outside In, except this selection uses a roughing and a finishing pass.
 - **Pocket Inside Out** - plunges tool at X-Y center of the insert and cuts outward, executing larger versions of the shape until the faces and relief cuts are milled.
 - **Pocket 2 Passes Inside Out** - cuts the same as Pocket Inside Out, except this selection uses a roughing and a finishing pass.
- **Mill Feed**—defines the X-Y feedrate.
- **Speed (RPM)**—identifies the speed at which the spindle rotates to machine the part.

- **Peck Depth**—Defines the maximum depth to be cut in one pass. If the total depth is greater than this value, multiple cutting passes occur. Entering a zero (0) value causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—identifies the rate at which the tool initially enters the part in Z-axis. Also used when plunging down in Z between peck depth passes.

Lettering Data Block

Use Lettering blocks to mill up to 30 block characters of lettering.

Type characters into the appropriate field using the keyboard.

Lettering data blocks may be rotated, mirror-imaged for mold use, or repeated using a patterns block.

[Cutter Compensation](#) is not available for HD3 Lettering. Milling is performed using the centerline of the tool.

These are the Lettering options:

- [HD3 Lettering](#)
- [Mill True-Type Lettering](#)

HD3 Lettering

The HD3 Lettering function mills block lettering into a part. The fields are defined as follows:

- **Block**—identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **X Start** and **Y Start**—Determine the X and Y coordinates for the lower left-hand corner of the first character to be milled.
- **Character Height**—Determines the height of the character set.
- **Character Width**—Determines the character size. The width includes the character left-justified, plus some spacing between it and the next character to be milled. Spacing between the characters is equal to the tool's diameter.


Because cutter compensation is not used in this routine and letter contouring follows the center of the tool, character spacing can be adjusted by adjusting the tool diameter in [Tool Setup](#).

- **Text**—Contains characters to be milled into the part. This field will support up to 30 block characters.
- **Z Start**—Identifies the point at which the plunge feed rate begins.
- **Z Bottom**—Identifies the point at which the mill feed rate begins. The value initially displayed has been calculated by the control and can be retained or changed to a different value.
- **Peck Depth**—Defines the maximum depth to be cut in one pass of the tool. If the total depth is greater than this value, multiple tool passes occur. Entering the value zero (0) causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Defines the rate at which the tool initially enters the part.
- **Mill Feed**—Defines the X-Y feedrate. See also [Feed and Speed](#).
- **Speed (RPM)**—Identifies the spindle speed for the tool calculated in Tool Setup. Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Tool Diameter**—Contains the diameter entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).

Mill True-Type Lettering

Mill True-Type Lettering fields are:

- **Y MAPPING**—specifies the Y (height) dimension of the lettering:
 - **Body Only**—defines the height of the body of the lettering. Ascenders and descenders are calculated automatically.
 - **Descended**—defines the height of the body and descenders of the lettering. Ascenders are calculated automatically.
 - **Ascended**—defines the height of the body and ascenders of the lettering. Descenders are calculated automatically.
 - **Full Font**—defines the height of the body, ascenders, and descenders of the lettering. No part of the lettering is calculated automatically.



1	Body only
2	Descended
3	Ascended
4	Full font

Y Mapping

- **X BASE**—X axis bottom left coordinate of the Sizing Box
- **Y BASE**—Y axis bottom left coordinate of the Sizing Box
- **X LENGTH**—X axis length of the Sizing Box
- **Y LENGTH**—Y axis length of the Sizing Box
- **ORIENTATION**—the angle about the Z axis to which the text should be rotated. The center of rotation is located at XY BASE.
- **TEXT**—the text to be milled
- **Z START**—the Z coordinate at which plunge feedrate begins
- **Z BOTTOM**—Z Bottom coordinate
- **CONTOUR COUNT**—the number of letters and spaces
- **FONT**—the lettering font. The font selection dialog box is opened with the **SELECT NEW FONT F3** softkey, when the cursor is in the TEXT field.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Peck Depth**—Defines the maximum depth to be cut in one pass of the tool. If the total depth is greater than this value, multiple tool passes occur. Entering the value zero (0) causes the total programmed depth to be cut in one pass of the tool.
- **Plunge Feed**—Defines the rate at which the tool initially enters the part.
- **Mill Feed**—The X-Y feedrate. See also [Feed and Speed](#).
- **Speed (RPM)**—Defines the spindle speed for the tool calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Pocket Overlap**—Appears when Pocket Boundary Milling Type is selected. Pocket Overlap is the percentage of tool diameter that overlaps for each pass in a pocket milling operation.

Swept Surface

The Swept Surface option in WinMax allows you to program draft angles for pocket or island walls with greater flexibility, including Spiral, Constant Z level, and Cusp Height cutting strategies.

Swept Surface builds on Ultimax's 3D Mold option. The basic elements in Swept Surface programming are:

- Draw Profile Contour—build the XZ or YZ shape of the part
- Draw Along Contour—build the shape of the contour
- Swept Surface—provide details of how to cut the part

To begin a new Swept Surface program block, perform the following steps:

1. From a New Block screen, select the MILLING *F3* softkey.
2. Select the More *F7* softkey.
3. Select the SWEPT SURFACE *F4* softkey.
4. Use the drop-down list to select the type of contour in the TYPE field: Draw Profile, Draw Along, or Swept Surface.

⇒ A Swept Surface program block must contain all three types of contours: Draw Profile, Draw Along, and Swept Surface.

5. To program Draw Profile Contours or Draw Along Contours, place the cursor in the TYPE field, and select the EDIT ALONG CONTOUR *F6* or the EDIT PROFILE CONTOUR *F7* softkey.

Draw Profile Contour

Set the TYPE field to DRAW PROFILE(S) and select the EDIT PROFILE CONTOUR *F7* softkey. Segment types are:

- Line
- Arc
- Blend Arc
- Helix
- 3D Arc

⇒ The Draw Profile Contour screen is displayed as Swept Surface (Profile Contour).

Draw Along Contour

Set the TYPE field to DRAW ALONG and select the EDIT ALONG CONTOUR *F6* softkey. Segment types are:

- Line
- Arc
- Blend Arc
- Helix
- 3D Arc

⇒ The Draw Along Contour screen is displayed as Swept Surface (Along Contour).


Swept Surface

Swept Surface parameters establish the machining characteristics. Fields are:

- **TYPE**—specifies the type of contour:
 - **DRAW PROFILE(S)**—program the XZ or YZ part dimensions.
 - **DRAW ALONG**—program the XY contour that the XZ or YZ profile follows.
 - **SWEPT SURFACE**—program the details of the Swept Surface.
- **TYPE OF CORNERS**—the type of corner (rounded, extended, or truncated) to insert when there is a change of direction in the Draw Along contour.
- **INDIVIDUAL PROFILES**—allows different profile contours to be used for individual segments of the Draw Along contour.
- **ROLL START POINT**—when YES, sweeps the profile down to the horizontal plane at the start point.
- **ROLL END POINT**—when YES, sweeps the profile down to the horizontal plane at the end point.
- **Z START**—the Z coordinate at which plunge feedrate begins.
- **STEP CONNECT TYPE**—the type of segment (arc or line) to connect passes of normal cut direction .
- **USE CUSP HEIGHT**—when YES, step over is calculated from the specified cusp height.
- **MIN CUSP OVERLAP (%)**—minimum cutter overlap used for cusp height (percent of cutter diameter); USE CUSP HEIGHT field must be set to YES.
- **POCKET FIRST**—select YES if pocketing should be done before milling the swept surface.

Tabs at the bottom of the screen contain fields for Roughing, Finishing, Pocket, Pocket Finishing, and SFQ:


- **TOOL**—specifies the tools to be used for roughing, finishing, pocketing; select from list or enter a number.
- **CUT DIRECTION**—controls the tool path while the part is machined. There are three choices for the CUT DIRECTION field:
 - **With Contour** - machines the contour using the profile contour originally programmed.
 - **Normal** - tool path follows the part at right angles to the profile contour.
 - **Spiral** - machines a continuous tool path resulting in a smoother surface.
- **BIDIRECTIONAL**—specifies the direction of the tool path while the part is being machined. There are two choices for the BIDIRECTIONAL field:
 - **Yes** - causes the tool to machine in both directions without retracting the tool until the entire contour is complete.
 - **No** - causes the tool to machine in one direction, based on the direction of the contour definition, while retracting between each pass.



1	Yes
2	No

Bidirectional Field

- **MILL FEED**—defines the X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value.
- **SPEED (RPM)**—spindle speed for the tool, calculated in Tool Setup. Entering a value here overrides the Tool Setup value for this data block.
- **STOCK ALLOWANCE**—leaves or removes extra material on the surface of the part. Stock Allowance can be used for roughing, undersizing, or oversizing a surface. A Ball-Nosed End Mill must be used to maintain a uniform stock allowance dimension over the complete surface. A positive stock allowance value programmed using a Flat End Mill leaves sufficient material for a finishing pass.




1	Print Dimension
2	+ Stock Allowance
3	- Stock Allowance

Stock Allowance



When machining harder materials, progressively smaller stock allowances can be used in a series of finishing blocks to optimize cutting efficiency.


- **MIN Z**—limits the negative Z motion to the Centerline Z value when set to Yes.
- **STEP SIZE**—the distance on the surface between cutter passes. Ultimately, this dimension determines the surface finish of the part. A larger step size machines faster but leaves a rougher surface. A smaller step size machines more slowly but leaves a smoother surface. Step size significantly affects the drawing speed of the graphics screen.



1	Step Size
---	-----------

Step Size Example

- **PECK DEPTH**—specifies the distance the tool will drill down into the part before stopping to clear out or break the chips. If used, this parameter is not usually larger than the diameter of the tool.



A	Z Start
---	---------

Peck Depth Example

- **PLUNGE FEED**—Z feedrate for plunge in inches per minute.
- **Z ROUGHING**—specifies if the Z roughing strategy be applied to the roughing pass.
- **MILLING TYPE**—specifies the pocket milling type: None, Island, Pocket, Island & Pocket.
- **POCKET TYPE**—specifies the pocketing type: inward or outward.
- **POCKET OVERLAP (%)**—specifies cutter overlap as a percent of cutter diameter.
- **ROUGH SFQ**—specifies Surface Finish Quality for roughing.
- **FINISH SFQ**—specifies Surface Finish Quality for finishing.
- **POCKET ROUGH SFQ**—specifies Surface Finish Quality for pocket roughing.
- **POCKET FINISH SFQ**—specifies Surface Finish Quality for pocket finishing.

Lines/Arcs Data Blocks

Use [segments](#) and [cutter compensation](#) to program lines and arcs which create a [Mill Contour](#). The [Contour End](#) block marks the end of the programmed contour. These are the types of segments used to create a Mill Contour:

- [Contour Line](#)
- [Contour Arc](#)
- [Contour Blend Arc](#)
- [Helix](#)
- [3D Arc](#)

Select these segments from the Mill Contour screen by moving the cursor to the Segment field and selecting the **Insert Segment Before** softkey or pressing the PAGE DOWN key. The **Line**, **Arc**, **Blend Arc**, **Helix**, and **3D Arc** softkeys appear.

Mill Contour

A series of line and arc segments can be programmed in a single data block to form a complete contour.

The Mill Contour fields are defined as follows:

- **Block**—Identifies the block number for this Mill Contour data block. The system determines the number by the data block's position in the program.
- **Segment**—Identifies the [Segments](#) number within the Mill Contour operation.
- **Tool**—Identifies the number of the tool used to cut the segments in this contour.
- **Finish Tool**—Identifies the tool number used for the finish pass. If a finish tool is selected, the first tool leaves the amount of material selected in the Finish Z field in Milling Parameters. The finish tool removes the remaining stock down to the programmed dimension.
- **Milling Type**—Identifies whether the system should automatically compensate for the diameter of the tool when determining tool path. With the cursor in the Milling Type field, select different types of [Cutter Compensation](#) or pocket type with the softkeys or drop-down list box.
- **Pocket Type**—Appears with **Inward** and **Outward** softkey and drop-down list box choices when Pocket Boundary or Pocket Island is chosen for Milling Type. The choices define whether spindle movement spirals from inside the pocket or outside the pocket.
- **Enable Blend Moves**—Appears when either [Left](#) or [Right](#) is selected in the Milling Types field. When this field is set to Yes, the Lead Length and Lead Angle fields will be used for Post Processing Part Programs if the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **X Start** and **Y Start**—Identify the X and Y starting point coordinates of the first segment.

- **Maximum Offset**—Appears when either [Profile Left](#) or [Profile Right](#) Milling Type is selected. The value is the distance between the programmed contour and the tool center during the first pass. The number entered here must be manually calculated. Refer to [Maximum Offset](#) for details.
- **Pocket Overlap**—Appears when Pocket Boundary Milling Type is selected. Pocket Overlap is the percentage of tool diameter that overlaps for each pass in a pocket milling operation.
 - ⇒ If you change the Pocket Overlap using this field and save the file as an HD3 file, a Change Parameters data block will be inserted into the HD3 file to make the Pocket Overlap change. The Change Parameters block changes only the Pocket Overlap, leaving all other parameters as they were.
- **Lead Length**—Identifies the [Lead Length](#) for this Mill Contour. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Left or Right. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **Lead Angle**—Identifies the [Lead Angle](#) for this Mill Contour. See [Lead In/Out Moves](#). This field only appears for NC posted programs. This field is only available when Milling Type is set to Left or Right. Lead In/Out Moves will be ignored in the post unless Enable Blend Moves is set to Yes and the Display Apt Fields in Editor field on the Post Processor Configuration screen is set to Yes.
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type of tool entered during [Tool Setup](#).
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Z Bottom**—Identifies the point where the mill feed rate begins.
- **Peck Depth**—Determines the distance the tool will drill down into the part before stopping to clear out or break the chips. If used, this parameter is usually not larger than the diameter of the tool.
- **Plunge Feed**—Determines the rate at which the tool initially enters the part.
- **Mill Feed**—Identifies the X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value. See also [Feed and Speed](#).
- **Speed (RPM)**—Determines the spindle speed for the tool calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Reverse Mirrored**—Appears if the contour block will be cut with a mirror pattern, and the MILLING TYPE field is not set to Pocket boundary or Pocket Island. If this field value is No, the contour will always be milled from the contour start block to the contour end block, and helixes can not be cut in the reverse direction. If the field value is Yes in the original contour, the cutting direction is determined by whether the contour is mirrored. The default value is Yes.

- **Finish Diameter**—Contains the tool diameter entered for the Finish Tool during [Tool Setup](#).
- **Finish Type**—Contains the tool type entered for the Finish Tool during [Tool Setup](#).

Contour Line

For line segments, the [Auto-Calc feature](#) can automatically calculate certain unknown dimensions after you enter sufficient data.

Line segment fields are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number within the Mill Contour operation. The system determines the number by the position of this segment in the contour.
- **X End, Y End, and Z End**—Identify the X, Y, and Z End coordinates. Refer to [Automatic Calculations](#) to see how entering data affects this field.
- **XY Length**—Identifies the XY length. Refer to [Automatic Calculations](#) to see how entering data affects this field.
- **XY Angle**—Identifies the XY Angle or the angle of the line segment (from the start point to the end point), measured counterclockwise from the 3 o'clock position. Refer to [Automatic Calculations](#) to see how entering data affects this field.
- **Feed**—Identifies the feedrate the control will try to achieve while milling this segment. This value is carried forward from the Mill Contour screen's [Mill Feed](#) field. See also [Feed and Speed](#).
- **X Start, Y Start, and Z Start**—Identify the X, Y, and Z starting points. The Start fields are carried forward from the previous segment's end points.

Contour Arc

For arc segments, the Auto-Calc feature can automatically calculate certain unknown dimensions after you enter sufficient data.


The Arc fields are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number within the Mill Contour operation. The system determines the number by the position of this segment in the contour.
- **Direction**—Determines the direction of the arc from the start point (clockwise or counter-clockwise).

- **X End, Y End, and Z End**—Identify data coordinates (values for X End, Y End, and Z End) used in the [Automatic Calculations](#).
- **X Center, Y Center, and Z Center**—Identify data coordinates (values for X Center, Y Center, and Z Center) used in the [Automatic Calculations](#).
- **Radius**—Identifies the radius (used in the [Automatic Calculations](#)).
- **Feed**—Identifies the rate at which the tool initially enters the part. This value is carried forward from the Mill Contour screen's [Mill Feed](#) field. See also [Feed and Speed](#).
- **X Start, Y Start, and Z Start**—Define the X, Y, and Z starting points of this segment. The Start fields are carried forward from the previous segment's end points.

Contour Blend Arc

A blend arc is an arc that joins two other segments and is tangent to both. Use a blend arc to join two line segments, to join a line segment and an arc segment, or to join two arc segments. The segments to be joined must have a theoretical point of intersection.



Two Lines Joined by a Blend Arc

1 X/Y Start


2 X/Y End

3 Segment 1 (Line)

4 Segment 1 End/Segment 3 Start (Point of Intersection)

5 Segment 2 (Blend Arc)

6 Segment 3 (Line)



Line and Arc Joined by a Blend Arc

1 X/Y Start


2 X/Y End

3 Segment 1 (Line)

4 Segment 1 End/Segment 3 Start (Point of Intersection)

5 Segment 2 (Blend Arc)

6 Segment 3 (Arc)



Two Arcs Joined by a Blend Arc

1 X/Y Start

2 X/Y End

3 Segment 1 (Arc)

4 Segment 1 End/Segment 3 Start (Point of Intersection)

5 Segment 2 (Blend Arc)

6 Segment 3 (Arc)

Blend Arc Examples

If the only information known about an arc is its radius, it is easier to program it as a blend arc if the segments intersect.

The Contour Blend Arc fields are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number within the Mill Contour operation. The system determines the number by the position of this segment in the contour.
- **Radius**—Identifies the radius of the arc.
- **Feed**—Identifies the feed value carried forward from the Mill Contour screen's [Mill Feed](#) field. See also [Feed and Speed](#).
- **Direction**—The direction of the arc from the start point (clockwise or counterclockwise).
- **X Start** and **Y Start**—The X Start and Y Start coordinates of the first segment.
- **X End** and **Y End**—The X End and Y End coordinates.
- **X Center** and **Y Center**—The X and Y coordinates used to define the circular path of the blend arc.

Reference values programmed in a previous segment to a blend arc define the start point of this segment and are displayed in parentheses. These values can only be changed in the segment in which they were created.

Some guidelines that must be followed when creating a blend arc:

- The first or last segment of a Mill Contour data block cannot be blend arc segments.
- Blend arc segments cannot be adjacent to one another in a program cannot be blend arc segments. For example, if segment #2 is a blend arc, neither segment #1 nor #3 can be blend arc segments.
- Segments that are adjacent to the blend arc segment must intersect at some point in their theoretical plane. Therefore, if segment #2 is a blend arc, segments #1 and #3 must theoretically intersect at some projected point.
- The Radius of a blend arc segment cannot be too large to be tangent to both of the adjoining segments.
- If any coordinate (start point, center point, or end point) is important to the construction of the two segments to be blended, the segment must be programmed as an arc and not as a blend arc.
- The Feed field is initially displayed with a value carried forward from the previous segment. This value can be accepted or changed.



A series of arcs and lines can be programmed in a single data block to form a complete contour. Press the right Arrow key to program additional Line and Arc segments for the current data block.

Helix

For Helix data blocks, the Auto-Calc feature can automatically calculate certain unknown dimensions after you enter sufficient data.

The Helix fields are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number within the Mill Contour operation. The system determines the number by the position of this segment in the contour.
- **Direction**—Defines the direction of a helix from the starting point. There are two softkey choices when the cursor is on the Direction field.
 - **CW** - the helix will be cut in a clockwise direction.
 - **CCW** - the helix will be cut in a counterclockwise direction.
- **X End, Y End, and Z End**—Identify the X, Y, and Z coordinates for the end point of the helix segment. Refer to [Automatic Calculations](#) to see how entering data affects this field.
- **X Center and Y Center**—Identify the X and Y coordinate for the center point around which the helical pattern is drawn. Refer to [Automatic Calculations](#) to see how entering data affects this field.
- **Radius**—Defines the length of the dimension from the center point of the helical pattern to its outer edge.
- **Lead**—Defines the change in the Z axis dimension for each 360° of revolution of the helix. This value provides information for the calculation of the X End, Y End, Z End, and Sweep Angle fields.
- **Sweep Angle**—Defines the total number of degrees in the helical arc to be cut. This number can be greater than 360. This value provides information for the calculation of the Z End field and the Lead fields.
- **Feed**—Identifies the rate from the Mill Contour screen's [Mill Feed](#) field. See also [Feed and Speed](#).
- **X Start, Y Start, and Z Start**—Define the X, Y, and Z starting points of this segment. The Start fields are carried forward from the previous segment's end points.

3D Arc


Use 3D Arc to create a three-dimensional arc segment.

- ⇒ Do not confuse the 3-D feature with the 3-D Part Programming Option. The 3-D Arc feature is always included in the WinMax software. Refer to the *3-D Part Programming Option Manual* for more information on this option.

The following fields define a 3-D Arc:

- **X, Y, and Z End**—define the end point for the arc segment. These fields are required when defining a 3-D Arc.
- **X, Y, and Z Center**—define the center point for the arc segment. These fields are required when defining a 3-D Arc.
- **X, Y, and Z Point**—define the plane of the arc when it is 180° or greater.
- **Feed**—rate from the previous segment. This value can be accepted or changed.

This diagram shows the relationships of the coordinates to each other:



1	Start Point
2	Center Point
3	X, Y, Z Point
4	End Point

180° 3D Arc

To calculate the centerline of cutter movement, remember these points. Refer to [Cutter Compensation](#) for information about cutter compensation.

- Depending on the axis being worked, X can be interchanged with Y or Z.
- The X and Z points must be calculated for an X-Z arc.
- The Y and Z points must be calculated for a Y-Z arc (all arcs travel through at least two axes).
- To calculate the centerline in the X axis for a ball-nosed end mill, use this formula:

$$X_a = \frac{R_i}{R}(X_s - X_c) + X_c$$

Here are the elements of this formula:

X_a = Actual centerline dimension of cutter in X axis

X_s = Arc reference starting point in the X axis

X_c = X center point

R_i = Radius of arc minus ½ cutter diameter

R = Radius of arc



Follow these *guidelines* when programming 3-D arcs:

- Never program cut right or cut left cutter compensation into a 3-D arc block.
- Always program the centerline of cutter movement.
- Lower the tool calibration point to one-half the cutter diameter by manually changing the Tool Zero reference point.

For example, when using a 1/4" ball-nosed end mill with Tool Zero of 2.2500" (ball tip touched to work surface), the new zero calibration is 2.3750". Remember this change when entering Z Up and Z Start dimensions (which must include the value of this manual change to the reference point).

Contour End

This block marks the end of the programmed contour. To view the previous segment, select the **Previous Segment** softkey. If there are no existing segments, select the **Insert Segment Before** softkey or the PAGE DOWN key to create a new segment.

The Contour End fields are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number within the Mill Contour operation. The system determines the number by the position of this segment in the contour.

The Contour End screen is shared by Lines and Arcs, Rotary Lines and Arcs, and 3D Mold.

HOLES OPERATIONS

Holes Data Block

1. Begin a Holes Data Block by displaying the Input screen and selecting the **Part Programming** softkey or icon.
 2. Select the **Insert Block Before** softkey.
 3. Select the **Holes** softkey. The Hole Operation softkey choices appear.
 4. Select the appropriate softkey for the type of operation
 5. Select the tool for the first operation in the data block.
 - The structure of a hole drilling data block is more complex than other conversational data blocks. To describe a hole drilling process in a data block, enter different types of instructions.
 - Each type of drilling instruction requires creating a separate operation within the data block.
 6. Program the operation.
 7. After completing an operation, place the cursor in the Operation field and the following softkeys are available:
 - **Next Hole Operation** - places a new Holes operation into the data block after the operation currently displayed on the screen.
 - **Delete Operation** - removes the currently displayed operation from the holes data block
 - **Insert Operation Before** - places another operation into the data block before the operation currently displayed on the screen.
- ⇒ That when the cursor is at the Peck Type field, the softkeys change to Standard and Chip Breaker. When this program is run on the control, the drill pulls out to the Z Start after reaching the Peck Depth for Standard Peck type and dwells at the Peck Depth for Chip Breaker peck type.

The New Hole Operation menu includes Bolt Circle and Locations softkeys. Select the **Locations** softkey, and the system displays columns for entering the X and Y coordinates of each location.

When the description of a drilling operation is complete, these softkeys are available:

- **Delete Location** - remove the location coordinates of the hole location currently marked with the cursor.
 - **Insert Location Before** - place another pair of location coordinates before the location currently marked with the cursor.
- ⇒ Choose the Drill softkey if you want to pick a true center drill. Center Drill is just for "Spot" operations.

Drill Overview

See also:

[Drill](#)

[Center Drill](#)

[Counterbore](#)


[Countersink](#)

[Spotface](#)

[Gun Drill](#)

Drill Operations drill different types of holes. The Drill Operation types are Drill, Center Drill, Counterbore, Spotface, Countersink, and Gun Drill. The fields do not differ with the types of operation, except Gun Drill.

The diagram below shows the relationships of the field names to positions of the tool to the work piece:



1	Head
2	Part
3	Table
4	Z Start Plane
5	Rapid Traverse
6	Retract Clearance Plane
7	Plunge Feed
8	Z Bottom

Reference Points Relative to Drill Operations

Be aware of the drill bits' characteristics. The system does not keep track of the type and length of flutes on the bits or the shapes of drills with pilots or other multiple-diameter drills.

This motion occurs in a drilling operation:

1. The table moves at the rapid traverse rate to the programmed X and Y dimensions.
2. The Z axis moves at the rapid traverse rate to the programmed retract clearance.
3. When these coordinates are reached, the Z axis moves at the rapid traverse rate to Z Start.
4. Then the Z axis moves at the programmed plunge feed rate until reaching the Z Bottom dimension.
5. The Z axis dwells the time specified and rapid traverses to the retract clearance.

The rapid traverse rate, retract clearance, and drill dwell are selected in [Program Parameters](#) or [Change Parameters \(Holes\)](#).

When all values are programmed, the [Bolt Circle](#) and [Locations](#) softkeys are available.

- **Delete Operation**—Clears this programmed Drill operation.
- **Insert Operation Before**—Adds another Hole operation before the current one.
- **Exit**—Returns to the previous screen level.

Additional operations for this block can be programmed, such as another Drill Operation (i.e., a Center Drill, Counterbore, or Spotface), a Tap Operation, Bore and Ream Operations, Bolt Circle Pattern, or Hole Locations.

Drill or Bore and Ream Operations

Select the **Drill Operations** softkey on the New Hole Operation screen to select the type of drilling operation. The appropriate screen appears with fields describing the operation.

Select the [Bore and Ream Operations](#) softkey on the New Hole Operation screen to select the type of boring and reaming operation. The appropriate screen appears with fields describing the operation.

- **Block**—Identifies the block number for this operation.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Hole Operation Type** (not labeled) - allows you to select a different hole operation type from the drop-down list. You may also use the softkeys to select another hole operation type. Select the **More** → softkey to access more tool type softkeys.

Drill Operations drill different types of holes. The Drill Operation types are [Drill](#), [Center Drill](#), [Counterbore](#), [Spotface](#), [Countersink](#), and [Gun Drill](#). The fields do not differ with the types of operation, except Gun Drill.

- **Tool**—Identifies the tool number for this data block.
- **Z Start**—Identifies the point where the spindle begins to rotate. The Z Start field is the dimension where the Z axis plunge feed rate begins.

- **Z Bottom**—Identifies the bottom of the finished hole.
- **Plunge Feed** —Identifies the rate at which the tool initially enters the part. The Z Start parameter is the dimension where the Z axis plunge feed rate begins. The Z Bottom parameter is the point of maximum Z-down and the dimension where the plunge feed rate ends.
- **Speed (RPM)**—Identifies the speed at which the spindle rotates to drill the hole, calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Peck Depth**—Used only with Drill. The distance the tool drills down into the part before stopping to clear out or break the chips. If used, this parameter is usually not larger than the tool's diameter. If a specific number of pecks is desired, the value for Peck Depth can be calculated by determining the absolute distance between Z Start and Z Bottom and dividing that value by the desired number of pecks. For example: a distance of 1.0000 inch between Z Start and Z Bottom divided by a peck depth of 0.2500 inch requires four (4) pecks to drill the hole.
- **Peck Type**—Used only with Drill. Two softkey choices appear: Standard and Chip Breaker.
 - **Standard** - the tool retracts to the Z Start and then plunges to the peck clearance plane selected in [Program Parameters](#) or [Change Parameters](#).
 - **Chip Breaker** - the tool dwells at each peck level before continuing to feed to the next peck level. (Dwell time is the time selected in [Program Parameters](#) or [Change Parameters \(Holes\)](#).)
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).


Counterbore

Use Counterbore to enlarge the end of a previously drilled hole. This operation creates an enlarged area at the end of the hole to accommodate a bolt, cap screw, or pin. These square-shoulder fasteners can then be inserted flush with the top of the part or slightly below the surface of the material.

To avoid unneeded tool changes, use Counterbore before drilling the hole.

Countersink

Countersink enlarges the top end of a hole to a cone shape to accommodate the head of a flat or oval headed machine screw. The hole is enlarged so that when the screw is inserted, the screw head will be flush with or slightly below the top of the work piece surface.



Countersunk screw head

Drill

Use a drill to create holes that may be complete or may be used as the starting points for additional drilling operations.

Center Drill

Select Center Drill when the work piece is very rigid to create a guide hole for the drilling tool that will be used to complete the hole. Center drilling helps keep holes in their proper locations and prevent runout.

Center drills are special tools with short flutes, but a standard drilling tool may be used to create these starting holes.

Spotface


Spotface smooths and squares the surface around a previously drilled hole to provide a seat for a bolt head, a nut, or the shoulders on mating members. The spotfacing operation is a shallow counterboring operation. Spotfacing is often used when the surface of the part is uneven.

To avoid unnecessary tool changes, Spotface can be used before drilling the hole.

Gun Drill

Select the Gun Drill feature when using a very long tool and drilling deep holes, as if drilling out the center of a gun barrel. A long, rotating tool may whip off center when approaching the cutting surface, so a drilling cycle that controls the approach to the work piece and corrects positioning of the tool is required.

The Gun Drill selection positions the tool without rotating the spindle. This allows the tip of the tool to position precisely in a pre-drilled starting hole, as shown in the diagram below.



1	Work Piect
2	Planned Path
3	Pre-drilled Starting Hole
4	Long tool moves into position with the spindle off to avoid whipping

Gun Drilling

To use the Gun Drill features, perform these tasks:


- Describe the gun drill tool during Tool Setup.
- Create a starting hole for the drill as the first step in part programming.
- Create a Gun Drill data block in the part program.

Each Gun Drill data block must contain at least two operations: one describing the starting hole and one for the gun drill hole.

To create a Gun Drill data block, begin on a New data block screen and follow these general steps:

1. Press the Drill Operations softkey.
2. Create the first operation of the data block by describing the starting hole portion of the data block. Select either the Drill softkey or the Center Drill softkey. Type in the description of the starting hole into the fields displayed on the screen.
3. When all of the starting hole data have been entered, begin the second operation in this data block.
4. Press the Drill Operations softkey and then the Gun Drill softkey.

The following illustration shows the Gun Drill program fields as they relate to a part and the drilling tool:



1	Work Piect
2	Move at Repid Traverse Feedrate down to Z Top
3	Z Top
4	Z Top Feed—feedrate between Z Top and Z Start
5	Z Start—spindle begins to rotate at Speed (RPM)
6	Z Bottom

Gun Drill Positions

The Gun Drill fields are defined as follows:

- **Block**—Identifies the block number for this operation.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Tool**—Identifies the tool number for this data block and enters that tool's Diameter and Tool Type on this screen.
- **Z Top**—Identifies the starting point of the gun drill cycle. The tool moves rapidly to this point and then slowly moves into the pre-drilled starting hole.
- **Z Start**—Identifies the position inside the pre-drilled hole where the spindle begins to rotate.
- **Z Bottom**—Identifies the bottom of the finished hole.
- **Z Top Feed**—Identifies the rate at which the tool moves from the Z Top position to the Z Start position.
- **Plunge Feed**—Identifies the feedrate between the Z Start and the Z Bottom positions.
- **Speed (RPM)**—Defines the speed at which the spindle rotates to drill the hole. See also [Feed and Speed](#).
- **Spindle Stop**—Identifies the point at which the spindle stops rotating after drilling the hole. This field may be set to be the Z Bottom or the Z Start position.
- **Peck Depth**—Identifies the distance the tool drills down into the part before stopping to clear out or break the chips. If this field is used, it is usually not larger than the tool's diameter.
- **Peck Type**—Select whether the drill pulls out to the Z Start position after reaching Peck Depth (Standard) or whether the drill dwells at the Peck Depth (Chip Breaker).
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).

Tap Operations

Select the **Tap Operations** softkey on the New Hole Operation screen.

Tap and **Rigid Tap** softkeys appear.

- **Tap** - programs a standard tapping sequence.
- **Rigid Tap** - programs a tapping sequence in which the same hole is tapped repeatedly with precision.


The Tap/Rigid Tap fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Z Bottom**—Identifies the bottom of the hole.
- **Speed**—Identifies the spindle speed for the tool, calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Peck Depth**—Identifies the distance the tool will drill down into the part before stopping to clear out or break the chips. The Peck Depth is usually smaller than the tool's diameter. Peck Depth is used with Rigid Tap.
- **Dwell**—Time Determines the pause in seconds before the tool retracts at the bottom of a drill operation. Dwell Time is used with Rigid Tap.
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).
- **Pitch**—Shows the distance between threads. Defined in Tool Setup for Tap tool types, this value is calculated automatically, based on values entered in [Tool Setup](#).
- **Plunge Feed**—Identifies the rate at which the tool enters the part. This value is calculated automatically, based on values entered in [Tool Setup](#).

Bore and Ream Operations

The Bore and Ream Operation types are Bore, Ream, Bore Rapid, Bore Orient, and Ream Rapid. Motion varies according to the Bore and Ream operation type.


Use a bore when a straight and accurately round hole is needed. A boring bar usually has one or, at the most, two blades projecting out from the shank. The blades are adjustable on many types of boring bars.



1	Shank
2	Blade depth adjustment dial
3	Replaceable cutter inserts

Two-Bladed Boring Bar with Adjustment Dial

Use a ream to size a previously drilled hole. A reaming tool has multiple flutes that run vertically along the shank of the tool. During reaming, the cutter follows the angle of the existing hole and cannot be used to straighten the angle of the hole.



Reaming Tool

The Bore and Ream fields are defined as follows:

- **Block**—Identifies the block number for this operation.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Tool**—Identifies the tool number for this data block.
- **Z Start**—identifies the point where the spindle begins to rotate. The Z Start field is the dimension where the Z axis plunge feed rate begins.
- **Z Bottom**—Identifies the bottom of the finished hole.

- **Plunge Feed**—Identifies the feed rate between the Z Start and the Z Bottom positions.
- **Speed (RPM)**—Identifies the speed at which the spindle rotates to drill the hole, entered in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block. See also [Feed and Speed](#).
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).

Back Spotface

Use the Back Spotface function to cut out the underside of holes that must be cut through the workpiece.

This motion sequence occurs with Back Spotface:

1. Rapid to Z Start minus cutter offset and set the spindle speed to a plunge speed.
2. Move to Z Plunge minus cutter offset at a closing feedrate to close the cutter.
3. Rapid to Z Bottom minus cutter offset.
4. Dwell for a specified reverse dwell amount, reverse the spindle direction and ramp to cutting speed to open the cutter.
5. Move up to Z Depth minus cutter offset at a cutting feedrate.
6. Dwell for the drill dwell time (from program parameters).
7. Rapid down a Z Clearance amount.
8. Dwell for the Reverse Dwell time and reverse the spindle direction to plunge speed to close the cutter.
9. Move to Z Retract minus cutter offset at a closing feedrate to insure the cutter is closed.
10. Rapid out of the hole.

The Back Spotface fields are defined as follows:


- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Z Plunge**—Identifies the point within the hole to which the tool feeds before rapid movement to Z Bottom. This action assures that the cutter is fully closed, preventing damage to the tool and part.
- **Z Bottom**—Identifies the bottom of the finished hole.

- **Z Depth**—Identifies the depth to which the tool feeds
- **Z Clearance**—Determines the incremental distance to rapid the tool away from the cutting distance. At this point, the tool pauses and the spindle returns to its original direction to close the cutter.
- **Z Retract**—Determines the distance the tool feeds back up through the hole to be certain that the tool is properly closed before rapid movement to the Retract Clearance height.
- **Closing Feed**—Determines the feed at which the tool enters the hole at the top and bottom to be certain that the tool is closed.
- **Cutting Feed**—Determines the feed the tool uses while milling.
- **Plunge Speed**—Identifies the speed of the spindle with the tool closed while entering or exiting the hole.
- **Cutting Speed**—Identifies the speed of the spindle with the tool open.
- **Reverse Dwell**—Determines the number of seconds that the spindle dwells when it is reversing to give the tool time to open or close.
- **Tool Diameter**—Contains the value entered during [Tool Setup](#).
- **Tool Type**—Contains the type entered during [Tool Setup](#).

Bolt Circle

For each hole data block, you must include a [Locations](#) or a bolt circle operation. A Bolt Circle operation executes a series of equally spaced holes in a common circle. This operation allows skipping holes in the bolt circle.

All Locations programmed in a block containing a Bolt Circle are executed in addition to the Bolt Circle pattern. All operations programmed in a data block are performed at all locations specified in that block.



A	Start Angle
B	X Center, Y Center
C	Radius

Bolt Circle Pattern

The **Locations** and **Bolt Circle** softkeys are not available for the first operation in a Holes block because they require prior operations to identify the type of operation, the tool, reference points, and machining information.

Move to the next Block or the next Operation by placing the cursor in the desired field and selecting the appropriate softkey (**Next Block**, **Next Hole Operation**, etc.). See also [Data Block Creation and Navigation](#).

The Bolt Circle fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **Number of Holes**—Determines the number of holes in the pattern, including those skipped. Up to 250 holes can be programmed in one operation.
- **X Center** and **Y Center**—Identify the X and Y coordinates for the center of the Bolt Circle.
- **Radius**—Determines the radius of the circle between the coordinate center and the center of the cutter's starting point.
- **Start Angle**—Determines the angle of the circle measured counter-clockwise from the 3 o'clock position to the first hole. This angle may be specified to the nearest one-thousandth of a degree.
- **Skip List**—Enter up to 24 positions that should be skipped (not drilled). In the example above, there are 6 holes in the pattern. If you do not want to drill holes for positions 2 and 5, enter 2 and 5 in the Skip List field.

Locations

For each hole data block, you must include a location or a [bolt circle](#) operation.

- All Locations programmed in a block containing a Bolt Circle are executed in addition to the Bolt Circle pattern.
- All operations programmed in a data block are performed at all locations specified in that block.

The **Locations** and **Bolt Circle** softkeys are not available for the first operation in a Holes block because they require prior operations to identify the type of operation, the tool, reference points, and machining information.

With the cursor in a Location X or Y field, the **Add Location** and **Insert Location Before** softkeys appear. Select one of these softkeys to either add or insert fields in the list for entering data. The **Delete Location** softkey appears when at least one location is in the list.

Up to 10 locations can be displayed on the screen. If there are more than 10 locations in the data block, use the CTRL key in combination with either the up or down arrow keys, the PAGE UP or PAGE DOWN keys, or the HOME or END keys to access the remaining locations. If you press ENTER, the cursor moves to the next field; if you press ENTER with the cursor in the last Location field, the cursor moves to the Block field.

Move to the next Block or the next Operation by placing the cursor in the desired field and selecting the appropriate softkey (**Next Block**, **Next Hole Operation**, etc.). See also [Data Block Creation and Navigation](#).

The Holes Locations fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Operation**—Identifies the operation number for this function. The system determines the number by the position of this function in the data block.
- **X** and **Y**—Identify the X and Y coordinates of the location.

Holes End Block

The WinMax software inserts a Holes End Block screen at the end of each Holes data block.

The fields on the Holes End Block screen are defined as follows:

- **Block**—Identifies the block number for this data block. The system determines the number by the position of this data block in the program.
- **Operation**—Identifies the operation number for this Holes data block. The system determines the number by its position in the data block.

PATTERNS OPERATIONS

Patterns operations repeat or modify a sequence of data blocks. Save programming time by duplicating part geometry to complete a part program or create multiple parts from one program.

Patterns may only be nested 10 levels deep.

Here are the type of Patterns operations:

[Loop](#)

[Pattern Locations](#)


[Scale](#)

[Mirror Image](#)

[Pattern End](#)

Loop Rectangular

This routine repeats a pattern a specified number of times along lines parallel to the X and Y axes. The original pattern is always milled at its programmed location. Always program a Pattern End data block following a Loop Rectangular block.



1	X Axis
2	Y Axis
3	Original Pattern
4	X Distance
5	Y Distance
6	X Number = 3; Y Number = 2


Loop Rectangular

The Loop Rectangular fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Number**—Determines the number of times the programmed routine will be repeated along a line parallel to the X axis.
- **Y Number**—Determines the number of times the programmed routine will be repeated along a line parallel to the Y axis.
- **X Distance**—Determines the distance between the patterns along the X axis lines. (Negative values indicate direction.)
- **Y Distance**—Determines the distance between the patterns along the Y axis lines. (Negative values indicate direction.)

Loop Linear

This routine repeats a pattern a specified number of times along a line defined in the X-Y plane. Even though the defined line of this pattern is not parallel to the X or Y axes, the original pattern is always milled at its programmed location and orientation does not change with respect to the X and Y axes. Always program a Pattern End data block following a Loop Linear block.



1	X Axis
2	Y Axis
3	Original Pattern
4	Distance
5	Angle
6	X Distance
7	Y Distance
8	Number = 3

Loop Linear

The Loop Linear fields are defined as follows:


- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Number**—Determines the number of times the pattern will be repeated along the defined line.
- **X Distance** and **Y Distance**—Determine the distances between the repeated pattern in the direction of the X and Y axes (+ or -).

If the X or Y Distance measurement is entered, the control automatically calculates the values for the Angle and Distance fields. The calculated values, which appear grayed out, may be stored by pressing the **Store Value** softkey or the ENTER key when the cursor is on the field. If you do not want to use the calculated value, type in a different value.

- **Angle**—Determines the angle (in degrees) between the defined line and the X positive axis. A positive value is counterclockwise (CCW) from the 3 o'clock position, and a negative value is clockwise (CW) from the 3 o'clock position.
- **Distance**—Determines the dimensional value between repeated patterns along the defined line.

Loop Angular

This routine repeats a programmed pattern a specified number of times along a circular path. Pattern orientation does not change with respect to the X and Y axes. The original programmed pattern is not executed at its original position unless the routine places it at that location. The pattern is only shown in the locations specified by the routine. Always program a Pattern End data block following a Loop Angular block.



1	X Axis
2	Y Axis
3	Original Pattern
4	XY Center
5	Start Angle
6	Rotate Angle
7	XY Reference
8	Number = 3

Loop Angular

The Loop Angular fields are defined as follows:


- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Number**—Determines the number of times the pattern is repeated along the specified circular path.
- **X Center** and **Y Center**—Identify the X and Y coordinates of the reference point about which the pattern is rotated.
- **Start Angle**—Identifies the angle value between the original pattern and the location of the first pattern created by this routine.
- **Rotate Angle**—Identifies the angle between the repeated patterns being executed by this routine.
- **X Reference** and **Y Reference**—Identify the X and Y coordinates of the reference point (the only point in the pattern always on the circular path)

defined by this routine).

Loop Rotate

This routine repeats a pattern along a circular path. Loop Rotate moves the pattern around the X-Y center point and executes the pattern only at the programmed locations.

The original programmed pattern is not executed at its original position, unless this routine places it at that location. The pattern is only shown in the specified locations. Always program a Pattern End data block following a Loop Rotate block.



1	X Axis
2	Y Axis
3	Original Pattern
4	XY Center
5	Start Angle
6	Rotate Angle
7	XY Reference
8	Number = 3

Loop Rotate

The Loop Rotate fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Number**—Determines the number of times the pattern will be repeated along the specified circular path.
- **X Center** and **Y Center**—Determine the X and Y coordinates used to define the circular path of the repeated pattern.
- **Start Angle**—Determines the angle value between the original pattern and the location of the first pattern created by this routine. If this location is the

same as the original programmed pattern, the value in this field will be zero.

- **Rotate Angle**—Identifies the angle between the repeated patterns being executed by this routine.


Pattern Locations

Enter a Pattern Location block each time a programmed pattern is to be repeated. The pattern is repeated by offsetting the pattern with each displacement specified in the Pattern Location block. Always program a Pattern End data block following a Pattern Location block.

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Offset, Y Offset, and Z Offset**—Identify the location where the pattern is to be executed in the X, Y, and Z axes. If this is Location #1 and the pattern is to be at its original location, this coordinate must be zero. The value for this field is the offset for the X or Y axis.

Scale

This routine scales a programmed pattern down or up in a range of 0.100 to 10.000 (10% to 1000%) respectively. Always program a Pattern End data block following a Scale block.



1	X Axis
2	Y Axis
3	Original Pattern
4	Scaled Pattern
5	XY Reference
6	X Scale = 3; Y Scale = 2; Z Scale = not shown

Pattern Scale

The Scale fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **X Reference, Y Reference, and Z Reference**—Determine the X, Y, and Z coordinates of the point from which the scaling will be performed.
- **X Scale, Y Scale, and Z Scale**—Determine the scaling factor from the X, Y, and Z axes. If scaling is not executed from the axis, enter 1.0000.
 - A value that is less than 1.0000 scales down the pattern.
 - A value that is greater than 1.0000 scales up the pattern.

When you use [Cutter Compensation](#) in the program, the X and Y scale factors must be equal, except for these selections where the X and Y scale factors can be different:


- Circle (ON)
- Frame (ON)
- Ellipse (ON)
- Contour (ON)
- True-Type Font (ON)
- HD3 Lettering

When using Z scaling, the Peck Depth, Retract Clearance Plane, Peck Clearance Plane, and Z Safety Plane values are not affected.

Z Bottom and Z Start are the values commonly affected by Z scaling.

Mirror Image

This pattern programs a part as a mirror image of an existing programmed part. The routine can execute the mirror image alone or the original part and the mirror image. Always program a Pattern End data block following a Mirror Image block.



1	X Axis
2	Y Axis
3	Original Pattern
4	Angle
5	XY Point on Mirror Line

Mirror Image

The Mirror fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Keep Original**—Select Yes for this field if the original will be cut as well as the mirror image. If only the mirror image is to be produced, select No for this field.
- **X and Y**—Identify the X and Y coordinates for a point on a line about which this routine occurs as measured from part zero to the mirror line.
- **Angle**—Enter the orientation in degrees of the mirror line (which passes through the X-Y dimensions above). This is measured from the 3 o'clock position. A positive value is CCW.

Pattern End

There are no fields to enter in this data block. It is a marker at the end of the sequence of data blocks used in a Pattern operation. Press the Review List softkey to view a part program summary and determine the position of the Pattern End data blocks.

There must be an equal number of Pattern blocks and Pattern End data blocks. Use the right and left arrow keys to scroll through the blocks, press the **Insert Before** softkey to insert a pattern End block before a displayed data block.

SPECIAL OPERATIONS

Special data blocks can be inserted between operational data blocks to change the position of the table, automatically stop a program, or temporarily change the part program parameters or set a new part zero.

Position Data Block

Use a Position data block to move the table or to stop motion so you can adjust the work piece or to gain clearance around the tool or work piece. See also Part Setup Safety Work Region.

Use a Position data block instead of a [Change Parameters](#) data block in these instances:

- Between operations, when a clamp or raised portion of the part is higher than the programmed relative clearance.
- When cutting occurs inside a cavity and is followed by work inside another cavity in which an optimal Retract Clearance for operations in the recessed areas is below the surface of the part.
- The Z Retract is the same as the Z safety plane height in a Position data block.

The fields for a Position data block are defined below:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
- **X, Y, Z**—Determine the X and Y coordinates for the position to which the tool should move (after Z Top position is reached). This dimension is measured relative to Part Zero.
- **Stop**—Determines whether the program will stop after executing the current Position block. When the cursor advances to the Stop field, **Yes** and **No** softkeys appear. Press the **Yes** softkey if you want the program to pause (the spindle will pause also). Press the flashing Start Cycle button to continue with the part program. If this Position block is not a stop block, press the **No** softkey.



If you want to open the CE Safety enclosure doors after the Position data block executes (the Stop field is Yes), press the Machine Mode Interrupt console key, then press the Start Cycle button. The enclosure doors can be opened and the axes jogged. To resume program execution, close the enclosure doors and press the Start Cycle button.

- **Index Pulses**—Contains the number of positioning movements that the indexer head will make when rotating through an operation. It is used only when indexer equipment is attached to the machine. A new Position block must be put into the part program each time the part needs to move to a new indexer position.
- **Tool**—Identifies the number and type of tool.

Graphics On/Off

Graphics On and Graphics Off program blocks allow you hide selected operations in the graphics display. For example, setting a Graphics Off block as block 3 in a part program and Graphics On as block 10 will hide blocks 4-9 when the part is viewed using Solid or Toolpath graphics.



All blocks that are hidden by this operation are still cut when the program is run.

Change Parameters

Use this feature to change data stored within the [Program Parameters](#) screens:

- [Change Parameters \(General\)](#)
- [Change Parameters \(Milling\)](#)
- [Change Parameters \(Holes\)](#)
- [Change Parameters \(Probing\)](#)
- [Change Parameters \(Performance\)](#)

When a part program is executed, the data selected in the Program Parameters are in effect until the system encounters another Change Parameters data block or until the end of the program.

When planning a change to the Retract Clearance parameter, consider the following points:

1. This parameter is defined relative to the Z Start dimension and can optimize Z axis tool motion between localized operations.
2. If all of the operations are at the same Z Start plane, there is no difference between a relative and an absolute clearance. However, when groups of cutting operations are at different Z levels on the part, programming a relative Retract Clearance can be more efficient than an absolute retract dimension. It is possible, using a relative Retract Clearance, to eliminate unnecessary tool motion and save execution time.
3. If the Z Start dimension of the next operation is different from that of the current operation, the control uses the higher of the two values for Retract Clearance before positioning the part in the X-Y axes.

4. To achieve a Retract Clearance close to the part may require the use of a Position data block. Programming a Position block causes the tool to retract to the Z Top (+) of the Safety Work Region.

Examples of areas in which a Position data block must be used rather than a simple parameter change are as follows:

- Between operations, a clamp or raised portion of the part is higher than the programmed relative clearance.
- When cutting occurs inside a cavity and is followed by work inside another cavity in which an optimal Retract Clearance for operations is below the surface of the part.

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Parameters (General)

Use this feature to change the General Parameters for the program you are working on.

⇒ The Change Parameters (General) fields are the same as [General Parameters 1](#) and [General Parameters 2](#).

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Parameters (Milling)

Use this feature to change Milling Parameters for the program you are working on.

⇒ The Change Parameters (Milling) fields are the same as [Milling Parameters 1](#) and [Milling Parameters 2](#).

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Parameters (Holes)

Use this feature to set the Holes Parameters for the program you are working on.

⇒ The Change Parameters (Holes) fields are the same as [Holes Parameters](#).

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Parameters (Probing)

Use this feature to set the Probing Parameters for the program you are working on.

⇒ The Change Parameters (Probing) fields are the same as [Probing Parameters](#).

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Parameters (Performance)

Use this feature to change Performance Parameters for the program you are working on.

⇒ The Change Parameters (Performance) fields are defined the same as [Performance Parameters](#).

Refer to [Position Data Block](#) for information about when to use a Position block instead of changing parameters.

Change Part Setup

Use this function to change the [Part Setup](#) part zero coordinates and the Offset Z value. Change Part Setup values remain in effect until the next Change Part Setup block. The Auto screen will show the part position relative to the current part setup block. To change the part setup back to the original parameters, enter another Change Part Setup screen with the original parameters at the point in the program where the setup must be reset.

- ⇒ Part Zero A and Centerline A fields appear on the screen when the Rotary option is installed.
When the program will be used to cut more than one part, insert another Change Part Setup data block at the end of the program to restore the original (default) part setup.

To create a new Change Part Setup data block:

1. From the Input screen, select the **Part Programming** softkey or icon.
2. Select the **Insert Block Before** softkey.
3. When the New Block screen appears, select the **Miscellaneous** softkey to display the Miscellaneous options shown in the softkey selections.
4. Select the **Part Setup** softkey.

The Change Part Setup fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Part Zero X/Y**—Defines the X and Y locations in machines coordinates for part zero.
- **Offset Z**—Defines the Z dimension offset for part zero. This field is usually left at 0 and the Tool Calibration field in [Tool Setup](#) is used to determine each tool's part zero.

Machine Function

M52 through M55 are used to enable auxiliary equipment or a unique machine function from within a part program. M52 enables Auxiliary Output 1, M53 enables Auxiliary Output 2, M54 enables Auxiliary Output 3, M55 enables Auxiliary Output 4.

M62 disables (turns off) Auxiliary Output 1 (M52), M63 disables Auxiliary Output 2 (M53), M64 disables Auxiliary Output 3 (M54), and M64 disables Auxiliary Output 4 (M55).

To include this data block in a Conversational part program, perform the following steps:

1. From the New Block screen, select the Miscellaneous softkey.
2. Select the Machine Function softkey. You may include any of the functions appearing in the Machine Function list in your program.



If the Machine Function softkey appears “grayed out,” the machine does not have auxiliary machine or equipment specific M codes defined.

Lube Cycle

If additional lubrication is needed, insert this block into your program to pulse the lube pump. The current lube cycle will not be affected. Check your machine manual to see if your lube reservoir/pump supports programmed inputs. If your lube pump and or reservoir is actuated by a timer, this option will not function. Most Hurco machines made after 1998 have timer actuated lube, but the Lube Cycle option is provided for backward compatibility with older machines. This option is not needed in newer machines due to higher quality components and adequate lube application.

Comment Block

Comment blocks are useful for the programmer to outline tooling requirements and part setup data. Comment blocks will display text to the operator during program execution when the block is encountered in the program. The amount of time a comment block will be visible can be programmed in the comment data block. Subsequent machining data blocks will continue to executed during this time.

When posting Conversational programs to NC, Comment Blocks explain the program code or provide information, such as setup instructions.

Comment Block fields are as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Stop**—Allows the program operation to be paused until further input from the operator. If the Stop field is set to Yes when the program is running on the machine, the spindle goes to its Z Top position and the coolant shuts off.
- **Display Time**—The amount of time the comment will be displayed when this

block is encountered during program run.

- **Line 1-10**—Enter up to 10 lines of information to display. Each line holds up to 50 characters.

Insert Block

When posting Conversational programs to NC, use an Insert Block to insert up to ten lines of NC code (Text Option) or up to ten lines of APT code (APT option).

Insert Block fields are as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Type**—Choose either Text or APT
- **Line 1-10**—Enter up to 10 lines of text. Each line holds up to 50 characters.

NC/CONVERSATIONAL MERGE

WinMax allows you to execute an ISNC G-code (NC) program from within a Conversational part program with NC/Conversational merge. G-code programs can be used and re-used within the Conversational program.

To include this data block in a Conversational program, select the NC PROGRAM CALL softkey. Use the PROGRAM NUMBER field to initiate the NC program. For programs that use variables, the ARG TYPE fields allows you to enter argument variables to pass to a subprogram. ARG TYPE STRING accommodates a small number of variables, while ARG TYPE LIST accommodates a larger number of variables. See the *NC Programming Manual* and the *NC Productivity Package (NCP) Option Manual* for more information about variables and arguments.

To invoke a G-Code program from within a Conversational part program, the program must be loaded in Program Manager. The first line of NC code following the percent (%) sign must contain the program number preceded by the letter "O" (not a zero) or a colon (:); for example, **O1234** or **:1234**. There cannot be any other information on this line and "O" or ":" must be the first character. The program must end with an M99 to allow other Conversational program operations after the NC program is complete, as in the following program (O number and M99 are bolded for emphasis):

Example:

```
%  
O5085  
(#1 IS THE START ANGLE)  
(#2 IS THE NUMBER OF GEAR TEETH)  
(#3 IS THE OUTSIDE RADIUS)  
(#11 IS THE INSIDE RADIUS)  
(#4 IS THE GEAR CENTER PT X COORD)  
(#5 IS THE GEAR CENTER PT Y COORD)  
(#6 IS THE GEAR CENTER PT Z COORD)  
(#19 IS THE TOOTH TO SKIP)  
(#18 IS THE TOOTH RATIO)  
/  
T1 M06  
M03G00G21G90X0Y0Z0S1800  
(VARIABLE #4006 - INCHES/METRIC)  
IF[#4006EQ20]GOTO10  
IF[#4006EQ21]GOTO15  
N10#850=25.4  
GOTO20  
N15#850=1.0  
N20G0X-3Y-5  
Y5  
X8
```

Y-5

#30=[360.0/#2]

#31=0

#22=[#30*#18]

#23=#30-#22

#24=#11*#850

#25=#3*#850

#26=#20*#23

X#4 Y#5

G90G00G16X#25Y#1

G01Z-.25F20.

WHILE[#31LT#2]DO250

#1=[#1+[#22]]

G03G16X#25Y[#1]R#3

G01X#24Y[#1+#26]

#1=[#1+[#23]]

G03X#24Y[#1-#26]R#11

G01X#25Y[#1]

G15

N200#31=#31+1

N400END250

M99

NC PART PROGRAMMING

This section describes the use of NC (Numerical Control) Part Programming, which includes the BNC (Basic Numerical Control) and the ISNC (Industry Standard Numerical Control) Editor portion of the CNC software as it is used on the machine tool console. This section explains the following:

- [NC Part Programming Principles](#)
- [NC Editor](#)
- [NC Parameters](#)
- [Preparatory Functions - G Codes](#)
- [Spindle Speed - S Codes](#)
- [Tool Functions](#)
- [Miscellaneous Functions - M Codes](#)

NC Part Programming Principles

NC part programming adheres to the ANSI/EIA *RS-274-D* standard terminology with extensions for BNC and ISNC dialects. In addition, the NC programming facilities were designed to use as much of the WinMax Conversational system as possible. As a result, most of the screens are the same in both the NC and the conversational systems. This allows a smooth transition between the two.

The primary difference between conversational and NC programming is the program editors. The NC is programming uses standard G and M codes; whereas, conversational programming uses plain English or another supported programming language.

⇒ The CNC software can read NC files from the serial port directly into dynamic memory or run NC files that are partially loaded into dynamic memory. NC files can be serially loaded to the hard disk.

NC Part Programming

NC part programs can be created using the CNC on the machine tool or off-line CNC programming software running on a personal computer. NC programs cannot be converted to conversational programs, nor can NC programs be converted automatically to any other NC format.

NC Part Program Components

NC programs are a series of characters and words that form program blocks. These program blocks tell the machine tool how and where to move. The operator needs to understand the basic program structure and the types of codes in order to create, edit, and run a program successfully. These components make up NC code:

Program Start

All NC programs begin with a “%” (percent) character. When a *percent character* is received, the control starts to accept, check, and load blocks into its memory. If you are creating a new part program at the control, the percent character is automatically inserted at the beginning of the program.

Sequence Number

A sequence number serves as a block label; it has no other significance within the part program except being required with GOTOs in the NCPP option and the M99 jump command. Sequence numbers are often used to mark the beginning of milling sequences so you can restart at a given sequence number or recall specific operations within the program.

When programming on an off-line system, sequence numbers should be used sparingly. Sequence numbers (N words) are optional in the NC Editor, and they are useful in programs sent over the RS-232 link. However, the absence of sequence numbers permits faster processing (loading, syntax checking, and parsing) of the part program and can result in improved part program execution. In addition, omission of these numbers increases the amount of the program that can fit into memory.

⇒ If you request renumbering of part program sequence numbers, any sequence numbers in GOTO statements will not be updated. You must then press the (F1) Yes softkey before re-sequencing will take place. To cancel the renumbering, press the (F8) No softkey. In general, you will not want to renumber part programs that use GOTO statements.

Address Characters

An address character is the first character of a word in a program block. The Ignore Command signals the system to ignore the remainder of the block. The Comment Command characters are used to delimit comments. The following is a list of the address characters recognized by this system:

- / Ignore Command
- () Comment Command
- : Subprogram Number (NCPP Option)
- A Rotary Dimension Around X-axis
- B Rotary Dimension Around Y-axis
- D Tool Diameter Offset
- F Feedrate
- G Preparatory Functions
- H Index into the tool length offset table
- I X-axis Arc Center/Offset, X scale factor, Canned Cycle Bore Shift

- J** Y-axis Arc Center/Offset, Y scale factor, Canned Cycle Bore Shift
- K** Z-axis Arc Center/Offset, Z scale factor, Canned Cycle Repeat
- L** Tool Length Offset, Data Set Mode
- M** Miscellaneous Functions
- N** Sequence Number
- O** Subprogram Number (NCPD option)
- P** Subprogram Number, Dwell Time, Scaling Factor
- Q** Canned Cycle Bore Shift, Peck Depth
- R** Rotation Angle, Return Level, Circular Interpolation Radius
- S** Spindle Speed Function
- T** Tool Select
- X** Primary X Motion Dimension, Dwell Time
- Y** Primary Y Motion Dimension
- Z** Primary Z Motion Dimension

Special Characters

Special characters are ASCII characters within a file which have special meaning to the system and cannot be edited. The following special characters are recognized by the NC software:

- **%—Beginning/End of tape**—signals the system that all of the following characters are part of the program. The system automatically adds this character to the beginning of a new program. You can also include the % character to signal the End of Tape.
- **E—End of tape— (EOT)** (optional for BNC and ISNC)—signals the NC system that no more legal program characters follow. This character is optional to provide compatibility with existing programs that include EOT characters at the end.
- **[CR]—Carriage Return**—signals the End of a Program Block.
- **[CRLF]—Carriage Return/Line Feed Pair**—signals the End of a Program Block (identical to [CR]).

⇒ [CRLF] is not shown when the program is viewed in the NC Editor.

Words

A word is a group of alphanumeric characters. The first character is an address character—a letter such as M or G. The address character is followed by a signed or unsigned numeric value. Some sample NC words are "X-.03" and "G00." One word or groups of words form a program block.

Block

A block is a group of words terminated by the end-of-block character: a carriage return [CR] or a carriage return/line feed pair [CRLF]. Each block within a part program must be terminated with either a [CR] or a [CRLF].

The following illustration shows a typical NC block and its components:




Figure 1. Typical NC Block

Default M and G Codes

Upon power up, control reset, initial entry into the NC Editor, or after erasing a program, the system presets these M codes as defaults:

- M05 Spindle Off
- M09 Both Coolant Systems Off

The system also presets certain G codes as the default active codes. The default G codes are highlighted in the G Code Table in the "Preparatory Functions-G Codes" section.

The system uses the units specified when the NC Editor is selected, not the G codes, for graphics display and running the part program.

Navigation

To move the cursor from a block to the beginning of the next block, press the down arrow (↓). Use the right/advance arrow (→) and the left/back arrow (←) to move the cursor within a block. Use the Enter key to move the cursor between words and blocks.

To move to the beginning of the current block, press the *Home* key or the up arrow (↑). If the cursor is already at the beginning of the block, pressing the up arrow moves the cursor to the beginning of the last word in the previous block.

To move from a word to the beginning of the next word, press the Enter key. If the cursor is at the end of the current block when the Enter key is pressed, the editor automatically presents the next legal address character.

To move from one character to the next, press the right arrow. If the cursor is at the end of the current block, the cursor wraps around to the beginning of the block.

To move from one character to the preceding character, press the left arrow. If the cursor is at the start of the current block, it wraps around to the end of the current block.

Delete characters or words from a block using these methods:

- To delete numeric data, position the cursor on the number and press the Delete key.
- To erase the entire word, position the cursor on the address character and then press the left arrow or the Delete key. The entire word is removed since numeric data is not allowed in an NC program without an address character to introduce it.

NC EDITOR

The NC Editor is used for creating or changing an NC part program. The NC Editor is similar to a text editor on a personal computer.


⇒ Select the Change Editor softkey on the Auxiliary screen to switch the program editor type between Conversational and NC.

Editor Menus

The editor menus are arranged with the most commonly used features listed in the main menu (insert, delete, and jump). The submenus contain search and edit functions, which include graphics markers, syntax checking, and program execution features. The submenus also have file and program selection or deletion functions.

Edit Screen Fields

The NC Editor screens have display and data entry areas and several softkey menus used for creating and editing NC part programs. After entering the tool and part setup information, press the Part Programming (F3) softkey on the Input screen.



NC Editor screen

The percent sign (%) in the NC Editing Region indicates the beginning of the program and the "E" line indicates the end of the program. The NC Editor cursor is a gray rectangle. It appears between the start and end lines of a new program; otherwise, it appears after the start line of an existing program.

- **OPTNUM/AUTONUM**—The OPTNUM/AUTONUM status label in the upper right-hand corner of the screen shows whether the program numbering is done manually by the operator or automatically by the system. Set this field with the [Block Numbering](#) softkey in the [Search and Edit menu](#). Use the **Auto/Optional Numbering Toggle** softkey to switch between the two choices.
 - **OPTNUM** - either exclude the sequence numbers or type them at the beginning of each new programming block.
 - **AUTONUM** - the system automatically numbers the lines. The Numbering Increment field appears in the upper left-hand corner of the screen to allow you to select the numbering increment. Enter the increment (i.e., 5 or 10). The system numbers lines in these increments.
- **Insert/Over Indicator**—The line in the upper right-hand corner containing the Insert label, shows whether the editor is in character insert (Insert) or character overwrite (Over) data entry mode.
 - **Insert mode** - characters are inserted in front of the current character.
 - **Overwrite mode** - characters replace the currently highlighted character and move the cursor to the next character.
- **Editor Status Line**—The editor status line provides the following information:
 - **Block** - indicates the line of the NC program on which the cursor is currently placed.
 - **Block Skip** - indicates whether blocks with the Ignore character (I) are interpreted and executed (Block Skip Off) or ignored (Block Skip On). This field is set in the [Program Execution](#) menu.
 - **Units** - indicates what unit of measurement is selected in User Preferences.
- **NC Editing Region**—The area in the center of the screen is the editing region where you enter the NC program data. The area to the left of the program block is reserved for program block indicators.
- **Syntax Checking**—The NC Editor provides syntax checking which ensures that the characters in a program are legal and in the proper order.

The syntax checking facility searches for the following problems:

- Invalid or incomplete blocks.
- Invalid or incomplete address codes.
- Numeric errors.

In checking a block for errors, the system ensures that legal characters are entered for the currently active G codes. Blocks that violate the syntax rules appear on the screen with the "ERR" label to their left.

- **Range Checking**—Ranges are specified after scaling. Several different levels of range checking are performed on values used in NC programs. Since all the alphabetic characters except G, M, N, O, and ":" can be used to pass parameters to subprograms, all the address characters are tested to verify that they are within the range -999999.99999 to +999999.99999. Sequence numbers from 0 to 9999999 are allowed.

The interpreter level, a more stringent range checking, is also performed on some address values because of their special meaning. For example, a more stringent limit is put on F (feedrate).

Additional range checking is performed at the navigation level to prevent the machine from exceeding physical limitations. More restrictive ranges may be

This table lists the ranges for NC address characters:

Address Characters	Definition	English Range	Metric Range
:	Program Number	0.0 to 9999	0.0 to 9999
F	Feedrate	0.0 to 999.9	0.0 to 99999.9
G	G Command	0.0 to 255.0	0.0 to 255.0
H	Tool Offset	0.0 to 200.0	0.0 to 200.0
K	Canned Cycle Repeat	0.0 to 9999	0.0 to 9999
M	M Command	0.0 to 255.0	0.0 to 255.0
N	Sequence Number	0.0 to 9999999	0.0 to 9999999
P	Program Number	0.0 to 9999	0.0 to 9999
R	Rotation Degrees	0.0 to 360.0	0.0 to 360.0
S	Spindle Speed	0.0 to 65535.0	0.0 to 65535.0
T	Tool Number	0.0 to 99.0	0.0 to 99.0

Table 1. English and Metric Ranges for NC Address Characters

Starting a New NC Program

To begin NC part programming, press the Input key. Refer to [Program Manager](#) for information about saving, opening, and loading programs.

The NC file extension is set in [User Preferences](#).

These steps help determine the most efficient tool movement and basic program structure to save time during programming:

1. Determine the tool path on the print and label the points where the path direction changes.
2. Make a chart showing the coordinates of each point identified in the previous step.
3. Identify the spindle movements that will be necessary during cutting.

NC Programming Rules

Here are some basic rules to follow when creating NC part programs:

- The axis letter always precedes the numeric information.
- In most cases an integer works the same as a decimal or real number. In the following cases an integer is scaled by the appropriate scaling factor to maintain compatibility with existing NC programs:

Feedrate: F (BNC only)

Rotation: R (ISNC Only)

Dwell: P, X (Both BNC and ISNC)

Scaling: P (ISNC only)

⇒ If an integer is below the acceptable range after scaling, a "Below Minimum Value" error message occurs.

- All axis dimensions are considered to be positive unless a minus sign is entered. When describing *axis motion*, the codes for the program block must contain the following information in order to move properly:
 - Axis identification (e.g., X, Y, Z).
 - Direction the axis will move (+ or -).
 - Distance the axis will move (e.g., 4.0).
 - Enter the speed preceded by the F address character to program a *feedrate* in a block.
 - Include a Z parameter in the NC part program to permit the system to draw the part on the graphics screen. An absolute Z command must occur after a tool change before making another move command.

NC Editor Menus

Hurco's NC system provides many levels of program editing, as well as editing tools, to simplify the task.

The NC Editor contains these menus:

- [Basic Programming Menu](#)
- [Search and Edit Menu](#)
- [Jump and Search Functions Menu](#)
- [Wireframe Graphics Markers and Syntax Errors Menu](#)
- [Program Execution and Verification Menu](#)

Basic Programming Menu

While entering NC codes to create blocks, you may wish to insert new blocks, delete blocks, or display different sections of the part program on the screen.

The Basic Programming softkeys provide these functions:

- **Insert Block Before**—Inserts a blank line before the block where the cursor is located. This permits addition of a new block of data.
- **Delete Block**—Removes the block where the cursor is positioned.
- **Jump to Beginning**—Moves the cursor to the beginning of the first program block in memory.
- **Jump Page Forward**—Moves the cursor to the beginning of the last block on the screen. If the cursor is already on the last block of the screen, the next page of blocks is displayed with the cursor at the top of the page.
- **Jump Page Backward**—Moves the cursor to the beginning of the first block on the screen.
- **Jump to End**—Moves the cursor to the beginning of the last program block in memory.
- **More →**—Displays the next menu.
- **Exit Editor**—Exits the NC Editor and moves to the Input screen. Select **Part Programming** to return to the NC Editor screen.

Search and Edit Menu

The **Search** and **Edit** softkeys provide access to additional searching and editing functions.

When the **More →** softkey is selected from the Basic Programming menu, these softkeys appear:

- **Jump & Search Functions**—used to locate specific codes and blocks in a part program.
- **Edit Functions**—used to change blocks in a part program.
- **Insert/Overstrike Mode Toggle**—switches the [data entry style](#) between insert and overwrite.
- **Block Numbering Mode**—displays the Numbering [submenu](#) used to locate and change block numbering.
- **Tag Block**—tags up to 10 blocks (0 to 9). The editor displays the tag number to the left of the current block.
- **Jump to Tagged Block**—provides a field at the top left-hand corner of the screen in which to enter the block number. (Tag number (0-9): ____) Type the block number for the Jump and press ENTER. When ENTER is pressed, the system positions the cursor at the selected tagged block.
- **More →**—displays the next menu.

Tag Block

1. Position the cursor on a block to be tagged.
2. Select the **Tag Block** softkey.
3. The NC Editor displays the tag number to the left of the current block.

Once a block is tagged, it remains tagged until the tag number is reused.

Tag numbers are reused after the last number (9) has been assigned.

Jump and Search Functions Menu

The Jump and Search Functions Menu provides the flexibility to locate hard-to-find items in program memory using the block or sequence number or searching for specific address characters, numeric parameters, or words.

The following are the Jump and Search softkeys and their functions:

- **Jump to Block Number**—positions the cursor on blocks according to their places in NC memory (not according to their sequence numbers).
 - Select this softkey and the system displays an area at the top of the screen where the number of the line in the program can be entered.
 - Press the plus key (+) before typing the number to tell the editor to jump forward in the program by the specified number.
 - Press the minus key (-) before typing the number to tell the system to jump backward in the program by the specified number.
 - Enter an unsigned number to jump the cursor to that block number. For example, if a 5 is entered, the cursor jumps to the fifth block number.
 - Specify a block number that is larger than the number of blocks in a program to jump the cursor to the last block of the program.
- **Jump to Sequence Number**—positions the cursor on the N code line.
 - Select this softkey and the system displays an area at the top of the screen for you to type in the sequence number of the line in the program where you wish the cursor to jump.
 - Place the cursor somewhere before the anticipated location of the desired NC block, because the software does not search backward through the file.
 - Press the ENTER key and the software searches forward through the file for the first NC block. If the desired sequence number is found, the software positions the cursor on the NC block containing the sequence number.
- **Search for Text**—changes the Jump-Search softkeys to the [Search Functions softkeys](#).
- **Exit**—redispays the previous group of softkey options.

The remaining softkeys operate the same as in the [Basic Programming Functions](#) menu:

- Jump to Beginning
- Jump Page Forward
- Jump Page Backward
- Jump to End

Search Functions

Select the **Search for Text** softkey on the **Jump and Search** submenu. The **Search Functions** softkeys appear and the Search field appears in the upper left-hand corner of the screen.

These softkeys allow you to perform search and replace operations.

To perform search operations, follow these steps:

1. If a character is in the Search field from a previous search, press the console Clear (C) key. Type the address letter.
2. Enter a numeric value at this point, or press Enter to type in a replacement string.
3. Select the Search Forward (F1) softkey or the Search Back (F2) softkey.
 - To continue searching select the Search Again (F3) softkey.
 - To change the direction of the search, select the appropriate softkey—Search Back followed by Search Forward or vice versa.
4. Continue to press the softkey to search until the block is found or until the “No more occurrences” message appears.

To replace the search text throughout the program, follow these steps:

1. Type in the search text at the top of the screen.
2. Press the Enter key.
3. Type in the replacement text in the Replacement field.
4. Select the Replace All (F7) softkey to replace all instances of the search text.
5. Select the Exit (F8) softkey to return to the original Jump and Search softkeys.

Edit Functions

The Edit Functions menu allows you to perform editing operations on groups of blocks within the NC part program. To perform editing operations on groups of blocks within the NC part program, follow these steps:

1. Press the More softkey on the main menu screen to display the Edit Functions (F2) softkey.
2. Press F2, and the following softkeys appear:
 - **Jump & Search Functions**—display the same submenu as in the main [Search and Edit screen](#).
 - **Select Range of Blocks**—identify the blocks to move, copy, or delete by selecting a range of blocks before performing any of the edit functions.
 - **Clear Range of Blocks**—select to erase the tags then select either the **Yes** or **No** softkey to confirm the operation.



Clearing the tag range does not delete the blocks.

- **Copy Range of Blocks**—copy a block or a range of blocks to another location in the program.
- **Move Range of Blocks**—move a range of blocks to another location in the program.

⇒ The [sequence numbers](#) of the **copied** or **moved** range of blocks are not changed, so there will be duplicate sequence numbers in the program unless the program is re-numbered. However, this will not affect program execution since the system ignores the sequence numbers while running the program (except when GOTOs or M99 jump statements are used in the program with the NCPP option).

Also, check the program to be certain that the copied G codes do not cancel active G codes and create errors in the program.

- **Delete Range of Blocks**—delete a range of blocks in the program.

⇒ The program sequence numbers will have a gap in the numeric order unless the program is re-numbered. This does not affect program execution.

Be sure to check the program so that the deleted G codes do not create errors in the program.

- **Jump to Tag**—move the screen's focus and cursor to the tagged block.

Select Range of Blocks

1. Position the cursor on the first block to be tagged.
2. Select the **Select Range of Blocks** softkey to insert an asterisk (*) in the left-hand column.
3. Use the Arrow keys to move the cursor to a different block within the program. All blocks between the first and last selected blocks are marked with asterisks.
4. Select the **Exit** softkey to complete the block selection operation.

Copy Range of Blocks

1. Place the cursor where the tagged blocks are to be copied.
2. Select the **Copy Range of Blocks** softkey. One or more blocks must be tagged with an asterisk (*).
3. The system asks if the block should be copied before the currently selected block.
4. Select the **Yes** softkey to copy the blocks or the **No** softkey to cancel the operation.

Move Range of Blocks

1. Place the cursor where the tagged blocks are to be moved
2. Select the **Move Range of Blocks** softkey. One or more blocks must be tagged with an asterisk (*).
3. The system asks if the block should be moved before the currently selected block.
4. Select the **Yes** softkey to move the blocks or the **No** softkey to cancel the operation.

Delete Range of Blocks

1. Place the cursor on the group of blocks to be erased.
2. Press the Delete Range of Blocks (F5) softkey. The system asks for confirmation to delete the tagged blocks. Press the Yes (F1) softkey to delete the blocks or the No (F8) softkey to cancel the operation.



The program sequence numbers will have a gap in the numeric order unless the program is re-numbered. This does not affect program execution.

Be sure to check the program so that the deleted G codes do not create errors in the program.

Block Renumbering Mode

Select the **Block Renumbering Mode** softkey to change the Numbering Increment for automatic numbering. The softkey options change after this softkey is selected.

The default automatic numbering increment appears in the Numbering Increment field in the top left corner of the screen. To change this setting, follow these steps:

1. Press the left arrow key.
2. Type the new number; most operators use increments of 5 to 20. You may use up to four digits.
3. Select the **Exit** softkey to access more softkey functions.

The softkeys on the Numbering submenu have these functions:

- **Jump & Search Functions**—display the same submenu as in the main [Search and Edit screen](#).
- **Auto/Optional Numbering**—switches the line [numbering method](#) between AUTONUM (system automatically numbers) and OPTNUM (operator enters the numbers).
- **Begin Numbering**—re-numbers all of the blocks that have sequence numbers according to the selected increment. Blocks that do not have sequence numbers will not be re-numbered.
- **Jump to Tag**—positions a previously tagged block at the top of the editing region.
- **Exit**—re-displays the previous submenu softkeys.

Wireframe Graphics Markers and Syntax Errors Menu

The Wireframe Graphics Markers and Syntax Errors menu allows a portion of a part program to be selected by setting start and end markers. It also finds and positions the cursor on a syntax error in a part program.

The **Wireframe Graphics Markers** and **Syntax Errors** softkeys provide these functions:

- **Set Wireframe Start Marker**—marks the current block as the beginning point for the graphics display by inserting a left bracket ([) to the left of the block. If the start and end blocks are set as the same block, a pound sign (#) appears before the block.
- **Set Wireframe End Marker**—marks the current block as the ending point for the graphic display by inserting a right bracket (]) to the left of the block. If the start and end blocks are set as the same block, a pound sign (#) appears before the block.
- **Reset Wireframe Markers**—returns the start and end graphics markers to their default settings. The defaults are the beginning and end of the program.
- **Jump to Syntax Error**—searches for the next invalid block. When it reaches the end of the program, the system begins searching from the beginning of the program. When the system finds a block with errors, the cursor stops at the block, and the cursor is positioned on the incorrect word. An error message also appears at the bottom of the screen to explain the error.
- **More**→—displays the next menu.

Program Execution and Verification Menu

Use the Program Execution and Verification Menu features to prepare for program execution or to restrict the program execution to a specific section.

The Program Execution softkeys provide these preparation facilities for program execution:

- **Set Start Marker**—indicates the block that the system should use to start program execution when running and verifying the program.
- **Set End Marker**—indicates the block that the system should use to end program verification and execution.
- **Reset Start/End Markers**—restores the start and end markers to their defaults. The defaults are the beginning and end of the program.
- **Block Skip Enable**—switches on the block skipping facility during program execution. With this facility enabled, the system skips the NC codes which follow the Ignore (/) character.
- **More**→—Displays the next menu.

NC PARAMETERS

The **NC Parameters** softkey accesses these functions:

- [NC Configuration Parameters \(screens 1 and 2\)](#)
- [NC M and G Code Program Numbers](#)
- [NC Variables](#)

NC Configuration Parameters (Screen 1)

Use this screen to change general NC part program parameters.

The NC Configuration Parameters fields are defined as follows:

- **Linear Positioning**—specifies the type of move produced in the XY plane when rapid positioning. When this field is set to Yes, the move is in a straight line. When this field is set to No, the move is 45 degrees to the nearest X or Y axis and then to the end point along one axis.
- **Least Dwell Units**—specifies the dwell units when using an integer to specify dwell. This field can be set to 0.001 or 0.0001.
- **Least Scaling Factor**—specifies the units of the scaling factor when an integer is used with the scaling command. This field can be set to 0.001 or 0.0001.
- **Disable X/Y/Z Scaling**—disables any scaling performed in the X, Y, or Z axis, respectively.
- **Reference Point X/Y/Z**—specifies the reference point for the G28 command. The WinMax software allows you to select the tool change positions (X, Y, Z) or maximum travel limit (X, Y).
- **Tool Length Tolerance**—determines value used for tool probing.
- **NC Optional Program Stop**—specifies if program should stop on M01 command.

NC Configuration Parameters (Screen 2)

- **M6 Initiates Tool Change**—initiates a tool change at the M06 code when set to Yes. If set to No, tool changes are initiated by a T code.
- **Default Tool Number**—indicates which tool will be used at the beginning of the program.
- **Allow Vacant Variables**—allows variable values to be left blank when Yes is selected.

- **Assume Feedrate .1 Increment**—assumes a feedrate increment of .1 when Yes is selected.
- **Default Cutter Comp Lookahead**—identifies the number of segments in a contour that are checked to determine if the contour crosses itself and if the tool will fit into the contour. The default is 1. The range is from 1 to 9.



Use the default value of 1 look ahead block and test the program using Graphics. If the contour crosses itself when set to 1 block, reset this value to a higher number and retest using the graphics screen. The smaller the number of look ahead blocks, the more efficient your program will run, saving time and control memory.

- **Enable Lead In Calculations**—enables software to calculate cutter compensation lead in path.
- **Enable Lead Out Calculations**—enables software to calculate cutter compensation lead out path.

NC M and G Code Program Numbers

Use this screen to change M code and G code program numbers for an NC part program using the NCPP option.

The NC M and G Code Program Numbers fields are defined as follows:

- **Macro Mode B**—provides compatibility between different NC dialects from various machine tool control manufacturers and provides the potential to embed more NC computer programming.
- **Enable User M/G Codes**—enables user customization of M codes and/or G codes to perform specialized tasks. User defined M and G codes define a custom code which performs a specialized task, replace an existing G or M code, or provide compatibility between different NC dialects from various machine tool control manufacturers.
- **Enable User S/B/T Codes**—enables user customization of S codes, B codes, or T codes to perform specialized tasks. User defined S, B, or T codes replace spindle and tool functions with custom subprograms.
- **M-Code**—allows programming of customized M codes. Up to 13 user defined M codes can be programmed from M01 through M255 (except M02, M30, M98, and M99). Negative numbers cannot be entered in the column for user defined M codes. Enable programmed M codes using the Enable User M Codes function.
- **G-Code**—allows programming of customized G codes. Up to 10 user defined G codes can be programmed from G01 through G255 (except G65, G66, and G67). If a negative number is entered for a user defined G code, the subprogram becomes modal. Enable programmed G codes using the Enable User G-Codes function.

NC Variables

Use this screen to define Global and System NC variable codes and subprograms for an NC part program using the NCPP option. Programs with variables can be reused for various applications. All variables must begin with the "#" character followed by a valid, writeable register number and an equal sign. The following example sets the variable value (#500) to 100:

```
# 500 = 100
```

Some variables are read only when an operator attempts to write to the variable.

There are four types of variables that can be used in NC programming:

- **Global**—can be used by all programs. Assign a global variable before it is used in an equation or expression, or the variable will be considered vacant, generating an error unless the [Allow Vacant Variables](#) field is set to Yes. Use the Global 100-199 and Global 500 - 999 softkeys to enter global variables on the NC Variables screen.
- **System**—provide information about the state of the system such as X, Y, and Z external work compensation, miscellaneous system parameters, modal information, position information, and G code group status. Use the **Tool Offset 2001-2200**, **Work Offset 2500-2999**, **Misc 3000-3014**, **Modal 4001-4320**, and **Position 5001-5083** softkeys to enter system variables on the NC Variables screen.
- **Local**—are valid only within the current program. These variables are only available in Macro Mode B and range from #1 to #33. Enter local variables in the [NC Editor](#) screen.
 - Assign a value to the local variable before it is used in an equation or expression, or the variable will be considered vacant, generating an error unless the [Allow Vacant Variables](#) field is set to Yes.
 - When the subprogram call is not made using an M98, local variables are nested, meaning that when a subprogram call is made, a new set of local variables is received and the old set is stored. After leaving the subprogram, these local variables are destroyed and the previous set is restored.
 - Passing parameters to subprograms automatically initializes local variables when subprogram calls other than M98 are made.
- **Arguments**—available only Macro Mode A. Arguments are used to pass parameters to subprograms. Parameters are the addresses which follow G65, G66, and M98 codes. Enter arguments in the [NC Editor](#) screen.
 - For table and the [Macro Mode A G Code Group Status](#) table.

Use the softkeys to select the type of NC Variable to appear on the NC Variables screen:

- Global 100-199
- Global 500 - 999
- Tool Len Offset 2001-2200
- Work Offset 2500-3000

The **More** → softkey accesses these softkey choices:

- Misc 3000-3021
- Position 5061-5083
- Tool Dia Offsets 12001-12200

The **More** → softkey returns to the first softkey menu described above.

The **Toggle Units** softkey toggles the dimensional variables (Tool Offset, Work Offset, Position) between inch and metric.

Macro Mode A Subprogram Variables

In this table, the values for the NC parameters are stored in addresses #8004 to #8026 for Macro Mode A subprogram calls.

The status for each variable is stored in address #8104 to #8126.

The status for the variables is non-zero (>1) if an argument is specified in the subprogram call, and zero otherwise.

Macro Mode A Subprogram Variables

NC Parameter	Value Address	Type	Status Address	R/WW/WWW
I	#8004	ARG	#8104	R
J	#8005	ARG	#8105	R
K	#8006	ARG	#8106	R
F	#8009	ARG	#8109	R
G	#8010	ARG	#8110	R
H	#8011	ARG	#8111	R
M	#8013	ARG	#8113	R
N	#8014	ARG	#8114	R
P	#8016	ARG	#8116	R
Q	#8017	ARG	#8117	R
R	#8018	ARG	#8118	R
S	#8019	ARG	#8119	R
T	#8020	ARG	#8120	R
X	#8024	ARG	#8124	R
Y	#8025	ARG	#8125	R
Z	#8026	ARG	#8126	R

Macro Mode A G Code Group Status

In this table, the value for each G Code Group is stored in addresses #8030 to #8046 for Macro Mode A subprogram calls G65, G66, and user defined G codes and M codes.

The status for each G Code Group is stored in addresses #8130 to #8146.

The status is non-zero if an argument is specified in the subprogram call, and empty otherwise.

Macro Mode A G Code Group Status

G Code	Value Address	Type	Status Address	R/W
00	#8030	ARG	#8130	R
01	#8031	ARG	#8131	R
02	#8032	ARG	#8132	R
03	#8033	ARG	#8133	R
05	#8035	ARG	#8135	R
06	#8036	ARG	#8136	R
07	#8037	ARG	#8137	R
08	#8038	ARG	#8138	R
09	#8039	ARG	#8139	R
10	#8040	ARG	#8140	R
11	#8041	ARG	#8141	R
15	#8045	ARG	#8145	R
16	#8046	ARG	#8146	R

NC PROBING PART SETUP

It is possible to perform a part probe setup using calls to a set of predefined subprograms. A subprogram is a group of commands stored under one name. These probing subprogram calls mimic the probe part setup conversational data block.

The first five subprogram calls (P1000 through P5000) are used to set internal reference locations that perform the probing function. The sixth subprogram, P6000, performs the probing operation.

In addition, an NC program utilizing G31 commands can be used to perform a probing part setup.

⇒ Probing is used for setting up part zero for G54 only.

Here is an example of the NC codes for probing part setup:

```
G165 P1000 X0.0 Y0.0
```


```
G165 P2000 X1.0 Y8.0 Z-10.0
```

```
G165 P3000 X4.0 Y1.0 Z-10.0
```

```
G165 P4000 X4.0 Y2.0 Z-5.0
```

```
G165 P5000 X1.0 Y2.0 Z-10.0
```

```
G165 P6000 X+1 Y+1 A1
```



The previous example illustrates these subprograms:

- P1000 is used to set the X and Y reference locations.
- P2000 is used to set the X Start Location.
- P3000 is used to set the Y Start Location.
- P4000 is used to set the Z Start Location.
- P5000 is used to set the Skew Start Location.
- P6000 is used to set the X and Y direction (+1.0 means positive -1.0 means negative) and the Skew axis (A = 1 for X axis, A = 2 for Y axis, any other value or no A parameter indicates no skew axis).

- ⇒ The P1000 to P5000 subprograms must be used prior to P6000. Once a P6000 is used, the internal reference locations are reset to zero after the probing operation is performed. To retry the part setup, the P1000 to P5000 subprograms must be reset before P6000.

PREPARATORY FUNCTIONS - G CODES

This section defines G codes and their functions. This information is often needed when using an off-line CAM or CAD/CAM system to create NC part programs.

G Code Groups

The G codes are grouped by functions.

Group	Function	Group	Function
00	One-Shot	10	Return from Canned Cycles
01	Interpolation	11	Scaling
02	Plane Selection	12	Macro/Subprogram
03	Dimension	14	Coordinate System Selection
05	Feed	15	Precision Cornering
06	Measurement	16	Rotation
07	Cutter Compensation	17	Polar Coordinates
08	Tool Length Compensation	18	Mirroring
09	Canned Cycles	19	Program Parameters for Surface Finish/Data Smoothing

Table 2. G Code Groups



The system displays the number 010 as an alarm if an invalid G code (one not listed in the following table) is entered.

More than one G code can be specified in the same block. If more than one is from the same group, the last G code entered is active.

Specifying a group 01 (Interpolation) G code in a canned cycle automatically enters the G80 condition (Canned Cycle Cancel). Conversely, a group 01 G code is not affected by the canned cycle G codes.

G Code Table

The following table lists the G codes, identifies the defaults (in the shaded areas), lists Modal (M) or Non-modal (N) types, identifies groups, and describes the G codes' functions.

Some G codes are strictly BNC or strictly ISNC, and are identified as such in this manual. Otherwise, the G codes apply to either dialect.

G Code	Type	Group	Function
G00	M	01	Positioning (Rapid Traverse)
G01	M		Linear Interpolation (Cutting Feed)
G02	M		Circular Interpolation/Helical CW
G02.4	M		3D Circular Interpolation CW
G03	M		Circular Interpolation/Helical CCW
G03.4	M		3D Circular Interpolation CCW
G04	N	00	Dwell, Exact Stop
G05.1	M	19	Surface Finish Parameters
G05.2	M		Data Smoothing
G05.3	M		Surface Finish Quality
G09	N	00	Decelerate Axis to Zero
G10	N		Data Setting
G11	N		Data Setting Mode Cancel
G15	M	17	Polar Coordinates Cancel
G16	M		Polar Coordinates
G17	M	02	XY Plane Selection
G18	M		ZX Plane Selection
G19	M		YZ Plane Selection
ISNC G20	M	06	Input in Inch
ISNC G21	M		Input in mm
G28	N	00	Return to Reference Point
G29	N		Return from Reference Point
G31	N		Skip Function

G Code	Type	Group	Function (Continued)
G40	M	07	Cutter Compensation Cancel
G41	M		Cutter Compensation Left
G42	M		Cutter Compensation Right
G43	M	08	Tool Length Compensation + Direction
G44	M		Tool Length Compensation - Direction
G45	N	00	Tool Offset Increase
G46	N		Tool Offset Decrease
G47	N		Tool Offset Double Increase
G48	N		Tool Offset Double Decrease
G49	M	08	Tool Length Offset Compensation Cancel
G50	M	11	Scaling Cancel
G51	M		Scaling
G50.1	M	18	Mirroring Cancel
G51.1	M		Mirroring
G52	N	00	Local Coordinate System Setting
G53	N		Machine Coordinate System Selection
G54	M	14	Work Coordinate System 1 Selection
G54.1			Aux Work Coordinate Systems
G55	M		Work Coordinate System 2 Selection
G56	M		Work Coordinate System 3 Selection
G57	M		Work Coordinate System 4 Selection
G58	M		Work Coordinate System 5 Selection
G59	M		Work Coordinate System 6 Selection
G61	M	15	Decelerates to Zero–Precision Cornering
G64	M		Cancels Precision Cornering
G65	N	12	Macro Command, Subprogram Call
G66	M		Modal Subprogram Call
G67	M		Modal Subprogram Call Cancel
G68	M	16	Coordinate Rotation
G69	M		Coordinate Rotation Cancel
BNC G70	M	06	Input in Inch
BNC G71	M		Input in mm
G73	M	09	Peck Drilling Cycle
ISNC G74	M		Left-handed Tapping Cycle
ISNC G74 with M29	M		Rigid Tapping

G Code	Type	Group	Function (Continued)
BNC G74	M	01	Single-quadrant Circular Interpolation
BNC G75	M		Multi-quadrant Circular Interpolation
G76	M	09	Bore Orient Cycle
G80	M		Canned Cycle Cancel
G81	M		Drilling Cycle, Spot Boring
G82	M		Drilling Cycle, Counter Boring
G83	M		Peck Drilling Cycle
G84	M		Tapping Cycle
ISNC G84.2	M		Rigid Tapping Cycle
ISNC G84.3	M		Rigid Tapping Cycle
ISNC G84 with M29	M		Rigid Tapping Cycle
G85	M		Boring Cycle
BNC G86	M		Bore Orient Cycle
ISNC G86	M		Bore Rapid Out Cycle
BNC G87	M		Chip Breaker Cycle
ISNC G87	M		Back Boring Cycle
BNC G88	M		Rigid Tapping Cycle
ISNC G88	M		Boring Cycle Manual Feed Out, Dwell
G89	M		Boring Cycle Bore and Dwell
G90	M	03	Absolute Command
G91	M		Incremental Command
G92	N	00	Programming of Absolute Zero Point
G93	M	05	Inverse Time
G94	M		Feed per Minute
G98	M	10	Return to Initial Point in Canned Cycle
G99	M		Return to R Point in Canned Cycle

Table 3. G Codes in order of Codes

The following table lists the G codes by group, identifies the defaults (in the shaded areas), lists Modal (M) or Non-modal (N) types, and describes the G codes' functions.

Group	G Codes	Type	Function
00	G04	N	Dwell, Exact Stop
	G09	N	Decelerate Axis to Zero
	G10	N	Data Setting
	G11	N	Data Setting Mode Cancel
	G28	N	Return to Reference Point
	G29	N	Return from Reference Point
	G31	N	Skip Function
	G45	N	Tool Offset Increase
	G46	N	Tool Offset Decrease
	G47	N	Tool Offset Double Increase
	G48	N	Tool Offset Double Decrease
	G92	N	Programming of Absolute Zero Point
01	G00	M	Positioning (Rapid Traverse)
	G01	M	Linear Interpolation (Cutting Speed)
	G02	M	Circular Interpolation/Helical CW
	G02.4	M	3D Circular Interpolation CW
	G03	M	Circular Interpolation/Helical CCW
	G03.4	M	3D Circular Interpolation/Helical CCW
	BNC G74	M	Single-quadrant Circular Interpolation
	BNC G75	M	Multi-quadrant Circular Interpolation
02	G17	M	XY Plane Selection
	G18	M	ZX Plane Selection
	G19	M	YZ Plane Selection
03	G90	M	Absolute Command
	G91	M	Incremental Command
05	G93	M	Inverse Time
	G94	M	Feed per Minute
06	BNC G70	M	Input in Inch
	BNC G71	M	Input in mm

Group	G Codes	Type	Function (Continued)
07	G40	M	Cutter Compensation Cancel
	G41	M	Cutter Compensation Left
	G42	M	Cutter Compensation Right
08	G43	M	Total Length Compensation + Direction
	G44	M	Total Length Compensation – Direction
	G49	M	Tool Length Offset Compensation Cancel
09	G73	M	Peck Drilling Cycle
	ISNC G74	M	Left-handed Tapping Cycle
	ISNC G74 with M29	M	Rapid Tapping
	G76	M	Bore Orient Cycle
	G80	M	Canned Cycle Cancel
	G81	M	Drilling Cycle, Spot Boring
	G82	M	Drilling Cycle, Counter Boring
	G83	M	Peck Drilling Cycle
	G84	M	Tapping Cycle
	ISNC G84.2	M	Rigid Tapping Cycle
	ISNC G84.3	M	Rigid Tapping Cycle
	ISNC G84 with M29	M	Rigid Tapping Cycle
	G85	M	Boring Cycle
	BNC G86	M	Bore Orient Cycle
	ISNC G86	M	Bore Rapid Out Cycle
	BNC G87	M	Chip Breaker Cycle
	ISNC G87	M	Back Boring Cycle
	BNC G88	M	Rigid Tapping Cycle
	ISNC G88	M	Boring Cycle Manual Feed Out, Dwell
	G89	M	Boring Cycle, Bore and Dwell

Group	G Codes	Type	Function (Continued)
10	G98	M	Return to Initial Point in Canned Cycle
	G99	M	Return to R Point in Canned Cycle
11	G50	M	Scaling Cancel
	G51	M	Scaling
12	G65	N	Macro Command, Subprogram Call
	G66	M	Modal Subprogram Call
	G67	M	Modal Subprogram Call Cancel
14	G54	M	Work Coordinate System 1 Selection
	G55	M	Work Coordinate System 2 Selection
	G56	M	Work Coordinate System 3 Selection
	G57	M	Work Coordinate System 41 Selection
	G58	M	Work Coordinate System 5 Selection
	G59	M	Work Coordinate System 6 Selection
15	G61	M	Decelerates to Zero-Precision Cornering
	G64	M	Cancels Precision Cornering
16	G68	M	Coordinate Rotation
	G69	M	Coordinate Rotation Cancel
17	G15	M	Polar Coordinate Cancel
	G16	M	Polar Coordinates
19	G05.1	M	Surface Finish Parameters
	G05.2	M	Data Smoothing
	G05.3	M	Surface Finish Quality

Table 4. G Codes in order of Groups

Rapid Traverse (G00)

Rapid Traverse mode (G00) is the default and moves the axes to a specified location at the rapid feedrate programmed in the Program Parameters screen. Up to five axes (X, Y, Z, A, B) of coordinated rapid motion can be specified while in this mode.

Set either a linear or non-linear tool path on the NC Parameters screen. The linear tool path is the default. ISNC and BNC have different linear tool path modes. In the ISNC linear mode the tool motion is in all three axes (X, Y, Z) simultaneously. In the BNC linear mode the motion is divided into separate X, Y, and Z moves. The motion in the XY plane is a straight line.

The ISNC and BNC non-linear modes are the same. In the non-linear tool path mode, the XY plane motion is broken down into a 45° move and a straight line move parallel to either the X or Y axis. The determination of whether the 45° move or the straight line move is made depends first on the distances from the current position to the end position along the X and Y axes.

If it is desired that the tool move to a position which is compensated, G41 or G42 needs to be specified along with the offset before any axis coordinates are given. The rapid traverse rate is set on the General Parameters screen.

⇒ The G00 mode is canceled by using the G01, G02, G03, or canned cycle (G73, G76, G81–G89) commands.

G17, G18, or G19 determine plane of offset.

G90 specifies absolute dimensioning and G91 specifies incremental dimensioning.

Another work coordinate system can be selected by using commands G54 through G59.

Format

The format of the rapid traverse command is as follows:

G00 X_____Y_____Z_____A_____B_____

Example


If one axis of movement is specified in a G00 block, that axis moves at the rapid traverse feedrate. When two axes of movement are specified in a G00 block, the rapid traverse feedrate is assigned to the longest vector component. The resulting feed that appears on the screen may actually exceed the rapid traverse feedrate parameter.

If a block containing a G00 word also contains a Z word that causes the Z-axis to move away from the part, the Z-axis moves first. The other specified axes then move in linear or non-linear mode at the rapid feedrate to their specified end points. If Z is to move toward the part, all axes except Z move in linear or non-linear mode at rapid feedrate to their specified end points; then Z moves down to its end point. If no Z is programmed, all axes move at rapid feedrate coordinated to the specified end point. G00 is a member of the tool positioning code group and is *canceled* by G01, G02, G03, and G81–G89.



This code is used for positioning only and should never be used for cutting material.

The diagram below shows the two different rapid traverse modes:



G00 Axis Movement

Linear Interpolation (G01)

The Linear Interpolation code (G01) moves the axes to a specified location at the programmed feedrate. Up to five axes (X, Y, Z, A, B) of coordinated motion can be specified while in this mode. The programmed feedrate can be changed by adding an F word to any NC block while in this mode. X, Y, Z, A, B, and F dimensions need to be supplied only if they change.



G01 is a member of the tool positioning code group and is *canceled* by G00, G02, G03 and the canned cycle (G73, G76, G81–G89) commands.

G90 specifies absolute dimensioning and G91 specifies incremental dimensioning.

G41 or G42 may be optionally selected if a cutter offset is desired.



This code is used when the tool is in contact with the work piece to cut a line parallel to an axis or at an angle to an axis.

Format


The format of the linear interpolation command is as follows:

G01 X_____ Y_____ Z_____ A_____ B_____ F_____

F specifies the associated feedrate along the tool path. If rotary axis parameters (A and B) are used, the feedrate units are in degrees/minute.

Example

The diagram below illustrates the linear interpolation axis movement:



G01 Axis Movement

Circular and Helical Interpolation (G02 and G03)

These two codes are members of the tool positioning code group. The Clockwise Circular or Helical Interpolation code (G02) causes the axes to generate an arc or helix in a clockwise direction. The previous block's end point defines the start point of the arc.

- ⇒ If the first segment in a contour is an arc with a radius smaller than the radius of the tool, the +-control will generate an error message indicating that you need to use a tool with a smaller radius or program a larger radius.

The Counterclockwise Circular or Helical Interpolation code (G03) causes the axes to generate an arc or helix in a counterclockwise direction. The previous block's end point defines the start point of the arc.

- ⇒ Calculate the linear feedrate to verify that it does not exceed various limit values.

⇒ Both G02 and G03 codes are *anceled* by G00, G01, the canned cycle (G73, G76, G81–G89) commands, or by each other.

The programmed feedrate can be changed by adding an F word to any NC block when this code is active.

G17, G18, or G19 specify plane of interpolation.

G41 or G42 may be optionally selected if a cutter offset is desired.

G40 is used to *cancel cutter offset*.

G02 or G03 cannot be used in a start up block in offset mode.

(X,Y) for G17, (X,Z) for G18, and (Y,Z) for G19 specify the end location on the selected plane.

R or the incremental coordinates ((I,J) or (I,K) or (J,K)) specify the arc center location. The R is modal and stays in effect until another R value is specified or (I,J) is used. With the R (radius) parameter, you specify the radius. You do not need to calculate the center point.

- A positive R produces an arc of less than or equal to 180°.
- A negative R produces an arc of greater than or equal to 180°.
- The R takes precedence over an I, J, or K in the same block.

For BNC, I, J, K, and R are modal for G02 and G03. The I, J, and K center point location is incremental from start point in G91 mode and absolute coordinates in G90 mode.

For ISNC, when G02 or G03 are specified, the I, J, and K are reset to 0.0. They remain modal until another G02 or G03 is encountered. R is not reset to 0.0. For ISNC, the I, J, and K are incremental from the start point in both G90 and G91 mode.

⇒ You can specify an R value for arcs when the arc is in the G17 XY plane or the G19 YZ plane.

Arcs use the right-hand coordinate system for all planes, except when using Basic NC for the G18 XZ plane. Arcs use a left-hand coordinate system when using the Basic NC for the G18 XZ plane.

When interpreting an arc in ISNC, a helix will be the result if a valid center point was established in the previous block and only a Z value is given.

F specifies the feedrate in degrees/minute along the arc in the circular plane.

Format

The formats of the Circular Interpolation commands are as follows:

Circular interpolation (Z = 0)


Helical interpolation (Z ≠ 0)

G02/G03 (for G17) X_____ Y_____ {R_____ or [I_____ and J_____]}Z_____ F_____

G02/G03 (for G18) X_____ Z_____ {R_____ or [I_____ and K_____]}Z_____ F_____

G02/G03 (for G19) Y_____ Z_____ {R_____ or [J_____ and K_____]}Z_____ F_____

This diagram illustrates circular and helical interpolation:



Circular and Helical Interpolation

G02 Example

Consider the following section of an NC program using a G02 code in absolute mode using R to specify the modal turn radius:

```
NC Part Program           1           Inch
G02.FNC

%
G00 G90
M25
T1 M06
Z5.05
X2.0 Y0.0
S2000 M03
Z0.05
G01 Z-0.5 F10.
G01 X2.0 Y0.0
G01 X0.5
```


A and B words are not allowed in circular interpolation mode. The programmed feedrate can be changed by adding an F word to any block while in this mode.

X, Y, and Z define the end point of the arc and I, J, and K define the center point of the arc. I represents the X center point; J represents the Y center point; and K represents the Z center point. The X, Y, Z, and F words do not need to be programmed when you are initially setting the circular interpolation mode if they have not changed from the previous block.

For BNC, the I, J, and K dimensions must be specified when initially setting the circular interpolation mode (when a G02 or G03 is in the block) to establish a center point.

For ISNC, I, J, or K are set to 0.0 if they are not initially specified.

Once the circular interpolation mode is set, the X, Y, Z, I, J, K, and F dimensions need to be supplied only if they change. A block with missing dimensions uses the last specified locations.

⇒ A circle or circular helix may be programmed by either using the same end and start point, or by not programming the end points. Ensure that the specified end point is mathematically on the arc.

If the programmed end point is not on the arc or helix, an end point is calculated using the start point, center point, and programmed end point. The start point and center point determine the radius of the arc and thus the distance of the calculated end point from the center point. The center point and programmed end point determine the line on which the calculated end point results.

⇒ Arcs in this system are approximations that are comprised of small line segments or arc chords.

The chord error of arcs and helices may be controlled through the *chord error* parameter in the Program Parameters screen. The default chord error is 0.0001 inches (.003 mm). This creates very smooth arcs, but may limit the maximum feedrate for the arc or helix. Larger chord errors allow higher feedrate arcs or helices, but may be less accurate.

3D Circular Interpolation (G02.4 and G03.4)

The 3D Circular Interpolation (G02.4 and G03.4) codes are part of the tool positioning code group. These codes require two lines of NC code:

- The first line contains a set of X, Y, and Z values which represent the Intermediate Point.
- The second line contains a set of X, Y, and Z values which represent the End Point.

The Radius, Direction (CW or CCW), and Center Point are calculated based on the current location, the Intermediate Point, and the End Point. G02.4 and G03.4 can be used interchangeably to represent the same arc. The actual direction is calculated by the software.

⇒ Both G02.4 and G03.4 codes are canceled by G00, G01, the canned cycle commands (G73, G76, G81-G89), or by each other.

The programmed feedrate can be changed by adding an F word to any NC block when this code is active.

G17, G18, G19 are irrelevant for these G codes.

G41 and G42 may not be used with these G codes.

Example

Below is a program example using G03.4:

```
%  
T1 M6 S500 M3  
G0 X0 Y0 Z6  
G1 X0 Y0.0 F5.  
Z0  
G3.4 X5.0 Y2.5 Z1.0          (Intermediate Point)  
X10.0 Y0.0 Z0.0            (End Point)  
G0Z6  
M2  
E
```

Dwell Mode (G04)

The Dwell Mode code (G04) causes the machine to delay the shift to the next block in the program by the amount specified by parameter P or X for a specified amount of time. When an integer is used with the G04 command, the value is multiplied by 0.01 for BNC and .001 or .0001 for ISNC depending on the Least Dwell Units programmed on the NC Parameters screen.

The BNC format for the dwell time is as follows:

Real Number: .3 second = G04 X.3 or G04 P.3

Integer Number: .3 second = G04 X30 or G04 P30

This is the ISNC format for the dwell time programmed with a real number:

Real Number: .3 second = G04 X.3 or G04 P.3

When .001 is programmed for the Least Dwell Units field on the NC Parameters screen, the ISNC format for the dwell time programmed with an integer is this:

Integer Number: .3 second = G04 X300 or G04 P300

When .0001 is programmed for the Least Dwell Units field on the NC Parameters screen, the ISNC format for the dwell time programmed with an integer is this:

Integer Number: .3 second = G04 X3000 or G04 P3000

The Dwell Mode code is only active in the programmed block, but the dwell time is modal and it affects most of the canned cycles.

Format

G04 P_____ or X_____

The P or X parameters specify seconds. The range of values is 0.001–9999.999 seconds.

Surface Finish (G05.1)

The code determines the type of finish quality, Pn. When n = 1, the Surface Finish Quality is Precision. When n = 2 the Surface Finish Quality is Standard. When n = 3 the Surface Finish Quality is Performance. The parameter Qm sets the chord segment for the finish, where m is the acceptable error value.

Data Smoothing (G05.2)

This code has two components.

Pn enables or disables the process. When n = 0, NC Block Smoothing is Off. When n = 1, NC Block Smoothing is On.

Qm sets the Tool Path Tolerance. The deviation from the tool path the system will tolerate, m, must be between 0 to 0.0005 inches, inclusive (0 to 0.012 mm).

Surface Finish Quality (G05.3)

The G05.3 command is used with the Select Surface option.

G05.3 P_, where the P value is 1.0 to 100.0. P1 gives a smoother surface but requires a longer cutting time. P100.0 cuts down time to cut the part, but gives a rougher surface finish.

Precision Cornering (G09)

The Precision Cornering code (G09) decelerates the axes to zero velocity at the end of the block in which it is programmed. After stopping, the axes accelerate to the programmed feedrate in the next block. This causes a sharp corner to be cut regardless of the programmed feedrate. The G09 code is not part of a G code group, so it affects only the axis movement of the block in which it is specified.

Setting Work Coordinate Systems with G10

This code is used for setting tool offsets, entering tool wear data, and changing work coordinate systems. The G11 command cancels the data setting mode.



G10 commands can not be performed by graphics at the same time that the program is running.

Setting External Work Zero Offsets (G10 with L2)

One of six work coordinate systems can be changed as shown below where P is used to select the external work zero point offset value (P parameter = 0), or one of the work coordinate systems (P parameter = 1 to 6), and X, Y, Z, A, B is the work zero point offset value of each axis. G90 specifies absolute dimensioning and G91 specifies incremental dimensioning.

Format

The command format for setting external work zero offsets is as follows:

```
G10 L2 P____ X____Y____Z____ A ____ B ____
```

Setting Tool Offsets with G10

This code is used for setting tool length and radius offsets. The G11 command cancels the data setting mode.

Initializing Tool Length Offsets (G10 with P, R)

G10 is used with the P and R parameters. P is the offset number 01 through 200, and R is the offset amount which may be absolute or incremental depending on G90 or G91.

Format

This is the command format for initializing tool length offsets:

```
G10 P____ R____
```

Initializing Tool Offsets (G10 with T, H, D)

G10 is used with the T, H and D parameters. The T parameter is the offset number 01 through 200, H is the tool length offset and D is the tool radius offset.

Format

This is the command format for initializing tool offsets:

```
G10 T____ H____ D____
```

Assigning Tool Offsets (G10 with L3)

The following example shows how to assign tool offsets. T is the tool number, H is the tool length offset number, and D is the cutter compensation (offset) number.

Format

The command format for assigning tool offsets is as follows:

```
G10 L3 T_____H_____D_____
```

Example

The following tool offset initialization example shows how to set up a program to assign offsets to the tools.

```
G10L3  
T0001 H_____ D_____ (for tool 1)  
T000n H_____ D_____ (for tool n)  
G11 (to cancel)
```

⇒ The tool number does not require leading zeroes.

Polar Coordinates Command (G16)

This command allows coordinates in the current block to be input in polar coordinates (radius and angle). The first coordinate in the currently selected plane is the radius coordinate in mm, and the second coordinate in the plane is the angle in degrees. For the XY plane, the X value represents radius and the Y value represents the angle.

G16 is canceled by G15 (Polar Coordinates Cancel).

Format

The command format for Polar Coordinates is as follows:

```
G16 X_____ Y_____ Z_____
```

Example


Select Metric mode for the following sample program using the Polar Coordinates command:

```
NC Part Program          1          Metric  
PIE.FNC  
  
%  
T1 M06  
M03 G00 G90 X0 Y0 Z0 S1800  
G01 Z-.25 F20.
```

G01 G16 X50. Y60.
G03 X50. Y120. R50.
G15
G01 X0 Y0
M02

Plane Selection

The three codes in the plane selection group and their relationships to each other are illustrated below:



Plane Selection Group Codes

XY Plane Selection (G17)

The XY Plane Selection code (G17) is the default and sets the plane for circular interpolation modes G02 and G03 to the XY plane. The X, Y, Z, I, and J words are valid in circular interpolation blocks; K words are invalid. If a Z word is programmed in the circular interpolation block, a helix is generated in the XY plane. The direction of an arc or helix in the XY plane can be determined by looking at the XY plane with positive X to the right and positive Y going up. The XY plane is a right-handed coordinate system (thumb points to positive Z, and fingers wrap in counterclockwise direction).

In G17, the arc end point is defined by the X and Y words in the block. The arc center point is defined by the I and J words in the block.

G17 is canceled by G18 and G19.


Format

The format of the XY plane selection command is as follows:

G17 X____ Y____

Example

The diagram below illustrates XY plane selection:



XY Plane Selection (G17)

XZ Plane Selection (G18)

The XZ Plane Selection code (G18) sets the plane for the circular interpolation codes G02 and G03 to the XZ plane. The X, Y, Z, I, and K words are valid in circular interpolation blocks; J words are invalid. If a Y word is programmed in the circular interpolation block, a helix is generated in the XZ plane. The direction of an arc or helix in the XZ plane can be determined by looking at the XZ plane with positive X to the right and positive Z going up.

Basic NC and ISNC handle the XZ plane differently. For Basic NC, the XZ plane is a left-handed coordinate system (thumb points to positive Y, and fingers wrap in clockwise direction). For ISNC, the XZ plane is a right-handed coordinate system (thumb points to positive Y, and fingers wrap in a counterclockwise direction).

In G18, the arc end point is defined by the X and Z words in the block. The arc center point is defined by the I and K words in the block.

G18 is canceled by G17 and G19.


Format

The format of the XZ plane selection command is as follows:


G18 Z____ X____

Example

The diagrams below illustrate XZ plane selection in Basic NC and in ISNC:



Basic NC XZ Plane Selection (G18)



ISNC NC XZ Plane Selection (G18)

YZ Plane Selection (G19)

The YZ Plane Selection code (G19) sets the plane for circular interpolation codes G02 and G03 to the YZ plane. The X, Y, Z, J, and K words are valid in circular interpolation blocks; I words are invalid. If an X word is programmed in the circular interpolation block, a helix is generated in the YZ plane. The direction of an arc or helix in the YZ plane can be determined by looking at the YZ plane with positive Y to the right and positive Z going up. The YZ plane is a right-handed coordinate system (thumb points to positive X, and fingers wrap in counterclockwise direction).

In G19, the arc end point is defined by the Y and Z words in the block. The arc center point is defined by the J and K words in the block.

G19 is canceled by G17 and G18.


Format

The format of the YZ plane selection command is as follows:

G19 Y____ Z____

Example

The diagram below illustrates YZ plane selection:



YZ Plane Selection (G19)

Units of Measure ISNC G20, G21

Before setting the coordinate system at the beginning of the program, the units of measure must be specified in an independent block. A part program may switch between English and Metric modes as long as the format of the dimensions is correct for the chosen mode.

The Imperial Units of Measure code (ISNC G20) signals the system that the dimensions are in inches.

ISNC G20 is canceled by G21.

The Metric Units of Measure code (ISNC G21) signals the system that the dimensions are metric units.

ISNC G21 is canceled by G20.

Format

These are the command formats for the inch/metric conversion commands:

ISNC:

G20: Inch command

G21: Metric command



The ISNC G20 and G21 codes do not affect the units of measure used in the graphics and machine status display screens. The displays are controlled by the units selected when entering NC editing.

Automatic Return To and From Reference Point (G28 and G29)

Any point within the machine coordinate system can be selected as the reference point. The return to reference point is often used to move the part forward so you can remove chips from the part and inspect the part. Select the reference point on the NC Parameters screen.

The Automatic Return To Reference Point command (G28) specifies an automatic return to the reference point for the designated axes. An intermediate point can be specified with the X____Y____Z____ parameters. If no intermediate point coordinates are specified, the system uses the previous intermediate point coordinates. If no intermediate point coordinates are specified during the current program execution, the machine returns directly to the reference point.

The Automatic Return From Reference Point command (G29) specifies an automatic return from the reference point through the intermediate point, if specified by a previous G28, and to the end point designated by the X, Y, and Z parameters. If no intermediate point coordinates were specified during the current program execution, the machine will return directly from the reference point to the specified end point.

G28 Format

The format for the automatic return to reference point command is:

G28 X____ or Y____ or Z____

These parameters specify the absolute or incremental location of the intermediate point in coordinates relative to the current coordinate system. The G28 command is only performed for the axes which follow the G28. For example, if an X value follows the G28, the machine moves to the X reference point, not the Y or Z reference point.

As another example, a typical method to home the Z axis using incremental mode is shown below. The combination of G91 and a value of zero for the Z axis causes the Z axis to move directly to the home (reference) point without moving through an intermediate point.

```
G91 G28 Z0
```

```
G90
```

```
.  
.   
.
```

G29 Format

The format for the Automatic Return to Reference Point command is:

G29 X____ Y____ Z____

When the G29 command is given, the system returns to the most recently used working coordinate system. These parameters specify the absolute or incremental location of the

end point in coordinates relative to the current coordinate system in effect when the G28 command was processed.

Example

This sample program uses G28 and G29 to return the spindle to and from the reference point. Set Part Zero to X12 Y9 before running the program.

```
NC Part Program           1           Inch
PLAIN_28.FNC
%
G00 X0 Y0 Z0
G28 X-7 Y-8
G29 X3 Y-4
M02
```

Skip (Probing) Function (G31)

The Skip Function command is used to perform probing within an NC program, allowing you to specify a target position. The machine axis will stop when the target position is reached, or if the probe comes in contact with another surface. The Skip Function command can be programmed on a PC, but it can only be run properly on the control. On a PC, the command works similarly to the Linear Interpolation (Cutting Feed) (G01) command. The Skip Function command is a one-shot command and is only effective in the current block.

Two-touch and single-touch probing is supported. These modes are selected with the M41 and M42 codes. Two-touch probing is the default probing mode.

When performing two-touch probing (M42 specified), the probe moves in the specified direction until it touches the part, backs up away from the part, and then moves forward again at a feedrate of F/10. When the probe touches the part again, the trigger point is stored in variable #5061 (X axis), #5062 (Y axis), or #5063 (Z axis) with the NCPP option. The NCPP option allows you to create macro subroutines and use conditional statements and math functions. (Refer to [NCPP Option](#) for more information about the variables and subprograms.)

When performing one-touch probing (M41 specified), the probe does not back up after the first touch.

Values may be written to tool offset variables so they can be viewed after running the program on the Tool Offset screen. If the system does not have the NCPP option, the values need to be recorded manually. A Programmed Stop (M00) command can follow the G31 block to stop the machine so you can record the machine's location.

The values which are stored are referenced to the current coordinate system (working, local, or machine). If the probe does not touch the part before the end of the movement, the end coordinate value is stored in #5061, #5062, or #5063.

The current positions of the XY and Z axes can be retrieved using the #5041, #5042, and #5043 registers. The values can then be stored into part setup using the G10 code. For example, to set the X value for work offset G54, use the following G10 command:
G10 L2 P1 X[#5041]

Format

The format for the Skip (Probing) Function is as follows:

G31 X____ Y____ Z____ and/or F____



This command cannot be performed with cutter compensation (G41, G42, G43 {with G18 or G19}, G45, G46, G47, and G48).

Example


The following program example finds the center point within a box when run on the control.

```
NC Part Program          1          Inch
G31_TEXT.FNC

%
(GO TO INITIAL PART ZERO)
G01 X0 Y0 F15.
G31 X7 F15.
#2001 = #5061
G01 X0 Y0 F25.
G31 X-7 F15.
#2002 = #5061
#2003 = [#2002+#2001]/Z
G01X#2005Y#2006F25.
N100 M00
G31 Y5 F15.
#2004 = #5062
G01 X#2003 Y0F25.
G31 Y-5 F15.
#2005 = #5062
#2006 = [#2004+#2005]/Z
(THE SPINDLE NOW MOVES TO THE CENTER OF THE BOX)
G01 X#2003 Y#2006
```

Parallel sides are assumed to be aligned with the X and Y axes. Additional programming steps will be required to determine the angle between the sides and the X and Y axes (skew angle) if the sides are not aligned. The initial part zero is set somewhere within the box.

The probe moves in the +X and then the -X direction to determine the center point between the sides in the X axis.



ISNC Skip (Probing) Function

Tool Offsets (G40–G49)

Tool Offsets include Cutter Compensation and the Tool Length Offsets and Tool Radius Offsets. Cutter Compensation G codes G40–G42 are used to control tool movement. Access the Tool Offsets from the Tool Setup screen. Select the Tool Offsets (F4) softkey. From the Tool Offsets screen, select either Tool Length (F3) or Tool Radius (F3). The softkey toggles between these selections.

- The Tool Length Offset Table contains the tool length offset (G43, G44).
- The Tool Radius Offset Table holds signed values for cutter compensation (G40–G42) and diameter compensation (G43–G48).

The measurement units for the offsets in the Tool Offset Table depend on the programmed units. If -9.5 is entered for tool offset 15, that tool offset is -9.5 inches (or -9.5 mm, depending on the unit of measurement).

The **Toggle Units softkey** on the NC Tool Offsets screen changes the units of measurement between inch and metric.

Use either the **Page Up** and **Page Down** softkeys, the PAGE UP and PAGE DOWN keys, or the scroll bar to scroll through all of the Tool Offset fields. The keyboard up and down arrows move through the fields displayed on the screen.


Cutter Compensation (G40–G42)

Cutter compensation may be used for two purposes. First, it may be used when the dimensions in the program and the part surface are the same. The system calculates the proper tool path by using the part surface and the tool diameter information.

Second, cutter compensation corrects the difference between the diameters of the tool specified and the tool actually used to cut the part. This situation often occurs when the program originates from an off-line device. Note that the coordinates of those programs are usually tool center line data.

- ⇒ If the first segment in a contour is an arc with a radius smaller than the radius of the tool, the control will generate an error message indicating that you need to use a tool with a smaller radius or program a larger radius.

Cutter compensation is based on the direction of travel of the tool. To determine which type of cutter compensation to use, look at the part as if you are moving around the part always keeping the tool ahead of you. Then it becomes obvious whether the tool needs to be on the right or the left of the programmed line or the boundary of the part as shown in the illustration below.



Cutter Compensation

Cutter Compensation – ISNC and Basic NC Programming Differences

You may program cutter compensation using ISNC or Basic NC. There are differences between the two. For example, programming cutter compensation using ISNC requires that you use D codes. This is not the case with Basic NC. Other differences include how ISNC and Basic NC interpret D code values.

Tool Radius Offset

ISNC

To program cutter compensation using ISNC, you must use a D code. The D code specifies an index into the Tool Offset Table or an actual offset value. For example, in the command G41 D5, the index value is an actual offset value of 5.



An error will be generated if there is a decimal point.

You may access the Tool Radius Offset Table from the Tool Length Offset screen. The Tool Radius Offset page contains 200 registers for storing radius offsets.

Basic NC

To program cutter compensation using Basic NC, you may choose whether or not to use a D code. If you do not use a D code, Basic NC will use the value in the Diameter Comp field from the Tool Setup screen.

If you use a D code, Basic NC interprets the D code value based on whether you are calling out a tool change or commanding a G41 or G42.

If you use a D code when calling out a tool change, enter the actual tool diameter. Basic NC divides this value by two to calculate the tool diameter offset.

If you are programming a G41 or G42 code, Basic NC interprets the D code based on whether the D code value contains a decimal point:

- Contains a decimal point – Basic NC interprets the D value as the tool diameter offset
- Does not contain a decimal point – Basic reads the D value as an index value for the Tool Offset table

Tool Length Offset

You may use a G43 code to program tool length offsets. This is true for ISNC and Basic NC. Use an H code to specify an index into the Tool Offset Table. For example, in the command G43 H01, the index value is "01".

The value in the Tool Offset Table is a negative value that represents the distance from the Z home position to the top of the part with the tool tip touching the top of the part.



Another way to program a tool length offset would be to use the Zero Calibration field in the Tool Setup screen, and not use the G43 H code. This is recommended, especially if you are using the Tool Probing software.

Cutter Compensation Off (G40)

The Cutter Compensation Off code (G40) is the default. It cancels cutter compensation by erasing all the data in the system's cutter compensation look-ahead buffers and moving to the current uncompensated endpoint at the programmed feedrate.

G00 or G01 must be selected in order for this command to cancel the offset compensation. Each axis moves straight (G01) or at rapid traverse (G00) from the point of the old vector at the start point toward the end point. The machine should be in G40 mode before the end of a program. Otherwise, when the program ends in the offset mode, positioning cannot be made to the terminal point of the program, and the tool position will be separated from the terminal position by the vector value.

Format

The command format for Cutter Compensation Off is as follows:

G40 X____ Y____

If the parameters are omitted, the tool moves the old vector amount in the opposite direction which effectively cancels the offset.



It is possible to switch from left to right cutter compensation (and vice versa) without first canceling cutter compensation.

Cutter Compensation Left (G41)

The Cutter Compensation Left code (G41) switches on cutter compensation. It establishes a new tool path left and parallel to the programmed path. The distance between the new tool path and the programmed path is equal to the cutter compensation value for the programmed tool.

G41 is canceled by G40.

The offset executes only in the G17 offset plane. In simultaneous three-axis control, the tool path projected on the offset plane is compensated.

G00, G01, G02, or G03 must be specified.

Format

The command format for cutter compensation left is as follows:

G41 X ____ Y____ D____

If the offset number for cutter compensation is D00, the system will not go into G41 mode.

Cutter Compensation Right (G42)

The Cutter Compensation Right code (G42) switches on cutter compensation and establishes a new tool path right of and parallel to the programmed path. The distance between the new tool path and the programmed path is equal to the cutter compensation value for the programmed tool.

G42 is canceled by G40.

This command is an offset method similar to G41 except that the offset is to the right of the programmed path looking in the direction in which the tool is advancing. The offset is performed only in the G17 offset plane. Only the coordinate values of an axis in the offset plane are affected by the offset. In simultaneous three-axis control, the tool path projected on the offset plane is compensated.

G00, G01, G02, or G03 must be specified.

Format

The command format for cutter compensation right is as follows:

G42 X _____ Y _____ D _____


If the offset number is D00, the system will not go into G42 mode.

Cutter Compensation Programming

Follow these steps to use cutter compensation:

1. Enter the part surface description according to the final dimensions of the part.
2. Enter the full cutter diameter as a positive number in the Diameter Compensation field in Tool Setup, or supply a D word when changing tools (Basic NC only).
3. Activate cutter compensation in the desired direction (left or right of part surface with respect to tool path direction).
4. Supply an entry move from somewhere outside the part to the start point of the part surface, i.e., somewhere outside of the compensated path. The part surface appears as a blue line on the graphics display.
5. Following all of the blocks to be compensated, provide an *exit move* to somewhere outside the compensated path and turn off cutter compensation (G40). When a G40 is programmed, cutter compensation extracts any remaining information from its look-ahead buffer and moves to the last programmed end point. The tool moves from the compensated end point of the previous move to the end point of the exit move.
6. Be certain that the exit move is outside the compensated path. Otherwise, turning off cutter compensation may cut into the part surface. To check the exit move, use graphics to verify the tool path movements.

The tool moves from the start point of the entry move and ends at the compensated start point for the part surface as shown in the graph below:



1	Part
2	Actual Tool Path
3	Programmed Move

Cutter Compensated Tool Movement

In the previous illustration, the value in the Diameter Compensation field is 1.00, and these codes were used to control tool movement:

- G00 G40 X5. Y5.
- G41 X7. Y2.



Z movements may be used for the entry and exit moves. For example, turn on cutter compensation when moving to a Z Start plane before plunging. Turn off cutter compensation after retracting the tool from the part.



Turn off cutter compensation using a G40 code before ending a program or all programmed blocks may not be cut.



Refer to [NC Parameters](#) for information about the DEFAULT CUTTER COMP LOOK AHEAD field in the NC Parameters screen.

Tool Length Offset (G43, G44, G49)

Tool offsets, G43 and G44 tool length compensation codes, are used to compensate tool length without altering the NC program. G43 is for positive tool length compensation. G44 is for negative tool length compensation. Either the G49 command, or an H00 command, immediately cancels the offset.

The tool offset specified by a G43 or G44 overrides the tool length offset from the Zero Calibration field on the Tool Setup screen. The Zero Calibration field on the Tool Setup screen is always treated as a negative Z offset. For example, if a value of 3.0 is put in the Zero Calibration field, a Z offset value of -3.0 is stored. If the command G43 H1 is then used where the value -2.2 is stored in the H1 offset register, WinMax uses a tool offset of -2.2. The table below illustrates tool offsets:

Tool Setup Screen Zero Calibration	Tool Length Offset Mode	H1	Total Tool Offset
3.0	G43	-2.2	-2.2
3.0	G44	-2.2	+2.2
3.0	G49	-2.2	-3.0
3.0	G49	+2.2	-3.0
3.0	G43	+2.2	+2.2
3.0	G44	+2.2	-2.2

Table 5. Tool Offsets



The values in the Tool Setup screens always remain in the units selected when going into the NC Editor.

For Basic NC (BNC)

An H address may specify an index into the tool length offset table without specifying a G43 or G44. In such a case, the value in the tool length offset table is used as the tool offset. This is equivalent to the Zero Calibration field on the Tool Setup screen.

For BNC and ISNC, if the system is in the G43 and G44 mode already, an H code can be used by itself to replace the existing tool length already in effect.

⇒ If no G43 or G44 is programmed and an H offset is not specified, tool lengths are taken from the Tool Setup screen.

An offset in the X axis can be specified with the G19.

An offset in the Y axis can be specified with the G18.

If a G17 is provided, or none of the plane selection commands (G17, G18, and G19) is present, specify an offset in the Z axis.

The G17, G18, and G19 used in this block are only used to specify the axis of the tool offset and will not affect the specified plane.

An offset in the X or Y axis cannot be specified when cutter compensation is active or commands G45–G48 are being used.

Commands G45–48 support existing X or Y axis tool offset programs; however, to save time, automatic Cutter Compensation (G40–G42) should be used instead.

Commanding an H00 cancels an offset.

Either G43 or G44 is in effect until a G49 or H00 is used.

Format

The H is the Offset Code with a range of H00 to H200. G17 is optional when a Z axis offset is desired.

[G17 _____] or [G18 _____] or [G19 _____] H_____

The following four examples illustrate tool length offset H codes with the G43 and G44 codes. Tool 1 had a value of 5.0 for the Zero Calibration field on the Tool Setup screen. The Tool Length Offset 1 value is –6.0 and the Tool Length Offset 2 value is –7.5.

Example 1

T01 M06

With these offsets, the calibrated tool length will be 5.0. That length is taken from the Tool Setup screen)

Example 2

T01 M06

H02

At this point, the calibrated tool length will still be 5.0 because no G43 or G44 has been entered.

Example 3

T01 L4.0 M06

G43 H01

At this point, the calibrated tool length is 6.0 because the L value was superseded by the offset value of 6.0.

Example 4

T01 M06 - sets the tool length to be 5.0

H02 - tool length remains 5.0

G43 - tool length remains 5.0

H02 - sets the tool length to be 7.5

Tool Radius Offset (G45–G48)



ISNC and Basic NC – the tool used for cutter compensation must be smaller than or equal to the arc that you have programmed. If the tool radius is greater than or equal to the arc radius, the compensated tool path will sweep in the opposite direction of the programmed arc.

The tool position offset commands increase or decrease the amount of axis movement. Offset values within the following ranges can be selected for the tool radius offset commands:

	<u>mm input</u>	<u>inch input</u>
Offset Value	0~±999.999 mm	0~±99.999 in.
	0~± 999.999°	0~±999.999°



G45–48 support existing X or Y axis tool offset programs. However, to save time, use the automatic Cutter Compensation (G40-G42) instead.

Tool Radius Offset Increase (G45)

This command increases the specified block's tool radius offset amount by the value stored in the offset value memory.

Tool Radius Offset Decrease (G46)

This command decreases the specified block's movement amount by the value stored in the offset value memory.

Tool Radius Offset Double Increase (G47)

This command increases the specified block's movement amount by twice the value stored in the offset value memory.

Tool Radius Offset Double Decrease (G48)

This command decreases the specified block's movement amount by twice the value stored in the offset value memory.

Format

The command format for the tool position offsets is as follows:

GXX X____Y____Z____A____B____D____

GXX is an optional Interpolation (Group 1) move command, and D is the offset command. The number which follows D is an index into the tool offsets table. The offset value is modal and needs to be specified only once. The offset is applied to all axes specified in the parameters.

Example

Set tool offset 1 to the desired offset before running the following program using the Tool Radius Offset commands (G45 through G48):

**Industry-Standard NC Part Program 1 Inch
G45_G48.FNC**

```
%  
N10 G10 P1 R0.5  
N20 G00  
N30 G90  
N40 M25  
N50 T1 M06  
N60 Z5.0 X0. Y0.  
N70 S2000 M03  
N80 Z0.05  
N90 G00 Z-0.5 F10.
```

NC Part Program
G45_G48.FNC

2

Inch

N200(INNER OUTLINE WITHOUT USING OFFSETS)
N210 G91 X4 Y4
N220 G01 X3
N230 Y1.5
N240 X4
N250 G45 Y-1.5
N260 X3
N130 G03 X1 Y1 I0. J1
N140 G01 Y4
N150 X0
N160 G02 X-2 Y2 I0. J2
N170 G01 Y0
N180 X-3
N190 Y-2.5
N200 X-3
N210 Y2.5
N220 X-3
N230 G03 X-1 Y-1 I0. J-1
N240 G01 Y-2
N250 X1
N260 Y-4
N265 Z5.05
N270 G00 X-4 Y-4
N275 G90 X0 Y0
N280(OUTER OUTLINE USING G45, G46, G47, AND G48)
N290 G91 G46 X4 Y4 D1
N300 G47 G01 X3 F20.
N305 Y1.5
N307 G48 X4
N308 Y-1.5
N309 G45 X3
N310 G45 G03 X1 Y1 I0. J1
N320 G45 G01 Y4
N330 G46 X0
N340 G46 G02 X-2 Y2 I0. J2
N350 G45 G01 Y0.
N360 G47 X-3
N370 Y-2.5
N380 G48 X-3
N390 Y2.5

NC Part Program
G45_G48.FNC

3

Inch

N400 G45 X-3
N410 G45 G03 X-1 Y-1 I0. J-1
N420 G45 G01 Y-2
N430 X1
N440 Y-4
N450 G00 G46 X-4 Y-4
N460 G00 Z5.05
N470 M25
N480 M05
N490 M02

Scaling (G50 and G51)

The G51 code is used to scale subsequent move commands by a programmable scale factor and must be in an independent block.

Scaling is not applicable to the following movement in case of canned Z axis movements. If scaling results are rounded and units less than 5 are ignored, the move amount may become zero and may affect cutter movement. Whether the scaling function is effective or not, it can be set by a parameter for each axis. The scaling function always becomes effective for the circular radius command R in the G51 mode, regardless of these parameters.

One or more axes' scaling can be disabled on the NC Parameters screen. The methods for specifying the scaling center point and the scaling factor are different with BNC and ISNC.

For BNC, X, Y, and Z are the scaling center points in absolute coordinates. The I, J, and K codes specify the scale factor for the X, Y, and Z axes. If only I is specified, all axes will be scaled by that factor. Scaling G51 codes may not be nested.

For ISNC, these two methods can be used to specify scaling parameters:

Method 1: X, Y, or Z present. X, Y, Z define the scaling center point. If I, J, or K are present, they define the scaling factors. If they are absent and P is present, the P value defines the scaling factor for all three axes. If P is an integer (no decimal point) the value is multiplied by the least scaling factor parameter on the NC Parameters screen; otherwise, the exact P value is used.

Method 2: X, Y, or Z absent. I, J, K define the scaling center point. P provides the scaling factor if provided for all three axes. If P is an integer (no decimal point) the value is multiplied by the least scaling factor parameter on the NC Parameters screen; otherwise, the exact P value is used.

Format

The format of the BNC scaling code is as follows:

G51 X___ Y___ Z___ I___ J___ K___

The format of the ISNC scaling code is as follows:

Method 1: G51 X___ Y___ Z___ (I___ J___ K___ or P___)

Method 2: G51 I___ J___ K___ P___



The smallest unit of scaling is either 0.001 or 0.00001 when an integer P value is provided. The Least Scaling Factor field on the Configuration Setup screen is used for setting the smallest unit of scaling.

If scaling factors are not specified, the default scaling factor 1.0 is used.

If the scaling center point is not specified, the G51 command point is used for the scaling center.

Scaling can be enabled/disabled for a particular axis on the Configuration Setup screen.

Example

Here is a BNC sample using the scaling codes:

Using G91 — G00 X20. Y20.

G51 X40. Y40. I.5

G01 X40.


Y40.

X-40.

Y-40.

G50

The following diagram illustrates the previous code sample:



G51 Scaling Code



The Scaling (G51) command must always be canceled with a Cancel Scaling (G50) command.

Mirror Image (G50.1 and G51.1)

Mirroring (G51.1) and Mirroring Cancel (G50.1) commands are used when the shape of the workpiece is symmetric to an axis. The whole part can be prepared by programming a subprogram and using programmable mirror imaging. Ordinary mirror image comes after the programmed mirror image. The first movement command must be absolute when in this mode. The following actions occur when the mirror image is applied to only one axis composing a plane:

- Circular Command: CW and CCW are reversed.
- Cutter Compensation: Right and Left Offset are reversed.
- Coordinate Rotation: Rotation angle becomes reversed.

Format

The formats of the mirroring codes are as follows:

G51.1 X___ or Y___ or Z___

G50.1 [X0] or [Y0] or [Z0]

Specifying a G50.1 with no X, Y, or Z parameter cancels the mirroring code in the X, Y, and Z axes. The coordinates about which the tool path will be mirrored are in absolute values. The mirroring codes create the following special conditions:


- For circular commands CW and CCW are reversed.
- Cutter compensation for Right and Left are reversed.
- Mirroring G51.1 codes may not be nested.

G51.1 is used to mirror a tool path about the X, Y, or Z axis while G50.1 is used to cancel mirroring for the X, Y, or Z axis.

⇒ This mode is canceled by G50.1. The first movement command after a G50.1 command must be an absolute command. This mode must not be specified in the G68 or G50 mode.

Example

In the illustration below, part #1 (in the upper right corner) is mirrored three times into part #2, #3 and #4. Note that the direction of the tool path (shown as directional arrows numbered 1, 2, and 3) on each part changes with each mirroring operation:



BNC G50.1 and G51.1 Mirroring Codes

The following program example mirrors the part as shown in the example from the previous page:

```


NC Part Program                               1                               inch
MIRROR.FNC

%
N10 (FIG 7-94 MIRRORING EXAMPLE)
N42 ( )
N44( MAIN PROGRAM )
N46 ( )
N50 M98 P8888
N60 (2-PART#1 MIRRORING IN X)
N70 G51.1 X1.5
N80 M98 P8888
N90 (3-MIRRORING CONTINUED IN Y)
N100 G51.1 Y1.5
N110 M98 P8888
N120 (CANCEL INITIAL X & Y MIRROR)
N130 G50.1

```


Example

This illustration shows setting a local coordinate system using the G52 command:



Setting Local Coordinate System Using G52

The following is a sample program, which uses G52 to set local coordinates:

```

NC Part Program                                1                                Inch
LOC_COOR.FNC

%
N10 G00 G90
N40 M25
N45 X0 Y0
N50 T1 M06
N60 Z5.
N90 S2000 M03
N100 Z0.05
N110 M98 P2121
(USE LOCAL COORD SYSTEM)
N240 G52 X-1.5 Y-1.5
N320 G65 P2121
N380 G52 X1.5 Y-1.5
N390 M98 P2121
N430 G52 X0 Y-3
N440 M98 P2121
N430 Z5.
N1170 M25
N1190 M05
N1200 M02
O2121
N500 X1
    
```

NC Part Program	2	Inch
------------------------	----------	-------------

LOC_COOR.FNC
N510 Y1
N520 X0
N530 Y0
M99

Machine Coordinates (G53)

This Machine Coordinates (G53) command moves the tool to the X,Y,Z, A, B machine coordinate position at rapid traverse. This command is only effective in the block in which it is specified and in Absolute mode (G90). The system reverts to the last commanded work coordinate system.

If a local coordinate (G52) is used before a machine coordinate (G53) is commanded, the local coordinate is canceled when the system goes back to the last commanded coordinate system. Reinstate the local coordinate system with another G52.

Format

The format of the machine coordinates command is as follows:

G53 X____Y____Z____ A ____ B ____

Example

Before running this sample program, set the shift offsets to X0 Y0 Z0 and set part zero to X2.0 Y3.0 and Z1.0.

NC Part Program	1	Inch
------------------------	----------	-------------

MACHCOOR.FNC

%
G00 G90
M25
X0 Y0
T1 M06
Z5.
S2000 M03
Z0.05
G01 X1 F30.
Y1
X0
Y0
(USE MACHINE COORD SYSTEM)
G01 G53 X0
G53 X1 F30.
G53 Y1
G53 X0

NC Part Program

2

Inch

MACHCOOR.FNC

G53 Y0

G53 G00 Z5.

M25 M05

M02

E



When running a program on the control, do not use negative shift offsets with G28 or G53. An error message will occur since the negative machine positions cannot be implemented.

Multiple Work Coordinate Systems (G54–G59)

These modal commands select the work coordinate systems 1–6. The work coordinate systems are affected by the work offsets, the shift offset, and the G92 (Set Part Zero) command. Coordinate system 1 is the same as the part setup and it is the default coordinate system. Coordinate systems 1–6 are established by manually entering work offset values for G55–G59 on the Work Offset screen or with the G10 command.

Use the G10 command to set tool offsets, enter tool wear data, and change work coordinate systems, and use the G92 command to set part zero. All six work coordinate systems can be moved an equal distance and direction by using the G92 command.

Format

The format of the multiple work coordinates command is as follows:

G54 (Select work coordinate system 1)

G55 (Select work coordinate system 2)

G56 (Select work coordinate system 3)


G57 (Select work coordinate system 4)

G58 (Select work coordinate system 5)

G59 (Select work coordinate system 6)

Example

When in the NC mode, the Part Setup screen has the Work Offsets (F1) softkey to display up to six work coordinates (G54–G59) and a set of shift offset values. As shown below, these codes are used to set multiple part zeroes for multiple parts fixtured to the table and milled consecutively using the same part program.



Work Offset G Codes for Multiple Parts

The coordinates defining G54 are the part zero coordinates for the original part defined on the Part Setup screen. Set the X, Y, and Z values for the G54 to G59 codes. These work offsets are stored in memory, but not with the part program.

The G54 work offsets are the same registers as those in the Part Setup screen for Part Zero X, Y, and offset Z. Editing G54 work offsets for multiple coordinate systems updates the part setup for X, Y, and Z on the Part Setup screen.

Aux Work Coordinate Systems (G54.1)

There are 93 additional X, Y, Z, and optional Rotary A and B work offsets available in NC programming. To access any of these offsets call G code **G54.1 Pn**, where **n** is 1 thru 93. For example, to change to auxiliary work offset 46, call **G54.1 P46** in the NC program.

To update work offset values, use data setting G code **G10 L20 Pn** to set the Auxiliary work offsets values. For example, to update work offset 46 value call **G10 L20 P46 X12.5 Y3.0 Z-0.5**

Precision Cornering On (G61) and Off (G64)

Precision cornering allows non-tangent blocks to be milled with precise corners, regardless of programmed feedrate.

⇒ Precision cornering works differently on machines that have the UltiPro II option installed. Please use the tables below to determine how precision cornering will operate on your machine.

The NC Precision Cornering codes work in the following manner in standard Hurco machines. If you have the UltiPro II option installed, refer to the Precision Cornering with UltiPro II Option table.

Code	Action
G61	Causes the axes to decelerate to zero velocity at the end of a block, if the blocks are not tangent. Tangency is defined as an angle of 5° or less between two consecutive blocks. If the angle is greater than 5°, the system stops and then accelerates to the programmed feedrate in the next block.
G64 (default)	Causes the axes to decelerate to zero velocity at the end of a block, if the blocks are not tangent. Tangency is defined as an angle of 44° or less between two consecutive blocks. If the angle is greater than 44°, the system stops and then accelerates to the programmed feedrate in the next block. The first line is marked as a stop when complete.

Table 6. Standard Precision Cornering

The NC Precision Cornering codes work in the following manner in Hurco machines that have the UltiPro II option installed. If you do not have the UltiPro II option installed, please refer to the Standard Precision Cornering table.

Code	Action
G61	Causes the axes to decelerate to zero velocity at the end of a block, if the blocks are not tangent. Tangency is defined as an angle of 44° or less between two consecutive blocks. If the angle is greater than 44°, the system stops and then accelerates to the programmed feedrate in the next block. The first line is marked as a stop when complete.
G64 (default)	Causes the axes to traverse all blocks at a constant feedrate and blends for constant surface finish with no regard to tangency. The first line is not marked as a stop when complete.

Table 7. Precision Cornering with UltiPro II Option

Special Program Support

Rotation (G68 and G69)

The Coordinate Rotation (G68) command turns on coordinate system rotation, and the Coordinate Rotation Cancel (G69) command turns off coordinate system rotation.

Format

The G68 code uses this format to command rotation:

G68 (XY___ or XZ ___ or YZ___) R___

When the G17 plane is used, X and Y addresses are used in the format to describe the center point. When G18 is used, X and Z describe the center point. If the plane is defined using G19, the Y and Z addresses define the center point.

R specifies the angle of rotation. A positive R value indicates a CCW direction, and a negative R value indicates a CW direction. When the coordinate values of rotation center are omitted, the current position is used as the center point.

The range of R depends on whether BNC or ISNC is selected and whether an integer or decimal value is specified. Here are the R ranges for each NC type:

BNC: R has a range of -360.0 to +360.0, whether an integer or real number is used.

ISNC: Units of R have a value of 0.001° when R is an integer.

R has a range of $-360,000 \leq R \leq 360,000$ when R is an integer value.

R has a range of -360.0 to +360.0 when R is a real number.

Rotation is canceled with a G69. Do not use G17, G18, or G19 while in the G68 mode. Use G69 to disable the G68 mode, change the plane, and then go back to the G68 mode.

⇒ G68 codes may not be nested.

Example

This program uses the rotation codes:

ISNC Part Program	1	Inch
G68.FNC		

```
%  
(USING REAL NUMBER WITH G68)  
T1 M06  
Z5.05  
G01 Z-0.5 F10.  
G91 X1.0  
Y2.0  
X-1.0  
Y-2.0  
(CANCEL ROTATION)  
G69  
(USING INTEGER NUMBER WITH G68)  
G68 X0 Y0 R45000  
X1.0  
Y2.0  
X-1.0  
Y-2.0  
(CANCEL ROTATION)  
G69  
M05  
M02
```

Units of Measure (BNC G70, G71)

Before setting the coordinate system at the beginning of the program, the units of measure must be specified in an independent block. A part program may switch between English and Metric modes as long as the format of the dimensions is correct for the chosen mode.

The Imperial Units of Measure code (BNC G70 signals the system that the dimensions are in inches.

BNC G70 is canceled by G71.

The Metric Units of Measure code (BNC G71 signals the system that the dimensions are metric units.

BNC G71 is canceled by G70.

Format

These are the command formats for the inch/metric conversion commands:

BNC:

G70: Inch command

G71: Metric command



The BNC G70 and G71 codes do not affect the units of measure used in the graphics and machine status display screens. The displays are controlled by the units selected when entering NC editing.

Peck Drilling (G73)

For Peck Drilling, the spindle moves down in incremental steps and retracts to a position set on the Holes Parameter screen. After each peck, the drill is retracted by the Peck Clearance Plane value set on the General Parameters screen. These screens are described earlier in this manual.

Spindle positioning is performed on the XY plane and hole machining is performed on the Z axis. These parameters are stored as modal values; therefore, if a parameter value does not change for subsequent drilling commands, those commands do not have to contain the parameter.


Format

The command format for the Peck Drilling canned cycle is as follows:

G73 X____, Y____, Z____, R____, Q____, F____, [K____ or L____]

Example

The diagram below illustrates tool movement for the G73 command:



Tool Movement for the Peck Drilling Cycle (G73)

Left-Handed Tapping Cycle (ISNC G74)

During the Left-Handed Tapping Cycle the spindle rotates CCW to the bottom of the hole. Then the spindle stops, an optional dwell is performed, the spindle rotates CW, and left-handed tapping is performed.

The positioning for this cycle is performed on the XY plane and hole machining is performed on the Z axis. During left-handed tapping, the feedrate override is ignored and the cycle does not stop until the end of the return operation, even if a feed hold is applied.

If a Start Spindle Clockwise (M3) code is in effect, the spindle direction will be reversed prior to executing a G74 cycle. Rigid Tapping is performed when an Enable Rigid Tapping (ISNC M29) code is used in a block previous to the G74 block.

Format

The command format for the Left-Handed Tapping cycle is as follows:

G74 X____, Y____, Z____, R____, P____, F____, [Q____,]
[K____, or L____].



Z is the distance from the R Point (in Return to R Point in Canned Cycle [G99] mode) to the Z Bottom or the distance from the Initial Point (in Return to Initial Point in Canned Cycle [G98] mode) to the Z Bottom.

Q is the optional peck depth. If Q equals 0.0, pecking is not performed. Q used for G74 with M29 applies only to rigid tapping.

Single-Quadrant Circular Interpolation (BNC G74)

The Single-Quadrant Circular Interpolation Mode (G74) causes the system to interpolate arcs and helices in a single quadrant only. The arc or helix must remain within the quadrant in which it started (the arc or helix cannot be larger than 90°). Since the arc cannot cross quadrants, the center point is determined by looking toward the center of the arc from the start point. I, J, and K are unsigned incremental distances from the arc start point to the center of the arc.

G74 is canceled by G75.

Multi-Quadrant Circular Interpolation (BNC G75)

The Multi-Quadrant Circular Interpolation Mode (G75) is the default and causes the system to interpolate an arc or helix across all quadrants. The arc or helix can start and end in any quadrant. An arc or helix may be up to 360° in this mode. The center point data can be represented in two different ways based on the current machine dimension mode (G90 and G91).

G75 is canceled by G74.

Bore Orient (G76)

The Bore Orient cycle provides a feed-in, stop-feed, orient spindle, move tool away from part surface, rapid-out, and spindle restart sequence suitable for boring operations when the tool needs to be moved away from the part surface before retracting out of the hole. If the default Bore Orient Retract vector is not suitable, I and J words may be used to specify a new retract position.

A value needs to be entered in the Bore Orient Retract field on the Holes Parameters screen (described earlier in this manual). That value specifies the distance the X and Y axes travel to retract the tool from the part surface during the Bore Orient cycle.

A spindle oriented stop is performed at the bottom of the hole and the spindle retracts after shifting in the direction opposite to the cutter direction. High precision and efficient boring is performed without scratching the workpiece surface.

⇒ The Bore Orient G86 mode continues to be supported to provide compatibility with existing BNC programs.

The bore orient cycle moves the axes in this manner:

1. The spindle should already be switched on.
2. The spindle positions the tool at the rapid speed to the XY location, if necessary.
3. The spindle moves down at the specified feedrate to the Z value.
4. The spindle stops and orients.
5. The spindle moves from the XY location to the IJ position or to the Bore Orient Retract distance.
6. The system rapidly moves Z to the initial Z location.

⇒ This cycle applies only to machines that have an electronic or mechanical orient feature (refer to the machine tool owner's manual).

Format

The format of the Bore Orient cycle is as follows:

G76 X____, Y____, Z____, [I____, J____, or Q____] R____, P____, F____,
[K____, or L____]

⇒ I and J may also be used instead of Q to specify an incremental bore shift value and direction. If Q is used, the Q value must be a positive number; otherwise, an error message will occur.


For BNC, Q and I, J are optional to maintain compatibility with older programs. A default Z value of 1.0 will be used for BNC if a Q word is not contained in the same block with the G86 command. Q is not modal for BNC.



The Q value is modal. Since Q is used as the cut-in value for G73 and G83, use care when specifying Q.

Example

The diagram below illustrates tool movement for the Bore Orient cycle:



Tool Movement for the Bore Orient Cycle (G76)

Canned Cycle Cancel (G80)

Canned Cycle Cancel is a machine default mode and cancels all canned cycles. When a cycle is canceled using a G80, program execution returns to the One-Shot (G00, G01, G02, or G03) mode that was in effect before the canned cycle was executed. Use either G00, G01, G02, or G03 to cancel a canned cycle.

The G80 cycle also cancels the R and Z Points. That is, $R = 0$ and $Z = 0$ for the incremental command. Other drilling data are also canceled.

Drill, Spot Boring (G81)

The Drill, Spot Boring cycle is a feed-in, rapid-out sequence. The axes move in this manner with the spindle switched On:

1. Ensure that the initial Z location is above Z bottom and above any obstructions.
2. The tool is positioned at the Initial Z location and moves at the rapid speed to XY if it is in the block.
3. The spindle drills down to Z Bottom at the specified feedrate.
4. The spindle moves up to Z Start at the rapid speed.

Format

The command format for Drill cycle is as follows:

G81 X____, Y____, Z____, R____, F____, [K____, or L____]


Example

This is a sample BNC Drilling cycle:

G81 Z1.0000 (inches) G90 or G91

Here is a sample ISNC Drilling cycle and a tool movement diagram:

G81 Z-1.0000 (inches) in G91 mode



Tool Movement for the Spot Boring Cycle (G81)

Drill with Dwell, Counter Boring (G82)

The Drill with Dwell, Counter Boring cycle provides a feed-in, dwell, and rapid-out sequence.


Format

The command format for the Drill with Dwell cycle, or Counter Boring, is as follows:

G82 X____, Y____, Z____, R____, P____, F____, [K____, or L____]

Example

This diagram illustrates tool movement for the Counter Boring cycle:



Tool Movement for the Counter Boring Cycle (G82)

Deep Hole Drilling (G83)

The Deep Hole Drilling cycle provides a sequence of feed-in and rapid-out movements until the specified hole depth is reached.

For BNC, each feed-in moves the distance of the peck depth. The tool will rapid back to the Z Start position.

For ISNC the tool will rapid out to the Return point.

Next the tool will rapid down until it reaches the starting point for the next peck (for either BNC or ISNC). The starting point is an incremental distance above the last peck, defined on the Holes Parameter screen as the Peck Clearance Distance.

BNC has three Z values: Z1, Z2, and Z3. They may be programmed in this canned cycle and are unsigned incremental distances. There is a rapid traverse back to R at the end of each pecking cycle and then the tool feed begins above where the tool stopped during the last pecking cycle.



Z1 is the total depth for the hole.

Z2 is the depth of the first peck.

Z3 is the depth for each of the remaining pecks.

Z2 and Z3 must be smaller than Z1.

If Z2 and Z3 are not programmed, this canned cycle functions like G81.

If Z3 is not programmed, Z2 is the depth for each peck. The last peck for the hole is the programmed peck depth or the remaining distance from the last peck to the bottom of the hole, whichever is smaller.

If Z1, Z2, and Z3 do not change between G83 blocks, they need not be reprogrammed. Use the Precision Cornering codes (G61 and G64) to control the Z axis deceleration between pecks.

Format

The command formats for the Deep Hole Drilling cycle are as follows:

BNC: G83 X____,Y____, Z____, [Z____,] [Z____,] R____,
F____,[K____, or L____]

⇒ For BNC, the first Z is the distance from Z Start to Z Bottom. The second Z is the first cut-in depth. The optional third Z is the depth of the remaining pecks. The Zs are always positive. All of the peck depths will be the same if the third Z is left out.


For BNC, R is always positive and is an incremental distance from the initial point to point R.

ISNC: G83 X____,Y____, Z____, R____, Q____, F____,
[K____, or L____]

⇒ ISNC has one Z parameter which represents the location of Z Bottom.

Example

The diagram below illustrates tool movement for the G83 code:



Tool Movement for the Deep Hole Drilling Cycle (G83)

Tapping (G84)

The Tapping cycle provides a tap sequence. The current feedrate (F) and spindle speed (S) are used. The spindle accelerates to the defined speed and the Z axis plunges at the defined feedrate. At the bottom of the hole, the spindle and Z axis decelerate in coordination to a stop. They then reverse directions and accelerate in coordination to the programmed feed and speed. Once back to the original Z level, the spindle shuts off and reverses back to the original direction in preparation for the next operation.

For BNC, G84 is used for right- and left-handed tapping. Start Spindle Clockwise (M3) or Start Spindle Counterclockwise (M4) commands determine whether right- or left-handed tapping is performed.

For ISNC, G84 performs right-handed tapping only. A Start Spindle Counterclockwise (M4) command causes the system to reverse the spindle direction at the start of the cycle to ensure that right-handed tapping is performed.

Use the following formula to calculate the correct feed and speed for the tap cycle:

Feedrate:

Feed in inches or mm per minute = Spindle RPM / threads per inches or mm

Spindle RPM:

Spindle RPM = Feed in inches (mm) per minute × threads per inch (mm)

⇒ When an M3/M4 command is detected in a program and the current tool in the spindle is defined as a tapping tool in tool setup, the system looks 10 blocks ahead for another tap cycle, a G01/G02/G03 code, or a canned cycle other than a tap. If any cutting move (G01, G02, G03, or any canned cycle other than a tap) is found within 10 moves or 10 rapid moves are found, the spindle is turned on as usual. If a G84 is found and all moves from the M3/M4 are rapid moves, the spindle is not turned on, and the rapid moves will be executed with the spindle off.

The spindle rotates clockwise to the bottom of the hole. At the bottom of the hole, the spindle is reversed and rotates counterclockwise and tapping is performed. During the tapping, the feedrate override is ignored and the cycle does not stop until the end of the return operation, even if a feed hold is applied.

For ISNC, a Rigid Tap Enable (M29) command initiates rigid tapping instead of regular tapping. Rigid Tap is disabled with a G00, G01, G02, G03, or G80 command. The programmed feedrate can be overridden for rigid tapping.

Format


The command format for the Tapping cycle is as follows:

G84X____, Y____, Z____, R____, P____, F____, [Q____,] [K____, or L____]

- ⇒ P is used only with ISNC for the Tapping cycle. P specifies a dwell period at the bottom of the hole and after leaving the hole.
- Q, the optional peck depth, is only used with ISNC for the Tapping cycle. If Q equals 0.0, pecking is not performed. M29 is required with Peck for Rigid Tapping.

Example

The diagram below illustrates tool movement for the Tapping cycle (G84):



Tool Movement for the Tapping Cycle (G84)

Boring (G85)

The Boring cycle provides a feed-in and feed-out sequence suitable for boring.

The boring cycle moves the axes in this manner:

1. The spindle should already be switched on using an M3 code.
2. The tool is positioned over the hole location.
3. At the G85, the spindle feeds to Z Bottom as specified.
4. At Z Bottom, the spindle feeds to the Z Start position.

⇒ It is possible to have an XY position move with the G85 code.


Format

The command format of the Boring cycle is as follows:

G85 X____, Y____, Z____, R____, F____, [K____, or L____]

Example

The diagram below illustrates tool movement for the Boring cycle (G85):



Tool Movement for the Boring Cycle (G85)

Bore Rapid Out Cycle (ISNC G86)

The ISNC Bore Rapid Out canned cycle is a feed-in, rapid-out sequence. The spindle stops at the bottom of the hole and is retracted at the rapid traverse rate.

The Bore Rapid Out canned cycle moves the axes in this manner with the spindle switched on:

1. The tool is positioned at the Initial Z location and moves at the rapid speed to XY if it is in the block.
2. The spindle bores down to Z Bottom at the specified feedrate.
3. The spindle turns off.
4. The spindle moves up to Z Start at the rapid speed.
5. The spindle turns on.


Format

The command format for the Bore Rapid Out cycle is as follows:

G86 X____, Y____, Z____, R____, F____, [K____, or L____]

Example

This diagram illustrates tool movement for the Bore Rapid Out cycle:



Tool Movement for the Bore Rapid Out Cycle (G86)

Chip Breaker (BNC G87)

The Chip Breaker cycle provides drilling with a dwell every 0.050" (1.27 mm) to break off the chip. The dwell time is automatically calculated so the spindle revolves two times to break the chip. After the dwell, the system feeds another 0.050" (1.27 mm) and again breaks the chip until the bottom of the hole is reached. This cycle breaks the chip without retracting the tool entirely from the hole as with the Deep Hole Drilling cycle (G83). Use the Precision Cornering codes (G61 and G64) to control the Z axis deceleration between dwells.

The Chip Breaker cycle moves the axes in this manner with the spindle switched on:

1. The tool is positioned at the rapid speed to XY if necessary.
2. The spindle moves down 0.05" at the feedrate.
3. The spindle dwells at that location for two rotations.
4. The spindle moves down another 0.05" at the feedrate.
5. This is repeated until the Z depth is reached.
6. The spindle moves at the rapid speed to the initial Z location.

Format

The format of the Chip Breaker cycle is as follows:

G87 X___ Y___ Z___ F___, [K___, or L___]

Back Boring (ISNC G87)

The Back Boring cycle provides a boring sequence in the positive Z direction. Boring is performed from the specified R level to the Z level. Positioning is performed on the XY plane and hole machining is performed on the Z axis.

Format

The command format for the back boring cycle is as follows:

G87 X___, Y___, Z___, R___, Q___, I___, J___, P___,
F___, [K___, or L___]




R is used to specify the depth to which the bore moves before shifting over Q or IJ and moving up to the Z level.

Q is used to store an incremental bore shift value. I and J may also be used instead of Q to specify an incremental bore shift value. I and J can be used to specify a distance and direction. Q can only specify distance; the direction is pre-defined by machine parameters.

ISNC G87 Example

The drawing below illustrates tool movement for the Back Boring cycle (ISNC G87):



Tool Movement for the Back Boring Cycle (ISNC G87)

Rigid Tapping (BNC G88; ISNC G84.2; ISNC G84.3)

Rigid tapping allows the same hole to be tapped repeatedly with precision. The rigid tapping feature increases accuracy by synchronizing the rotation of the spindle with the feed of the Z axis. ISNC G84.2 is used for right-handed tapping, and ISNC G84.3 is used for left-handed tapping. M29 is required for Rigid Tapping.

The format of the rigid tapping cycle is as follows:

M29

G88X____, Y____, Z____, Z____, R____, F____, P____
 [K____, or L____]

or

M29

G84.2X____, Y____, Z____, Z____, R____, F____, P____
 [K____, or L____]

or

M29

G84.3X____, Y____, Z____, Z____, R____, F____, P____
 [K____, or L____]

⇒ The second Z parameter defines the peck depth.

Canned Boring with Manual Feed Out and Dwell (ISNC G88)

With this canned cycle, a dwell is performed at the bottom of the hole and the system goes into Interrupt mode. The spindle can then be retracted manually using the jog controls. When the desired manual position is reached, follow these steps:

1. Press the console Auto button (in Machine Mode group).
2. The Start button starts flashing and the "Press Start Button" message displays.
3. Press the Start button.
4. The program finishes the canned cycle and then continues with the rest of the program.


Format

The command format for the Boring With Manual Feed Out and Dwell canned cycle is as follows:

G88 X____, Y____, Z____, R____, I____, J____, P____, F____, [K____, or L____]

Example

The drawing below illustrates tool movement for the Canned Boring with Manual Feed Out and Dwell cycle (ISNC G88):



Tool Movement for ISNC G88 Cycle

Bore with Dwell (G89)

The Bore with Dwell cycle provides a feed-in, dwell, and feed-out sequence.

The Bore with Dwell cycle moves the axes in this manner with the spindle switched on:

1. The tool positions at the rapid speed to XY position, if necessary.
2. The spindle moves down at the feedrate to Z Bottom.
3. The spindle stays at the Z Bottom position for the specified dwell time.
4. The spindle moves Z up to Z Start at the rapid speed.


Format

The command format for the Bore with Dwell cycle is as follows:

G89 X____, Y____, Z____, R____, P____, F____, [K____, or L____]

Example

The drawing below illustrates tool movement for the Bore with Dwell cycle (G89):



Tool Movement for the Bore with Dwell Cycle (G89)

Absolute and Incremental (G90, G91)

The Absolute Machining Mode (G90) is the default and signals the system that the programmed dimensions are relative to part zero. Once programmed, this default stays in effect until canceled with a G91.

The Incremental Machining Mode (G91) signals the system that all programmed dimensions are incremental distances from the position in the previous block. Once programmed, this mode stays in effect until canceled with a G90.

If Absolute Machining Mode (G90) is activated, the center points I, J, and K are absolute Cartesian (rectangular) coordinates from part zero.

If Incremental Machining Mode (G91) is activated, the center points I, J, and K are signed incremental distances from the arc start point.

Format

This is the command format for each position command:

Absolute command:

G90 X_____Y_____Z_____

Incremental command:

G91 X_____Y_____Z_____

Example

A machine is resting at the programmed part zero location, and the following blocks are executed in inches:


```
N2 G01 X1.0 Y1.0 F10.0
```

```
N4 X1.0 Y1.5
```

If the system is in Absolute Machining mode (G90), the N2 block causes the axes to travel at a 45° angle to the 1.0" position in X and 1.0" in Y. As a result of the N4 block, the machine remains at the 1.0" position in X and Y moves to the 1.5" position.

If the system is in Incremental Machining mode (G91), the N2 block causes the axes to travel at a 45° angle to the 1.0" position in X and the 1.0" position in Y—just as before. But, as a result of the N4 block, X continues to move 1.0" to the 2.0" position; Y moves 1.5" to the 2.5" position.

The diagram below illustrates absolute and incremental axis moves.



Differences Between Absolute and Incremental

Coordinate System Setting

This section explains the commands used for these coordinate system settings: part zero, machine coordinates, multiple work coordinates, local coordinates, polar coordinates, and automatic return to and from reference point.

Part Zero Setting (G92)

This command establishes the work coordinate system so that a certain point of the tool, for example the tool tip, becomes X, Y, Z, A, B in the established work coordinate system. The distance shifted with this command is added to all subsequent work coordinate system zero point offset values; all work coordinate systems move by the same distance. The G92 command can be used in any work coordinate system (G54–G59).

⇒ Cancel Scaling (G50) must be active before selecting G92.

A G92 command makes the dimensions included in the block the new part relative position for the current machine location. The new part zero location is calculated from the current location of the axes and the dimensions included in the G92 block.

The part zero location is only altered for dimensions programmed in the G92 block. This makes it possible to alter the part zero locations for certain axes without affecting the others.

G92 is invalid while *cutter compensation* is on.

Format

This is the format of the setting part zero command:


G92 X_____Y_____Z_____A_____B_____

Example

Set Part Zero (G92) establishes new part relative coordinates at the current axis positions. For example, if the machine is positioned at part relative X2.0 and Y2.0, the block G92 X0.0 Y0.0 would make the current X and Y axis part relative positions equal 0.0. The machine axes will not move, but the status screen changes to reflect the new part zero reference point(s). Any programmed coordinates after the G92 block are referenced to the new part zero location(s).

Use the G92 code for repeating parts of a program at another location. The following is a sample of the codes used in incremental mode. Refer to the diagram below for an illustration of these codes.

```
NC Part Program                               1                               Inch
PARTZERO.FNC
%
N10 G0 X20. Y20.
N12 X40.0
N14 Y40.0
N16 X20.0
N18 Y20.0
N20 X70.
N22 G92 X0.    ← Set new part zero
N24 X20.0
N26 Y40.0
N28 X0.0
N30 Y20.0
M02
```



Set Part Zero (G92)

Feed Functions

The Feedrate (F words) value establishes the non-rapid move feedrate. It remains active for all non-rapid moves until another Feedrate code is entered.

For Inch units in Basic NC, the actual feedrate is dependent on the usage of a decimal point. If no decimal point, the actual feedrate is one-tenth of the programmed feedrate (F30 equates to 3 inches per minute). If a decimal point is specified then the actual feedrate will be the programmed feedrate (F30.0 is 30 inches per minute). For metric units in Basic NC, the actual feedrate is the same as the programmed feedrate regardless of a decimal point (F75 and F75.0 are both 75 millimeters per minute).

The Feedrate code is active before the other commands in the program block are executed. G94, Feed per Minute Feedrate, is the default setting unless otherwise specified.

Inverse Time Feedrate (G93) and Feed Per Minute Feedrate (G94)

The default setting for Feedrate is G94 for Feed per Minute Feedrate, either inches per minute or millimeters per minute. G93 cancels G94 and G94 cancels G93.

Inverse Time (G93) can be specified to change the feedrate as a function of time and distance. If the time is unchanged but the distance changes then the actual feedrate will change proportionally. The format for Inverse Time is F6.3 (maximum of six digits before the decimal point and maximum of three digits after the decimal point) and the units are minutes. Feedrates of up to 999999.999 can be programmed using G93. The time is computed by dividing one by the Inverse Time programmed. The actual feedrate is the distance divided by the time.



The feedrate must be specified for every move.

Example

```
G93 G1 X5.0 F10.0
```

```
Y7.0 F10.0
```

Time is $1/10.0\text{min} = 0.1\text{min}$

Actual Feedrate for first line is $5.0\text{in}/0.1\text{min} = 50\text{ipm}$.

Actual Feedrate for second line is $7.0\text{in}/0.1\text{min} = 70\text{ipm}$.

Format

```
G93 X____ Y____ Z____ A____ C____ F____ (activate Inverse Time)
```

```
  X____Y____ Z____ A____ C____ F____
```

...

```
G94 X____ Y____ Z____ F____ (cancel Inverse Time and enable Feed Per Minute feedrate)
```

Canned Cycle Descriptions

Canned cycle descriptions, formats, and examples follow.


Return to Initial Point in Canned Cycles (G98)

Position the Z axis to the initial level. The initial level is the last position of the Z axis before the canned cycle is started. The Z axis rapids or feeds to the Z Retract Clearance level, based on the canned cycle being performed. Z Start in the canned cycle description is then equal to the initial point.

Format

G98 (no parameters follow)

Example



1	Initial Level
2	Retract Level

Return to R Plane Example

Sample NC Part Program Using G98

Below is a program example using G98:

```
%  
N1 G90 G80 G40 G21  
N2 T1M6  
N3 G43 H1 S3000 M3  
N4 Z78.0 M8  
N5 F1270.0  
N6 G99 G81 X15 Y15 R28.0 Z-10.0  
N7 Y35.0  
N8 X60  
N9 G98 Y15.0  
N10 G99 X140.0  
N11 Y35.0  
N12 X185.0  
N13 G98 Y15  
N14 G80  
N15 G0 G91 M28 Z0 M5 M9  
N16 M30  
E
```

Return to R Level in Canned Cycles (G99)

The Return to R Level in Canned Cycles command positions the Z axis to a return (R) level. The Z axis rapids or feeds to the return level between locations during canned cycles. Z Start in the canned cycle descriptions is then equal to the Return Point. Even when the canned cycle is performed in G99 mode, the initial level remains unchanged.

For BNC, specify an R with the G99.

For ISNC, the modal value of R is used.

Format

The format of this code is as follows:

G99 R____




For BNC, the R parameter is an incremental distance from the initial Z level. Use this code to reduce the returned distance between locations during canned cycles.

For ISNC, the R parameter is an absolute Z level in G90 mode and an incremental negative Z distance in G91 mode.

Example

The drawing below illustrates tool movement for the Return to R Level in Canned cycles (G99) command:



Tool Movement for the G99 Cycle

Canned Cycles

Canned cycles use a one-block G code to provide drilling, boring, and tapping operations. Using one G code instead of several helps simplify writing NC programs. Various parameters are used in common with all or most of the canned cycles. For instance, Z is used to specify the canned cycle's depth, P is used to specify dwell time, and F is used to specify the feedrate. For BNC, if there is no spindle speed and direction specified in the program, these values are retrieved from the tool page.

The table below contains canned cycles, G codes, and spindle operation while moving in the negative Z direction, being at Z Bottom, and moving in the positive Z direction.

Operation	G Codes		Spindle Operation		
	BNC	ISNC	In -Z Direction	At Z Bottom	In +Z Direction
Peck Drilling	G73	G73	Peck Feed	None	Rapid Traverse
Left Handed Tapping	G84 with M04	G74	Feed	Spindle Stop, Dwell, Spindle CW	Feed
Bore Orient	G76 G86	G76	Feed	Oriented Spindle Stop	Rapid Traverse
Canned Cycle Cancel	G80	G80	None	None	None
Drill, Spot Boring	G81	G81	Feed	None	Rapid Traverse
Drill with Dwell, Counter Boring	G82	G82	Feed	Dwell	Rapid Traverse
Deep Hole Drilling	G83	G83	Peck Feed	None	Rapid Traverse
Tapping	G84 with M03	G84	Feed	Spindle Stop, Dwell, ISNC Spindle CCW or BNC Spindle CW	Feed
Boring	G85	G85	Feed	None	Feed

Operation	G Codes		Spindle Operation		
	BNC	ISNC	In -Z Direction	At Z Bottom	In +Z Direction
Bore Orient Cycle	G86	-			
Bore Rapid Out	-	G86	Feed	Spindle Stop	Rapid Traverse
Back Boring	-	G87	Feed	Spindle Stop, Spindle Move, Spindle Start	Rapid Traverse
Chip Breaker	G87	-	Peck Feed with Dwell	None	Rapid Traverse
Boring with Manual Feed Out	-	G88	Feed	Dwell	Manual Move, Rapid Traverse
Rigid Tapping	G88	G74 with M29; G 84 with M29; 84.2; or 84.3	Feed	Spindle Stop, Dwell, Spindle Reverse	Feed
Bore with Dwell	G89	G89	Feed	Dwell	Rapid Traverse

Table 8. Canned Cycles, G Codes and Z Spindle Operations

These canned cycles are different for BNC than ISNC:

BNC-Specific Canned Cycles	ISNC-Specific Canned Cycles
G84 with M04 Left-Handed Tapping	G74—Left-Handed Tapping
G84 with M03 Tapping	G84—Tapping
G86—Bore Orient Cycle	G86—Bore Rapid Out
G87—Chip Breaker	G87—Back Boring
G88—Rigid Tapping	G74 and G84 with M29— Rigid Tapping
	G88—Boring with manual Feed Out

Table 9. BNC and ISNC Specific Canned Cycles

Canned Cycle Parameters

These parameters are used for programming the various canned cycles. They determine the spindle movement. In the pages that follow, the canned cycles are described and the parameters for each one are identified.

Parameter	Description
F	Feedrate
I	Signed, incremental distance from start point to center of spindle shift position (X axis).
J	Signed, incremental distance from start point to center of spindle shift position (Y axis).
K	Number of repeats for a series of operations in a specified block. Range = 1 through 6; Default = 1. If K = 0, drilling data is stored and no drilling is performed. The incremental distance and direction between canned cycles is determined by the previous block's position from the first canned cycle's position. K and L parameters function the same.
L	Number of repeats for a series of operations in a specified block. Range = 1 through 6; Default = 1. If L = 0 drilling data is stored and no drilling is performed. The incremental distance and direction between canned cycles is determined by the previous block's position from the first canned cycle's position. K and L parameters function the same.
P	Dwell time at the bottom of the hole.
Q	Incremental peck depth value or spindle shift distance.
R	BNC: Incremental, positive distance from the Initial Point to Point R. Only used in G99 mode for BNC. ISNC: Represents absolute Z level at which machining begins in either G98 or G99. Must be specified for all ISNC canned cycles.
X	X axis hole position data.
Y	Y axis hole position data.
Z	Defines Z Bottom location. BNC: Always a positive value. In G98 mode: incremental distance down from initial point. In G99 mode: incremental distance down from the R level. ISNC: In G90 mode: absolute Z level. In G91 mode: negative incremental value measured from the R level.

Table 10. Canned Cycle Parameters

Depth (Z Parameter)

Z is used to specify the canned cycle's depth. All canned cycles require a Z word. Z Start is the Z level where the negative Z (-Z) axis movement begins. This dimension is the same as the Return to Initial Point in Canned Cycle (G98) and the Return to R Point in Canned Cycle (G99) codes. The Z Bottom parameter is the point of maximum Z down (except for ISNC G88) and the dimension where the -Z axis movement ends.

A rapid move at the Z Start level is automatically used to move from one canned cycle block to another. Make sure the current Z Start level is high enough to clear all fixtures and obstacles.

Note the differences in the definitions for BNC and ISNC Z parameters in the previous table.

- For BNC, the current Z level should be established before invoking the canned cycle (via G00 or G01). Once a Z distance is established, it does not need to be reprogrammed until the canned cycle mode is canceled or changed.
- For ISNC, the Z word represents a negative or positive absolute Z drilling level in G90 mode which must be below the current Z level, or an incremental negative distance from the current R level in G91 mode.

Dwell (P Parameter)

Many of the canned cycles have dwell capability. The scaling factors used with the canned cycle dwell *parameter* P are the same as Dwell, Exact Stop (G04). The length of dwell time is modal and can be specified using one of these methods:

- G04 with a P or X value
- P value with a canned cycle command
- Dwell parameters on the Holes Parameters screen

⇒ Taps use the Bore Dwell parameter.

If you use the default dwell parameters on the Holes Parameters screen, G04 P0.0 or a P0.0 is required with the canned cycle command to cancel any previously commanded dwell time.

Feedrate (F Parameter)

The current feedrate is used for feed moves and may be reprogrammed in any canned cycle block by including an F word. The feedrate parameter applies only to the Z direction during canned cycles.

⇒ For BNC files, if no decimal point is included, the system automatically divides the feedrate by 10.

For ISNC files, if no decimal point is included and the Assume Feedrate .1 Increment field on the NC Parameters—Configuration Parameters screen is set to Yes, the system automatically divides the feedrate by 10.

Canceling or Replacing Canned Cycles

All canned cycles are *anceled* by G00, G01, G02, G03, (the One-Shot Group 00 G codes) or G80 (Canned Cycle Cancel).

Current canned cycles can be *replaced* with another canned cycle without first canceling the canned cycle.

If a G00, G01, G02, G03, or G80 occurs in the same block with a canned cycle command (for example G00 G85), the G00 is ignored and the canned cycle command (G85 in this case) is executed. If a G00, G01, G02, or G03 command follows a canned cycle command, the X, Y, Z parameters are used to perform the interpolation or rapid positioning, and the remaining canned cycle parameters in the block are ignored.

All canned cycle data are modal. When a canned cycle is canceled using G00 or G80, the R point, canned cycle repetition value K, and the Q (cut-in, bore shift) are canceled.

⇒ Except for tap cycles, canned cycles do not activate the spindle. The program must have a Start Spindle Clockwise (M03) or Start Spindle Counterclockwise (M04) to turn on the spindle prior to executing a canned cycle. For tap cycles, both the spindle speed and direction are retrieved from the tool library if not specified in the program. If a spindle speed is not provided with the M3 or M4, the spindle speed from the tool library is used.

Canned cycles, which turn off the spindle during the cycle, automatically restore the spindle to the original speed and direction before completing the cycle. If a canned cycle requires a certain spindle direction and the opposite spindle direction is currently in effect, the system reverses the spindle direction automatically.

SPINDLE SPEED - S CODES

The Spindle Speed code (S) specifies the spindle rotation speed. The spindle does not rotate until a Start Spindle Clockwise (M03) or a Start Spindle Counterclockwise (M04) is programmed. The software retrieves the spindle speed from the tool library if an S code is not provided.

If the S is present with an M03 or an M04 in the same program block, it is active before the other codes in the program block are executed. If an S is not specified prior to the first M03 or M04, the speed specified in the Tool Setup data is used. As soon as an S appears in the program, its value is used for the M03s and M04s that follow until a new S value is encountered.

For ISNC, if the spindle has already been turned on, the S code is sufficient for changing spindle speed. If the spindle is already turned on and an S code occurs either in a tool change block or in a block following a tool change block, the spindle ramps up to the new spindle speed after the tool change.

TOOL FUNCTIONS

These codes control tool selection: T, L, and D. The L and D codes are for BNC only. To activate these codes, an M06 code must be contained in the same block. To activate the L and D words, an M06 must be used with a T word. The NC Parameters screen contains two fields for controlling tool changes: the Default Tool Number and the M6 Initiates Tool Change.

D Codes

The Tool Diameter Offset codes (D values) are used in ISNC and BNC programs and cause the specified dimension to be loaded into the tool diameter register.

Otherwise, for BNC only, the Diameter value in the appropriate Tool Setup data is used. This dimension is used for cutter compensation, again, only for BNC.

Negative values are not permitted.

L Codes (BNC)

The Tool Length Offset (L) codes cause the specified dimension to be loaded into the tool offset register. Otherwise, the Zero Calibration value in the appropriate Tool Setup data is used.

Negative values are not permitted.

T Codes

The Tool Select (T) codes specify the tool number. The value is composed of up to two digits. Placing the T word in a block does NOT cause a tool change to occur.

If the M6 Initiates Tool Change field is set to Yes, the M06 code must be used to initiate the tool change.

If the M6 Initiates Tool Change field is set to Yes, and a program has a T Code without an M6 Code, the machine will pre-fetch the tool. When this occurs, the tool changer moves the tool carousel so the next tool is ready, but does not complete the change until it encounters the M6.

MISCELLANEOUS FUNCTIONS - M CODES

Miscellaneous Functions (M codes) cause machine-related action (e.g., coolant control and tool changes). Each Miscellaneous Function is explained below. Multiple M codes can be used within an NC block.

M Code Table

M Code	Definition
M00	Cancels the spindle and coolant functions; stops part program execution
M01	Program stop often used when the operator wants to refixture the part
M02	Marks the end of the program; stops the spindle, coolant, and axes feed
M03	Starts clockwise rotation of the spindle
M04	Starts counterclockwise rotation of the spindle
M05	Switches the spindle off
M06	Requests an automatic tool change
M07	Switches on secondary coolant systems
M08	Switches on primary coolant system
M09	Switches off both the primary and secondary coolant
M10	Switches on both the primary and secondary coolant
M20	Advances the indexer one position
M25	Retracts the Z axis to the home position (tool change height)
M26	Select Part Probe Signal
M27	Select Tool Probe Signal
ISNC M29	Enables rigid tapping
M30	Indicates the end of the main program
M32	Clamps the rotary A axis
M33	Unclamps the rotary A axis
M34	Clamps the rotary B axis
M35	Unclamps the rotary B axis
M36	Switches off the servos
M38	Reads and places the state of the laser OK signal
M39	Reads and places the state of the laser static signal
M40	Reads and places the state of the laser dynamic signal

Table 11. M Codes

M Code Table —Laser Operation

M Code	Definition
M41	Deactivates two-touch probing when using the G31 command
M42	Enables automatic two-touch probing with the G31 command. If the part probe touches during a G31 move, the probe will automatically back up and then attempt a second touch at a reduced feedrate.
M43	Increases the barrier air.
M44	Reduces barrier air.
M45	Opens the shutter.
M46	Closes the shutter.
M47	Turns the laser emitter on.
M48	Turns the laser emitter off.
M49	Turns the laser receiver on.
M50	Turns the laser receiver off.
M52	Enables auxiliary output 1.
M53	Enables auxiliary output 2.
M54	Enables auxiliary output 3.
M55	Enables auxiliary output 4.
M56	Rotates the pallet changer for a non-confirmation pallet change.
M57	Rotates the pallet changer to pallet 1.
M58	Rotates the pallet changer to pallet 2.
M59	Turns chip conveyor forward mode on.
M60	Turns chip conveyor reverse mode on.
M61	Stops the chip conveyor.
M62	Disables auxiliary output 1.
M63	Disables auxiliary output 2.
M64	Disables auxiliary output 3.
M65	Disables auxiliary output 4.
M68	Enables washdown coolant system.
M69	Disables washdown coolant system.
M76	Normal A Axis operation (default).
M77	Reverses A Axis operation.
M78	Normal B Axis operation (default).
M79	Reverses B Axis operation.
M80	C Axis is right-handed (default).
M81	C Axis is left-handed.
M98	Subprogram call.
M99	Jump; Return from subprogram.

Table 12. M Codes—Laser Operations

Program Functions

The Program Functions (M00, M01, M02, and M30) stop the execution of the part programs.

Program Stop (M00)

The Program Stop (M00) cancels the spindle and coolant functions and terminates further program execution after completion of other commands in the same program block. When the program is stopped, existing modal information remains unchanged as in single block operation. The Start Cycle button on the control flashes and this prompt message appears:

Cycle complete; press start to continue.

Pressing the Start Cycle button resumes the spindle and coolant operation and continues the program execution.

This M code should not be set simultaneously with other M codes. M00 is executed following execution of the rest of the address words on the block. Here is an example using the M00 code:

```
N10 G01 X2. Y1. F10. M00
```

In this example, the machine moves to the X2/Y1 location before it shuts down.

⇒ Program blocks should be included that retract the tool to a safe position before a block containing an M00 is programmed. If these program blocks are not included, the spindle stops while cutting the part.

Planned Stop (M01)

The Planned Stop Code (M01) pauses the program and shuts off the spindle. M01 is ignored unless previously validated in the parameter page.

- Include a data block to retract the tool to a safe position before a block containing an M01 is programmed. If the retract tool data block is not included, the spindle will stop while cutting the part.
- If you want to open the CE Safety enclosure doors after M01 executes, press the Machine Mode Interrupt console key, then press the Start Cycle button. The enclosure doors can be opened and the axes jogged. To continue with the program, close the enclosure doors and press the Start Cycle button.

⇒ You can also pause the program and shut off the spindle by selecting the NC Optional Stop On/Off softkey on the Auto Run screen or setting the NC Optional Program Stop parameter on the NC Configuration Parameters screen. Refer to [Auto Mode Monitoring](#) and [NC Parameters](#) for more information.

End of Program (M02)

The End Of Program code (M02) indicates the end of the main program (the completion of the part), and is necessary for the registration of CNC commands from tape to memory. M02 stops the spindle, the coolant, and the axis feed after completing all of the commands in the program. M02 is active after the block is executed.

- ⇒ The M02 does NOT stop the NC program loader if the program is loading from a serial link. An E character must be transmitted to signal the loader that the entire program has been sent to the remote device.

- ⇒ This M code should not be set simultaneously with other M codes unless it is the last M code in the block.

Start Spindle Clockwise (M03)

The Start Spindle Clockwise code starts a clockwise spindle rotation (as viewed from the headstock). The spindle reaches the programmed speed before X, Y, and Z (also A and B if present) axis feed starts. If the spindle speed has not been defined, the Tool Setup screen's spindle speed is used.

M03 is active before the other commands in the block are executed.

Start Spindle Counterclockwise (M04)

The Start Spindle Counterclockwise code starts spindle rotation in a counterclockwise direction (as viewed from the headstock). The spindle reaches the programmed speed before X, Y, Z (A or B) feed starts. If the spindle speed has not been defined, the Tool Setup screen's spindle speed is used.

M04 is active before the other commands in the block are executed.

Spindle Off (M05)

The Spindle Off code is the default and causes the spindle to stop in a normal manner. If the machine is equipped with a brake, it is applied. The coolant is also turned Off.

M05 is active after the other commands in the block are executed.

M6 Initiates Tool Change

Use this field on the NC Parameters screen to indicate whether tool changes are initiated with the M6 or with the T code. Set this field to No and the M6 is ignored and tool changes are initiated whenever a T code is found in the program (not when T is used for user-defined subprogram or subprogram parameter).

If this field is set to Yes, the M6 is required for tool changes.

If this field is set to Yes and a T code is used without the M6, the machine will “pre-fetch” the tool. When this occurs, the tool changer moves the tool carousel so the next tool is ready, but does not complete the change until it encounters the M6.

Change Tool (M06)

The Change Tool code requests that the machine perform a tool change. These tool changes should be performed in rapid traverse mode. The following sequence occurs if an automatic tool changer is present and in the Auto Tool Change mode:

1. The Z axis retracts to tool change position.
2. The machine moves the X and Y axes to the Tool Change position if the tool change position parameter is set to Yes.
3. The spindle orients and stops.
4. The “old” tool is returned to the tool changer.
5. The “new” tool is placed in the spindle.
6. New tool offsets from the Tool Offset screen are loaded into the appropriate registers. The Tool Length Offsets from G43 and G44 remain in effect.
7. The program continues.



The M06 is optional if the M6 Initiates Tool Change field on the NC Parameters screen is set to Yes; otherwise, tool changes are performed with the T code.

This sequence occurs for manual tool changes:

1. Z axis retracts to its tool change position.
2. The machine moves the X and Y axes to the Tool Change position if the tool change position parameter is set to Yes.
3. The spindle stops and orients.
4. The screen prompts for a tool change.
5. Change the tool and press the Start Cycle button on the control to allow the program to continue.
6. New tool offsets are loaded into the appropriate registers.
7. The program continues.

⇒ The first Z dimension after a tool change must be absolute. Any Z dimension programmed in a tool change block is ignored.

Secondary Coolant On (M07)

The Secondary Coolant On code switches on the mist coolant, if available. M07 is active before the other commands in the block are executed.

Primary Coolant On (M08)

The Primary Coolant On code switches on the flood coolant, if available. M08 is active before the other commands in the block are executed.

Both Coolant Systems Off (M09)

The Coolant Off code is the default and switches off the coolant if it has been activated by Secondary Coolant On (M07) or Primary Coolant On (M08). M09 is active after the other commands in the block are executed.

Both Coolant Systems On (M10)

The Both Coolant Systems On code switches on the coolant if it has been activated by Both Coolant Systems Off (M09).

Clamp C-axis (M12)

The Clamp C axis code clamps the C axis. For C axis moves after M12, the C axis is automatically unclamped for the move and clamped again after the move is complete.

M12 is active before the other commands in the block are executed and is canceled by an Unclamp C axis (M13) command.

Unclamp C-axis (M13)

The Unclamp C axis code unclamps the C axis until an M12 is programmed.

M13 is active before the other commands in the block are executed and is canceled by a Clamp C axis (M12) command.

Oriented Spindle Stop (M19)

The Oriented Spindle Stop code causes the spindle to stop in the oriented position. A brake, if available, will be applied. The coolant is also turned off. This function only applies to machines which have an orient feature. On machines without the orient feature, this function works like the Spindle Off (M05) command.

M19 is active after the other commands in the block are executed.

Pulse Indexer One Increment (M20)

The Pulse Indexer One Increment code advances the *indexer* one position. A reply signal is sent back from the indexer to indicate when it is in position. When the signal is received, the program continues. For multiple indexes, separate M20 blocks must be programmed. (Refer to the indexer's manual and the *Hurco Maintenance Manual* for information on attaching an indexer to the machine.)

M20 is active after the other commands in the block are executed.

Z Axis to Home Position (M25) - Basic NC Programming only

The Z Axis to Home Position code retracts the Z axis to the home position (tool change height) at the rapid traverse rate selected in the Program Parameters screen. The first Z value after an M25 must be absolute.

M25 is active before the other commands in the block are executed.

Select Part Probe Signal (M26)

When G31 is used to invoke probe motion, the machine will move to the specified destination until either the destination is reached or a probe deflection occurs. The Select Part Probe Signal (M26) alerts the G31 move to detect a part probe deflection.

Select Tool Probe Signal (M27)

When G31 is used to invoke probe motion, the machine will move to the specified destination until either the destination is reached or a probe deflection occurs. The Select Tool Probe Signal (M27) alerts the G31 move to detect a tool probe deflection.

Enable Rigid Tapping (ISNC M29)

When Enable Rigid Tapping (M29) is used before a Left-Handed Tapping Cycle (ISNC G74) or Taping Cycle (G84) command, rigid tapping is performed. M29 stays in effect until a One-Shot (G00, G01, G02, G03) code or Canned Cycle Cancel (G80) command is used.

End Program (M30)

This command indicates the end of the main program and is necessary for the registration of CNC commands from *tape* to memory. When the end of program command is executed, the CNC enters a *reset state* and the program returns to the beginning. Cycle operation may be stopped, and the CNC unit may reset depending on the machine tool. The CNC tape is rewound to the start of the program in both memory and tape operation. However, when using a tape reader without reels, the tape is not rewound. When using a tape reader with reels, the tape returns to the ER (%) code at the start of the tape even if several programs exist. Some machines indicate tape rewind with the End of Program (M02) command.



This M code should not be set simultaneously with other M codes unless it is the last M code in the block.

Clamp A-axis (M32)

The Clamp A-axis code clamps the A axis. For A axis moves after M32, the A axis is automatically unclamped for the move and clamped again after the move is complete.

M32 is active before the other commands in the block are executed and is canceled by an Unclamp A axis (M33) command.

Unclamp A-axis (M33)

The Unclamp A axis code unclamps the A axis until an M32 is programmed.

M33 is active before the other commands in the block are executed and is canceled by a Clamp A axis (M32) command.

Clamp B-axis (M34)

The Clamp B axis code clamps the B axis. For B axis moves after M34, the B axis is automatically unclamped for the move and clamped again after the move is complete.

M34 is active before the other commands in the block are executed and is canceled by an Unclamp B axis (M35) command.

Unclamp B-axis (M35)

The Unclamp B axis code unclamps the B axis until an M34 is programmed.

M35 is active before the other commands in the block are executed and is canceled by a Clamp B axis (M34) command.

Servo Off Code (M36)

The servos may be turned off using the Servo Off (M36) command.

Control power to the machine will be turned off. The control will still be powered on. This is similar to an emergency stop.

Laser Input Update (M38-M40)

These codes read the state of the three laser inputs (M38: OK signal; M39: static signal; and M40: dynamic signal).

Single-Touch Probing (M41)

For a G31 probing move, perform one touch.

Double-Touch Probing (M42)

For a G31 probing move, perform two touches. This is the default mode.

Barrier Air Control (M43 and M44)

Barrier air is used to prevent chips and debris from getting into the laser emitter and receiver. M43 causes the air flow at the probe to increase; M44 reduces the airflow. During operation of the probe, the barrier air should be increased whenever the probe shutter is open. It should remain at the high flow rate except during the actual tool measurement. When the shutter is closed, the flow rate may be reduced.

Shutter Probe Control (M45 and M46)

A pneumatic shutter protects the probe. During a measurement, the barrier air should be increased and the shutter opened. After the probe cycle is completed, the shutter should be closed and the barrier air reduced. M45 causes a brief puff of air that helps clear chips and debris from the probe. M46 closes the shutter.

Laser Emitter On/Off Control (M47 and M48)

M47 turns the laser emitter on. M48 turns the laser off. It is recommended to turn the laser emitter off when not in use.

Laser Receiver On/Off (M49 and M50)

M49 turns the laser receiver on. M50 turns the laser receiver off. It is recommended to turn the laser receiver off when not in use.

Enable Auxiliary Output 1 through 4 (M52 – M55)

M52 through M55 are used to individually enable auxiliary equipment or a unique machine function from within a part program. Enter performance time for the machine-specific M code in the M Code Table. When M52 through M55 are active, the corresponding auxiliary equipment or machine function is turned on, and any performance time is added to estimated run time.

M52 enables Auxiliary Output 1, M53 enables Auxiliary Output 2, M54 enables Auxiliary Output 3, M55 enables Auxiliary Output 4.

Nonconfirmation Pallet Change (M56 – M58)

M56 rotates the pallet changer without regard to position or pallet setup confirmation. M57 rotates the pallet changer to pallet 1. M58 rotates the pallet changer to pallet 2.

Chip Conveyor Fwd/Reverse/Stop (M59, M60, M61)

M59 enables chip conveyor forward mode. M60 enables chip conveyor reverse mode. M61 stops the chip conveyor motion.

Disable Auxiliary Output 1 through 4 (M62 – M65)

M62 through M65 turn off auxiliary equipment or machine functions enabled with M codes M52 through M55.

M62 disables Auxiliary Output 1 (M52), M63 disables Auxiliary Output 2 (M53), M64 disables Auxiliary Output 3 (M54), and M65 disables Auxiliary Output 4 (M55).

Washdown Coolant System (M68, M69)

M68 enables washdown coolant system. M69 disables washdown coolant system.

Right Handed C Axis (M80)

When this M code is active and a command is given to the C axis to go in a positive direction, the axis will rotate counter clockwise.

Left Handed C Axis (M81)

When is M code is active and a command is given to the C axis to go in a negative direction, the axis will rotate clockwise.

Subprogram Call (M98)


One way of specifying the number of iterations for a subprogram to perform is with M98 subprogram calls.

When making M98 subprogram calls, the P parameter is used to specify iterations as well as the subprogram number. Up to four digits can be used to specify iterations for a maximum of 9999 iterations. Leading zeros are not required when specifying iterations; however, leading zeros are required with a subprogram number that is less than 1000.


In Example 1 below, M98 P60050 must be used instead of M98 P650 to run program 50 with 6 iterations because the subprogram number (50) is less than 1000.

In Example 2, the M98 P23013000 subprogram example, the four digits to the left (2301) specify the number of iterations, and the four digits to the right (3000) specify the subprogram number.

Example 1



Example 2



As other examples, M98 P1 runs program 1 with no iterations, and M98 P100001 runs program 1 ten times.

Jump; Return from Subprogram (M99)

Each subprogram ends with an *M99* Jump statement.

This function allows specification of the Surface Contact Point, the Surface Normal Vector, and the Tool Vector. The CNC will compute the tool position automatically for ball nose, flat end, and bull nose endmills. The tool will be positioned to tangentially touch the specified Surface Contact Point.

3D MOLD

3D Mold Parameters

To create a three-dimensional (3D) part, define a two-dimensional (2D) profile in either the XY or XZ plane. Repeat the 2D profile along a straight line (translate) or repeat it around a centerline (revolve) to produce the final 3D shape. Choose Draw 2D Contour to draw the original 2D contour that will be manipulated using the 3D operations.

To program a 3D Mold data block from the Part Programming screen, select the **Insert Block Before** softkey then select the **Milling** Softkey that appears. On the **Milling** softkeys, select **3D Mold**.

Combine of any of the three types into composite contours (in conjunction with [Patterns](#)) to machine complex parts:

- **Y Revolved about X**—Use a 2D contour programmed in the XY plane and revolve it about a centerline on the X axis to produce the finished 3D contour.
- **XZ Revolved about Z**—Use a 2D contour programmed in the XZ plane and revolve it about a centerline on the Z axis to produce the finished 3D contour.
- **XZ Translated in Y**—Use a 2D contour programmed in the XZ plane and translate it in the Y axis.


Program a [finishing tool](#) to perform a [finishing pass](#).

Access the [3D Mold Contour](#) screens by selecting the Edit 3D Mold Contour softkey. This softkey is not available when the cursor is in the Block field. When you select the Edit 3D Mold Contour softkey, it changes to Edit 3D Mold Parameters so you can return to the parameters screen. The Edit 3D Mold Parameters softkey is not available when the cursor is in either the Block or Segment field.


The 3D Mold Parameter fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
 - **Tool**—Identifies the tool number for this data block and enters that tool's diameter and type on this screen.
 - **Finish Tool**—Identifies the finish tool number for this data block and enters that tool's diameter and type on this screen.
 - **Type**— Defines the type of 3D operation. There are four drop-down list box and softkey choices when the cursor is on the Type field.
- [Draw 2D Contour](#)
- **Y Revolved about X**—Use a 2D contour programmed in the XY plane and revolve it about a centerline on the X axis to produce the finished 3D contour.

- **XZ Revolved about Z**—Use a 2D contour programmed in the XZ plane and revolve it about a centerline on the Z axis to produce the finished 3D contour.
- **XZ Translated in Y**—Use a 2D contour programmed in the XZ plane and translate it in the Y axis.
- **Centerline Y and Centerline Z**—Determine the coordinate points of the center of the part on the Y and Z axes.



Increased Radius




Zero Radius

The Centerline Z field determines the Z axis position of the X axis centerline. Changing the Z axis centerline moves the X axis centerline above or below the part surface. This alters the depth of the 3D contour. The Z axis centerline is used only for XY Revolved About X.


To machine the 3D contour below the part surface, enter a negative value in the Centerline Z field. This value is equal to the radius of the part measured from the Y centerline.

Here is a convex contour programmed below the part surface:




Convex Contour Below the Part Surface

- Start Angle** and **End Angle**—Determine the starting and ending values of the angle of revolution for XY Revolved About X and XZ Revolved about Z. When determining Start and End Angles, remember that 0° is where the contour begins and is located at the 3 o'clock position.
 - The difference between the start and end angle determines the degrees that the 2D profile revolves about the axis.
 - Start and End angles can be entered as positive or negative numbers. CCW motion is programmed as a positive number; CW motion is programmed as a negative number:




Counterclockwise and Clockwise Motion

- Y Start** and **Y End**—Determine the length of the 3D contour along the Y axis for XZ Translated in Y, as shown in the example below:




Y Start and Y End Fields (XZ Translated in Y)

- **Cut Direction**—Controls the tool path while the 3D contour is machined. There are two choices for the Cut Direction field:
 - **With Contour** - machines the 3D contour using the tool path originally programmed.
 - **Normal** - tool path follows the part at right angles to the original two-dimensional profile.
- **Bidirectional**—Determines the direction of the tool path while the part is being machined. There are two choices for the Bidirectional field:
 - **No** - causes the tool to machine in one direction, based on the direction of the contour definition.
 - **Yes** - causes the tool to machine in both directions without retracting the tool until the entire contour is complete.




Bidirectional field

- **Step Size**—Determines the distance between cutter passes. Ultimately, this dimension determines the surface finish of the part. A larger step size machines faster but leaves a rougher surface. A smaller step size machines more slowly but leaves a smoother surface. Step size significantly affects the drawing speed of the graphics screen.




Step Size

- **Finish Step Size**—Determines the distance between cutter passes for the finish tool.
- **Min Z**—Limits the negative Z motion to the Centerline Z value when set to Yes.
- **Z Start**—Identifies the point above the part where the spindle begins to rotate.
- **Peck Depth**—Identifies the distance the tool will drill down into the part before stopping to clear out or break the chips. If used, this parameter is not usually larger than the diameter of the tool.



Peck Depth

- **Plunge Feed**—Identifies the rate at which the tool initially enters the part.
- **Mill Feed**—Identifies the X-Y feedrate. The value initially displayed has been calculated by the control and can be retained or changed to a different value.
- **Speed (RPM)**—Identifies the spindle speed for the tool, calculated in [Tool Setup](#). Entering a value here overrides the Tool Setup value for this data block.
- **Stock Allowance**—Leaves or removes extra material on the surface of the 3D contour. Stock Allowance can be used for roughing, undersizing, or oversizing a surface. A Ball-Nosed End Mill must be used to maintain a uniform stock allowance dimension over the complete 3D contour. A positive stock allowance value programmed using a Flat End Mill leaves sufficient material for a finishing pass.



Stock Allowance

- **Tool Diameter**—Contains the tool diameter entered for the tool during [Tool Setup](#).
- **Tool Type**—Contains the tool type entered for the tool during [Tool Setup](#).
- **Finish Diameter**—Contains the tool diameter entered for the finish tool during [Tool Setup](#).
- **Finish Tool Type**—Contains the tool type entered for the finish tool during [Tool Setup](#).

3D Mold Contour

Used in conjunction with [3D Mold Parameters](#) to mill a 3D Mold, program the part surfaces as a 2D profile in either the XY or XZ plane.

The Start Segment number is always 0. Use [segments](#) to program lines and arcs which create a contour. Repeat the 2D profile along a straight line (translate) or repeat it around a centerline (revolve) to produce the final 3D shape. The [Contour End](#) block marks the end of the programmed contour.

Select the [Edit 3D Mold Parameters](#) softkey to access the parameters screen. The **Edit 3D Mold Parameters** softkey is not available when the cursor is in either the Block or Segment field. When you select the **Edit 3D Mold Parameters** softkey, it changes to **Edit 3D Mold Contour**. This softkey is not available when the cursor is in the Block field.

The 3D Mold Start Segment fields are defined as follows:

- **Block**—Identifies the block number for the 3D Mold data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number for this operation.
- **X Start** and **Y Start** or **X Start** and **Z Start**— Identify the starting location for the X and Y or X and Z coordinates. The X and Y or X and Z coordinates are carried forward to the next Segment.

Continue programming the contour by using the Page Down key or by selecting the **Next Segment** softkey.

[Line](#), [Arc](#), and [Blend Arc](#) softkey choices appear.



WinMax allows you to paste a contour into a 3D Mold Block on the [Program Review screen](#). This allows you to use the same segments for a Mill Contour Block and a 3D Mold Block without entering each segment twice.

- To copy a contour, select the contour that you wish to copy on the Program Review Screen and press CTRL + C.
- To paste a contour, select the 3D Mold Block that you wish to paste the contour into on the Program Review screen and press CTRL + V.

3D Mold Line

Some 3D Mold Line fields are automatically calculated with the [Auto-Calc](#) feature.

The 3D Mold Line fields are defined as follows:

- **Block**—Identifies the block number for the 3D Mold data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number for this operation. The system determines the number by the position of this segment in the program.

The following fields change depending on the type of contour selected:

- **X End** and **Y End** or **X End** and **Z End**—Identify the X End and Y End or X End and Z End coordinates. If two End coordinates are entered (X/Y or X/Z), the control [automatically calculates](#) the XY (or XZ) Length and the XY (or XZ) Angle fields. Use **the Store Calculated Value** softkey to retain the calculated value.
- **XY Length** or **XZ Length**—Identify the XY Length or XZ Length. If two End coordinates are entered (X End and Y End or X End and Z End), the control [automatically calculates](#) the XY Length and the XY Angle fields. Use the **Store Calculated Value** softkey to retain the calculated value.
- **XY Angle** or **XZ Angle**—Identify the XY Angle or XZ Angle or the angle of the line segment (from the start point to the end point), measured

counterclockwise from the 3 o'clock position. If two End coordinates are entered (X End and Y End or X End and Z End), the control [automatically calculates](#) the XY Length and the XY Angle fields. Use the **Store Calculated Value** softkey to retain the calculated value.

- **X Start** and **Y Start** or **X Start** and **Z Start**—Define the starting points of this segment. The Start fields are carried forward from the previous segment's end points.

Continue programming the contour by using the PAGE DOWN key or by selecting the **Next Segment** softkey.

[Line](#), [Arc](#), and [Blend Arc](#) softkey choices appear.

3D Mold Arc

Some 3D Mold Arc fields are automatically calculated with the [Auto-Calc](#) feature.

The 3D Mold Arc fields are defined as follows:

- **Block**—Identifies the block number for the 3D Mold data block. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number for this operation. The system determines the number by the position of this segment in the program.
- **Direction**—Determines the direction of the arc from the start point (clockwise or counterclockwise).

The following fields change depending on the type of contour selected:

- **X End** and **Y End** or **X End** and **Z End**—Identify data coordinates (values for X End and Y End or X End and Z End) used in the [automatic calculations](#). Use the **Store Calculated Value** softkey to retain the calculated value.
- **X Center** and **Y Center** or **X Center** and **Z Center**—Identify data coordinates (values for X Center and Y Center or X Center and Z Center) used in the [automatic calculations](#). Use the **Store Calculated Value** softkey to retain the calculated value.
- **Radius**—Identifies the value for the Radius. The radius is used in the [automatic calculations](#). Use the **Store Calculated Value** softkey to retain the calculated value.
- **X Start** and **Y Start** or **X Start** and **Z Start**—Define the starting points of this segment. The Start fields are carried forward from the previous segment's end points.

Continue programming the contour by using the PAGE DOWN key or by selecting the **Next Segment** softkey.

[Line](#), [Arc](#), and [Blend Arc](#) softkey choices appear.

3D Mold Blend Arc

A blend arc is an arc that joins two other segments and is tangent to both. Use a blend arc to join two line segments, to join a line segment and an arc segment, or to join two arc segments. The segments to be joined must have a theoretical point of intersection. Refer to Mill Contour Blend Arcs for [illustrations](#) of blend arcs.

If the only information known about an arc is its radius, it is easier to program it as a blend arc if the segments intersect.

The 3D Mold Blend Arc fields are defined as follows:

- **Block**—Identifies the block number for this operation. The system determines the number by the position of this data block in the program.
- **Segment**—Identifies the segment number for this operation. The system determines the number by the position of this segment in the contour.
- **Radius**—Identifies the radius of the arc.
- **Direction**—Identifies the direction of the arc from the start point (clockwise or counterclockwise).

The following fields change depending on the type of contour selected:


- **X Start** and **Y Start** or **X Start** and **Z Start**—Define the starting points of this segment. The Start fields are carried forward from the previous segment's end points.
- **X End** and **Y End** or **X End** and **Z End**—Identify the End coordinates.
- **X Center** and **Y Center** or **X Center** and **Z Center**—Identify the X Center and Y Center or X Center and Z Center coordinates used to define the circular path of the blend arc.

Continue programming the contour by using the PAGE DOWN key or by selecting the **Next Segment** softkey.


[Line](#), [Arc](#), and [Blend Arc](#) softkey choices appear.

Roughing and Finishing Tools

In many applications, a Flat End Mill can be used for roughing, followed by a Ball-Nosed End Mill, which is required for cutting the finished surface.





Flat End Mill on a Contour



Ball-Nosed End Mill on a Contour



Flat End Mill - the cutter path is computed as if a Ball-Nosed End Mill is used. This

computation allows a Flat End Mill to be used for roughing without gouging the part, and in most cases leaves enough material to be removed for the finished surface using a Ball-Nosed End Mill.



Flat End Mill

Ball-Nosed End Mill - the system computes the compensated cutter path of the ball center:




Ball-Nosed End Mill

Special consideration must be taken when using a [Finish Tool for a Mill Frame, Mill Circle or Mill Contour](#).

Roughing and Finishing Passes

The Flat End Mill tool path is calculated as a Ball-Nosed End Mill for the roughing pass.

The maximum additional material remaining on the overall 3D contour will not exceed the tool's radius.




Roughing and Finishing Passes

ULTIPOCKETS OPTION

The UltiPocket™ programming option adds special milling routines for machining pocket boundaries with islands. This option provides complete clean out of odd-shaped pockets without cutting the islands programmed inside the boundary. The software automatically calculates the tool path around islands eliminating the long task of plotting these shapes. Islands may also be rotated, scaled, and repeated.

The following drawing shows an inward spiral boundary with three differently shaped islands.



The pocket feature is available for any of these standard Ultimex program data blocks, Mill Contour, Mill Frame, Mill Circle, or Patterns.

- ⇒ To use the UltiPocket feature, first establish the cutter compensation parameter and then program any UltiPocket data blocks.
- Refer to [Milling Parameters](#).
 - Select either Insert Arc or Insert Line for the Cutter Comp Parameter field. If this field does not appear on the Milling Parameters screen, the UltiPocket option has not been installed on the control.

Pocket Boundary

The Pocket Boundary is the outside frame of the part. The basic philosophy of the UltiPocket option is to program the boundary and then tell the system which pockets or islands to avoid within that boundary. This approach eliminates complex calculations and shortens the part programming process.

There are two types of Pocket Boundaries: Spiral Outward (no islands) and Spiral Inward.

Spiral Outward - No Islands

This selection is only for Circle and Frame data blocks without islands. When this routine is selected, the tool begins from the center region of the part outward to pocket the entire programmed boundary. This operation is, therefore, the same as the standard Ultimex Pocket selection. With this selection the cutter overlap is controlled by the Pocket Overlap value on the Milling Parameters screen, not the Pocket Overlap field on the Mill Circle and Mill Frame screens.

Spiral Inward

This selection cuts in from the outside of the defined boundary avoiding the defined islands. When this routine is selected, the tool enters the part and begins following a path formed by offsetting the boundary one-half the tool radius, plus the pocket overlap.

To control the percentage of overlap during cutting, enter a value in the Pocket Overlap field on the Mill Circle or Mill Frame screen. After the first pass, the tool follows a path produced by offsetting the boundary by the tool radius, plus the pocket overlap for each pass while avoiding islands inside the boundary.

After pocketing the boundary, the tool then cuts around the inside of the boundary and the outside of each island, using the selected blend offset and the programmed tool radius.

Programming Islands

After programming the mill data block for a boundary, an island can be defined by creating a Pocket Island data block. As many islands as desired may be defined (subject to computer memory on the control), but all must fit within the defined boundary and should allow the tool to completely define the island.

The island data block can be a Mill Frame, Circle, or Contour (provided it is a closed contour). The Pocket Island data blocks use the standard milling values from the boundary data block and do not display these parameters on the island programming screen. The pocket overlap percentage was also defined in the boundary data block.

Mill Contours

To create a Mill Contour data block using the UltiPocket option, set up the operation in the start segment (segment zero). As in standard Ultimex milling, an UltiPocket Mill Contour block consists of segments beginning with segment zero. With the cursor in the MILLING TYPE field, select one of the Pocket options in the Start segment to indicate whether this block is the boundary of the part or one of the islands within the boundary. The boundary must occur first in the program.

The segments after the Start segment are programmed in the same manner as standard milling lines and arcs. Automatic calculation of unknown points is available for these data blocks.

Mill Frame

The Mill Frame data block is often used to create the part boundary.

This block is programmed in the same manner as the standard Ultimax Mill Frame, with the addition of the Pocket Overlap percentage.

Mill Circle

The Mill Circle data block is used for both boundaries and islands. It is similar to the standard Mill Circle data block except that if this block is used to create an island, it uses the tool from the boundary data block.

Pattern

Pattern data blocks can be inserted to rotate, scale, or repeat islands. Only Pattern data blocks can be programmed between a boundary data block and an island. As many islands as desired may be defined (subject to available memory), but all must fit within the defined boundary.

Helical Plunge with UltiPocket Option

The Helical Plunge option is used with the UltiPocket option to define the plunging location when inward pocketing. Islands created using inward pocketing can influence plunge locations. A plunge location is determined that will not interfere with pocket islands.

The plunging location in outward pocketing is the same as a straight plunge. Outward pocketing is used only for mill frame, mill circle, and ellipse pocket boundaries that do not have pocket islands. Since islands are not present with outward pocketing, the plunging location is in the middle of the mill frame, mill circle and ellipse.

When the Helical Plunge option is installed, two additional pocketing-related fields appear on the Milling Parameters screen. These fields are Operator Specify Pocket Start and Inward Pocket Plunge Near Center.

The Operator Specify Pocket Start field takes precedence over the Inward Pocket Plunge Near Center field. If the Operator Specify Pocket Start field is set to Yes, the value of the Inward Pocket Plunge Near Center field is ignored.

When the Operator Specify Pocket Start field is set to No, the value of the Inward Pocket Plunge Near Center field is checked. If the Inward Pocket Plunge Near Center field is set to Yes, a starting location will be determined near the center of the pocket. If both fields are set to No, the default starting position will be used for the pocket.

Helical Plunge Using Operator Specify Pocket Start

To use the Operator Specify Pocket Start function:

1. Set the Type field to Pocket Boundary on the Mill Contour, Mill Frame or Mill Circle screen.
2. Set the Pocket Type field to Inward on the Mill Contour, Mill Frame or Mill Circle screen.
3. Set the Operator Specify Pocket Start field to Yes on the Milling Parameters screen.
4. The Pocket X Start and Pocket Y Start fields appear on the Mill Contour, Mill Frame, or Mill Circle screen. The operator identifies the pocket plunge location with the Pocket X Start and Pocket Y Start fields.

The Pocket X Start and Pocket Y Start fields define the centerline of the plunge path. This is the location where the helix will be centered. If a straight plunge is selected, the straight plunge will occur at the location.

The following figure shows the Pocket X Start and Pocket Y Start fields on the Mill Frame screen. See the "Helical Plunge Option" chapter for an example using Pocket Start X and Pocket Start Y fields.

⇒ For non-rotary blocks, Pocket X Start and Pocket Y Start define the XY starting location. For rotary blocks, these fields define the XA starting location.

An error message will display if the values for Pocket X Start or Pocket Y Start interfere with the pocket island or pocket boundary.

DXF OPTION

WinMax DXF offers greater flexibility, improved compatibility with AutoCad®, and the ability to save DXF changes directly to file (avoiding the need to send DXF files back to the CAD system for editing). DXF files are loaded directly into WinMax as follows:

1. Press the AUXILIARY console button.
2. Select the DXF icon on the Auxiliary screen.



The DXF Editor is functional in Conversational programs only. If the DXF Editor is started when the current active program is NC, a prompt asks if you want to start a new conversational part program. Answer Yes to create a new Conversational part program.

3. Find the DXF file on the Load DXF File screen, and select it to highlight.
4. Select the LOAD *F1* softkey.

The DXF program blocks are displayed in the Program Review Screen. On single-screen machines, use F+Draw (console key) to display the DXF drawing.

On dual-screen machines, the DXF drawing is displayed on the graphics screen. After building the data blocks, the part can be viewed in Solid or Toolpath graphics using the **Draw** console key. Switch the screen back to the DXF drawing using **F + Draw** (console keys). You can switch the screen back to the previously drawn graphic (without causing it to be redrawn) with the **Draw** console key. To redraw the graphic, select the **Draw** console key a second time (or access the DRAW OPTIONS F1 softkey).

The DXF file translation software is compatible with DXF files generated with AutoCAD version 9 and later. If you are using [AutoCAD 14](#), set the registers to generate Polylines and Ellipses so they are saved as pline entity types and not splines.

Here are the softkeys on the DXF screen:

- [Parameters](#)
- [Build DB](#)
- [Zoom Window](#)
- [Edit Drawing](#)
- [Layers](#)
- Save DXF
- [Part Programming](#)
- Quit CAD

The **Part Programming** softkey or icon toggles back to Part Programming without closing the DXF file. You may return to DXF at any time by selecting the DXF icon.

DXF Build Data Block

The **Build DB** softkey accesses the automatic data block building features. The system creates milling, holes, or position data blocks.

Milling - the Milling operation softkeys perform these functions in Lines/Arcs, Circles, Frame, 3D Mold, or Ellipse data blocks:

- [Accept](#)
- [Zoom Window](#)
- [Edit Drawing](#)
- [Reverse](#)
- [AutoChain](#)
- [Default Radius](#)
- [Exit/Cancel](#)

If you are using [AutoCAD 14](#), set the registers to generate Polylines and Ellipses so they are saved as pline entity types and not splines

Holes - the Holes operation softkeys perform these functions:

- [Accept](#)
- [Zoom Window](#)
- [Edit Drawing](#)
- [Window Select](#)
- [Intersect](#)
- [Default Order](#)
- [Exit/Cancel](#)

Position - the Position operation softkeys perform these functions:

- [Accept](#)
- [Zoom Window](#)
- [Edit Drawing](#)
- [Window Select](#)
- [Intersect](#)
- [Default Order](#)
- [Exit/Cancel](#)

Exit - return to the DXF softkeys.

DXF Parameters

These parameters link contour segments, define part zero within the drawing, and set the radius for frame corners.

Use the Move Zero and Select Value softkey to change the location of part zero. The **Exit** softkey returns to the DXF softkeys.

The fields on the DXF Parameters dialog box are defined as follows:

- **Endpoint Tolerance** - determines when the endpoints of segments are close enough to be considered equal (or coincident).
- **Part X Offset** and **Part Y Offset** - define part zero within the drawing. All dimensions are calculated from this point. The part zero symbol is a circle with crosshairs. To change this location manually, move the cursor to the field for Part X or Y Offset and enter the X or Y Offset values. To change this location graphically and automatically, use the **Move Zero** softkey.
- **Frame Radius** - determines the default corner radius for a frame.
- **Hole Diameter** - determines the default diameter for a hole.

Use the mouse and click the remaining DXF Parameter fields on (✓) or off ():

- **DXF Units are MM** - converts selected geometry to millimeters when clicked on, and to inches when clicked off.
- **Display Geometry** - displays converted lines on the graphic display as gray instead of black, illustrating which elements have been converted and which have not.
- **Autochain Contours** - allows autochaining to be turned off so that a contour may be created by individually selected segments into a chained contour. By default, segments are automatically chained to create contours.
- **Select Holes by Diameter** - selects holes with the diameter specified in the Hole Diameter field (defined above) when the [Window Select](#) softkey is used. This selection allows you to order the hole selection by size, which optimizes tool changes.

DXF Zoom Window

Use the **Zoom Window** softkey to enlarge an area of the drawing or zoom out to see a full view. Use the pointer to touch an area on the screen and drag across the screen to enlarge an area of the drawing. When an area is enlarged, use the following softkeys:


- **Zoom Out** - pulls back from the drawing incrementally to the previous magnification level without re-centering the part in the drawing.
- **Fit to View** - gives a full scale of the drawing with the part in the drawing auto-centered.
- **Pan** - relocates the center of the drawing on the Graphic display.
- **Exit** - returns to the previous menu.

DXF Edit Drawing

Use the Edit drawing feature to extend, join, modify, or split segments that need to be edited in order to create the proper geometry for the part program.

- **Extend** - locates the intersection of two lines and extends one or both of the lines to the intersection point.


To extend lines, select the [Edit Drawing softkey](#) and then the **Extend** softkey. Select the two lines that need to be extended. Both lines are highlighted when selected and extended to their points of intersection as shown in the examples below:



Extended Lines and Arcs

- **Join** - moves a selected line endpoint to the endpoint of a line or arc segment. Always select as the first endpoint the point that will be joined to the second endpoint. The endpoint at the opposite end of the first selected segment remains stationary and becomes a pivoting point. Both segments are highlighted when selected, and the screen is redrawn to reflect the joining of the two segments.
- **Modify** - is used to view or modify the actual geometry data of segments. Choose the [Select Point](#) softkey to view the segment data.
 - The [DXF Edit Modify - Arc](#) dialog box appears if you select an arc.
 - The [DXF Edit Modify - Line](#) dialog box appears if you select a line.
 - The [DXF Edit Modify - Point](#) dialog box appears if you select a point.
 - The segment appears gray on the Graphic display.

Choose the **Accept** softkey to retain the changes in the control's memory.



Joined Lines and Arcs

- **Split** - use to divide segments for selection, de-selection, and chaining. Segments may be split at midpoint or any point of intersection with other segments.
To split a segment, first select the segment and then select the point where the segment will be divided. When a segment is selected for splitting, the midpoint and all intersection points with the other segments are indicated with crosshair markers. Follow the directions in the Prompt display.
- **Delete** - deletes a programmed endpoint.
- **Trim** - trims a selected segment.
- **Explode PCurve** - shows an exploded view of a selected PolyCurve. If you are using [AutoCAD 14](#), set the registers to generate Polylines and Ellipses so they are saved as pline entity types and not splines.
- **Exit/Cancel** - return to the Main DXF menu.

DXF Layers

Many DXF drawings use layers - an electronic method of representing transparent acetate overlays used in hand-drawn drafting work.

- **Select Layer** - toggles the highlighted layer on and off.
- **All On** - turns on all of the layers.
- **All Off** - turns off all of the layers.
- **Exit** - return to the Main DXF menu.

DXF Edit Modify - Arc

The DXF Edit Modify - Arc dialog window contains these fields:

Start Angle - defines the starting point of the angle.

Sweep Angle - defines the total number of degrees in the arc to be cut. This number can be greater than 350.

Direction - identifies the direction of the arc from the start point.

Radius - identifies the radius of the arc.

Center X and **Center Y** - identify the X and Y coordinates for the center point of the arc.

DXF Edit Modify - Line

The DXF Edit Modify - Line dialog window contains these fields:

Endpoint1 X and **Endpoint1 Y** - define the first endpoints for the X and Y coordinates.

Endpoint2 X and **Endpoint2 Y** - define the second endpoints for the X and Y coordinates.

Length - identifies the line length.

XY Angle - identifies the angle of the XY coordinate.

DXF Edit Modify - Point

The DXF Edit Modify - Point dialog window contains these fields:

X Value – identifies the X location for the selected point.

Y Value – identifies the Y location for the selected point.

ROTARY

Rotary options and rotary equipment are typically used to cut around a cylindrical part while it is turning. WinMax software allows programming of parts using Rotary A, Rotary A Tilt B, and Rotary C Tilt A. See [Axis Diagram](#) for more information on rotation of rotary axes.

When a Rotary A Axis table is attached to the machining center, it has a fourth axis of motion—the A axis. Rotary A Tilt B allows you to tilt the table along the Y axis. Rotary A Tilt B is typically used for drilling holes in a cylinder, but can also be used when milling complex parts. The Y axis motion will stop and be replaced with the A axis. The tool is usually in line with the center of the rotary table along the Y axis, but it can be positioned off center as well (to use both the Y and A axes simultaneously, create the part program using NC part programming. Refer to [NC Part Programming](#) for more information.).

When the Rotary C Axis option is used in conjunction with a rotary table, the machining center has the A axis as a fourth axis of motion, and the C axis becomes a fifth axis of motion. The X axis motion is replaced with the C axis when a conversational Rotary C Axis data block is executed. To use both the X and C axes simultaneously, create the part using NC part programming. Refer to the "Enhanced NC Part Programming" chapter for more information.

Programming ranges and resolutions for the Rotary Table are plus (+)/minus (-) 9999.999 degrees absolute in a rotary contour and +/- 360.0000 degrees for all other operations. Positive (+) motion of the Rotary Table is in a counterclockwise (CCW) direction, as it would appear to the operator when standing at the "+X" end of the work table and facing the Rotary Table. The direction of the axis rotation can be configured to meet your needs by the Hurco Service Representative.

Rotary A Axis Part Programs

To use Rotary operations in a part program, the program must be created as a Rotary part program.

Steps to create a Rotary part programs:

- [Program Definition](#)
- [Part Setup](#)
- [Part Programming](#)


[Position Block](#)

[Milling Operations](#)

[Holes](#)

[Patterns](#)

Axis Diagram



On most machines, the A, B, and C rotary axes correspond to X, Y, and Z in this way:

- The A axis pivots around a center line parallel to the X axis.
- The B axis pivots around a center line parallel to the Y axis.
- The C axis pivots around a center line parallel to the Z axis.

Program Definition

To create a Rotary part program:

1. Select the Auxiliary console key.
2. Select Utilities Button.
3. Select User Preferences softkey.
4. Select Conversational Settings softkey.
5. Choose an axis configuration. Select either the Rotary A softkey or the Rotary A Tilt B softkey. In the HD3 program type field set the program type when saving to the HD3 format. For example, a Rotary A program saved as a standard HD3 file will have all rotary data removed during the save process.

Rotary Part Setup

Rotary Part Setup Fields are defined as follows:

A Centerline Y	Incremental distance (offset) from true part zero. If the Y axis part zero is the centerline of the rotary table, then the Y centerline offset value will be zero.
A Centerline Z	Incremental distance (offset) from true part zero. If Z part zero is the top of the part, then the Z centerline offset will be a negative value equal to the radius of the part if the part was sitting at 90° in the A axis.
B Centerline X	Incremental distance (offset) from true part zero. If the X axis part zero is the centerline of the rotary table, then the X centerline offset value will be zero.
B Centerline Z	Incremental distance (offset) from true part zero. If Z part zero is the top of the part, then the Z centerline offset will be a negative value equal to the radius of the part if the part was sitting at 0° in the B axis.
C Centerline X	Incremental distance (offset) from true part zero. If the X axis part zero is the centerline of the rotary table, then the X centerline offset value will be zero.
C Centerline Y	Incremental distance (offset) from true part zero. If the Y axis part zero is the centerline of the rotary table, then the Y centerline offset value will be zero.

The centerline is defined by values which are part/tool zero relative. These values can be determined by jogging an indicator to the centerline, or to a known dimension of a part on the rotary table. The centerline is also used with graphics display.

Rotary A Axis

Part Y axis is generally considered to run along the center of the rotary table and the top of the part is part Z zero.

Rotary C Axis

Part X axis is generally considered to run along the center of the rotary table and the top of the part is part Z zero.

The center of the rotary table may be used as part Z zero, especially if the piece being machined is asymmetrical.

Rotary Part Programming

To begin Rotary programming:

1. Create a new program and choose the appropriate rotary type on the Input screen. Note: You may have to select the Erase Functions softkey followed by the Erase All softkey to exit the standard HD3 program type editor.
2. Select the Part Programming softkey on the Input screen to access the New Block screen.
3. Press the Rotary softkey to access the rotary data block operations.

The *rotary operation softkeys* have the following uses:

- **Rotary Position**—Defines the A axis reference position. A position block must be added in the part program before any other rotary operation. The exception to this rule is the first data block in your rotary program. Typically, the first data block in a rotary program should be the Rotary Parameters data block. This gives a reference to the workpiece radius and centerline settings.
The Z Retract is the same as the Z safety plane height in a Rotary Position data block.
- **Rotary Lines and Arcs**—Describes the segments that will be cut as lines and arcs around a cylindrical-shaped part.
- **Rotary Circle**—Describes a machined circle that wraps around the rotary center line.
- **Rotary Frame**—Describes a machined frame that wraps around the rotary center line.
- **Rotary Loop**—Identifies the number of times a rotary pattern will be repeated.
- **Rotary Locations**—Indicates the locations on a part where a pattern will be repeated and the distances between repetitions.
- **Pattern End**—Marks the end of a rotary pattern.

[Rotary Parameters](#) Defines the Cylinder Radius and X/Y Off of Centerline parameters.

Rotary Parameters

The Rotary Parameter Block can be placed at any location in a program. The parameters set in this block will then affect any blocks that follow until the end of the program or another parameter block appears.

The Rotary Parameters are as follows:

- **Cylinder Radius**—If not specified, Ultimax subtracts the A Centerline Z value from the Z Start to calculate the Cylinder Radius. You can program an alternative cylinder radius if you want the machine to begin cutting at a location other than the Z Start.
- **Y Off of Centerline**—If No is selected, the tool will automatically position in Y directly over the centerline for rotary milling operations. If Yes is selected, the current Y position is used. (Only appears in Rotary A Axis Programs)

Rotary Position Block

A rotary position block must follow a rotary pattern data block. It is used to position the Rotary A, Rotary A Tilt B, and Rotary C Tilt A axes, and perform a rotary safety move, when desired. To create a position block, press the Rotary Position softkey on the new Block screen.

The fields on the Rotary Position screen have these definitions:

- **Tool**—The number of the tool used to perform the cutting operation.
- **X Position**—The X coordinate (relative to part zero of the desired table position. The default value is 0.0000.
- **Y Position**—The Y axis coordinate (relative to part zero) of the desired table position. The default value is 0.0000.
- **A Angle**—Enter the A axis coordinate (relative to part zero) of the desired table position. The default value is 0.0000.
- **B Angle**—Applies only to Rotary A Tilt B programs. Enter the B axis coordinate (relative to part zero) of the desired table position. The default value is 0.0000.
- **C Angle**—Applies only to Rotary C Tilt A programs. Enter the C axis coordinate (relative to part zero) of the desired table position. The default value is 0.0000.
- **Stop**—Select the Yes softkey to force the program to stop at a specific place – you can then open the enclosure doors and jog the axes. Press the Auto Mode or Single Mode console key to restart the part program. The default is No.
- **Rotary Safety Move**—This parameter is used if there is a potential collision between the rotary table and the machine column. If you select Yes, you can enter the table location in the machine position fields. The machine will move to the table position before moving the rotary axis. The default value is No.
- **X Safety Position** This field appears if Yes is selected for Rotary Safety Move. Enter the X coordinate for machine absolute position on the table. This value does not change and is not relative to the part. The default value is 0.0000.
- **Y Safety Position**—This field appears if Yes is selected for Rotary Safety Move. Enter the Y coordinate for absolute zero on the table. This value does not change and is not relative to the part. The default value is 0.0000.
- **Transform Part Zero**—When this field is Yes, the part zero will be rotated/tilted for non-rotary blocks. An additional Z offset field appears on the Hole

locations and Bolt Circle data block screens.

- **Bolt Circle Z Offset**—Available when Transform Part Zero is Yes. Indicates the bolt circle's center location in the Z axis.

Rotary Milling Operations

Rotary A Axis milling operations are programmed as XZA operations – motion is performed in these axes. The Y axis is *typically* held fixed at the Y centerline dimension.

Rotary AC Axis milling operations are programmed as CYZ operations. The X axis is moved to the C centerline dimension. In AC milling operations the A axis must be tilted to the 90 degree position.

Types of Milling Operations:

[Lines and Arcs](#)

[Circle and Frame](#)

Rotary Lines and Arcs

Programming Rotary Lines and Arcs is similar to standard [Conversational Lines and Arcs](#). [Rotary dimensions](#) are used in place of XY dimensions.

Cutter comp is calculated using the cylinder that includes the Z Start point. You can choose a cylinder of a different radius by programming a Rotary Parameters block before milling operation blocks.

- ⇒ If a Rotary Parameters block is not used to define the radius, the radius is defined as the distance from Z Start to A centerline Z.
- ⇒ Automatic calculation is not available with Rotary programming. You must calculate the values of unknown tangency points, end points, and center points for lines and arcs. See [Calculating Unknown Rotary Dimensions](#).

Calculating Unknown Rotary Dimensions

The following process provides an easy method to create rotary lines and arcs segments:

1. Begin by programming the part in a standard lines and arcs (X, Y) program – this allows unknown segments to be calculated.
2. Next translate the X or Y dimensions based on the type of rotary programming:

Rotary A Axis

Translate the Y dimensions in the program into A dimensions by using the formula shown below. In the equation, "r" is the radius of the cylinder.

$$A = \frac{180}{\pi \times r} \times Y$$

Rotary C Axis

Translate the X dimensions in the program into C dimensions by using the formula shown below. In the equation, "r" is the radius of the cylinder.

$$C = \frac{180}{\pi \times r} \times X$$

Rotary Circle and Frame

Rotary Circles and Frames are wrapped around the radius of the cylinder. Programming for a Rotary Circle or Frame is similar to [standard conversational program](#) with the following exceptions:

Rotary A Axis

The Y dimensions (on a standard mill circle or frame) are instead specified in A angular dimensions.

Rotary C Axis

The X dimensions (on a standard mill circle or frame) are instead specified in C angular dimensions.

⇒ See [Calculate Unknown Rotary Dimensions](#) (Rotary A Axis Lines and Arcs section to convert existing XY dimensions).

Rotary Patterns

Programming Rotary Pattern Data Blocks is similar to programming [standard Pattern Data Blocks](#), with a few exceptions. The following links discuss programming Rotary Pattern Data Blocks.

[Rotary Pattern Loop](#)

[Rotary Pattern Locations](#)

[Rotary Position Data Block](#)

Rotary Pattern Loop

In a Rotary A Axis Pattern Loop, the A dimension replaces the Y dimension - allowing the loop to revolve about the cylinder. In a Rotary C Axis Pattern Loop, the C dimension allows the loop to revolve around the cylinder. Nesting two Rotary Pattern Loop blocks simulates a rectangular grid wrapped around the cylinder (similar to Loop Rectangular blocks in non-rotary programming).

The fields on the Rotary Pattern Loop screen indicate the number of times the pattern will be repeated, and the distances between the repetitions. To access the Rotary Pattern Loop screen:

1. From the New Block screen, select the Rotary softkey.
2. Select the Rotary Loop softkey.

⇒ A *Pattern End* block must follow the sequence to close the pattern.

⇒ A *Rotary Position* block must follow any Rotary Pattern Loop block(s) in a program if non-rotary blocks (i.e., Hole operations) are used within a loop. Rotary Pattern Loop blocks only modify rotary blocks contained within the pattern. The Rotary Position block gives the pattern a reference to work from when starting from the beginning, or when using Recovery Restart.

Nested patterns require only one Rotary Position block. Generally, there should be one Rotary Position block for every unique loop.

Rotary Pattern Locations

Rotary Pattern Location blocks are identical to standard Pattern Location blocks, except an A and B, or A and C offset axis is included for each location.

⇒ A *Pattern End* block must follow the sequence to close the pattern.

The A and C axis offset units of measurement are in degrees.

⇒ A *Rotary Position* block must follow any Rotary Pattern Loop block. Rotary Pattern Loop blocks only modify blocks contained within the pattern. The Rotary Position block gives the pattern a reference to work from when starting from the beginning, or when using Recovery Restart.

Nested patterns require only one Rotary Position block. Generally, there should be one Rotary Position block for every unique loop.

Rotary Holes

To program holes on a rotary part, follow these steps:

Rotary A Axis

1. Program a single hole drilling operation in the same manner as in a standard program. Use the X location from the drawing and enter zero for the Y location.
2. If more than one hole is required in the same X axis plane, a Rotary Pattern Loop data block can be used.
 - ⇒ Do not add another location in the hole drilling data block unless two or more XA hole locations are required for the same A angular dimension.
3. 4. For multiple holes, you can choose to add either a Rotary Locations Block, [Pattern Loop Block](#), or a [Pattern Locations Block](#). Rotary Locations Blocks allow you to program holes at various locations and angles around the XA Axis.

Rotary C Axis

1. Program a single hole drilling operation in the same manner as in a standard program. Use the Y location from the drawing and enter zero for the X location.
2. If more than one hole is required in the same X axis plane, a Rotary Pattern Loop data block can be added.
 - ⇒ Do not add another location in the hole drilling data block unless two or more YC hole locations are required for the same C angular dimension.
3. 4 For multiple holes, you can choose to add either a Rotary Locations Block, [Pattern Loop Block](#), or a [Pattern Locations Block](#). Rotary Locations Blocks allow you to program holes at various locations and angles around the YC Axis.

PROBING OPTION

The Probing Option is used for machines equipped with tool and part probes. A tool probe is used to verify tool dimensions and detect tool wear and breakage. A part probe is used to locate and compensate for misalignment of the part. It may also be used for inspection of part features.

Tool and part probing may be used independently or together. Each probing type requires optional hardware and software.


Part Probe Deflection

Part probe positions and moves at Approach Feed until it reaches the geometry. It then backs up and moves again at Measurement Feed until it deflects the geometry a second time. The Measurement Feed touches are repeated a total of Repetitions times and the average is used.

Part Probe Working Envelope

The part probe cycles allow the part probe to operate within the constraints set in the *Part Probing Parameters*. A working envelope containing safe part probe *travel limits* is stored in the Part Probing Parameters.

The working envelope represents the area on the machine table in which the probe can search for geometric features. The travel limits mentioned in each of the Manual Mode Part Setup Probing Cycles and the Manual Mode Part Skew Probing Cycles are set in the working envelope. This area is determined by these fields in the Part Probing Parameters screen: X Min, X Max, Y Min, Y Max, and Z Min. Z Min is a location above the table. The X and Y parameters are illustrated in the figure below:



If the probe reaches any part probe *travel limit* before reaching the part feature, a fault occurs, motion stops, and an error message appears on the screen.

Each cycle's *feed rate* is determined by the value set in the [Part Probing Parameters](#) Approach Feed and Measurement Feed fields.

Tool Probe Setup Parameters

Tool probe setup parameters provide critical information on how the machine will use the probes. The parameters include fields specific to programming a touch probe or a laser probe. Tool probe setup parameters must be adjusted when a tool probe is relocated, or when probing feedrates are changed.

Tool probe setup parameters can be backed up and restored using the procedures described in [Restore](#).

The Tool Probe Deflection Offset softkey is used to access the Tool Probe Deflection Offsets screen.

The Store Machine Position softkey is used to record the axis's real-time position.

Select the Laser Probe softkey to access the laser tool probe fields.

When the cursor is on any of the Cal Tool fields, the *Determine Laser Beam Offset softkey* appears. This softkey initiates the cycle to set the beam offset value. Ultimax uses the Cal Tool D, Cal Tool H, and Cal Tool L fields in calculating the offset.

Refer to Laser Tool Calibration Cycle for information about the laser tool calibration cycle and the Determine Laser Beam Offset softkey.

Tool Probe Setup Parameters are defined as follows:

- **Type**—indicates the type of tool probe. If a tool probe is not present, the remaining tool probe parameters are not used.
- **Contact Point X, Contact Point Y** (touch tool probe only)—indicates the X and Y location (in machine coordinates) of the tool probe. When the machine is at this location, a tool will touch the center of the tool probe stylus. To enter these values easily, insert a tool in the spindle and jog down to the tip of the probe. When the tool tip is centered over the stylus, press the Sto Pos/Store Position key on the jog controls.
- **Center Beam X, Center Beam Y** (laser tool probe only)—indicates the center location of the beam in X or Y, depending on the orientation of the laser probe. Do not change this value after the Laser Tool Calibration cycle has been run, unless you re-run the cycle. Enter in an approximate value and the laser calibration cycle will determine the precise location.
- **Setup Fast Feed**—indicates the feed rate to use for setup moves near the probe. For example, when dropping down next to the probe to measure diameter, the drop down move uses this feed rate. This value is also used for calibrating the probe and the initial touch when determining deflection offsets.
- **Retract Feed**—indicates the feed rate to use when retracting away from the probe immediately after a deflection. This value is also used for the slow moves when determining deflection offsets.
- **Repetitions**—specifies the number of Slow Feedrate touches when touching tools to the probe. You can program up to 99 repetitions (default value is 3 for touch probe and 4 for laser probe) to get the average length and diameter of the tool.

- **Probing Axis**—specifies the axis of deflection in the X/Y plane. Orientation of the probe will determine if it deflects along the X axis or the Y axis. It is assumed the probe will always deflect along the Z axis.
- **Stylus Width** (touch tool probe only)—specifies the width of the probe's stylus along the Probing Axis.
- **Max Spread**—the deviation (difference) between the minimum and maximum probe readings. If the deviation is greater than the Max Spread value, an error message appears.
- **INIT Retract**—scales the initial retract move after a deflection.
- **INCR Retract**—scales the incremental moves that may be required if the probe is still deflected after the initial move.
- **Monitor Motion**—enables or disables additional motion error checking for the probe. When enabled, the probe is constantly checked to make sure the amount of deflection stays below the value in the Max Deflection field.
- **Max Deflection**—the value representing the maximum amount of probe deflection allowed.



If the Max Deflection value is exceeded, then a probe motion fault occurs and motion is stopped.

The remaining Tool Setup Probe Parameters fields appear when Laser Probe is selected. Ultimax uses the calibration values entered in the fields described below for calculating tool length and diameter each time the tool is measured.

Tool Setup Probe Parameters with Laser Probe Selected:

- **Beam Offset**—Displays the width of the beam based on + and - trigger points. This field is updated after running the Determine Laser Beam Offset cycle. You can adjust it to optimize performance.
- **Cal Tool D**—Contains the diameter (D) of the Laser Calibration Tool. This value can be obtained by measuring the diameter of a precision dowel or a laser calibration tool.
- **Cal Tool H**—Contains the height (H) of the Laser Calibration Tool. This value can be obtained by measuring the height of a precision dowel or a laser calibration tool.
- **Cal Tool L**—Contains the length (L) of the Laser Calibration Tool. This value can be obtained by measuring the length of a precision dowel or a laser calibration tool.

Part Probing Parameters

The part probing parameters are accessed through Part Setup. These parameters must be adjusted when a new stylus is installed in the part probe, when the probe work region is changed, or when probing feedrates are changed.

To *access* the Part Probe Parameters:

1. Select the Input console key to access the Input screen.

2. Press the Part Setup softkey.
3. Press the Part Probing softkey. The Part Setup screen is displayed with the Part Probing menu.
4. Select the Part Probe Parameters softkey. The Part Setup Probe Parameters screen appears.

The Part Setup Probe Parameters are defined as follows:

- **Present**—Indicates the presence of a part probe. Select the Yes or No softkey to indicate whether the probe is present. If not present, the remaining part probe parameters are not used.
- **Stylus Diameter**—The *stylus* tip diameter, available on the specification sheet for the probing equipment.
- **Approach Feed**—The feed rate used to locate the part feature to be probed.
- **Measurement Feed**—The feed rate used when measuring the part feature.
- **Repetitions**—The number of Slow Feed touches when measuring the part feature. Up to 99 repetitions can be programmed. The default value is 3.
- **X Min, X Max; Y Min, Y Max; Z Min**—The working envelope the probe tip uses to search for part features in X, Y, and Z machine coordinates. The envelope also helps protect against crashing the probe. These fields are similar to the safety work region in Part Setup.

⇒ When the cursor is in any of these fields, the RESET PROBE WORK REGION TO MAXIMUM and STORE MACHINE POSITION softkeys become active.

- The RESET PROBE WORK REGION TO MAXIMUM softkey allows you to expand the working envelope for a new part.
- You can jog the axes and use the STORE MACHINE POSITION softkey to record the positions.
- **Max Spread**—The difference between the minimum and maximum probe readings. If the difference is greater than the Max Spread value, an error message appears.
- **Circular Passes**—The number of times to probe a circular part. After each pass, the probe positions to the new center location and runs the cycle again. Multiple passes provide better data because each pass starts closer to the true center. The default value is 2.

⇒ Part Setup Probe Parameters are specific to each installation and is stored on the hard drive. If the hard drive is replaced or formatted, the above information must be restored. Refer to [Restore](#) for information about restoring parameters.



When the part probe is used, it must be activated by the control. For this to occur, the control needs to know when the probe is in the spindle. Ultimax provides a Probe tool type in the Tool Setup screen. Before using the part probe, enter the part probe as a tool in Tool Setup:

1. Determine which tool number to assign to the probe.
2. Switch to the Tool Setup screen.
3. Enter the probe's tool number in the Tool field.
4. Select Probe for the tool type.

The control activates the probe hardware when the number in the Tool In Spindle field matches the probe's Tool number.

- **INIT Retract**—scales the initial retract move after a deflection. Increase the value if experiencing repeatability problems.
- **INCR Retract**—scales the incremental moves that may be required if the probe is still deflected after the initial move.
- **Monitor Motion**—enables or disables additional motion error checking for the probe. When enabled, the probe is constantly checked to make sure the amount of deflection stays below the value in the Max Deflection field.
- **Max Deflection**—the value representing the maximum amount of probe deflection allowed.



If the Max Deflection value is exceeded, then a probe motion fault occurs and motion is stopped.

Tool Probe Calibration

Probe calibration is used on machines that have a tool probe to determine the *Z location* of the tool probe. This must be done only once after a control reset. Some systems use a tool probe and a part probe. Calibration methods vary between systems with tool probing only, and systems with both tool and part probing.

- When there is no part probe, a reference tool is used to touch the tool probe.
- When both probes are present, the calibration cycle touches the two probes together.

Touch Tool Probe Calibration

For this configuration, using a reference tool in the spindle, the Tool Setup Probe Parameters screen will have Touch Probe in the Type field.



Prior to probe calibration, the machine must be calibrated.

To access Touch Tool Probe Calibration:

1. Select the Input console button to access the Input screen

2. Select the Tool Setup softkey.
3. Select the Probing softkey
4. Select the Calibrate Tool Probe softkey.

The following sequence occurs:

1. A prompt appears requesting the reference tool number. The reference tool is a tool that works well with the tool probe, such as a drill or a tool with a single point. This reference tool will be used later in Part Setup.
2. Enter the appropriate tool number.
 - ⇒ If necessary, a tool change occurs, placing the reference tool in the spindle. If the tool is not in the magazine, you will be prompted for the tool.
3. The Z axis moves downward at the feed rate specified in the Setup Fast Feed field of the probe parameters screen.
 - The Z axis continues moving until a probe deflection occurs or Minimum Z is reached (value set in tool setup for the ref. tool).
 - If the reference tool reaches Minimum Z prior to deflection, an error message appears. The Minimum Z value should be adjusted as necessary.
4. The reference tool touches the tool probe, retracts slightly, and touches again at the feedrate specified in the Retract Feed field. The number of slow touches is specified by the Repetitions parameter. The average deflection position is recorded and saved for later use.

If for some reason the reference tool does not touch the probe, a fault will indicate that the probe deflection did not occur. You should then check the Tool Setup Probe Parameters screen and setup of the reference tool to correct the problem.

Touch Tool and Part Probe Calibration

For a tool probe and part probe configuration, make sure these fields are programmed properly:

- Set the Tool Setup Probe Parameters Type field to Touch Tool.
- Set the Part Setup Probe Parameters Present field to Yes.

⇒ Prior to probe calibration, the machine must be calibrated, and the part probe must be entered as a tool in Tool Setup (with tool type set to Probe).

In a tool and part probe system the part probe is placed in the spindle, activated, and touched to the tool probe. To activate the part probe, define the probe as a tool so Ultimax knows when the probe is in the spindle.

⇒ You must use a part probe instead of a reference tool for this configuration.

To access Touch Tool Probe Calibration:

1. Select the Input console button to access the Input screen
2. Select the Tool Setup softkey.
3. Select the Probing softkey.
4. Select the Calibrate Tool Probe softkey.

The following sequence occurs:

1. If the part probe is not already in the spindle, a "Part Setup Probe Tool Number" prompt appears. Enter the number that was previously selected for the part probe in Tool Setup.
2. Press the flashing Start Cycle button to perform the tool change, which will place the part probe in the spindle.

Or...

If the part probe is already in the spindle, press the flashing Start Cycle button and proceed to the next step.

3. The control activates the part probe. The table moves to the X,Y location specified by the Contact X and Contact Y fields in the Tool Setup Probe Parameters screen. If these fields have been entered correctly, the part probe should be directly in line with the tool probe stylus.
4. The Z axis starts moving downward at the feed rate specified in the Tool Setup Probe Parameters Approach Feed field.
 - The Z axis continues moving until a probe deflection occurs or Minimum Z is reached.
 - If the probe reaches Minimum Z prior to deflection, an error message appears. Minimum Z is set in the Part Setup Probe Parameters.
5. If the appropriate fields are set correctly, then the two probes will touch. The part probe will then retract slightly and touch again at the feed rate specified in the Measurement Feed field. The deflection position is recorded and saved for later use.

If for some reason the probes do not touch, the Z axis will stop when tool probe Minimum Z is reached. A fault will indicate that the probe deflection did not occur. Review the Part Setup Probe Parameters to correct the problem.

Laser Beam Calibration

The Laser Beam Calibration cycle uses a tool to probe the beam and determine the exact trigger point position in the light beam for X/Y and Z axes so the light beam can effectively measure tools. The *Determine Laser Beam Offset* softkey on the Tool Setup Probe Parameters screen initiates the cycle to set the beam offset value. Refer to the "Tool Probing Parameters" section for field definitions for this screen.


You must calibrate the laser system before using the light beam for measuring tools. The laser calibration tool or precision dowel used for performing calibration is inserted into the spindle just like any tool.

Laser Tool Calibration Calculations

The calibration tool's dimensions are determined by using a precision dowel or a laser calibration tool (see figure below). Use this formula to determine the location on the tool's diameter to interrupt the beam:

$$\text{Length} + (\text{Height} / 2) = \text{Point on Diameter to Interrupt Beam}$$

Ultimax uses the Cal Tool D(iameter), H(eight), and L(ength) fields (shown below as D, H, and L) and the trigger points established in this cycle to determine the Center Beam X or Y values, depending on the Probing Axis.




Laser Tool Calibration Cycle

Follow these steps to run the Laser Calibration Tool cycle:

1. Access the Tool Setup Probe Parameters screen using this softkey sequence:
 - a. Tool Setup softkey.
 - b. Probing softkey.
 - c. Tool Probe Parameters softkey.
2. In the Type field, select Laser Probe.
3. Enter values in the Cal Tool D, H, or L fields. The Determine Laser Beam Offset softkey appears when the cursor is in any of these fields.
4. Select the Determine Laser Beam Offset softkey.

The figure below illustrates the tool motion during this cycle:



Tool Probe Deflection Offset Calibration

Tool and part probe deflection offsets are the difference between the contact point of the probe and the actual receipt of a probe deflection signal. The offsets may vary for each direction of deflection. The switch points are repeatable to one micron or less.

These offsets need to be adjusted during an initial probe installation, a new stylus installation, or for centering or re-centering a stylus. They do not need to be performed each time the control is reset.

Tool Probe Deflection Offset

To access the Tool Probe Deflection Offset screen:

1. Select the Input console button to access the Input screen.
2. Select the Tool Setup softkey.
3. Select the Probing softkey
4. Select the Tool Probe Setup Parameters softkey.
5. Select the Tool Probe Deflection Offset softkey.

The Reference Tool Diameter field holds the diameter of the tool being probed.

The probe orientation determines the offsets used in the Probe Stylus Position fields. The -Z offset is always used along with +/-X or +/-Y, depending from which direction the probe can deflect.

The following sections describe the two methods for determining Tool Probe Deflection Offsets: Absolute Location or Reference Tool Touch.

Absolute Location

Use an edge finder to determine the absolute location of each edge of the probe stylus. Follow these steps:

1. Enter the Reference Tool Diameter.
2. Position the cursor on the desired offset field.
3. Position the reference tool to the correct start position.
4. Press the Use Probe to Determine Offset softkey. The Start Button flashes.
5. Press the flashing Start Button.
 - a. The cursor position determines which axis is moved and in what direction.
 - b. The deflected position is used to calculate the offsets.
 - c. The offset value appears in the current field.
 - d. The offsets are saved by the system so they are retained after power to the machine is turned off.
 - e. Unused fields contain a 0 value.
 - f. The sign of the offset is + for plus axis deflections and - for negative axis deflections.

Reference Tool Touch

Use a feeler gauge to determine the position where the reference tool touches the top and each side of the probe stylus. Follow the prompts on the screen to know which side of the stylus to use. Follow these steps:

1. Enter a 0 for the Reference Tool Diameter.
2. Position the reference tool in the correct start position. Begin with the top of the stylus.
3. Place the cursor in the -Z field of the Probe Stylus column.
4. Press the Use Probe to Determine Offset softkey. The Start Button flashes.
5. Press the flashing Start Button.
 - a. The cursor position determines which axis is moved and in what direction.
 - b. The deflected position is used to calculate the offsets.
 - c. The offset value appears in the -Z field.
 - d. The offsets are saved by the system so they are retained after power to the machine is turned off.
 - e. Unused fields contain a 0 value.
 - f. The sign of the offset is + for plus axis deflections and - for negative axis deflections.
6. Repeat these steps for the other two axis positions (+/- X and +/-Y). Position the reference tool appropriately and put the cursor in the appropriate Probe Stylus field.

You can manually adjust the deflection offsets to optimize performance. By running a probe cycle on a reference tool, you can make slight adjustments to the deflection offsets until the cycle returns with the exact value(s) desired.

Part Probe Calibration

This section describes the probe calibration and cycles available with the Probing Option. Once the probing equipment is calibrated, the tool and part can be calibrated using the probing equipment. This information can be stored in Tool or Part Setup, or in a data block, to be executed with the part program.

Probe calibration is only required on machines that also have a tool probe installed. Calibration methods vary between systems with tool probing only, and those with both tool and part probing. See the "Tool Probe Calibration and Cycles" section for more information.

Part Probe Deflection Offset Calibration

Part probe deflection offset is the difference between the contact point of the probe and the actual receipt of a probe deflection signal. The offset may vary for each direction of deflection.

Part probe deflection offsets need to be adjusted during an initial probe installation, a new stylus installation, or for centering or re-centering a stylus.

Part Probe Deflection Offset

To access Part Probe Deflection Offset:

1. Select the Input console key to access the Input screen.
2. Press the Part Setup softkey.
3. Press the Probing softkey. The Part Setup screen is displayed with the Part Probing menu.
4. Select the Part Probe Deflection Offsets softkey. The screen has softkeys for selecting the method to use for determining offsets.

The following sections describe the procedures to follow the Ring Gauge Method and Reference Block Method.

Ring Gauge

The Ring Gauge method probes in a circular pattern. Select the Part Probe Deflection Offsets softkey, followed by the Ring Gauge softkey. The following screen appears:

Follow these steps to determine a Ring Gauge Deflection Offset:

1. Enter the Diameter of the part.
2. Use an indicator or some similar method to determine the center of the gauge. Enter the Center of the gauge in the Center X and Center Y fields.
3. Jog the spindle to a point where the probe just touches the part. Enter that location in the Datum Z field by typing it in or by pressing the Store Position key on the Jog control.
4. Position the probe tip inside the gauge at the desired depth and select the Use Gauge to Get X&Y Offsets softkey. The Start button begins to flash.

5. Press the Start button to begin the cycle.
6. The probe touches the part at 36 points (10° increments) inside the gauge to automatically calculate the X and Y offsets. To determine the Z offset, position the probe tip above the chosen datum point and select the Use Datum Point to Get Z Offset softkey. The Start Button begins to flash.
7. Press the Start button to begin the cycle.
8. The probe touches off the datum point and calculates the offset.
9. The Offset values appear on the screen and are stored in memory. This offset will be used anytime the control uses a probe location.

Offset values may be entered manually. If you know the readings are off by a certain amount, you can make adjustments without even using the probe. The sign of the offset should be + for plus axis deflections, and - for minus axis deflections.

Reference Block

The Reference Block method probes in the + or - X or Y direction. Select the Part Probe Deflection Offsets softkey, followed by the Reference Block Method softkey. The following screen appears:

Follow these steps to determine the Reference Block Deflection Offsets for the X or Y axes:

1. Enter X or Y values manually in the Reference Block X or Y fields.
2. Position the cursor under the Deflection Offset column at the offset to be determined.
3. Jog the machine so the part probe is in the proper location to touch off the reference block for the desired axis and direction.
4. Press the Use Probe to Determine Offset softkey, and the Start button begins to flash.
5. Press the Start Button to start the cycle The probe touches off the reference block. The offset values are calculated, appear on the screen, and are stored in memory.

Follow these steps to determine the offset for the Z axis:

1. Jog the probe to the top of the reference block.
2. Use a feeler gauge to determine where the tip of the stylus would touch the reference block. Enter this value in the -Z field in the Reference Block column.
3. Select the Use Probe to Determine Offset softkey. The probe touches off the part in the Z axis to determine the offset.

Offset values may be entered manually. If you know the readings are off by a certain amount, you can make adjustments without using the probe.

The sign of the offset should be + for plus axis deflections and - for minus axis deflections.



The Ring Gauge method is more accurate than the Reference Block method.

- The probe measures the part at 36 points in 10° increments on the ring gauge.
- The 4 points measured on the reference block correspond to the 0° , 90° , 180° , and 270° values on the ring gauge. The remaining 32 values are estimated using the 4 actual measurements to fill in the 10° incremental offsets.

Tool Setup Probing Softkeys

Tool Setup Probing softkeys are as follows:

- [Tool Probe Setup Parameters](#)—Select the tool probe type and access tool probe parameters. Tool probe types are: Touch Probe, Laser Probe and No Probe.
- [Calibrate the Tool Probe](#)—Determine the Z location of the tool probe. Calibrate the Tool Probe only once for each reset of the control.
- **Probe A Single Tool**—Determines the length and/or diameter of a single tool.
- **Probe Multiple Tools**—Determines the length and/or diameter of multiple tools.
- **Position Tool Over the Probe**—Position the tool over the probe, before jogging Z to the desired position.
- **Select Tool Probe Cycle** Determine what part of the tool will be probed:
 - None – no tool probing occurs
 - Length – determine tool length
 - Diameter – determine tool diameter
 - Length & Diameter - determine tool length and diameter.
- **Probe Current Tool Now**—Available when the tool on the Tool Setup screen is also the tool in spindle. If the tool is already in the proper position for probing, the Z axis will not retract. Use this feature when the tool is just above the probe and the Rapid Z position is set. After probing, the Tool Setup screen reappears, and a "P" indicates the probed fields.
- **Exit**—Return to the Tool Setup screen.

Tool Setup Probing Fields

Tool Setup Probing fields are as follows:

- **Rapid Z Position**—The tool probe (in the Z axis) rapids down to this position and then continues downward at the speed specified in the Fast Feed field. Use the remote jog unit or type in a value for the Rapid Z Position field.

With the cursor in this field, the Position Tool Over Probe softkey can be used.

- **Spindle Usage**—Specifies in which direction the spindle should operate during the probe cycle. Choices are: manual (free rotating), oriented, clockwise (CW) or counter clockwise (CCW).

The default value for a touch tool probe is the reverse of the programmed tool. For example, if the tool is CW, Spindle Usage for a touch tool probe will default to CCW. For a laser tool probe, Spindle Usage value defaults to the programmed tool direction.

- **Spindle RPM**—Specifies spindle speed when the Spindle Usage field is set to either CW or CCW. When the operator updates the diameter setting for the tool probe, the Spindle RPM field will be updated with a suggested value – this value may be overwritten by the operator.
- **Fast Feed**—Specifies the feed rate used when making the initial touch of the probe (prior to measurement touches). When the operator updates the diameter setting for the tool probe, the Fast Feed field will be updated with a suggested value – this value may be overwritten by the operator.
- **Slow Feed**—Specifies the feed rate used when taking measurements after the initial deflection. The default value is 4 mm per minute for a touch probe, 25.4 mm per minute for a laser probe.
- **Minimum Z**—The lowest position that the Z axis will travel to during the probe cycle. Sets up a safety zone for each tool. The Minimum Z value should be low enough to allow proper deflection of the probe - especially important when checking diameter since the tool must drop down next to the probe stylus.
- **Length Offset X, Y**—Used to change the X or Y table position when probing tool length. This field will be ignored when probing tool diameter. Required for tools that have a cutter offset from the center.
- **Z Drop Down Depth**—Used only when measuring tool diameter. This parameter (a negative value) indicates the distance to drop down from where the tip of the tool touches the top of the probe. For example, if you want to measure the diameter of the tool ¼" from the tip, this parameter would be set to -0.25".
- **Side Clearance**—Specifies an additional distance to leave between the tool and tool probe when determining the tool diameter. This value can be adjusted to optimize probe cycle time.
- **Multi-Tool Probing**—Specifies which tools to probe and which to skip - used only in the multiple tool calibration cycle.
- **Sister Tool**—Identifies a spare tool to be used with Tool Monitoring.

Probe Part Setup

Use the Probe Part Setup data block to perform a part setup function using a probe. The probe will locate a point on the part such as a corner. When the program executes this data block, it will automatically probe the part and update Part Zero X, Part Zero Y, Probe Z, and X/Y Skew. The data block may be placed anywhere in the part program except within a Pattern.

The Probe Part Setup fields are defined as follows:

- **Block** - identifies the block number for this operation. The system determines the number by the position of this data block in the program. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Tool** - identifies the tool number for this data block and enters that tool's diameter and type on this screen. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Part Zero Cycle** - use the drop-down list or softkeys that appear when the field is selected to determine the geometric feature for this Part Zero Cycle.
- **Preset X/Y** - determines the X or Y coordinate to be assigned to the probed location.
- **Probe Direction X/Y** - (available only for Corner or Intersect) defines the X or Y value that determines the direction (positive or negative) that the probe moves when searching for the part. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Probing Radius** - (available only for Hole and Cylinder) enter the radius of the geometry. For a cylinder, this defines a clearance range to move the probe outside the cylinder. For a hole, this defines the maximum travel. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Z Depth** - (available only for Cylinder and Rect. Solid) defines the distance, relative to the Start Position, that the Z axis moves downward before changing direction and searching horizontally for each contact point on the geometry's surface. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Start Angle 1/2/3** - (available only for Hole and Cylinder) defines the three probe deflection points. Relative to the 3:00 position and increasing counterclockwise as viewed from above the part, the default angles are 0, 120, and 240, respectively. Change the angles if the part contains geometry that interferes with the defaults. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Probing Length X/Y** - (available only for Rect. Pocket and Rect. Solid) identifies the X or Y length of the geometry. For Rect. Pocket, this defines maximum travel. For Rect. Solid, this defines a clearance area to move the probe outside of the solid. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Offset X/Y** - (available only for Intersect) defines the X or Y offset positions from the Start Location. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **X Start X/Y/Z** - defines the X, Y, or Z coordinate that determines the starting point when probing along the X axis. This field appears on both the

[Probe Part Setup](#) and [Part Inspection](#) screens.

- **Y Start X/Y/Z** - defines the X, Y, or Z coordinate that determines the starting point when probing along the Y axis. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **XY Start X/Y/Z** - (available only for Hole, Cylinder, Rect. Pocket, and Rect. Solid) defines the X, Y, or Z coordinate that determines the starting point when probing along the XY axis. This field appears on both the [Probe Part Setup](#) and [Part Inspection](#) screens.
- **Z Start X/Y/Z** - defines the X, Y, or Z coordinate that determines the starting point when probing along the Z axis.
- **Skew Cycle** - select the geometric feature for this Skew Cycle from the drop down list or use the softkeys that appear when the Skew Cycle field is selected. If no Skew Cycle, select none.

The following fields appear based on the Geometric figure selected in the Skew Cycle field. They will not appear if None is selected in the Skew Cycle field.

- **Skew Axis** - defines the axis that is not square to the machine axis. This axis will be probed at two locations to determine its vector.
- **Preset X/Y** - defines an offset from Part Zero X or Part Zero Y of the feature to be probed.
- **Z Depth** - (available only when Cylinder or Rect. Solid is selected in the Skew Cycle field) defines the distance, relative to the Start Position, that the Z axis moves downward before changing directions and searching horizontally for each contact point on the geometry's surface.
- **Probing Length X/Y** - (available only when Rect. Pocket or Rect. Solid is selected in the Skew Cycle field) identifies the X or Y length of the geometry. For Rect. Pocket, this defines maximum travel. For Rect. Solid, this defines a clearance area to move the probe outside of the solid.
- **Probing Radius** - (available only when Hole or Cylinder is selected in the Skew Cycle field) enter the radius of the geometry. For a cylinder, this defines a clearance range to move the probe outside the cylinder. For a hole, this defines the maximum travel.
- **Probe Direction X/Y** - (available only when Edge is selected in the Skew Cycle field) defines the X or Y value that determines the direction (positive or negative) that the probe moves when searching for the part.
- **Skew Start X/Y/Z** - defines the X, Y, or Z coordinate that determines the starting point for the skewed axis.

Conversational Part Probing Cycles

Conversational part probing is used for locating the part's position and alignment on the table. Inserting a Probe Part Setup data block to run from the part program allows you to probe multiple parts and locate them at run time. This section describes probing cycles which are used for creating Probe Part Setup data blocks.

There are two types of cycles available for probing different types of part features: [Probing Cycles](#) and [Part Skew Probing Cycles](#). The cycles provide a method to

automatically enter the Part Zero X, Part Zero Y, Probe Z, and X/Y Skew (deg) fields.

Part Setup Screen

In addition to the standard Part Setup fields defined in [Part Setup](#), Ultimax updates these Part Setup fields with data obtained during the probing cycles:

- **Part Zero X, Y**—the part zero values established during Part Setup. Refer to the "Part Zero Storage" section in this chapter for details about the Part Zero X and Y fields.
- **Probe Z**—the distance from Z zero to the top of the part (i.e., the height, or Z Plane), including the reference tool or part probe in the spindle.
 - Z zero is the Z calibration point of the Z axis (Z = 0.0000).
 - WinMax adjusts tool length values automatically and Tool Zero Calibration is recalculated anytime Probe Z is changed.
- **X/Y Skew (deg.)**—represents, in degrees, how far the part is from perfect alignment with the table. Refer to the "Part Skew Probing Cycles" section of this chapter for more information about X/Y skew.

Part probing can be run either from Manual Mode or from [Auto Mode](#) inside the part program.

Part Zero Storage Cycle

At the end of each Probing Cycle, the results of the cycle are displayed in machine coordinates and do not include the Preset values.

Cycle	Results
Edge	Contact Position (X, Y, or Z)
Hole or Circle Pocket	Diameter, Center (X and Y)
Cylinder	Diameter, Center (X and Y)
Rectangular Pocket	Lengths (X and Y), Center (X and Y)
Rectangular solid	Lengths (X and Y), Center (X and Y)
Plane Intersection	Corner (X and Y)

Selecting the Accept Position as Part Zero softkey accepts the probed values and subtracts the presets to determine part zero. The new Part Zero values appear in the Part Zero X and Part Zero Y fields.

With an Edge probing cycle, the probe moves only one axis. Therefore, only one of Part Zero X, Part Zero Y, or Probe Z is set. With all other cycles, both Part Zero X and Part Zero Y are determined at the same time.



If the Preset values have not been entered at the beginning of the cycle, it is still possible to enter them or to change them before pressing the Accept Position as Part Zero softkey.

After pressing the Accept Position as Part Zero softkey, the initial Part Setup Screen appears with new Part Zero entries. The Part Zero X and Y fields now contain values carried over from the Corner X and Corner Y fields in the Plane Intersection Probe Cycle.

Manual Mode Part Setup Probing Cycles

During a Part Setup Probing cycle, the probe moves to specified points on the part, deflects, and stops in the center or at the Start Position (depending on the part feature). From the Part Setup screen, use the Probing softkey to access the [Probing Cycles](#).

Each cycle is described in detail in the following sections. When the cycle is finished, values representing the desired features are displayed. The fields for each cycle vary and are defined with each cycle description.

You can accept these values by pressing the Accept Position as Part Zero softkey when it appears. If you have entered Preset X or Preset Y offsets, these offsets are subtracted from the probed Part Zero values, and the new Part Zero values appear after pressing the Accept Position as Part Zero softkey.

Follow these steps to access the [Part Probe Cycles](#):

1. From the Part Setup screen, select the Probing softkey. These softkeys appear for selecting Probing functions:
2. Select the Part Zero Probe Cycles softkey. These softkeys appear for selecting the Part Probe Cycle types:

Depending on the Probing Cycle selected, different probing fields appear on the Part Setup screen.

Manual Mode Part Skew Probing Cycles

From the Part Setup screen, use the Probing softkey to access the [Probing Cycles](#). During a Part Skew Probing cycle the probe moves to specified points on the part, deflects, and stops in the center of the part feature. These cycles detect and compensate for *X/Y skew* in the work piece. *X/Y skew* represents, in degrees, how far the part is from perfect alignment with the table.

- A positive skew angle means the part is rotated in a counterclockwise direction from the machine axes (as viewed from above the part).
- A negative skew angle indicates a clockwise rotation from the machine axes.

Although this angle, if known, can be typed in, it is easier and more accurate to let the probe find the skew angle and automatically enter it.




For best results, it is recommended that you use the probe for determining Part Zero X, Part Zero Y, and X/Y Skew. Entering values for any of these fields with the keypad reduces the amount of information available for skew calculations. Also, the software must make assumptions that may reduce accuracy.

After probing the Part Zero position as a reference, the skew cycles allow you to probe a second feature on the part and adjust all machining operations by the skew angle to exactly match the part.

When the cycle is finished, the software displays values representing the desired features. The fields for each cycle vary and are defined with each cycle description.

You can accept these values by pressing the Accept X/Y Skew Angle softkey when it appears. Preset X or Preset Y offsets are used in the skew calculation. The presets are subtracted from the probed Part Zero values, and the new Part Zero values appear after pressing the Accept Position as Part Zero softkey.

The figure below illustrates a skewed work piece with a Preset Y offset.



Enter offsets for Preset X and Preset Y for a precise Skew Angle. If only one Preset value is entered, the skew angle will be approximate and should not exceed 3 degrees.

Skew Compensation is intended to be used for correcting a slight misalignment. If the skew angle contains only one Preset value and is greater than approximately 3 degrees, then Part Skew probing may not be exact, especially for Edge and Rectangular cycles.

Follow these steps to perform a Skew Probe Cycle for work piece skew compensation:

1. Perform the Part Zero Probe Cycle. Refer to the appropriate Part Probe Cycle in this chapter (i.e., Edge, Cylinder, etc.) or more information.
2. From the Part Setup screen, select the Probing softkey followed by the Part Skew Probe Cycles softkey to access the Part Skew Probe Cycles:

3. The following screen will appear for selecting the Skew Probe Cycle type. Press the appropriate softkey to select the desired cycle.

Depending on the Skew Probing Cycle selected, different probing fields appear on the Part Setup screen.



The following sections describe how to program each of the Part Skew Probing Cycles.

Automatic Mode

To locate part zero and to determine skew in the X-Y plane as part of the program instead of manually during Part Setup, the Probe Part Setup conversational data block can be used to automatically perform this function.

Access the Probe Part Setup data block from the Part Programming screen as a Miscellaneous Data Block. Select the Miscellaneous softkey from the New Block screen.

Probe Part Setup Data Block

From the New Block screen, press the Probe Part Setup softkey. The Probe Part Setup data block screen appears with fields for programming cycles to determine part zero alone or in addition to determining the skew in the XY plane.

The fields on the left-hand side of the screen and the X, Y, and Z Start fields apply to the Part Zero Cycle; the fields on the right-hand side of the screen and the Skew Start fields apply to the Skew Cycle.

Probe Part Setup Fields

The Probe Part Setup screen contains fields for the Part Zero Cycle and the Skew Cycle. The fields change depending on the selected cycle.

Automatic Part Zero Cycles

The fields listed below apply to Part Zero Cycles indicated and are defined as follows:

Part Zero Cycle	Field	Definition
All cycles	Tool	the tool number of the part probe.
All cycles	Part Zero Cycle	the geometric feature for this Part Zero cycle. Softkey choices appear for selecting the appropriate feature when the cursor is in this field.
All cycles	Preset X Preset Y	an offset for Part Zero X and/or Part Zero Y from the probed feature.
Corner and Plane Intersection	Probe Direction X Probe Direction Y	based on the Probe Axis field, defines which direction, positive or negative, the probe moves when looking for the part.
Rect. Pocket and Rect. Solid	Probing Length X Probing Length Y	the X or Y length of the geometry. For Pocket this defines maximum travel. For Solid this defines a clearance area to move the probe outside the Solid.
Cylinder and Hole or Circle	Probing Radius	the radius of the geometry. For Cylinder this defines a clearance range to move the probe outside the Cylinder. For Hole or Circle this defines maximum travel.

Part Zero Cycle	Field	Definition
Cylinder and Rectangular Solid	Z Depth	distance the Z axis moves downward before changing direction and searching horizontally for each contact point on the geometry's surface. Z Depth can be set to move the probe anywhere within the Z Axis travel limits.
Plane Intersection	Offset X Offset Y	X or Y offset positions from the Start location.
Cylinder and Hole or Circle	Start Angle1 Start Angle2 Start Angle3	the three probe deflection points. Relative to the 3:00 position and increasing counter-clockwise as viewed from above the part, the default angles are 0, 120, and 240, respectively. Change the angles if the part contains geometry that interferes with the defaults.
All cycles	X, Y, Z Start Positions	where to begin the probing process. The easiest method for entering the start positions is to jog the probe down to the desired start location and press the Store Position key. A single push of this key automatically enters all three coordinates (X, Y, and Z) for one Start position.

Automatic Skew Cycles

These fields apply to the Skew Cycle indicated and are defined as follows:

Skew Cycle	Field	Definition
All cycles	Tool	the tool number of the part probe.
All Skew cycles	Skew Cycle	the geometric feature for this Part Skew cycle. Softkey choices appear for selecting the appropriate feature when the cursor is in this field.
All Skew cycles	Skew Axis	define either the X or Y axis as the skew axis. There is no skewing in Z.
All Skew cycles	Preset X or Preset Y	an offset from Part Zero X or Part Zero Y of the feature to be probed. NOTE: Preset X and Preset Y are available in all cases. For better and more accurate skew compensation, the user should enter values for both fields
Cylinder and Rect. Solid	Z Depth	distance the Z axis moves downward before changing direction and searching horizontally for each contact point on the geometry's surface. Z Depth can be set to move the probe anywhere within the Z Axis travel limits.
Rect. Pocket and Rect. Solid	Probing Length X Probing Length Y	the X or Y length of the geometry. For Pocket this defines maximum travel. For Solid this defines a clearance area to move the probe outside the Solid.

Skew Cycle	Field	Definition
Cylinder and Hole or Circle	Probing Radius	the radius of the geometry. For Cylinder this defines a clearance range to move the probe outside the Cylinder. For Hole or Circle this defines maximum travel.
Edge	Probe Direction X or Y (depending on Skew Axis selection)	direction, positive or negative, the probe moves when looking for the part.
All Skew cycles	Skew Start Positions	where to begin the probing process. The easiest method for entering the start positions is to jog the probe down to the desired start location and press the Store Position key. A single push of this key automatically enters all three coordinates (X, Y, and Z) for one Start position.

Probe Part Setup Data Block Execution

When the program executes this data block, it will automatically probe the part and update Part Zero X, Part Zero Y, Probe Z and *X/Y Skew*. The data block may be placed anywhere in the part program except within a Pattern.

Part Inspection Cycles

To access the Part Inspection cycles, follow this softkey sequence from the Input screen:

1. Select Part Programming.
2. Select Miscellaneous.
3. Select More.
4. Select the Part Inspection softkey.

Part Inspection Fields

The fields on the Part Inspection screen change depending on the selected cycle and are defined as follows:

Inspection Cycle	Field	Definition
All cycles	Tool	the part probe tool number.
All cycles	Cycle	the type of cycle to be inspected.
Single Point	Probe Axis	the axis to be probed.
Single Point and Plane Intersection	Probe Direction X Probe Direction Y	based on the Probe Axis field, defines which direction, positive or negative, the probe moves when looking for the part.
Rectangular Pocket and Rectangular Solid	Probing Length X Probing Length Y	the X or Y length of the geometry. For Pocket this defines maximum travel. For Solid this defines a clearance area to move the probe outside the Solid.
Cylinder and Hole or Circle	Probing Radius	the radius of the geometry. For Cylinder this defines a clearance range to move the probe outside the Cylinder. For Hole or Circle this defines maximum travel.
Cylinder and Rectangular Solid	Z Depth	distance the Z axis moves downward before changing direction and searching horizontally for each contact point on the geometry's surface.
Plane Intersection	Offset X Offset Y	the X or Y offset positions from the Start location.

Inspection Cycle	Field	Definition
Cylinder and Hole or Circle	Start Angle1 Start Angle2 Start Angle3	the three probe deflection points. Relative to the 3:00 position and increasing counter-clockwise as viewed from above the part, the default angles are 0, 120, and 240, respectively. Change the angles if the part contains geometry that interferes with the defaults.
All cycles	X, Y, Z Start Positions	where to begin the probing process. The easiest method for entering the start positions is to jog the probe down to the desired start location and press the Store Position key. A single push of this key automatically enters all three coordinates (X, Y, and Z) for one Start position.

Part Inspection Programming

Follow these steps to program a Part Inspection data block:

1. Enter the part probe tool number in the tool field.
2. When the cursor is on the Inspection Cycle field, the softkeys change. Select a cycle type for the Inspection Cycle field.
3. Program the remaining fields as described in the "Part Inspection Fields" section. The data block is stored with the program and executed automatically.

Part Inspection Files

When the Part Inspection data block is executed, the part inspection files are automatically created. The position data is presented in part relative coordinates.

⇒ For single point inspection, the reported Z part position includes the Offset Z value from Part Setup.

Part Inspection files are saved to the same location as the part program, and have the same name as the part program, with a .TXT filename extension. These files can be printed with the Probing Data Printing softkey in Utilities/Printing Setup.

Probe Tool Monitoring

Probe Tool Monitoring is available to automatically monitor calibrated tools and detect breakage or wear.

The software compares the current tool dimensions to the calibrated dimensions stored in [Tool Setup](#) for the programmed tool. If the current dimensions deviate from the defined tolerance programmed in the tool monitoring menus, the tool is defective.

It is possible to program a spare tool to automatically replace a defective monitored tool. If the spare tool is not programmed, or if there is no ATC, axis motion stops and the following message appears on the screen: "Tool # x is defective, no more tools to substitute."

You can invoke tool monitoring in two ways:

- Enable the [Program Parameters](#) Automatic Tool Monitoring field. This setup automatically invokes tool monitoring immediately after tool changes for every probed tool.
- Use a data block in a Conversational Part Program to define which tool should be monitored through a specific monitoring cycle.

The following fields appear on the Tool Monitoring screen:

- **Block** - identifies the block number for this operation. The system determines the number by the position of this data block in the program. To move to another block, enter the number of the block.
- **Probe Cycle Type** - displays the type of detection cycle selected for the Probe Tool Monitoring. You may select **Tool Breakage Detection, Tool**

Length Wear Detection, Tool Diameter Wear Detection, or Tool Length & Diameter Wear Detection. The selection in this field determines the fields that appear on the Tool Monitoring screen.

- **Tool** - displays the number of the tool to be monitored. Enter the number of the tool that you wish to be monitored in this block.
- **Breakage Tolerance** - (available only for Tool Breakage Probe Cycle Types) enter the amount of deviation from the tool length programmed in the Zero Calibration field on the [Tool Setup screen](#).
- **Zero Cal Tolerance** - (available only for Tool Length Wear Detection and Tool Length & Diameter Wear Detection Probe Cycle Types) enter the amount of deviation from the tool length programmed in the Zero Calibration field on the [Tool Setup screen](#).
- **Diameter Tolerance** - (available only for Tool Diameter Wear Detection and Tool Length & Diameter Wear Detection Probe Cycle Types) enter the amount of deviation from the tool diameter programmed in the Diameter field on the [Tool Setup screen](#).
- **Speed** - displays the spindle speed value defined for this tool on the [Tool Setup Screen](#). This value can be manually changed on the Tool Monitoring screen. This field does not appear if the Spindle Usage field in Tool Setup Probing is set to Manual or Oriented.
- **Direction** - select the direction (CW or CCW) that the spindle will run. This field does not appear if the Spindle Usage field in Tool Setup Probing is set to Manual or Oriented.
- **Probing Method** - displays the method for referencing the tool that was specified in Tool Setup; field is read-only.
- **Spindle Usage** - displays the direction in which the spindle should operate during the probe cycle; specified in Tool Setup. Choices are manual (free rotating), oriented, clockwise (CW) or counter clockwise (CCW).
- **Sister Tool** - displays the tool that will be used to automatically replace the monitored tool if it deviates from the limits specified in the BREAKAGE TOLERANCE, ZERO CAL TOLERANCE, or DIAMETER TOLERANCE fields. The field is read-only. Sister tool is specified in Tool Setup.

You may use the above fields to program data blocks that will check for [Tool Breakage](#) and/or [Tool Wear](#).

Manual Tool Probing Cycles

Tool probing determines the Zero Calibration and/or Diameter values for a particular tool, and stores these values in the Tool Setup screen. The tool's length will be stored in the Zero Calibration field. The tool's diameter can also be probed and stored in the Diameter field.

Before using the tool probe, review the changes that appear on the Tool Setup screen. Any tool that has been calibrated with the probe will have a "P" *designator* next to the Diameter and Zero Calibration values.

The following two softkeys [Probe a Single Tool](#) and [Probe Multiple Tools](#) allow for manual probing of tools within tool setup.

Probe a Single Tool

The Probe a Single Tool feature determines the Zero Calibration value and/or tool diameter, based on the selection made for the Probe Cycle field. The tool must be already entered in Tool Setup before probing.

⇒ If the tool diameter will be probed, an approximate value must be entered in the diameter field. This approximate value will be replaced by the Probe value after the tool is probed.

Follow these steps to Probe a Single Tool:

1. Select the Input console button to access the Input screen.
2. Select the Tool Setup softkey. The Tool Setup screen appears.
3. Select the More -> softkey on the Tool Setup Screen.
4. Select the Tool Probing softkey.
5. Select the Probe a Single Tool softkey.
6. Enter the Tool Number to probe.
7. The Start Cycle button flashes. Press Start to begin the probe cycle.

⇒ A tool's Zero Calibration value is automatically recalculated anytime Probe Z is changed. If the Zero Calibration seems to be incorrect, check the Probe Z value in the Part Setup screen.

Probe Multiple Tools

The Probe Multiple Tools feature determines the Zero Calibration value and/or tool diameter, based on the selection made for the Probe Cycle field. The tools must be already entered in Tool Setup before probing.

All tools that have been defined in Tool Setup and have Multi-Tool Probing field set to Yes will be included in the multiple tool probing cycle. Any tool that has Multi-Tool Probing set to No will be skipped, but may still be probed using the single tool cycle.

⇒ If the diameters will be probed, an approximate value must be entered in the diameter field for each tool. The approximate values will be replaced by Probe values after each tool is probed.

Follow these steps to perform a Probe Multiple Tools cycle:

1. Select the Input console button to access the Input screen.
2. Select the Tool Setup softkey. The Tool Setup screen appears.
3. Select the More -> softkey on the Tool Setup Screen.
4. Select the Probe Multiple Tools softkey.
5. The Start Cycle button flashes and you are prompted to press it.

6. Press the Start Cycle button to continue. A tool will be probed only if the Probe Cycle is defined and the Multi-Tool Probing field is set to Yes. The first tool to meet these requirements is placed in the spindle and probed.
7. The next tool to meet the multi tool probing criteria is located in the tool list. A tool change occurs and the tool is probed.
8. The tool change and probing process repeats until the original tool in spindle is reached.

⇒ The entire Probe Multiple Tools process is automatic (as long as the tools are in the ATC), and does not require operator supervision.

Tool Wear Detection Data Block

Follow these steps to program a Tool Wear Detection data block:

1. From the Probe Tool Monitoring screen, select the Length Wear Detection, Diameter Wear Detection, or Length and Diameter softkey.
2. Enter the tool number to be monitored. The tool must be programmed in Tool Setup, and it must be calibrated.
3. Enter the Zero Calibration Tolerance or the Diameter Tolerance, or both if monitoring both length and diameter.
4. If desired, adjust the Speed (RPM) value.

When the data block executes, the current tool length is measured and compared with the tool length or diameter tolerance (or both, if monitoring both length and diameter). If the tool is shorter than the Zero Calibration value minus the programmed tolerance, the tool is worn. If the tool's diameter is less than the Diameter minus the programmed tolerance, the tool is worn. The "P" on the Tool Setup screen is replaced with a "D" to indicate the tool is defective.

If a spare tool was programmed, axis motion stops and a tool change automatically occurs. If there is no spare tool programmed in the ATC, axis motion stops and a message appears asking you to change tools.

Probing Cycles

Ultimax uses information programmed in the Part Setup screen to perform the Probing Cycles in Manual or Automatic mode.

Part Setup Probing Cycles

The table below describes the process for each Part Setup Probing Cycle:

Cycle Type	Cycle Parameter Input	Automatic Execution	Results Displayed	Optional Storage
Edge	Axis Probe Direction Positive or Negative Preset X or Y	Approach edge. Retract. Return to Start Position.	Deflection Position X, Y, or Z	Deflection Position X, Y, or Z is Part Zero X, Part Zero Y, or Probe Z.
Hole Circle Pocket	Start Angle 1, 2, 3 Preset X Preset Y	Approach 3 Circle Points from inside. Position Probe into Center.	Center X Center Y Diameter	Center is Part Zero X and Part Zero Y.
Cylinder	Probing Radius Start Angle 1, 2, 3 Z Depth Preset X Preset Y	Approach 3 Cylinder points from outside. Position Probe above cylinder Center.	Center X Center Y Diameter	Center is Part Zero X and Part Zero Y.
Rectangular Pocket	Preset X Preset Y	Approach the 4 pocket walls from inside. Position Probe into pocket Center.	Center (X) Center (Y) Length (X) Length (Y)	Center is Part Zero X and Part Zero Y.
Rectangular Solid	Probing Length (X) Probing Length (Y) Z Depth Preset X Preset Y	Approach the 4 Rectangle walls from outside. Position Probe above rectangle Center.	Center (X) Center (Y) Length (X) Length (Y)	Center is Part Zero X and Part Zero Y.
Plane Intersection	X Probe Direction Offset 1 Offset 2 Y Probe Direction Offset 1 Offset 2 Preset X Preset Y	Approach 2 points on each of the two planes. Return to Start Position.	Intersection point of the two planes in the X/Y coordinate system	Intersection point is Part Zero X and Part Zero Y.

Part Skew Probing Cycles


The following table describes the process of the Skew Probing Cycles:

Skew Cycle Type	Cycle Parameter Input	Automatic Execution	Display of the results	Optional storage
Edge	Axis X, Y, or Z Probe Direction: Positive or Negative Preset X or Preset Y	Approach edge. Retract. Return to Start Position.	Deflection Position X, Y, or Z Skew Angle (deg)	Skew Angle
Hole or Circle Pocket	Start Angle 1, 2, 3 Preset X Preset Y	Approach 3 Circle Points from inside. Position Probe into Center.	Center X Center Y Diameter Skew Angle (deg)	Skew Angle
Cylinder	Probing Radius Z Depth Start Angle 1, 2, 3 Preset X Preset Y	Approach 3 Cylinder Points from outside. Position Probe above cylinder Center.	Center X Center Y Diameter Skew Angle (deg)	Skew Angle
Rectangular Pocket	Preset X Preset Y	Approach the 4 pocket walls from inside. Position Probe into pocket Center.	Center X Center Y Length X Length Y Skew Angle (deg)	Skew Angle
Rectangular Solid	Probing Length X Probing Length Y Z Depth Preset X Preset Y	Approach the 4 Rectangle walls from outside. Position Probe above rectangle Center.	Center X Center Y Length X Length Y Skew Angle (deg)	Skew Angle


Edge Cycle

An Edge Cycle is used for determining the location of a specified edge of the part. During an Edge Cycle, the part probe moves to the X, Y, or Z edge of the part and records the deflection position.

The figure below shows part probe movement during X, Y, and Z Edge Cycles:



The figure below shows a side view of an Edge cycle probing in the X direction:



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these Part Setup fields appear for the Edge Probing Cycle:

- **Edge (X, Y, or Z)**—The machine coordinate position of the Edge Cycle. This field appears upon completion of the Edge Cycle.
- **Part Probe Cycle**—The type of cycle chosen from the Part Zero Probe Cycles softkey menu.
- **Probing Axis**—The axis to move toward the edge of the part: X Axis, Y Axis, or Z Axis.
- **Probing Direction**—The direction to probe: Positive or Negative. This field appears when the Probing Axis is X or Y. It is not available for Probing Axis Z.
- **Preset X, or Preset Y**—An offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional.

The offset(s) will be subtracted from the center point of the circle and applied to Part Zero X and Y, if you select the Accept Position as Part Zero softkey which appears after the cycle has been run. This field appears when the Probing Axis is X or Y. It is not available for Probing Axis Z.

Follow these steps to program an Edge Probing Cycle:

1. From the Part Zero Probe Cycles softkey menu, select Edge.
2. In the Probing Axis field, select the axis to move toward the edge of the part: X Axis, Y Axis, or Z Axis.
3. In the Probing Direction field, select the direction to probe. This field only appears when the Probing Axis is X or Y.
4. If you want to program an offset from Part Zero X or Part Zero Y, enter the offset value in the Preset X or Preset Y field. The field only appears when Probing Axis is X or Y.



After the Part Setup fields are entered, start the Edge Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, near the edge to be probed.
2. Press the Start Probing softkey. The Start Cycle button flashes.
3. Press the flashing Start Cycle button.
4. The Accept Position as Part Zero and Do Not Accept softkeys appear.
 - The Accept Position as Part Zero softkey accepts the edge position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.
5. The initial Part Setup screen appears with Part Zero entries established during the cycle.

Hole or Circle Pocket Cycle

The Hole or Pocket Cycle is used for determining the center location and diameter of a hole or pocket. During a Hole or Circle Pocket Cycle, the part probe moves from the inside of the circle out to three points on the edge, touches at each point, and returns to the Start Position within the circle after each touch. The software records each deflection position and calculates the center location. The probe positions in the center of the pocket.

The figure below shows part probe movement during a Hole or Circle Pocket Cycle:



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these *Part Setup* fields appear for the Hole or Circle Pocket Probing Cycle:

- **Center X**—The Center X machine coordinate location. This field appears upon completion of the cycle.
- **Center Y**—The Center Y machine coordinate location. This field appears upon completion of the cycle.
- **Diameter**—The diameter of the hole or circle pocket. This field appears upon completion of the cycle.
- **Part Probe Cycle**—The type of cycle chosen from the Part Zero Probe Cycles menu.
- **Start Angle 1, 2, 3**—The three probe deflection points. Relative to the 3:00 position, and increasing counterclockwise as viewed from above the part, the default angles are 0, 120, and 240, respectively. Change the angles if the part contains geometry that interferes with the defaults.
- **Preset X and Preset Y**—An offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional.

The offset(s) will be subtracted from the center point of the circle and applied to Part Zero X and Y if you select the Accept Position as Part Zero softkey, which appears after the cycle has been run.

Follow these steps to program a Hole or Circle Pocket Probing Cycle:

1. From the Part Zero Probe Cycles softkey menu, select Hole or Circle Pocket.
2. In the Start Angle fields, enter the desired approach angles.
3. If you want to program an offset from Part Zero X or Part Zero Y, enter the offset value in the Preset X or Preset Y field.

After Part Setup fields are entered, start the Hole or Circle Pocket Probing Cycle:

1. Place the part probe in the spindle and jog it to the Start Position - into the


pocket and below the surface.

2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.
4. The Accept Position as Part Zero and Do Not Accept softkeys appear.
 - Accept Position as Part Zero accepts the center position and subtracts presets to determine Part Zero.
 - Do Not Accept ignores the center value and the Preset X or Y value. Part Zero remains unchanged.
5. The initial Part Setup screen with Part Zero entries appears.

Cylinder Cycle

The Cylinder Cycle is used for determining the center location and the diameter of a cylinder. During a Cylinder Cycle, the part probe moves from the Start Position above the cylinder, out and down to three points around the diameter. The probe touches at each point and returns up and over to the Start Position above the cylinder after each touch. The diameter and the center location of the cylinder is determined.

The figure below shows part probe movement during a Cylinder Cycle:



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these *Part Setup fields* appear for the Cylinder Cycle:

- **Center X**—The Center X machine coordinate location. This field appears upon completion of the cycle.
- **Center Y**—The Center Y machine coordinate location. This field appears upon completion of the cycle.
- **Diameter**—The diameter of the cylinder. This field appears upon completion of the cycle.

- **Part Probe Cycle**—The type of cycle chosen from the Part Zero Probe Cycles softkey menu.
- **Probing Radius**—Value for the probe search radius. This value is used for determining the point at which the probe stops horizontal travel and begins to move downward.
- **Start Angle 1, 2, 3**—The three probe deflection points. Relative to the 3:00 position and increasing counterclockwise as viewed from above the part, the default angles are 0, 120, and 240, respectively. Change the angles if the part contains geometry that interferes with the defaults.
- **Z Depth**—Distance the Z axis moves downward before changing direction and searching horizontally for each contact point on the cylinder's diameter. Z Depth can be set to move the probe anywhere within the Z Axis travel limits.
 - ⇒ There should be no deflection during the Z move.
- **Preset X and Preset Y**—An offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional.

The offset(s) will be subtracted from the center point of the circle and applied to Part Zero X and Y if you select the Accept Position as Part Zero softkey, which appears after the cycle has been run.

Follow these steps to program a Cylinder Probing Cycle:

1. From the Part Zero Probe Cycles softkey menu, select Cylinder.
2. In the Probing Radius field, enter the probe search radius.
3. In the Start Angle fields, enter the desired approach angles.
4. In the Z Depth field, enter the distance the Z axis moves down before changing direction and searching horizontally for each contact point.
5. If you want to program an offset from Part Zero X and Part Zero Y, enter the offset value in the Preset X and Preset Y field.



When the Part Setup fields have been entered, start the Cylinder Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, above the cylinder.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the flashing Start Cycle button.
4. The Accept Position as Part Zero and Do Not softkeys appear.
 - Accept Position as Part Zero - accept the center and subtracts the presets to determine part zero.
 - The Do Not Accept - ignore the center values and the Preset X or Y value. Part Zero remains unchanged.
5. The initial Part Setup screen appears with Part Zero entries established during the cycle.

Rectangular Pocket Inside Cycle

The Rectangular Pocket Inside (or Rectangular Pocket) Cycle is used for determining the center location of the pocket and the X and Y length of the rectangle. During a Rectangular Pocket Cycle, the part probe moves from inside the pocket out to a point on each edge of the rectangle, touches at each point, and returns to the Start Position after each touch. The software records each deflection position and calculates the center location and lengths.

The figure below shows part probe movement during a Rectangular Pocket Cycle.



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these *Part Setup* fields appear for the Rectangular Pocket Cycle:

- **Center X**—The Center X machine coordinate location. This field appears upon completion of the cycle.
- **Center Y**—The Center Y machine coordinate location. This field appears upon completion of the cycle.
- **Length (X)**—The X length of the pocket. This field appears upon completion of the cycle.
- **Length (Y)**—The Y length of the pocket. This field appears upon completion of the cycle.
- **Part Probe Cycle**—The type of cycle chosen from the Part Zero Probe Cycles softkey menu.
- **Preset X or Preset Y**—Offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional. The offset(s) will be subtracted from the center point of the pocket and applied to Part Zero X and Y if you select the Accept Position as Part Zero softkey.

Follow these steps to program a Rectangular Pocket Cycle:

1. From the Part Zero Probe Cycles softkey menu, select Rectangular Pocket

Inside.

2. If you want to program an offset for Part Zero X or Part Zero Y, enter the offset value in the Preset X or Preset Y field.

After the Part Setup fields are entered, start the Rectangular Pocket Cycle:


1. Place the part probe in the spindle and jog the probe to the Start Position, into the pocket and below the surface.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.
4. The Accept Position as Part Zero and Do Not Accept softkeys appear. Press the appropriate softkey.
 - Accept Position as Part Zero - accept the center and subtracts the presets to determine part zero.
 - The Do Not Accept - ignore the center and length values and the Preset X or Y value. Part Zero remains unchanged.

Refer to the "Part Zero Storage" section of this chapter for more information.
5. The initial Part Setup screen appears with Part Zero entries established during the cycle.

Rectangular Solid Outside Cycle

A Rectangular Solid Outside (or Rectangular Solid) Cycle is used for determining the center location of the pocket and the X and Y length of the rectangle. During a Rectangular Solid Cycle, the part probe moves from above the rectangle out and down to a point on each of the four walls, touches at each point, and returns to the Start Position after each touch. Each deflection position is recorded the center position and lengths are calculated.

The figure below shows part probe movement during a Rectangular Solid Cycle:



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these Part Setup fields appear for the Rectangular Solid Cycle:

- **Center X**—The Center X machine coordinate location. This field appears upon completion of the cycle.
- **Center Y**—The Center Y machine coordinate location. This field appears upon completion of the cycle.
- **Length (X)**—The X length of the rectangle. This field appears upon completion of the cycle.
- **Length (Y)**—The Y length of the rectangle. This field appears upon completion of the cycle.
- **Part Probe Cycle**—The type of cycle chosen from the Part Zero Probe Cycles softkey menu.
- **Probing Length X**—A maximum value of the estimated X length. Half of this value is used to determine the point at which the Z axis begins to move downward (i.e., its horizontal travel limit for X).
- **Probing Length Y**—A maximum value of the estimated Y length. Half of this value is used to determine the point at which the Z axis begins to move downward (i.e., its horizontal travel limit for Y).
- **Z Depth**—The distance the Z axis moves downward before changing direction and searching horizontally for each contact point on the cylinder's diameter. Z Depth can be set to move the probe anywhere within the Z Axis travel limits.

⇒ There should be no deflection during the Z move.

- **Preset X and Preset Y**—An offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional. The offset(s) will be subtracted from the center point of the rectangle and applied to Part Zero X and Y if you select the Accept Position as Part Zero softkey, which appears after the cycle has been run.

Follow these steps to program a Rectangular Solid Cycle:

1. From the Part Setup Probe Cycles softkey menu, select Rectangular Solid Outside.
2. In the Probing Length X field, enter an estimate for the X length.
3. In the Probing Length Y field, enter an estimate for the Y length.
4. In the Z Depth field, enter the distance the Z axis should move down.
5. If you want to program an offset for Part Zero X and Part Zero Y, enter the offset value in the Preset X and Preset Y field.


When the Part Setup fields have been entered, start the Rectangular Solid Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, above the middle of the rectangle.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.
4. The Accept Position as Part Zero and Do Not Accept softkeys appear. Press the appropriate softkey.
 - Accept Position as Part Zero – accept the center and subtracts the presets to determine part zero.
 - The Do Not Accept - ignore the center and length values and the Preset X or Y value. Part Zero remains unchanged.
5. The initial Part Setup screen appears with Part Zero entries established during the cycle.

Plane Intersection (Non-Rectangular Corner) Cycle

A Plane Intersection Cycle is used for determining an X and Y intersection for a non-rectangular corner. During a Plane Intersection Cycle, the part probe moves from an offset position to two points in the X direction and two points in the Y direction to determine an X and Y intersection point.

The Plane Intersection cycle can be used with solid or pocket geometry. The figure below shows part probe movement with the two types of geometry:



In addition to the standard Part Setup fields which are defined in [Part Setup](#), these *Part Setup* fields appear for the Plane Intersection Cycle:

- **Corner X**—The X position of the intersection. This field appears when the cycle is finished.
- **Corner Y**—The Y position of the intersection. This field appears when the cycle is finished.
- **Probing Direction X**—The X direction to probe: Positive or Negative.
- **Offset 1**—The first Y offset position.
- **Offset 2**—The second Y offset position.
- **Probing Direction Y**—The Y direction to probe: Positive or Negative.
- **Offset 1**—The first X offset position.
- **Offset 2**—The second X offset position.
- **Preset X and Preset Y**—An offset for Part Zero X and/or Part Zero Y. Entering offsets in either of these fields is optional. The offset(s) will be subtracted from the corner point and applied to Part Zero X and Y if you select the Accept Position as Part Zero softkey, which appears after the cycle has run.

Follow these steps to program a Plane Intersection Cycle:

1. From the Part Zero Probe Cycles softkey menu, select Plane Intersection.
2. In the Probing Direction X field, select Positive or Negative.
3. In the Offset 1 field, enter the position for the first Y Offset, relative to the Start Position.
4. In the Offset 2 field, enter the position for the second Y Offset, relative to the Start Position.
5. In the Probing Direction Y field, select Positive or Negative.
6. In the Offset 1 field, enter the position for the first X Offset, relative to the Start Position.
7. In the Offset 2 field, enter the position for the second X Offset, relative to the

Start Position.

8. If you want to program an offset from Part Zero X or Part Zero Y, enter the offset value in the Preset X or Preset Y field.

When the Part Setup fields have been entered, start the Plane Intersection Cycle:

1. Place the part probe in the spindle and jog the probe into the Start Position, near the non-rectangular corner.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the flashing Start Cycle button.
4. The Accept Position as Part Zero and Do Not Accept softkeys appear. Press the appropriate softkey.
 - Accept Position as Part Zero - accept the corner position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept - ignore the corner values and the Preset X or Y value. Part Zero remains unchanged.
5. The initial Part Setup screen appears with Part Zero entries established during the cycle.

Edge Skew Cycle

Follow these steps to program an Edge Skew Probing Cycle:

1. From the Part Setup Skew Probe Cycle softkey menu, select Edge.
2. In the Probing Axis field, select the axis to move toward the edge of the part: X Axis, Y Axis, or Z Axis.
3. In the Probing Direction field, select the direction to probe: Positive or Negative. Z Axis always probes in the Negative direction.
4. Program an offset in the Preset X or Preset Y field, if desired.

When the Part Setup fields have been entered, start the Edge Skew Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, near the edge to be probed.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.

The tool motion for an Edge Skew Cycle is the same as the motion described for an Edge Cycle. The results appear in the Edge (X,Y, or Z) and Skew Angle (Deg) fields. The probe returns to the Start Position.

4. After the cycle runs, the Accept X/Y Skew Angle and Do Not Accept softkeys appear.
 - The Accept X/Y Skew Angle softkey accepts the skew position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.

5. The initial Part Setup screen appears with the skew value established during the cycle stored in the X/Y Skew (deg) field, if accepted.

Hole or Circle Pocket Skew Cycle

Follow these steps to program a Hole or Circle Pocket Skew Probing Cycle:

1. From the Part Setup Skew Probe Cycle softkey menu, select the Hole or Circle Pocket softkey.
2. In the Start Angle 1, Start Angle 2, and Start Angle 3 fields, enter the desired approach angles.
3. Program an offset in the Preset X and/or Preset Y field(s), if desired.

When the Part Setup fields have been entered, start the Hole or Circle Skew Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, inside the pocket near the center.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.

The tool motion for a Hole or Circle Pocket Skew Probing Cycle is the same as the motion described for a Hole or Circle Pocket Cycle. The results appear in the Center X, Center Y, Diameter, and Skew Angle (deg) fields. The probe stops in the center of the pocket.

4. After the cycle runs, the Accept X/Y Skew Angle and Do Not Accept softkeys appear.
 - The Accept X/Y Skew Angle softkey accepts the skew position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.

Refer to the "Part Zero Storage" section of this chapter for more information.

5. The initial Part Setup screen appears with the skew value established during the cycle stored in the X/Y Skew (deg) field, if accepted.

Cylinder Skew Cycle

Follow these steps to program a Cylinder Skew Probing Cycle:

1. From the Part Setup Skew Probe Cycle softkey menu, select Cylinder.
2. In the Probing Radius field, enter the probe search radius.
3. In the Start Angle fields, enter the desired approach angles.
4. In the Z Depth field, enter the distance the Z axis moves down before changing direction and searching horizontally for each contact point.
5. Program an offset in the Preset X and/or Preset Y field(s), if desired.

When the Part Setup fields have been entered, start the Cylinder Skew Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, above the cylinder near the center.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.

The tool motion for a Cylinder Skew Probing Cycle is the same as the motion described for a Cylinder Cycle. The results appear in the Center X, Center Y, Diameter, and Skew Angle (deg) fields. The probe stops in the center above the cylinder.

4. After the cycle runs, the Accept X/Y Skew Angle and Do Not Accept softkeys appear.
 - The Accept X/Y Skew Angle softkey accepts the skew position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.

Refer to the "Part Zero Storage" section of this chapter for more information.

5. The initial Part Setup screen appears with the skew value established during the cycle stored in the X/Y Skew (deg) field, if accepted.

Rectangular Pocket Skew Cycle

Follow these steps to program a Rectangular Pocket Skew Cycle:

1. From the Part Setup Skew Probe Cycle softkey menu, select Rectangular Pocket Inside.
2. Program an offset for the Preset X and/or Preset Y field, if desired.

When the Part Setup fields have been entered, start the Rectangular Pocket Skew Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, inside the rectangular pocket.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.

The tool motion for a Rectangular Pocket Skew Probing Cycle is the same as the motion described for a Rectangular Pocket Cycle. The results are displayed on the screen in the Center X, Center Y, Length (X), Length (Y) and Skew Angle (deg) fields. The probe stops in the center of the pocket.

4. After the cycle runs, the Accept X/Y Skew Angle and Do Not Accept softkeys appear.
 - The Accept X/Y Skew Angle softkey accepts the skew position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.

Refer to the "Part Zero Storage" section of this chapter for more information.

5. The initial Part Setup screen appears with the skew value established during the cycle stored in the X/Y Skew (deg) field, if accepted.

Rectangular Solid Skew Cycle

Follow these steps to program a Rectangular Solid Skew Cycle:

1. From the Part Setup Skew Probe Cycle softkey menu, select Rectangular Solid Outside.
2. In the Probing Length X field, enter the pocket's estimated X Length.
3. In the Probing Length Y field, enter the pocket's estimated Y Length.
4. In the Z Depth field, enter the distance the Z axis moves downward before changing direction and moving to the edges for deflection.
5. Program an offset for the Preset X and/or Preset Y field, if desired.

When the Part Setup fields have been entered, start the Rectangular Solid Skew Probing Cycle:

1. Place the part probe in the spindle and jog the probe to the Start Position, above the rectangle near the center.
2. Press the Start Probing Cycle softkey. The Start Cycle button flashes.
3. Press the Start Cycle button.

The tool motion for a Rectangular Solid Skew Probing Cycle is the same as the motion described for a Rectangular Solid Cycle. The results appear in the Center X, Center Y, Length (X), Length (Y), and Skew Angle (deg) fields. The probe moves to the center above the rectangle.

4. After the cycle runs, the Accept X/Y Skew Angle and Do Not Accept softkeys appear.
 - The Accept X/Y Skew Angle softkey accepts the skew position and subtracts the Preset X or Y value to determine Part Zero.
 - The Do Not Accept softkey ignores the edge position value and the Preset X or Y value. Part Zero remains unchanged.

Refer to the "Part Zero Storage" section of this chapter for more information.

5. The initial Part Setup screen appears with the skew value established during the cycle stored in the X/Y Skew (deg) field, if accepted.

NCPP OPTION

The NC Productivity Package (NCPP) option provides features that enhance productivity and aid in producing smaller, more powerful, and easier to maintain NC programs. NCPP features include variables, subprogram calls, macros, user-defined codes, mathematical equations and address expressions, and M99 jump statements. The NCPP option requires the presence of the ISNC option.

⇒ NC files that are larger than dynamic RAM memory can be serially loaded to the hard disk. The CNC can run NC files that do not entirely fit into dynamic RAM memory.

Modal Subprograms

Modal subprograms are executed every time a motion is performed (i.e., after a Move command). Use them for performing repetitive tasks at different locations. The repetitive tasks can be put inside a modal subprogram. A subprogram call can be made to a program which contains X, Y, and Z locations and will be executed at each of these locations.

A modal subprogram will not be modal within another modal subprogram. If the modal subprogram contains Move commands, the modal subprogram will not be performed after Move commands within the modal subprogram. This allows Move commands to be contained within modal subprograms.

These methods allow the subprogram call to be modal:

- A Modal Subprogram Call (G66) Command
- A Modal user defined G code

Modal Subprogram Call (G66)

In a G66 Modal subprogram call, the subprogram is repeatedly executed after each Move command until the Modal Subprogram Call Cancel (G67) command is performed.

Modal User Defined G Code

The user defined G code is made modal by entering a negative number in the G code column on the Change NC Parameters screen. Only one user defined G code can be designated as a modal subprogram. The first one in the list is treated as modal if more than one negative number is entered in the G code column. The remaining negative G codes are treated as regular user defined G codes.

When the modal user defined G code is encountered in the NC program, the subprogram becomes modal until a G67 is used. Only one modal subprogram can be in effect at any given time; an error message occurs if a modal subprogram is first initiated with a G66 command and the modal user defined G code is then attempted.

Modal Subprogram Cancel (G67)

The G67 command is used to cancel modal subprograms initiated with either the G66 or with a modal user defined G code.

Modal Subprogram Call (G66) Example

The following program draws a series of squares and rectangles:

%

(EXAMPLE OF MODAL SUBPROGRAM CALL G66)

(P6010 IS USED AS MODAL SUBPROGRAM)

(THE VALUES AFTER I AND J ARE PASSED TO)

(THE SUBPROGRAM. THE SUBPROGRAM IS ONLY)

(EXECUTED AFTER BLOCKS WITH MOVE COMMANDS.)

X0 Y0 Z0

X5 G66 P6010 I1. J1.5

Y-3

X-5

Y0

(MODAL SUBPROGRAM IS NOW CANCELED WITH G67)

G67

Y3

(THE MODAL SUBPROGRAM IS STARTED AGAIN WITH)

(NEW PARAMETERS.)

X0 G66 P6010 I3.J1.

Y0

Y-2

M02

:6010

(THIS SUBPROGRAM CREATES A SIMPLE BOX SHAPE.)

G91

X#4

Y#5

X-#4

Y-#5

G90

M99

Macro Modes

The CNC software provides compatibility between different NC dialects from various machine tool control manufacturers. The software calls NC macros (Macro Mode A or Macro Mode B) to be compatible with existing NC macros.

Older NC macros use the Macro A method of calling subprograms. The main difference between the two macro modes is Macro Mode A does not provide for local (general purpose) variables within a subprogram. Also, Macro Mode B provides the potential to embed more NC computer programming. The table below identifies each macro mode's variables and the functions for which the variables are used. (See [Variables](#) for more information about local variables.)

Functions	Subprogram Variables	
	Macro Mode A	Macro Mode B
Local Variables	None	#1-33
Tool Offsets	#1-#99	#2001-#2200
User defined M Codes	9001-9003	9001-9003; 9020-9029
Indirect Variable Referencing	#9100	#[#100]
Pass Subprogram Parameters	#8004-#8026; #8104-#8126	#1-#33
G Code Status	#8030-#8046; #8130-#8146	

To enable the appropriate macro mode, press the NC Parameters softkey on the Program Parameters screen. The NC Parameters—Configuration Parameters screen appears with the cursor in the upper left-hand corner at the default Macro Mode B Yes field.

Enable Macro Mode B by selecting the Yes softkey; enable Macro Mode A by selecting the No softkey.

- Macro Mode A contains 3 program numbers (9001–9003).
- Macro Mode B contains 13 program numbers (9001–9003 and 9020–9029).

Refer to the "User Defined Codes" section for more information about user defined codes.

The user can assign G or M codes in the appropriate column on the NC Parameters—M and G Code Program Numbers screen for each program number.

Macro Instruction (G65)

G65 Macro instructions are G65 commands which are used to perform mathematical, trigonometric, or program control functions instead of subprogram calls. These commands are intended to support existing programs which use this program format.

The value in the H parameter defines the operation being performed. In all instructions

except the GOTO commands H80 through H86, a variable number follows the P parameter. The operation's result is stored in that variable number. In the following command the value stored in variable #100 is added to the number 1 and the resultant value is stored in variable #115.

```
G65 H02 P#115 Q#100 R1
```

For the GOTO commands, the value which follows the P is a positive or negative integer. If the number is negative, the software begins searching for the sequence number at the beginning of the file and continues to search for the sequence number until reaching the end of the file. If the number is positive, the search for the sequence numbers begins with the block after the GOTO command and continues until reaching the end of the file. The software then searches from the beginning of the file until reaching the GOTO command block.

The values which follow Q and R are general purpose parameters which are used in mathematical, logical, or GOTO operations. The specific operations are listed in the following table.

Format

Here is the G65 Macro Instruction format:

```
G65 H ____, P #a__, Q #b__, R #c__,.
```

The table below lists the descriptions and instruction functions for the H codes used in the G65 macro instructions:

G65 Macro Instructions

H Code	Description	Instruction Function
H01	Definition, Substitution	$\#a = \#b$
H02	Addition	$\#a = \#b + \#c$
H03	Subtraction	$\#a = \#b - \#c$
H04	Product	$\#a = \#b * \#c$
H05	Division	$\#a = \#b / \#c$
H11	Logical Sum	$\#a = \#b .OR. \#c$
H12	Logical Product	$\#a = \#b .AND. \#c$
H13	Exclusive OR	$\#a = \#b .XOR. \#c$
H21	Square Root	$\#a = \sqrt{\#b}$
H22	Absolute Value	$\#a = \#b $
H23	Remainder	$\#a = \#b - \text{trunc}(\#b/\#c) * \#c$ #c trunc: discard fractions less than 1.
H24	Conversion from BCD to Binary	$\#a = \text{BIN}(\#b)$
H25	Conversion from binary to BCD	$\#a = \text{BCD}(\#b)$
H26	Combined Multiplication/Division	$\#a = (\#a * \#b) / \#c$
H27	Combined Square Root 1	$\#a = \sqrt{\#b^2 + \#c^2}$
H28	Combined Square Root 2	$\#a = \sqrt{\#b^2 - \#c^2}$
H31	Sine	$\#a = \#b * \text{SIN}(\#c)$
H32	Cosine	$\#a = \#b * \text{COS}(\#c)$
H33	Tangent	$\#a = \#b * \text{TAN}(\#c)$
H34	Arc tangent	$\#a = \text{TAN}(\#b/\#c)$
H80	Unconditional Divergence (GOTO)	GOTO a
H81	If Statement, Equals	IF $\#b = \#c$, GOTO a
H82	If Statement, Not Equal	IF $\#b \neq \#c$, GOTO a
H83	If Statement, Greater Than	IF $\#b > \#c$, GOTO a

G65 Macro Instructions

H Code	Description	Instruction Function
H84	If Statement, Less Than	IF #b < #c, GOTO a
H85	If Statement, Greater Than/Equals	IF #b >= #c, GOTO a
H86	If Statement, Less Than/Equals	IF #b <= #c, GO TO a

G65 Macro Instructions

For H80 through H86, if "a" has a negative value, the software performs a GOTO but begins looking for the sequence number at the beginning of the program. No variables can be used for the P parameter for H80 through H86.

⇒ The G65 Macro Instructions are intended to support existing Macro A programs. Use equations and regular GOTO statements in place of these instructions when developing new programs.

For example use #100 = 4.56 OR #110 instead of G65 #11 P#100 Q4.56 R#110.

And use IF [#150 EQ #160] GOTO 100 instead of G65 H81 P100 Q#150 R#160.

These commands can be used in either Macro A or B mode.

[G65 Example](#)

NCPP VARIABLE SUMMARY

In the tables below, the Type column indicates the type of variable: Argument (A), System (S), Common (C), and Local (L). The R/W column indicates whether the variable is Read or Read/Write.

Variable Number	Type	R/W	Local Variables for Macro Mode B (Note 3)
#1	A	R/W	Address A (Note 4)
#2	A	R/W	Address B (Note 4)
#3	A	R/W	Address C (Note 4)
#4	A	R/W	Address I (Note 1) or I1 (Note 2)
#5	A	R/W	Address J (Note 1) or J1 (Note 2)
#6	A	R/W	Address K (Note 1) or K1 (Note 2)
#7	A	R/W	Address D (Note 1) or I2 (Note 2)
#8	A	R/W	Address E (Note 1) or J2 (Note 2)
#9	A	R/W	Address F (Note 1) or K2 (Note 2)
#10	A	R/W	Address I3 (Note 2)
#11	A	R/W	Address H (Note 1) or J3 (Note 2)
#12	A	R/W	Address K3 (Note 2)
#13	A	R/W	Address M (Note 1) or I4 (Note 2)
#14	A	R/W	Address J4 (Note 2)
#15	A	R/W	Address K4 (Note 2)
#16	A	R/W	Address I5 (Note 2)
#17	A	R/W	Address Q (Note 1) or J5 (Note 2)
#18	A	R/W	Address R (Note 1) or K5 (Note 2)
#19	A	R/W	Address S (Note 1) or I6 (Note 2)
#20	A	R/W	Address T (Note 1) or J6 (Note 2)
#21	A	R/W	Address U (Note 1) or K6 (Note 2)
#22	A	R/W	Address V (Note 1) or I7 (Note 2)
#23	A	R/W	Address W (Note 1) or J7 (Note 2)
#24	A	R/W	Address X (Note 1) or K7 (Note 2)
#25	A	R/W	Address Y (Note 1) or I8 (Note 2)
#26	A	R/W	Address Z (Note 1) or J8 (Note 2)
#27	A	R/W	Address K8 (Note 2)
#28	A	R/W	Address I9 (Note 2)
#29	A	R/W	Address J9 (Note 2)
#30	A	R/W	Address K9 (Note 2)
#31	A	R/W	Address I10 (Note 2)

Variable Number	Type	R/W	Local Variables for Macro Mode B (Note 3)
#32	A	R/W	Address J10 (Note 2)
#33	A	R/W	Address K2 (Note 2)



1. Valid for argument assignment method 1 where multiple sets of (I,J,K) are not used.
2. Valid for argument assignment method 2 where multiple sets of (I,J,K) are used.
3. Local variables are used to pass arguments to a macro. If a local variable without a transferred argument is vacant in its initial status, it can be used freely in the macro.
4. Valid for argument assignment method 1 and 2.

Custom Macro Mode A

Variable Number	Type	R/W	Tool Offset Amounts
#1 to #99	S	R/W	Tool offset amounts for custom macro mode A
#100 to #199	C	R/W	Use these variables to store binary numbers as well as real numbers. All programs and subprograms can read and write to them. Variables #146, #147, and #149 also store the values which follow the B, S, and T code when B, S, and T subprogram calls are performed.
#500 to #999	C	R/W	Use these variables to store binary numbers as well as real numbers. All programs and subprograms can read and write to them.
#2000	S	R	Tool Offset Number 00. (Always 0.)
#2001 to #2200	S	R/W	Tool Offset Number 1-200 for H.
#12001 to #12200	S	R/W	Tool Radius Offset Number 1-200 for D.
#2500	S	R/W	X External Work Compensation. Compensation is applied to the Work Coordinate System 1 to 6 X value.
#2501 to #2506	S	R/W	X For Work Coordinate System 1 to 6
#2507 to #2599	S	R/W	G54.1 P1-P93 Auxiliary Work Offsets 1-93 X values.
#2600	S	R/W	Y External Work Compensation. Compensation is applied to the Work Coordinate System 1 to 6 Y value.
#2601 to #2606	S	R/W	Y For Work Coordinate System 1 to 6
#2607 to #2699	S	R/W	G54.1 P1-P93 Auxiliary Work Offsets 1-93 Y values.
#2700	S	R/W	Z External Work Compensation. Compensation is applied to the Work Coordinate System 1 to 6 Z value.
#2701 to #2706	S	R/W	Z For Work Coordinate System 1 to 6
#2707 to #2799	S	R/W	G54.1 P1-P93 Auxiliary Work Offsets 1-93 Z values.
#2807 to #2899	S	R/W	Auxiliary Work Offsets A/B values (for certain machines).
#2907 to #2999	S	R/W	Auxiliary Work Offsets B/C values (for certain machines).

Custom Macro Mode A

Variable Number	Type	R/W	Tool Offset Amounts
#3004	S	R/W	<p>If #3004 = 0 to 7, feed hold, feedrate override, or exact stop check will be enabled or disabled. Currently not implemented. #3004 Feed Hold Feedrate Exact Stop Override Check</p> <pre> 0 0 0 0 1 X 0 0 2 0 X 0 3 X X 0 4 0 0 X 5 X 0 X 6 0 X X 7 X X X </pre> <p>Key: 0 = Effective, X= Suppressed Feed Hold and Exact Stop are currently not implemented.</p>
#3005	S	R	<p>Provides the condition of mirror image of each axis at that time. Bit 0 : X axis (set to 1 if X axis mirroring is being used) Bit 1: Y axis (set to 1 if Y axis mirroring is being used) Bit 4: inch/mm status flag inch input (set to 1) mm input (set to 0) Bit 6: absolute/incremental flag absolute (set to 1) incremental (set to 0)</p>
#3020	S	R	<p>Indicates whether the probe touched during a G31 move. Equals 0 if the probe does not touch. Equals 1 if the probe does touch.</p>



For Ultimax PC/PC Plus #3102 is always 1; #3103-#3129 are always 0.0. For Ultimax 4 (CNC) #3110-#3115, #3120-#3125; #3129 are always 0.0.

Tool Probe

Variable Number	Type	R/W	Description
#3101	S		Current Tool Number
#3102	S	R	Tool Probe present
#3103	S	R	Tool Probe X location
#3104	S	R	Tool Probe Y location
#3110	S	R	Tool Probe X Plus Offset location
#3111	S	R	Tool Probe X Negative Offset location
#3112	S	R	Tool Probe Y Plus Offset location
#3113	S	R	Tool Probe Y Negative Offset location
#3114	S	R	Tool Probe Z Plus Offset location
#3115	S	R	Tool Probe Z Negative Offset location
#3116	S	R	Tool Probe Tool Length tolerance

Part Probe

Variable Number	Type	R/W	Description
#3120	S	R	Part Probe X Plus Offset location
#3121	S	R	Part Probe X Negative Offset location
#3122	S	R	Part Probe Y Plus Offset location
#3123	S	R	Part Probe Y Negative Offset location
#3124	S	R	Part Probe Z Plus Offset location
#3125	S	R	Part Probe Z Negative Offset location
#3126	S	R	Part Probe Z (reserved; not supported)
#3127	S	R	Part Probe Safety Min Z (reserved; not supported)
#3128	S	R	Tool Probe safety Min Z (reserved; not supported)
#3129	S	R	Tool Probe Z (reserved; not supported)

Tool Variables

Variable Number	Type	R/W	Description
#3201-#3300	S	R	Tool Type
#3301-#3400	S	R	Tool Diameter
#3401-#3500	S	R	Reserved
#3501-#3600	S	R	Tool Probe Offset X
#3601-#3700	S	R	Tool probe Offset Y
#3701-#3800	S	R/W	Probe Calibration
#3801-#3900	S	R/W	Tool Calibration



There are 100 variables each reserved for tool type, tool diameter, tool calibration, probe calibration, tool probe offset X, and tool probe offset Y regardless of whether or not the machine can handle that many tools. If the program tries to access a variable for a tool that does not exist, an error is generated. The variables for tool type (#3201 – #3300) have these values:

- Undefined: -10
- Drill: -11
- Tap: -12
- Bore: -13
- Mill: -14
- Face Mill: -15
- Ball End: -16
- Back Spot Face: -17
- Probe: -18
- Gun Drill: -19

Variable Number	Type	R/W	Modal Information from Previous Block
#4001 to #4021	S	R	G Code Groups 1 to 21
#4022	S	R	G Code Group 22
#4102	S	R	B Code
#4107	S	R	D Code
#4109	S	R	F Code
#4111	S	R	H Code
#4113	S	R	M Code
#4114	S	R	Sequence Number of previous block
#4115	S	R	Program Number of previous block
#4119	S	R	S Code
#4120	S	R	T Code
#4201 to #4221	S	R	G Code Groups 1 to 21
#4222	S	R	G Code Group 22
#4302	S	R	B Code
#4307	S	R	D Code
#4309	S	R	F Code
#4311	S	R	H Code
#4313	S	R	M Code
#4314	S	R	Sequence Number of current block
#4315	S	R	Program Number of current block
#4319	S	R	S Code
#4320	S	R	T Code

Variable Number	Type	R/W	Position Information
#5001 to #5006	S	R	X, Y, Z and A, B, C axis block end part coordinate respectively. Coordinates are referenced to the current coordinate system.
#5021 to #5026	S	R	X, Y, Z and A, B, C axis machine coordinate position respectively. Coordinates are referenced to the current working coordinate system. Based on real time measured position. These variable cannot be used while Cutter Compensation is active.
#5041 to #5046	S	R	X, Y, Z and A, B, C axis work coordinate position respectively. Coordinates are referenced to the current working coordinate system. Based on real time measured position. These variable cannot be used while Cutter Compensation is active.
#5061 to #5066	S	R	X, Y, Z and A, B, C axis skip signal position respectively. Coordinates are referenced to the current coordinate system (machine, local, or working). Based on real time measured position.
#5081 to #5083	S	R	X, Y, and Z axis tool offset respectively.

Arguments in the following table are variables used only in Macro A subprograms that pass parameters to subprograms. They are used to support existing Macro A subprograms. When a Macro A subprogram is called, the variables #8004 to #8026 are initialized with the address values in the calling program. Variables #8104 to #8126 are set to 1 if the address value is valid, and they are set to 0 if the address value is invalid.

In general, variables #8004 to #8026 are initialized after a subprogram call is made. These variables are not kept up to date. They are only valid immediately after a subprogram call. Variables #8104 to #8126 are set to 1 during a subprogram call and reset to 0 when the software returns from the subprogram.

Likewise, variables #8030 to #8046 are initialized to the G group modal status when a Macro A subprogram is called. Variables #8130 to #8146 are then set to 1 if the corresponding parameter is passed.

Variable Number				Macro Mode A Subprogram Parameters
Value	Status	Type	R/W	
#8004	#8104	A	R	I
#8005	#8105	A	R	J
#8006	#8106	A	R	K
#8009	#8109	A	R	F
#8010	#8110	A	R	G
#8011	#8111	A	R	H
#8013	#8113	A	R	M
#8014	#8114	A	R	N
#8016	#8116	A	R	P
#8017	#8117	A	R	Q
#8018	#8118	A	R	R
#8019	#8119	A	R	S
#8020	#8120	A	R	T
#8024	#8124	A	R	X
#8025	#8125	A	R	Y
#8026	#8126	A	R	Z



The G code groups' values are stored in addresses #8004 to #8026 for Macro Mode A subprogram calls G65, G66, and user defined M and G codes. The G code groups' status is stored in addresses #8114 to #8126. The software sets the value to 1 if an argument is specified in the subprogram call.

#8104 is non-zero if an argument is specified during the macro call and zero if no argument is specified.

#8004 has a valid value if #8104 is non-zero and may be undefined if #8104 is zero.

Variable Number				Macro Mode A G Code Group Status
Value	Status	Type	R/W	
#8030	#8130	S	R	Group 00 G codes
#8031	#8131	S	R	Group 01 G codes: G00, G01, G02, G03
#8032	#8132	S	R	Group 02 G codes: G17, G18, G19
#8033	#8133	S	R	Group 03 G codes: G90, G91
#8035	#8135	S	R	Group 05 G codes: G94
#8036	#8136	S	R	Group 06 G codes: G20, G21
#8037	#8137	S	R	Group 07 G codes: G40, G41, G42
#8038	#8138	S	R	Group 08 G codes: G43, G44, G49
#8039	#8139	S	R	Group 09 G codes: G73, G74, G76, G80-G89
#8040	#8140	S	R	Group 10 G codes: G98, G99
#8041	#8141	S	R	Group 11 G codes: G66, G67
#8045	#8145	S	R	Group 15 G codes: G61, G62, G63, G64
#8046	#8146	S	R	Group 16 G codes: G68, G69

⇒ The G code groups' status is stored in addresses #8030 to #8046 for Macro Mode A subprogram calls G65, G66, and user defined M and G codes.

The status is stored in addresses #8130 to #8146 and is non-zero if an argument is specified in the subprogram call. It is zero if no argument is specified in the subprogram call.

Variables_Option

Variables are used to create programs that can be easily modified. Programs with variables can be reused for various applications. All variables must begin with the "#" character followed by a valid, "writeable" register number and an equal sign.

The example that follows sets the variable value (#500) to 110:

```
# 500 = 110.
```

There are four types of variables that can be used in NC programming: [global](#), [system](#), [local](#), and [arguments](#). Arguments and local variables are only available in Macro Mode A. Some variables are [read only](#) and an error is generated when an attempt is made to write to the variable.

Addresses with Variables

NC blocks contain addresses with specific numbers. Variables can be used in place of numbers for addresses in the NC blocks, making the program generic. The example below uses variables in the block's address instead of the numbers they represent:

Number	Variable
0.00	#110
-10.00	#115
00	#120
0.25	#121
12.00	#122

Address with Variables

```
G#110 X[#122+.3] Y-[#115/5.] Z[#120 + #121]
```

Address with Numbers

The same address would be written as follows if numbers were used instead of variables:

```
G0.00 X[12.00 + .3] Y-[10.00/5] Z[1.00 + 0.25]
```

-Or-

```
G0.00 X12.3 Y2 Z1.25
```

Alarm 3000 Messages

Variable #3000 writes an Alarm 3000 error message to the screen. The following is an example of this type of error message:

```
#3000 = 140 (ARGUMENT MISSING)
```

The right-hand side of the equation must begin with a number in the range of 0 to 200

followed by a left parenthesis, a string which is limited to 26 characters, and a right parenthesis. This number is added to 500 and stored to variable #3000. The message "ARGUMENT MISSING" is displayed on the screen.

Vacant Variables

A variable is considered vacant if a local or global variable has not been assigned a value before it is used in an equation or expression. An error message occurs with vacant variables.

A variable can be tested to determine if it is vacant by comparing it with the null variable #0. The variable #0 is called the "null variable" because it cannot be used to store a value and is only used to perform vacant variable tests.

For example, the following IF conditional statement is true if variable #510 is vacant and false if the variable is not vacant (refer to the "IF Statements" section of this chapter for information about IF statements):

```
IF[#510 EQ #0] GOTO 100
```

⇒ The function NE (not equal) can also be used with vacant variables.

It is best to avoid using vacant variables in equations. However, when it is necessary to use them to maintain compatibility with existing programs, vacant variables can be used in some circumstances without receiving an error message.

The table on the following page shows what happens when vacant variables are used in equations versus setting variables to zero.

This table shows the difference between using vacant variables and setting variables to 0 in equations:

Comparison of Vacant Variables and Setting Variables to Zero (0)

Function	Examples	Null/Vacant Variable (#10 = <vacant>)	Variable Set to 0 (#10 = 0)
Assignment	#20 = #10	Error Message	#20 = 0
Multiplication	#20 = #10 * 3	#20 = 0	#20 = 0
	#20 = #10 * #10	Error Message	#20 = 0
	#20 = #10 * #0	Error Message	Error Message
	#20 = #0 * 3	Error Message	-
	#20 = #0 * #0	Error Message	-
Addition	#20 = #10 + 3	#20 = 0	#20 = 0
	#20 = #10 + #10	Error Message	#20 = 0
	#20 = #10 + #0	Error Message	Error Message
	#20 = #0 + 3	Error Message	-
	#20 = #0 + #0	Error Message	-
EQ (equal)	#10 EQ #0	True	False
	#10 EQ 0	Error Message	True
NE (not equal)	#10 NE #0	False	True
	#10 NE 0	Error Message	False
GE (greater than or equal to)	#10 GE #0	True	False
	#10 GE 0	Error Message	True
GT (greater than)	#10 GT #0	Error Message	Error Message
	#10 GT 0	Error Message	False
Other Functions	-	Error Message	Depends on Function

Variable Expressions

Instead of using a number after an NC parameter, a variable expression (or math expression) can be used.

- Brackets ([]) serve as delimiters in the expressions.
- A negative sign entered before the left bracket ([) indicates that the expression is negative (i.e. X-[[#110+3.4] + 4.5]).

Expression [Symbols](#) and [Keywords](#)

[Operation Priorities](#)

Indirect Variables

Variables can be referenced indirectly by using multiple levels of pound signs (#) and brackets ([and]).

$\#100 = 600 \Leftarrow \#100$ is equal to 600.

$\#600 = 4.5 \Leftarrow \#600$ is equal to 4.5.

$\#[\#100] = 4.5 \Leftarrow \#[\#100]$ is equal to #600; #600 equals 4.5.

Macro Mode A variables are referenced indirectly by using a "9" as the first number:

In #9500, #9 is the address of the value at 500, which is the same as using #[#500] in Macro Mode A or Macro Mode B.

Saving Variable Values to a File on the Control

When running the program on the CNC, if an error occurs during the program run, the variable values are not saved. The variable values are saved if the program runs successfully.

Variable Example

This program illustrates the use of #0 in an IF statement to determine if an argument is passed to subprogram 3100. There are two IF statements in sequence numbers 100 and 200 in the subprogram which test to verify that the calling program (0100) had passed parameters I and J which correspond to #4 and #7 in subprogram 3100, respectively. If either variable #4 or #7 is vacant, an Alarm 3000 error message is written to the screen. (Refer to the "Program Control Statements" section for more information about IF statements.)

```
%  
O0100  
T01 M06  
S1500 M03  
G00 G90 X5.0 Y5.0
```

```
G43 Z.1 H01
M08
G01 Z-.5 F5.0
G65 P3100 L.5 D2 F15.0
G00 Z.1 M09
G91 G28 Z0 M05
M30
:3100(True CIRCLE TYPE 1)
```

```
#27 = #4001
#28 = #4003
#29 = #4107
N100 IF[#4EQ#0] GOTO 1000
```

```
N200 IF[#7EQ#0] GOTO 1000
```

```
#1 = ABS [#4]-ABS [#(2000+#7)]
IF [#1LE0] GOTO 2
#20 = #1/2
#21 = ROUND [#20*1000]
#22 = #21/1000
#2 = #1-#22
#3 = #1-#2
IF [#23EQ#0] GOTO 10
G01 G91 X-#2 Y-#3 F#9
G17 G02 X-#3 Y#3 J#3
I#1
X#3 Y#3 I#3
G01 X#2 Y-#3 F[#9*3]
GOTO 5
N10 G01 G91 X-#2 Y#3 F#9
G17 G03 X-#3 Y-#3 J-#3
I#1 J0
X#3 Y-#3 I#3
G01 X#2 Y#3 F[#9*3]
GOTO 5
N1000 #3000 = 100(ARGUMENT MISSING)
N5 G#27 G#28 D#29
M99
```

Program Control Statements

Program control statements are NC blocks which direct the flow of the NC program or subprogram. The following section describes using the different NCPP option's program control statements.

Program control statements use keywords: GOTO, IF, WHILE, and DO. At least two letters of the keyword are required. For example, WH, WHI, WHIL, and WHILE all perform the same function. Some program control statements are only effective within the current program or subprogram, and other program control statements cause program execution to go to subprograms. The software can only locate sequence numbers that are in

memory.

The following program control statements are effective only within the *current program* being executed:

- [WHILE](#) [conditional expression] DO#
- [DO#](#)
- [IF](#) [conditional expression] [GOTO](#) [expression or #]
- [GOTO](#) [expression or #]
- [END#](#)
- [M99](#) or M99 P_____

These program control statements cause program execution to *call subprograms*:

- [M98](#) P_____
- [G65](#) P_____ L_____ [Optional Argument List]
- [G66](#) P_____ L_____ [Optional Argument List]
- User defined [G code](#) followed by [Optional Argument List]
- User defined [M code](#) followed by [Optional Argument List]
- User defined B, S, and T codes followed by optional parameter

Variables can be *referenced indirectly* to initialize a large block of variables, for example:

- #100 = 500
- WHILE [#100 LT 1000] DO 250
- #[#100] = 1.5
- #100 = #100+1
- END 250

The alternative to indirectly referencing variables is to have a program line for each variable as shown below:

- #500 = 1.5
- #501 = 1.5
- ...
- #999 = 1.5

In this case, 500 program lines would be required to perform what five program lines accomplished in the first example.

Subprograms

Subprograms are stand-alone NC programs that can be called from another NC program. Subprograms begin with the letter "O" or the ":" character followed by a four-digit number that identifies the subprogram. Each subprogram ends with an *M99* statement. The only limitation for the number of NC files and subprograms the software can load is the amount of available dynamic RAM memory.

The following is a sample subprogram:

```
N10 O7162  ⇐ begins with "O" followed by 4-digit number
N20 G00 G90
N30 M25
N40 X0 Y0
N50 T1 M06
N60 Z5.
N70 S2000 M03
N80 Z0.05
N90 M99    ⇐ ends with M99
```

Subprograms can be nested 15 levels deep. In general, different types of subprogram calls can be used in various combinations. There are some restrictions in the use of modal subprograms and user defined G, M, B, S, and T subprogram calls, however, which will be described in more detail later.

Programs cannot call themselves as subprograms because the repetition exhausts the 15 levels of subprogram nesting. For the same reason, a user defined code cannot be used in a program which is associated with the same user defined code. For example, a G65 P5000 command is illegal within the program 5000.

G65 Subprogram Call

The G65 subprogram command has the following form:

G65 P_____ L_____ [followed by optional arguments]

The P represents the subprogram number and the L represents the number of iterations that the subprogram must perform. These two methods of argument passing can be used together:

Arguments

In a G65 subprogram call, the local variables in the calling program are not copied to the local variables in the called subprogram. Arguments which follow the G65 command are copied to the local variables in the subprogram as illustrated in the following command:

G65 P5080 A0.0 B8 C2.3 S6 T2 H81 I9 J3.5 K0 Z-1 R.1

The value which follows A is copied to the local variable #1 in the subprogram. The table on the following page shows the relationships between the subprogram arguments and

the local variables in the subprograms.

Multiple Arguments

Multiple I, J, and K arguments can also be used as subprogram arguments. For example, if three I arguments are used in the subprogram call, the first I maps to the #4 variable, the second I maps to the #7 variable, and the third I maps to the #10 variable. The following subprogram call is legitimate:

G65 P2000 A2.3 B3.2 I2.0 J3. K5.4 I3. I5. J2. I6. W3. U3

Only numbers may be used as arguments in a G65 subprogram call; no variables or expressions can be used. If multiple iterations of the subprogram are to be performed, the local variables will be initialized to the same argument values.

Passing Argument Lists to Subprograms in Macro Mode B

There are several methods for passing arguments and parameters to subprograms. The G65 and G66 subprogram calls allow an argument list to be provided after the G65 and G66, respectively. The user defined M Code and the user defined G Code allow an argument list to be provided after the user defined Code. The argument list consists of various letters followed by values. The values are then stored as local variables within the subprogram.

The table below lists the correspondence between the arguments and the local variables in Macro Mode B. The argument list is optional. Any arguments which are not included in the list are given vacant status.

Macro Mode B

Local Variables	Subprogram Arguments	Local Variables	Subprogram Arguments
#1	Argument A	#18	Argument R or K5
#2	Argument B	#19	Argument S or I6
#3	Argument C	#20	Argument T or J6
#4	Argument I or I1	#21	Argument U or K6
#5	Argument J or J1	#22	Argument V or I7
#6	Argument K or K1	#23	Argument W or J7
#7	Argument D or I2	#24	Argument X or K7
#8	Argument E or J2	#25	Argument Y or I8
#9	Argument F or K2	#26	Argument Z or J8
#10	Argument I3	#27	Argument K8
#11	Argument H or J3	#28	Argument I9
#12	Argument K3	#29	Argument J9
#13	Argument M or I4	#30	Argument K9
#14	Argument J4	#31	Argument I10
#15	Argument K4	#32	Argument J10
#16	Argument I5	#33	Argument K2
#17	Argument Q or J5		

Layering of Local Variables Within Subprogram Calls

M98 subprogram calls use local variables differently from other subprogram calls since the called subprogram does not get a new set of local variables. Changes made to the local variables within the current subprogram will be retained when the calling program is re-instated.

Changes can be made to the local variables within the current subprogram, but when program execution returns to the calling program, the values of the local variables of the calling program are reinstated. The local variables in the subprogram can be changed, however, without affecting the local variables in the calling program. With other subprogram calls, unless an argument list is passed to the subprogram, the local variables are given vacant status.

Specifying Subprogram Iterations

The number of iterations for a subprogram to perform are specified with G65, G66, and M98 subprogram calls.

Using G65 and G66

When making G65 and G66 subprogram calls, the L parameter is used to specify iterations. The maximum number of iterations which can be specified with the G65 and G66 subprogram calls is 999.


Using M98

When making M98 subprogram calls, the P parameter is used to specify iterations as well as the subprogram number. Up to four digits can be used to specify iterations for a maximum of 9999 iterations. Leading zeros are not required when specifying iterations; however, leading zeros are required with a subprogram number that is less than 1000.


In Example 1 below, M98 P60050 must be used instead of M98 P650 to run program 50 with 6 iterations because the subprogram number (50) is less than 1000.

In Example 2, the M98 P23013000 subprogram example, the four digits to the left (2301) specify the number of iterations, and the four digits to the right (3000) specify the subprogram number.

Example 1:



Example 2:



As other examples, M98 P1 runs program 1 with no iterations, and M98 P100001 runs program 1 ten times.

Macro Instruction (G65)

G65 Macro instructions are G65 commands which are used to perform mathematical, trigonometric, or program control functions instead of subprogram calls. These commands are intended to support existing programs which use this program format.

The value in the H parameter defines the operation being performed. In all instructions except the GOTO commands H80 through H86, a variable number follows the P parameter. The operation's result is stored in that variable number. In the following command the value stored in variable #100 is added to the number 1 and the resultant value is stored in variable #115.

G65 H02 P#115 Q#100 R1

For the GOTO commands, the value which follows the P is a positive or negative integer. If the number is negative, the software begins searching for the sequence number at the beginning of the file and continues to search for the sequence number until reaching the

end of the file. If the number is positive, the search for the sequence numbers begins with the block after the GOTO command and continues until reaching the end of the file. The software then searches from the beginning of the file until reaching the GOTO command block.

The values which follow Q and R are general purpose parameters which are used in mathematical, logical, or GOTO operations. The specific operations are listed in the following table.

Format

The following is the G65 Macro Instruction format:

G65 H _____, P #a , Q #b , R #c ,.

The table below lists the Descriptions and Instruction Functions for the H codes used in the G65 macro instructions:

H Code	Description	Instruction Function
H01	Definition, Substitution	#a = #b
H02	Addition	#a = #b + #c
H03	Subtraction	#a = #b - #c
H04	Product	#a = #b * #c
H05	Division	#a = #b / #c
H11	Logical Sum	#a = #b .OR. #c
H12	Logical Product	#a = #b .AND. #c
H13	Exclusive OR	#a = #b .XOR. #c
H21	Square Root	#a = #b
H22	Absolute Value	#a = #b
H23	Remainder	#a = #b - trunc (#b/#c) * #c trunc: discard fractions less than 1.
H24	Conversion from BCD to Binary	#a = BIN(#b)
H25	Conversion from binary to BCD	#a = BCD(#b)
H26	Combined Multiplication/Division	#a = (#a * #b) / #c
H27	Combined Square Root 1	#a = (#b ² + #c ²)
H28	Combined Square Root 2	#a = (#b ² - #c ²)
H31	Sine	#a = #b * SIN(#c)
H32	Cosine	#a = #b * COS (#c)
H33	Tangent	#a = #b * TAN(#c)
H34	Arc tangent	#a = TAN(#b/#c)
H80	Unconditional Divergence (GOTO)	GOTO a
H81	If Statement, Equals	IF #b = #c, GOTO a
H82	If Statement, Not Equal	IF #b #c, GOTO a
H83	If Statement, Greater Than	IF #b > #c, GOTO a
H84	If Statement, Less Than	IF #b < #c, GOTO a
H85	If Statement, Greater Than/ Equals	IF #b >= #c, GOTO a
H86	If Statement, Less Than/Equals	IF #b <= #c, GO TO a

For H80 through H86, if "a" has a negative value, the software performs a GOTO but begins looking for the sequence number at the beginning of the program. No variables can be used for the P parameter for H80 through H86.

⇒ The G65 Macro Instructions are intended to support existing Macro A programs. Use equations and regular GOTO statements in place of these instructions when developing new programs.

For example use `#100 = 4.56 OR #110` instead of
`G65 #11 P#100 Q4.56 R#110`.

And use `IF [#150 EQ #160] GOTO 100` instead of
`G65 H81 P100 Q#150 R#160`.

These commands can be used in either Macro A or B mode.

User Defined Codes

M, G, S, B, and T codes can be customized to perform specialized tasks.

User defined G and M codes define a custom code which performs a specialized task, replaces an existing G or M code, or provides compatibility between different NC dialects from various machine tool control manufacturers. For instance, if a manufacturer uses G codes for canned cycles, User defined G codes can re-map the canned cycles. This allows a BNC subprogram to be used in ISNC mode.

The user defined B, S, and T subprograms provide additional user defined subprograms. User defined S and T subprograms replace the spindle and tool functions with custom subprograms.

Enable these codes on the NC Parameters Configuration Parameters screen by placing the cursor at the code's field and selecting the Yes softkey.

M Codes

Up to 13 user defined M codes can be programmed from M01 through M255 (except M02, M30, M98, and M99). Enable the user defined M codes by selecting Yes in the Enable User M Code field on the NC Parameters screen. The user defined M codes can be assigned to subprograms 9020 through 9029 and 9001 through 9003.

There are no modal user defined M codes; therefore, negative numbers cannot be entered in the column for user defined M codes on the Change NC Parameters screen.

G Codes

G1 through G255 (except G65, G66, and G67) can be programmed for user defined G codes. Enable the user defined G codes by selecting Yes in the Enable User G Code field on the NC Parameters screen. If a negative value is entered for one of the user defined G codes, the subprogram becomes modal. The subprogram is executed after every Move command once the modal G code is invoked.

The modal G code, like the G66 code, is canceled with a G67 command. Use programs 9010 through 9019 only for the user defined G codes.

S, B, and T Codes

Enable the user defined S, B, or T codes by selecting Yes in the Enable User S, B, or T Code field on the Change NC Parameters screen. The software executes the appropriate subprogram when it encounters an S, B, or T code in an NC program.

If a user defined T subprogram Call is made, Tool Function commands T_____ contained within program 9000 will be treated as normal Tool Function commands. If a number follows the T, this value is stored in variable #149. Including a number after the S, B, or T is optional.

The variable numbers and subprogram numbers are *fixed* for these subprogram calls:

User Defined B	Variable #146	Program #9028
User Defined S	Variable #147	Program #9029
User Defined T	Variable #149	Program #9000

Passing Single Dedicated Parameters to Subprograms

User defined subprogram calls' conditions are listed in the table below. If a user defined M, G, S, B, or T subprogram call is not allowed, it is treated as a normal M, G, S, B, or T code. There are no restrictions for G65, G66, and M98 subprogram calls provided that the subprogram has been loaded in memory.

For user defined S, B, and T subprograms, a single parameter is passed to the subprogram. These parameters are optional and they are stored at specific variable locations. The value of the passed parameter can be retrieved by accessing the specific variable which corresponds to the parameter. For example, variable #149 is used for the T subprogram parameter, variable #147 is used for the S subprogram parameter, and #146 is used for the B subprogram parameter. The table below lists the conditions for using modal and user defined subprograms:

Conditions Under Which User Defined Subprograms Can Be Utilized

Types of User Defined Subprograms	No Subprogram Call	M98	G65	G66	User M Code	User G Code	User B Code	User S Code	User T Code
User G Code	X	X	X	X		X	X	X	
User M Code	X	X	X	X			X	X	
User T Code	X	X	X	X					
User B Code	X	X	X	X					
User S Code	X	X	X	X					

While executing a user defined S Code subprogram, user defined G and M Codes can be used, but user defined S, B, and T Codes cannot. There are several different ways of performing subprogram calls. The information in the following table illustrates the different methods for making subprogram calls. The format of the optional argument list is the same for all the different methods of subprogram calls.

Subprogram Capabilities

Types of Subprogram Calls	Modal Capability	Can Specify Iterations	Optional Argument List	Single Predefined Parameters
G65		X	X	
G66	X	X	X	
M98		X		
User Defined G Codes	Optional		X	
User Defined M Codes			X	
T Code				X
B Code				X
S Code				X

This table shows which program numbers are assigned to the different macro calls and their variables:

Program #	Macro Call	Variables	Note
9000	T-Subprogram		Parameter @ #149
9001	M-Macro Mode A	#8004-#8026 are R/W,	
#8030-#8046 are R	Status #8104-#8146		
Tool Offsets #1-#99			
9002	M-Macro Mode A	#8004-#8026 are R/W,	
#8030-#8046 are R	Status #8104-#8146		
Tool Offsets #1-#99			
9003	M-Macro Mode A	#8004-#8026 are R/W,	
#8030-#8046 are R	Status #8104-#8146		
Tool Offsets #1-#99			
9010	G-Code		
9011	G-Code		
9012	G-Code		
9013	G-Code		
9014	G-Code		
9015	G-Code		
9016	G-Code		
9017	G-Code		
9018	G-Code		
9019	G-Code		
9020	M-Macro Mode B	#1-#33	
9021	M-Macro Mode B	#1-#33	
9022	M-Macro Mode B	#1-#33	
9023	M-Macro Mode B	#1-#33	
9024	M-Macro Mode B	#1-#33	
9025	M-Macro Mode B	#1-#33	
9026	M-Macro Mode B	#1-#33	

Program #	Macro Call	Variables	Note
9027	M-Macro Mode B	#1-#33	
9028	M-Macro Mode B	#1-#33	B-Parameter @ #146
9029	M-Macro Mode B	#1-#33	S-Parameter @ #147

User Defined G Code Example

The example below shows how the BNC G86 Bore Orient cycle can be re-mapped to the ISNC G76 cycle. Up to 10 user defined G codes can be defined on the Change NC Parameters screen.

To re-map BNC G86 to ISNC G76 follow these steps:

1. Enable the user defined G codes.
2. Set 9010 to 86 on the Change NC Parameters screen.
3. Load the 9010: program.

```
G99 G90 G00 X0.0 Y0.0 Z1.0
```

```
G86 X2.0 Y3.0 Z3.0 I1.0 J0.0 R1.0 F100.
```

⇐ User defined G86 called

```
O9010
```

⇐ Subprogram 9010 Start
(user defined G86)

```
IF [#4003 EQ 91] GOTO 100
```

```
(TRANSLATION FOR ABSOLUTE MODE)
```

```
G76 X#24 Y#25 Z[#5003-#26] R[#5003-#18] I#4 J#5 F#9
```

```
GOTO 200
```

```
(TRANSLATION FOR INCREMENTAL MODE)
```

```
N100 G76 X#24 Y#25 Z[-#26] R[-#18] I#4 J#5 F#9
```

```
N200
```

```
M99
```

⇐ End of Subprogram 9010

User Defined G and M Code Example

Follow these steps before running the sample user defined G and M code program:

1. Press the console Input key to display the Input screen.
2. Press the Program Parameters softkey.
3. Select the NC Parameters softkey. The Change NC Parameters screen appears.
4. Enable the User M Codes and G Codes fields by placing the cursor at each field and selecting the Yes softkey.
5. Enter 77 into the 9020 field.
6. Enter -96 into the 9010 field.

The following program re-maps a BNC G86 Bore Orient cycle to the ISNC G76 cycle:

```
%
```

```
(FIRST ENABLE USER DEFINED G AND M CODES)
```

(SET USER DEFINED 9010 TO -96)

(SET USER DEFINED 9020 TO 77)

X0 Y0 Z0 ⇐ *Main Program Start*

G96 ⇐ *G96 Call*

X5

Y-3

X-5

Y0

G67

Y3

X0

M77 ⇐ *M77 Call*

Y4

M77

M02 ⇐ *Main Program End*

:9010 ⇐ *Subprogram 9010 Start (user defined G96)*

G91

X1

Y1

X-1

Y-1

G90

M99 ⇐ *End of Subprogram 9010*

:9020 ⇐ *Subprogram 9020 Start (user defined M77)*

G91

X.75

Y1.5

X-.75

Y-1.5

M99 ⇐ *End of Subprogram 9010*

E

X-[#147/2] Y-#147

G90

M99

Global Variables

Global variables are general purpose variables that can be used by all programs. Assign a value to the global variable before it is used in an equation or expression, or the variable will be considered vacant. An error message is generated when the system attempts to read a vacant variable.

If the value of a global variable is changed in a program, all other programs can reference that variable with the new value.

Global variables range between #100 to #199 and #500 to #999.

System Variables

System variables are predefined variables that provide information about the state of the system such as X, Y, Z, external work compensation, miscellaneous system parameters, modal information, position information, and G code group status.

For instance, the coordinates of a probe touch are saved to variables #5061, #5062, and #5063 when using the G31 command. These variables contain information about the probe's location when the probe touch occurs.

Macro Mode A Local Variables

Local variables are general purpose variables that are only valid within the current program. They are only available in Macro Mode A and range from #1 through #33. Assign a value to the local variable before using it in an equation or expression, or it will be considered vacant. An error message is generated when the system attempts to read a vacant variable.

These variables are nested, meaning that when a subprogram call is made, a new set of local variables is received and the old set is stored. After leaving the subprogram, these local variables are destroyed and the previous set is restored.

Passing parameters to subprograms automatically initializes local variables when subprogram calls other than M98 are made. Refer to the "Passing Parameters to Subprograms" section for more information.

Macro Mode A Arguments

Parameters are the addresses which follow G65, G66, and M98. Arguments include the parameter's G group status, and they are used to pass parameters to subprograms. In the table below, the subprogram numbers listed in the Value column contain the code variable or G group modal status, and the subprogram numbers in the Status column contain the status of corresponding values. Notice that these arguments are read only.

Macro Mode A Parameters

In the table below, the parameters' values (I, J, K,.....Z) are stored in addresses #8004 to #8026 for Macro Mode A subprogram calls. The status for each variable is stored in addresses #8104 to #8126. The status for the variables is non-zero ($\neq 1$) if an argument is specified in the subprogram call, and zero otherwise.

Macro Mode A Subprogram Parameters

NC Parameter	Value of Variable	Type	Status of Variable	R/W
I	#8004	ARG	#8104	R
J	#8005	ARG	#8105	R
K	#8006	ARG	#8106	R
F	#8009	ARG	#8109	R
G	#8010	ARG	#8110	R
H	#8011	ARG	#8111	R
M	#8013	ARG	#8113	R
N	#8014	ARG	#8114	R
P	#8016	ARG	#8116	R
Q	#8017	ARG	#8117	R
R	#8018	ARG	#8118	R
S	#8019	ARG	#8119	R
T	#8020	ARG	#8120	R
X	#8024	ARG	#8124	R
Y	#8025	ARG	#8125	R
Z	#8026	ARG	#8126	R

Macro Mode A G Code Groups

The value for each G Code Group is stored in addresses #8030 to #8046 for Macro Mode A subprogram calls G65, G66, and user defined G and M Codes. The status is stored in addresses #8130 to #8146. The status is non-zero if an argument is specified in the subprogram call, and empty otherwise.

Macro Mode A G Code Group Status

G Code	Value of G Code	Type	Status of G Code	R/W
00	#8030	ARG	#8130	R
	#8031	ARG	#8131	R
	#8032	ARG	#8132	R
	#8033	ARG	#8133	R
05	#8035	ARG	#8135	R
06	#8036	ARG	#8136	R
07	#8037	ARG	#8137	R
08	#8038	ARG	#8138	R
09	#8039	ARG	#8139	R
10	#8040	ARG	#8140	R
11	#8041	ARG	#8141	R
15	#8045	ARG	#8145	R
16	#8046	ARG	#8146	R

Read/Write Restrictions

Read only variables are fixed values. You can change write only variables. Some variables within NCPP are read only (R), some are write only (W), and others are read/write (R/W). Most variables can be used to store either real variables or 32 bit binary values, and the software performs the appropriate conversions when the variables are used within equations.

This table lists the NCPP variable types and read/write restrictions.

Variable Number	Type	Restriction	Variable Number	Type	Restriction
#1 to #33	L	R/W	#4309	S	R
#1 to #99	S	R/W	#4311	S	R
#100 to #199	G	R/W	#4313	S	R
#500 to #999	G	R/W	#4314	S	R
#2000	S	R	#4315	S	R
#2001 to #2200	S	R/W	#4319	S	R
#2500	S	R/W	#4320	S	R
#2501 to #2506	S	R/W	#5001 to #5004	S	R
#2507 to #2599	S	R/W			
#2600	S	R/W	#5021 to #5023	S	R
#2601 to #2606	S	R/W	#5041 to #5043	S	R
#2607 to #2699	S	R/W			
#2700	S	R/W	#5061 to #5063	S	R/W
#2701 to #2706	S	R/W	#5081 to #5083	S	R
#2707 to #2799	S	R/W			
#2807 to #2899	S	R/W			
#2907 to #2999	S	R/W			
#3000	S	R/W	#8004	A	R/W
#3004	S	R/W	#8005	A	R/W
#3005	S	R	#8006	A	R/W
#4001 to #4021	S	R	#8009	A	R/W
#4022	S	R	#8010	A	R/W
#4102	S	R	#8011	A	R/W

Variable Number	Type	Restriction	Variable Number	Type	Restriction
#4107	S	R	#8013	A	R/W
#4109	S	R	#8014	A	R/W
#4111	S	R	#8016	A	R/W
#4113	S	R	#8017	A	R/W
#4114	S	R	#8018	A	R/W
#4115	S	R	#8019	A	R/W
#4119	S	R	#8020	A	R/W
#4120	S	R	#8024	A	R/W
#4201 to #4221	S	R	#8025	A	R/W
#4222	S	R	#8026	A	R/W
#4302	S	R	#8030	A	R
#4307	S	R	#8031	A	R
#8032	A	R	#8117	A	R
#8033	A	R	#8118	A	R
#8035	A	R	#8119	A	R
#8036	A	R	#8120	A	R
#8037	A	R	#8124	A	R
#8038	A	R	#8125	A	R
#8039	A	R	#8126	A	R
#8040	A	R	#8130	A	R
#8041	A	R	#8131	A	R
#8045	A	R	#8132	A	R
#8046	A	R	#8133	A	R
#8104	A	R	#8136	A	R
#8105	A	R	#8137	A	R
#8106	A	R	#8138	A	R
#8109	A	R	#8139	A	R
#8110	A	R	#8140	A	R
#8111	A	R	#8141	A	R
#8113	A	R	#8145	A	R

Variable Number	Type	Restriction	Variable Number	Type	Restriction
#8114	A	R	#8146	A	R
#8116	A	R			



Type:

A = Argument

G = Global

L = Local

S = System

Restriction:

R/W = Read/Write

R = Read

Expression Symbols

Various keywords and symbols can be used in the expressions. At least two letters of the keyword are required: RO, ROU, ROUN, and ROUND perform the same function. The software checks spelling. RUON is not a valid abbreviation for ROUND, but ROUN is acceptable.

Symbol	Description	Example
+	Addition	#500 = #600 + 2.3
-	Subtraction	#500 = #600 - 2.3
/	Division	#500 = #600 / 2.3
	Multiplication	#500 = #600 * 2.3
^	Power (i.e. 2^2, 2 to the 2nd power, or 4)	#500 = 4.5 ^ 2 #500 will be set to 20.25.

Expression Keywords

The table below describes the keywords:

Operation Keyword	Description	Example
ABS	Absolute Value	#500 = ABS [-#550]
ACOS	Arc or Inverse Cosine function	#500 = ACOS [#540]
AND	Logical AND	#500 = #600 AND 48
ASIN	Arc or Inverse Sine function	#500 = ASIN [#540]
ATAN	Arc Tangent (degrees)	#500 = ATAN [.34]
BCD	Convert Binary to BCD Format	#500 = BCD [#600]
BIN	Convert BCD to Binary Format	#500 = BIN [#600]
COS	Cosine (degrees)	#500 = COS [45.3]
DEGREES	Converts radians to degrees	#500 = DEGREES [5.437] #500 will be set to 311.52 degrees.
EQ	Equal	#500 = #510 EQ 3.4 #500 will be set to 0 if false; 1 if true.
EXP	Exponential function	#500 = EXP [3.67] #500 will be set to 39.252.
FIX	Discards fractions less than 1	#500 = FIX [45.2375] #500 will be set to 45
FUP	Adds 1 for fractions less than 1	#500 = FUP [45.2375] #500 will be set to 46
GE	Greater Than Or Equal To	#500 = #510 GE 3.4 #500 will be set to 0 if false; 1 if true.
GT	Greater Than	#500 = #510 GT 3.4 #500 will be set to 0 if false; 1 if true.
HSIN	Hyperbolic Sine function	#500 = HSIN[#540]
HCOS	Hyperbolic Cosine function	#500 = HCOS [#540]
INVERSE	Binary Inverse function	#500 = [7 AND [INV[3]]] #500 will be set to 4.0.

Operation Keyword	Description	Example
LE	Less Than or Equal To	#500 = #510 LE 3.4 #500 will be set to 0 if false; 1 if true.
LN	Natural Logarithmic function	#500 = LN [24.89] #500 will be set to 3.2144.
LOG	Logarithmic function	#500 = LOG [345.89] #500 will be set to 2.5389.
LT	Less Than	#500 = #510 LT 3.4 #500 will be set to 0 if false; 1 if true.
NE	Not Equal	#500 = #510 NE 3.4 #500 will be set to 0 if false; 1 if true.
OR	Logical OR	#500 = 41 OR 4
RADIANS	Converts degrees to radians	#500 = RADIANS [270.34] #500 will be set to 4.718 radians.
ROUND	Rounds off	#500 = ROUND [34.56 result is 35]
SIN	Sine (degrees)	#500 = SIN [#610]
SQRT	Square Root	#500 = SQRT [#540]
TAN	Tangent (degrees)	#500 = TAN [32.4]
XOR	Logical Exclusive OR	#500 = #560 XOR 34

The software automatically converts real numbers to hexadecimal format before performing logical operations. The Operation Keyword "AND" does not function on real numbers. As shown below, the #500 value is truncated to 32 and the #550 value is truncated to 48. When the "AND" function is performed, the truncated numbers are stored in variable #560.

- #500 = 32.456
- #550 = 48.98
- #560 = [#500 AND #550]

These examples are valid variable expressions:

- G01 X#140 Y [#500 + 2.] Z[#550 * [SIN [#130 + 23.5]]]
- G02 Z [2.3 / [SIN 43]] Y[2 ^ 3] G20 M25
- X [ROUN[3.45 * COS[#520]]]
- R [SQRT[#510 ^ 2] + [#511 ^ 2]]
- G01 X-#510 Y-[#520 + 4.5] Z4

Operation Priorities

The interpreter gives operations within the expression a certain priority in order to determine how the expression is evaluated. This is a listing of the priorities:

Priority	Operation	
Highest	Functions	
Second	Symbols:	Power (^)
Third		Multiplication (*) Division (/)
Lowest		Addition (+) Sub- traction (-)

Although the interpreter assumes this priority, in order to make the NC program more understandable and more maintainable, use brackets to divide the expressions. For example, G01 X[34.5+23.4 / 32] should be rewritten as G01 X[34.5 + [23.4/32]]. Using spacing within an expression can also make the expression more readable. Decimal points and leading or trailing zeros are not required with the numbers.

GOTO Statements

GOTO statements jump the program to a specific number in the program. Any valid address expression can be used in place of a sequence number after the GOTO. Fractions are truncated. For example, GOTO 3.45 and GOTO 3 work the same. The program cannot locate sequence numbers that are not in memory. If the search reaches the end of the program without finding the sequence number, the software generates an error message.

Positive GOTO Statement

If the resultant value is positive, the software searches for the sequence number from the point of the GOTO to the end of the program. Then it proceeds to the beginning of the program and searches for the sequence number until reaching the starting point (GOTO statement).

Negative GOTO Statement

If the resultant value of the expression is negative, the search begins at the beginning of the program.

IF Statements

IF statements contain a conditional expression and a GOTO statement. The expression which follows the GOTO must result in a valid sequence number; otherwise, an error message is generated. The program cannot locate sequence numbers that are not in memory. The following line illustrates an IF statement's components:

- IF [conditional expression] GOTO [expression or #]
- If the conditional expression has a value of 1, it is true, and the GOTO is performed.
- If the conditional expression has a value of 0, it is false, and the next NC block is executed.
- If the conditional expression has a value other than 0 or 1, it is invalid.

These are examples of conditional expressions used in IF statements:

```
IF[[[#100 LT 2.3] OR [#320LE7.34]] AND [#400LT3.4]] GOTO#340
```

```
IF[#150 EQ 2] GOTO 10
```

```
IF[#750 GT 2.34] GOTO [[#550+23]/40]
```

WHILE Loops

WHILE loops contain a conditional expression and a DO statement. This is a sample WHILE loop:

- WHILE [conditional expression] DO number
- NC block

- NC block
- NC block
- END number

The blocks between the WHILE statement and the END statement are repeated as long as the conditional expression is true. The following are other details about WHILE loops:

- A WHILE loop must have a matching END statement within the same program.
- The DO must match the number following END and must be an integer in the range of 1 to 255.
- The program cannot locate sequence numbers that are not in memory.
- No other NC commands can be contained on the same lines as the WHILE or END statements.
- If the WHILE conditional expression is false, the program continues execution with the NC block which follows the END statement.
- DO loops operate the same as WHILE loops with a conditional expression which is always true.
- The DO statement can also be used by itself without the WHILE conditional statement. +

⇒ To exit an infinite WHILE loop while the program is being drawn, press the console Draw key.

DO Loops

DO loops operate the same as WHILE loops with a conditional expression which is always true. The DO statement can also be used by itself without the WHILE conditional statement. The following are some additional details about DO loops:

- DO loops must contain a matching END statement within the same program.
- The numbers following DO and END must match and must be an integer in the range of 1 to 255.
- The program cannot locate sequence numbers not in memory.
- No other NC commands can be contained on the same lines as the DO or END statements.

The following is a sample DO loop:

- DO number
- *NC block*
- *NC block*
- *NC block*
- END number

The blocks between the DO statement and the END statement are repeated continuously in an infinite loop unless one of the following events occurs:

- The program exits the loop with a GOTO or M99 P ____ jump statement.
- The program execution is terminated with an M02 or M30.
- The right mouse button is pressed. The right mouse button acts as a graphics reset.



To exit an infinite DO loop while the program is being drawn, press the console Draw key.

Stop Program Execution

The M02 (End of Program) and M30 (End Program) program control statements stop program execution. The following examples of program control statements are used correctly:


Nested WHILE Loops	Branch Outside WHILE Loop	Subprogram Call from Inside WHILE Loop	Reuse of DO-END Pairing Number
WHILE[...] DO 100 <i>NC blocks</i> WHILE[...] DO 200 <i>NC blocks</i> WHILE[...] DO 250 <i>NC blocks</i> END 250 <i>NC blocks</i> END 200 <i>NC blocks</i> END 100	WHILE[...] DO 200 <i>NC blocks</i> GOTO 3535 <i>NC blocks</i> END 200 <i>NC blocks</i> N3535	WHILE[...] DO 150 <i>NC blocks</i> M98 P3000 <i>NC blocks</i> END 150 <i>NC blocks</i> WHILE[...] DO 200 <i>NC blocks</i> G65 P3000 <i>NC blocks</i> END 200 <i>NC blocks</i>	WHILE[...] DO 100 <i>NC blocks</i> END 100 <i>NC blocks</i> WHILE[...] DO 100 <i>NC blocks</i> END 100 <i>NC blocks</i> WHILE[...] DO 100 <i>NC blocks</i> END 100

These examples show **incorrect** use of program control statements:

Incorrectly Nested WHILE Loops	Branch Into a WHILE Loop	Improper Reuse of DO-END Pairing Number
WHILE[...] DO 100 <i>NC blocks</i> WHILE[...] DO 200 <i>NC blocks</i> WHILE[...] DO 250 <i>NC blocks</i> END 100 <i>NC blocks</i> END 200 <i>NC blocks</i> END 250	GOTO 3535 <i>NC blocks</i> WHILE[...] DO 200 <i>NC blocks</i> N3535 <i>NC blocks</i> END 200	WHILE[...] DO 100 <i>NC blocks</i> WHILE[...] DO 100 <i>NC blocks</i> END 100 <i>NC blocks</i> END 100 <i>NC blocks</i>

NC Part Programming Example

Following the simple drawing below, of a part program, is a sample NC part program that may be used to test the BNC programming features.



Sample NC Part Program Drawing


For instructions describing entering codes into a program, refer to the "Editing NC Programs" section of the "Editing NC Part Programming" chapter.

Here is one way the part shown on the previous page may be programmed using the NC system:

```
%  
N10 G0 G90 x0. Y0. S500 T1 M6  
N12 X0.5 Y0.5 Z0.5 M3  
N15 G81 X0.5 Y0.5 Z0.75 F5.  
N20 X0.5 Y7.5  
N25 X9.5 Y7.5  
N30 X9.5 Y0.5  
N35 G0 X0. Y0. S1000 T2 M6  
N40 G0 X5. Y6.5 Z0.5  
N50 G0 G42 X5. Y6.5 M3  
N55 G1 Z-0.25 F5.  
N65 G2 X5. Y1.5 I5. J4. F10.  
N70 X5. Y6.5 I5. J4.  
N71 G0 Z0.5  
N72 G0 G40 X5. Y6.5  
N75 G0 Y10.5 Z3. M2  
E
```


NCPP Example - Bolt Hole Circle

The Bolt Hole Circle program uses subprograms to produce five different Bolt Hole patterns, as shown below, and specifies which canned cycle to use, how many holes to skip, and on which hole to begin the skip.



Bolt Hole Circle Example Drawing

```


%
O4000
T1 M06
M03 G00 G90 X0 Y0 Z0 S1800
#500 = 99
G65 P5080 A30.0 B10 C2.5 S4 T3 H81 I-9 J-3.5 K0 Z-1 R-.7
G65 P5080 A30.0 B12 C2.6 S2 T4 H81 I9 J-3.5 K0 Z-1 R-.2
G65 P5080 A0.0 B8 C2.3 S6 T2 H81 I9 J3.5 K0 Z-1 R-.4
G65 P5080 A30.0 B9 C2.5 S2 T1 H81 I-9 J3.5 K0 Z-1 R-.1
#1 = 0
WHILE [#1LT5] DO 100
#500 = 98
G65 P5080 A90.0 B5 C[1.5+#1] S0 T0 H81 I0 J0 K.5 Z-2 R-.7
#1 = #1+1
N1000 END 100
M02
O5080
(#1 IS THE START ANGLE)
(#2 IS THE NUMBER OF HOLES)
(#3 IS THE RADIUS)
(#4 IS THE BOLT CIRCLE CENTER PT X COORD)
(#5 IS THE BOLT CIRCLE CENTER PT Y COORD)
(#6 IS THE BOLT CIRCLE CENTER PT Z COORD)
(#18 IS THE RETURN LEVEL)
(#19 IS THE HOLE TO SKIP)
(#11 IS THE CANNED CYCLE NUMBER)
(#26 IS THE HOLE DEPTH)
#30 = [360.0/#2]
#31 = 0
#32 = 0

```

```
#33 = 0
WHILE [#31LT#2] DO 250
#7 = [#1+[#31*#30]]
IF [[#19-1]EQ#31] GOTO 200
IF[#32EQ1] GOTO 200
#33 = 1
G00 Z#6
G#500 G#11 Z#26 X[#4+[#3*COS[#7]]] Y[#5+[#3*SIN[#7]]] R[#18] F20.
N200 #31 = #31+1
IF [#33EQ1] GOTO 300
IF [#20EQ0] GOTO 300
#20 = #20-1
#32 = 1
GOTO 310
N300 #32 = 0
N310 #33 = 0
N400 END 250
M99
```

NCPP Example - Gear Pattern

The program below uses Polar Coordinates in a subprogram to generate a Gear pattern:




Display of Gear Pattern Example

```
%
M03 G00 G21 G90 X0 Y0 Z0 S1800
(VARIABLE #4006 - INCHES/METRIC)
IF [#4006 EQ 20] GOTO 10
IF [#4006 EQ 21] GOTO 15
N10 #850 = 25.4
GOTO 20
N15 #850 = 1.0
N20
```

```
G65 P5085 A30.0 B8 C2.5 S0 H2. I1 J1 K1 R.45 T.2
G65 P5085 A0.0 B5 C1.5 S0 H1.2 I5 J3 K1 R.3 T.2
G65 P5085 A15. B20 C1.8 S0 H1.5 I5 J-3. K1 R.6 T.1
M02
/
O5085
(#1 IS THE START ANGLE)
(#2 IS THE NUMBER OF GEAR TEETH)
(#3 IS THE OUTSIDE RADIUS)
(#11 IS THE INSIDE RADIUS)
(#4 IS THE GEAR CENTER PT X COORD)
(#5 IS THE GEAR CENTER PT Y COORD)
(#6 IS THE GEAR CENTER PT Z COORD)
(#19 IS THE TOOTH TO SKIP)
(#18 IS THE TOOTH RATIO)
/
#30 = [360.0/#2]
#31 = 0
#22 = [#30*#18]
#23 = #30-#22
#24 = #11*#850
#25 = #3*#850
#26 = #20*#23
G52 X#4 Y#5 Z#6
G90 G00 G16 X#25 Y#1
G01 Z-.25 F20.
WHILE [#31LT#2] DO 250
#1 = [#1+[#22]]
G03 G16 X#25 Y[#1] R#3
G01 X#24 Y[#1+#26]
#1 = [#1+[#23]]
G03 X#24 Y[#1-#26] R#11
G01 X#25 Y[#1]
G15
N200 #31 = #31+1
N400 END 250
M99
E
```

TOOL FIXTURE (TPS) OPTION

The Tool Fixture (TPS) option provides an alternative way to manually move tools to and from the spindle during tool setup or program execution. TPS has two components, a tool fixture and an optikey that enables the option. The fixture is attached to the table, near the front enclosure doors. It is not removable, except for complete removal.



Tool Fixture

TPS is used as part of a tool change sequence from Tool Setup or Manual or Auto mode. Tools are laterally loaded into and unloaded from the tool fixture, and use the same spindle orient position as the ATC arm.

Tools used with TPS are limited by the tool fixture's height and diameter, as well as ATC weight restrictions. Tools inserted into the spindle with TPS must be removed with TPS. You can convert a tool loaded with TPS into an auto tool, as long as it fits the diameter and weight constraints of the magazine. Once the tool becomes an auto tool, it is no longer tracked as a TPS loaded tool.



You can insert a tool or remove a tool using TPS in Tool Setup, Manual Mode or Auto Mode. This section describes tool loading and unloading using TPS in Tool Setup.

Tool Removal

Automatic Tool Removal Using TPS

Follow the instructions below to use TPS to automatically remove a tool from the spindle:

1. Select the Input console key to access the Input screen.


2. Select the Tool Setup softkey.
3. With the cursor in the Tool field, enter the number of the tool you want to change into the spindle.
4. Select the Auto Tool Change console button. The Start Cycle button begins flashing.
5. Press the Start Cycle console button to initiate the tool removal process. The enclosure doors can now be opened. A "Confirm Empty Fixture. Close Doors and Press Start to Continue" message appears. The Start Cycle button flashes.
6. Make certain the Tool Fixture is empty. Press the Start Cycle button and its stops flashing.
7. A "Remove Tool X from Fixture, Close Doors & Press Start" message appears on the screen.
8. Remove the tool from the fixture, close the enclosure doors and Press the Start Cycle button.
9. The tool entered in step #3 is inserted from the magazine into the spindle.
10. The tool removal is complete.



You must use Manual Mode if the tool you are removing was the last tool in the spindle.

Automatic Tool Change Using TPS

Follow the instructions below to complete an Auto Tool change using TPS

1. Select the Input console button to access the Input screen.
 2. Select the Tool Setup softkey to access the Tool Setup screen.
 3. With the cursor in the Tool field, enter the number of the tool that will be inserted into the spindle using TPS.
 4. Press the Tool Changer Auto console button. The Start Cycle button begins flashing.
 5. Press the Start Cycle button to initiate the tool change.
 - a. The Z axis rapids to the home position.
 - b. The X and Y axes rapid to the Access position. An "Insert Tool X in Fixture. Press Start" message appears. The Start Cycle button flashes again.
-  If the Tool in Spindle is 0, a message will appear confirming that the spindle is empty. If the Tool in Spindle is a number other than 0, the tool will be removed from the spindle (automatically put into the magazine or you will be prompted to be removed manually)
6. Insert the tool into the fixture.
 7. Close the enclosure doors. Press the Start Cycle button.
 - a. The Start Cycle button stops flashing.
 - b. The X and Y axes rapid to the Fixture position.

- c. The spindle orients (if it is not already oriented).
 - d. The spindle unclamps.
 - e. The Z axis rapids to the Clear position (its position before the tool change began) - then moves at a fixed, reduced feedrate to the Fixture position. The spindle clamps the tool.
 - f. The Z-axis moves to the Fixture position at a reduced feedrate.
 - g. The spindle clamps the tool.
 - h. The X and Y axes move to the Clear position (their positions before the tool change began) at a reduced feedrate.
 - i. The Z axis rapids to the Tool Change position.
8. The tool change is complete.

⇒ A message requesting the tool be removed from the spindle using TPS will be displayed for any tool that was inserted into the spindle with TPS. You may use TPS to remove the tool or manually unclamp the tool to remove it from the spindle.

Bypass TPS in an Automatic Tool Change

Follow the instructions below to complete an Auto Tool change and bypass TPS:

1. Select the Input console button to access the Input screen.
2. Select the Tool Setup softkey to access the Tool Setup screen.
3. With the cursor in the Tool field, enter the number of the tool that will be inserted into the spindle.
4. Press the Tool Changer Auto console button; the Start Cycle button begins flashing. Press the Start Cycle button. If there is a tool in the spindle, remove it before proceeding. If the spindle is empty, the machine moves to the Access position.
5. When prompted to insert the tool into the fixture, manually insert the tool into the spindle. To install a tool using TPS, see [Automatic Tool Change Using TPS](#)
 - a. Press the spindle unclamp button and insert the tool. The prompt changes to "Insert Tool XX in Spindle & Press Start Cycle."
 - b. Release the unclamp button. The tool is clamped in the spindle.
6. Close the enclosure doors and press the Start Cycle button.
7. The tool change is complete.

⇒ Any tool that is inserted into the spindle manually (bypassing TPS) *must* be removed manually.

HELICAL PLUNGE OPTION

The Helical Plunge programming option provides helical plunge as an alternative machining strategy. Helical plunge and straight plunges can be used separately for roughing and finishing phases, or they can be used together for the same operation. For example, you can rough with a helical plunge and finish with a straight plunge.

In the Helical Plunge option, the tool rotates around the cut and moves down the Z-axis. The cutting tool is continuously cutting deeper and enters and exits the machined part only once.

To use Helical Plunge, set the Mill or Finish Plunge Type in Milling Parameters to Helix.

[Helical Plunge Milling Parameter Fields](#)

[Helical Plunge \(Inside/Outside\) for Mill Frames, Mill Circles and Ellipses](#)

[Helical Plunge with Lines and Arcs](#)

[Helical Plunge with UltiPocket](#)

[Helical Plunge with 3-D Part Programming Option](#)



- Helical Plunge uses the **feedrate** programmed by the operator on the mill circle, mill frame, ellipse, or mill contour start screens.
- **Pattern blocks** can be used with helical plunging. A scaled-up or scaled-down pattern will not affect the diameter of the helix plunge. When using a mirror image pattern, the helical plunge will be in the negative Z direction.
- Helical Plunge for **rotary mill frames**, mill circles, and mill contours is similar to helical plunging for non-rotary mill frames, mill circles, and mill contours.

Helical Plunge Milling Parameter Fields

On the Milling Parameters screen, choose the Mill Plunge Type as Helix. If the Helical Plunge option is enabled, the fields specifying the plunging parameters appear. If the fields do not appear, the Helical Plunge option has not been installed on the control. Call Hurco or a Hurco distributor to purchase the option.



Helical Plunge Milling Parameter fields are available only in Conversational Programming.

- **Mill Plunge Type**—specifies the plunging strategy to use for the milling pass. Choose Straight or Helix. The default setting is Straight.

- **Mill Plunge Ramp Slope**—defines the slope of the helical ramp for the milling tool. The range is 1o to 90o. Choosing 90o will result in a Straight Plunge. The default value is 10o.
- **Mill Plunge Helix Radius**—used for specifying the Helical Plunge radius as a percentage of the tool diameter. The range is from 0% to 100%. Choosing 0% results in a Straight Plunge. If a value of 50% or less is chosen, it will prevent a post (a thin cylinder of material formed after helical plunging) from being formed by the Helical Plunge. The default setting is 25%.
- **Finish Plunge Type**—specifies the plunging strategy to use for the finish phase. Choose Straight or Helix. The default setting is Straight.
- **Finish Plunge Ramp Slope**—defines the slope of the Helical Ramp for the finishing tool. Range is 1° to 90°. Choosing 90o will result in a Straight Plunge. The default setting is 25°.
- **Finish Plunge Helix Radius**—defines the value of the Helical Plunge radius as a percentage of the diameter of the finishing tool. The range is 0% to 100%. If a value of 50% or less is chosen, it will prevent a post from being formed by the Helical Plunge. The default setting is 25%.
- **Operator Specify Pocket Start**—if YES, the pocket start location fields will appear on pocket boundary screens, when spiral inward pocketing is selected. The default setting is No. The value of Inward Pocket Plunge Near Center is ignored. Refer to [Helical Plunge with UltiPocket](#) for more information.
- **Inward Pocket Plunge Near Center**—if YES, UltiPocket will attempt to perform a plunge near the center of the pocket. Using this parameter may help prevent interferences with pocket islands and boundaries. The default setting is No. For this field to be enabled, the Operator Specify Pocket Start value must be No. Refer to [Helical Plunge with UltiPocket](#) for more information.

Helical Plunge (Inside/Outside) for Mill Frames, Mill Circles and Ellipses

Helical Plunge is similar for milling the inside or outside of mill frames, circles, and ellipses (with or without blend-in moves). The center location of the helical plunge is the same as a straight plunge. The direction of the helical plunge (clockwise, CW, or counter clockwise, CCW) will be determined by the tool spin direction (CW or CCW) and the milling direction (climb or conventional). If Blend Offset is used, the helical plunge will be centered about the plunge point of the Blend Offset.

The helical plunge direction that provides a smooth transition to the tool path will be chosen. Helical plunge is not allowed when Milling Type On is selected.

[Helical Plunge of Mill Frame Inside with No Pecking and Blend Offset Example](#)

[Helical Plunging of Mill Frame Inside with Pecking and Straight Plunge Finish Pass and Blend Offset Example](#)

Helical Plunge with UltiPocket

The Helical Plunge option is used with the UltiPocket option to define the plunging location when inward pocketing. The operator can specify the pocket plunge location using the Operator Specify Pocket Start function, or start the pocket plunge near the center by using the Inward Pocket Plunge Near Center function. See the UltiPocket Option chapter for more information on using the Helical Plunge option with UltiPocket.

When both the Operator Specify Pocket Start and the Inward Pocket Plunge Near Center are set to No, the plunge locations are used that would have been used without the Helical Plunge option.

⇒ An error message appears if the plunge point specified would violate the programmed part surface.

Helical Plunge with Operator Specified Location

When the operator specifies the plunge point, all of the helix plunge moves will occur at that location, even for the pocket boundary.

Helical Plunge in the Center of a Pocket

When the Inward Pocket Plunge Near Center field value is Yes (Operator Specify Pocket Start value must be No), a plunge point near the center of the pocket will be chosen. Islands near the center will impact upon the plunge point's location.



When machining a part with a lot of webbing (many small pockets separated by walls), it may be desirable to disable helical plunging.

Helical Plunge with Outward Pocketing


Helical plunging occurs near the center of the pocket when used with Outward Pocketing, and only one plunge location is needed. The Operator Specify Pocket Start and the Inward Pocket Plunge Near Center fields have no effect on Helical Plunge with Outward Pocketing.

Helical Plunge of Mill Frame Inside with No Pecking and Blend Offset

The tool will helical plunge to the Z Bottom level and then perform the normal blend-in move. The direction of the helical plunge arc will smoothly transition to the blend-in arc. For instance, if the blend-in arc is CCW, the direction of the helical plunge will be CW. The following isometric views are created by setting the Draw Plunge Moves graphics parameter field to Yes.

⇒ This graphical representation is only for informational purposes and cannot be viewed with Ultimax.

The graphics show the finish pass only if a finish tool is specified in the frame block, and do not show individual peck levels.




Helical Plunge with No Pecking and Blend Offset (Isometric View)

Helical Plunging of Mill Frame Inside with Pecking and Straight Plunge Finish Pass and Blend Offset

The following example is a Mill Frame Block Type with Inside Milling Type. The finish tool specified and the peck depth is set to 0.6 inches.


First Peck - The tool helical plunges down to the -first peck depth, then mills another full circle to ensure that all material down to the first peck is removed. After the full circle is completed, a 180o blend in arc is performed. The direction of the helical plunge will always be in the opposite direction of the blend-in arc.

⇒ These graphical representations are only for informational purposes and cannot be viewed with Ultimax.



First Peck (Isometric View)

Second Peck and All Pecks to Finish Peck Depth - The tool will rapid down to the previous peck depth plus the peck clearance plane. The tool then helical plunges down to the next peck depth or the Z Bottom plus the Finish Z. If the tool is at a peck depth, a 360o arc will be machined. The 360o arc will not be machined if it is the last peck depth. Instead, a blend-in arc will be machined. The blend-in arc for the last peck depth will be similar to the one machined for the first peck.




Second Peck (Isometric View)

Finish Pass - The tool will rapid down to the Z Start and plunge feed down to the Z Bottom. A blend-in move is performed before milling the frame contour.



When helical plunge is used for roughing passes, a large amount of material is removed around the point of entry. Therefore, using helical plunging for the finish passes is probably not necessary.



Finish Pass (Isometric View)




If the finish tool is larger than the roughing tool, helical plunges should also be performed for the finish pass. If a post was created by the roughing tool (the Helix plunge radius was greater than 50 percent) the finish tool may be cutting into the post.

Helical Plunge with Lines and Arcs

Helical plunge with lines and arcs occurs at the start of the contour.

The following example shows helical plunging with right cutter compensation of a contour.



Helical Plunging with Lines/Arcs (Isometric View)

⇒ An error message will be displayed if the helical plunge would cut into a part surface. If this error message appears, move the starting location of the contour to an area that will not cause interference.

Helical Plunge with 3-D Part Programming Option

Helical plunging is supported in the 3-D Part Programming option. A helical plunge can be performed when the Mill Plunge Type field is set to Helix.

Only one helical plunge occurs when using a bi-directional tool path. When performing helical plunge using unidirectional tool path, a helical plunge occurs for each cutter pass.



When programming complex 3-D parts, the operator should review helical plunge placements in graphical form before milling to ensure helical plunges from one block do not interfere with neighboring blocks.

If Mill Plunge Type field is set to Helix, but the helical plunge does not appear on the graphics screen, check the Z Start field on the Mill 3-D block screen. The plunges may not appear if Z Start value is too low.

ULTINET

The UltiNet option provides connection to your Local Area Network (LAN) for communication with other CNCs, PCs, or file servers using standard TCP/IP and FTP protocols.

UltiNet FTP Client

Any file operation performed by an operator at the machine uses the UltiNet FTP client:

1. From the Input screen, select the **PROGRAM MANAGER F8** softkey.
2. From the Program Manager screen, select the **FTP MANAGER F8** softkey.
3. Select host from the list and select the **CONNECT F1** softkey, or select the **ADD HOST F4** softkey to add a connection.

The FTP Manager displays the current connection.

The following tasks can be performed from the FTP Manager screen:

- read a program from the server
- write a program to the server
- copy a program from the server
- copy a program to the server
- rename a program
- delete a program
- create a directory
- delete a directory

UltiNet FTP Server

The UltiNet FTP server runs as a background task, invisible to the operator, providing access to the Hurco machine from a remote computer. To enable the FTP server:

1. In Auxiliary mode, select the **UTILITIES** softkey.
2. Select the **USER PREFERENCES F2** softkey.
3. Use the **MORE** softkey to find and select the **FTP SERVER SETTINGS F2** softkey.

Once a connection is made, a user may perform the following tasks:

- Transfer files to or from the Hurco machine
- Create a directory

- Delete a directory
- Delete files
- Rename files anywhere in the directory structure

FTP Server Settings

The WinMax console can serve as an FTP Server. These fields appear on the FTP Server Settings screen:

- **Enable FTP Server**—Enable the WinMax Control to act as an FTP Server.
- **FTP Server Port**—The port number for FTP access.
- **Maximum Idle Time (Mins)**—Maximum amount of time before connection is dropped.
- **User Name**—The log in name that will allow users access to the FTP Server.
- **Password**—The password that corresponds to the user name and allows access to the FTP Server.
- **Path**—The file path that the users will be allowed access to.

INDEX

Numerics

- 10-base T *1 - 11*
- 3D Arc Data Block *2 - 49*
- 3D circular interpolation
 - G02.4 and G03.4 *3 - 38*
- 3D Mold Blend Arc *4 - 9*
- 3D Mold Contour *4 - 6*
- 3D Mold Line *4 - 7*
- 3D Mold Parameters *2 - 35*

A

- A Axis *4 - 25*
- A axis
 - clamp, M32 *3 - 111*
 - unclamp M33 *3 - 111*
- A Centerline Y / Z field *1 - 53*
- A Offset softkey *1 - 86*
- Abort Port Operation softkey, Serial I/O screen *1 - 47*
- absolute machining mode, G90 *3 - 90*
- Access *4 - 20*
- ACCELERATED DRAW F2 softkey, graphics screen *1 - 95*
- activate spindle, canned cycle *3 - 101*
- Active Error Listing *1 - 48*
- Active Status Listing *1 - 48*
- Add
 - 4 - 19*
- ADD AS MANUAL TOOL F5 softkey, Unmatched Tools Review *1 - 70*
- Add As Manual Tool softkey
 - Tool Review screen *1 - 70*
- Add Location softkey *2 - 64*
- ADD MATERIAL F1 softkey, Tool and Material Database screen *1 - 75*
- ADD TOOL F1 softkey, Tool and Material Database *1 - 74*
- ADD TOOL F1 softkey, Tool and Material Database screen *1 - 74*
- Address Characters *3 - 2*
- Addresses with Variables *4 - 106*
- Advanced Tool Settings *1 - 62*
- ADVANCED TOOL SETTINGS F1 softkey, Tool Setup screen *1 - 59*
- Advanced Tool Settings softkey *1 - 59*
- air
 - probe barrier, M43 (increase) *3 - 112*
 - probe barrier, M44 (decrease) *3 - 112*
- Alarm 3000 Messages *4 - 107*

- All Off *4 - 23*
- All On *4 - 23*
- Allow Vacant Variables field, NC Parameters *3 - 17*
- Along Contour *2 - 39*
- Angle field, Advanced Tool Settings *1 - 64*
- Angle field, Loop Linear data block *2 - 68*
- Angle field, Mirror Image *2 - 73*
- ANSI/EIA RS-274-D standard *3 - 1*
- APPLICATION FONT SIZE, User Interface Settings *1 - 34*
- Arc
 - 4 - 20*
- Arc Segments *2 - 8*
- ARG *3 - 21, 3 - 22*
- Arguments, NC *3 - 19*
- arrow keys *1 - 6*
- Assume Feedrate .1 Increment field, NC Parameters *3 - 18*
- ATC *1 - 13*
 - large tools *1 - 15*
 - loading *1 - 14*
 - tool removal *1 - 15*
- ATC Z-Axis Move to Zero *1 - 41*
- Auto Mode *1 - 89*
- Auto Mode Monitoring *1 - 90*
- Auto, Tool Library *1 - 73*
- Auto/Optional Numbering softkey, NC Editor *3 - 15*
- AutoCAD *4 - 19, 4 - 20*
- AutoCalc *2 - 5*
- AutoChain *4 - 20*
- Automatic Calculations *2 - 5*
- Automatic mode *4 - 60*
- automatic return
 - from reference point, G29 *3 - 48*
 - to reference point, G28 *3 - 48*
- AUTOMATIC TOOL MONITORING field, Probing Parameters *1 - 82*
- AUTOMATICALLY LOAD TOOLS INTO MTC, Tool Utilities and Settings *1 - 36*
- AutoSave Settings *1 - 45*
- AUTOSAVE SETTINGS softkey, Utilities screen *1 - 36*
- Aux Output 2 Confirmation Enable *1 - 42*
- Aux Work Coordinate Systems, G54.1 *3 - 70*
- Auxiliary console key *1 - 5*
- Auxiliary Mode *1 - 32*
- auxiliary output
 - disable, M62 through M65 *3 - 113*
 - enable, M54 through M55 *3 - 112*
- Auxiliary Work Offsets *1 - 56*
- Axis
 - 4 - 25*

- axis
 - control [1 - 7](#)
 - select switch [1 - 9](#)
- Axis Diagram [4 - 25](#)
- Axis Feed Rate dial [1 - 7](#)
- Axis Limit Switches field, Auto Mode [1 - 91](#)
- axis, motion [3 - 9](#)
- Axis, Spindle, and Machine Control Dials, location on console [1 - 4](#)
- Axis, spindle, and machine control, location on console [1 - 3](#)

- B**
- B Axis [4 - 25](#)
- B axis
 - clamp M34 [3 - 111](#)
 - unclamp M35 [3 - 111](#)
- B Centerline X / Z field [1 - 53](#)
- B Codes [4 - 119](#)
- B Offset softkey [1 - 86](#)
- back boring, G87 ISNC [3 - 86](#)
- Back Spotface [2 - 62](#)
- BACKGROUND COLOR field, Graphics Settings [1 - 94](#)
- Backup Config & Machine Files [1 - 34](#)
- Ball-Nosed End Mill [4 - 11](#), [4 - 12](#)
- Ball-Nosed End Mill on a Contour [4 - 10](#)
- Base [1 - 1](#)
- Baud Rate field, Serial Port Settings [1 - 44](#)
- Begin Numbering softkey, NC Editor [3 - 15](#)
- Begin Reading from Port softkey, Serial I/O screen [1 - 47](#)
- Begin Writing to Port softkey, Serial I/O screen [1 - 47](#)
- beginning of tape [3 - 3](#)
- Bidirectional field, 3D Mold Parameters [4 - 4](#)
- BIDIRECTIONAL field, Swept Surface [2 - 40](#)
- Blend Offset field, Milling Parameters [1 - 78](#)
- Blend Overlap field, Milling Parameters [1 - 78](#)
- block
 - editing [3 - 13](#)
 - sequence numbers [3 - 15](#)
- Block field, 3D Mold Arc [4 - 8](#)
- Block field, 3D Mold Blend Arc [4 - 9](#)
- Block field, 3D Mold Contour [4 - 7](#)
- Block field, 3D Mold Line [4 - 7](#)
- Block field, 3D Mold Parameters [4 - 1](#)
- Block field, Auto Mode [1 - 91](#)
- Block field, Back Spotface [2 - 62](#)
- Block field, Bolt Circle data block [2 - 64](#)
- Block field, Bore and Ream Operations [2 - 54](#)
- Block field, Boring and Reaming Operations [2 - 61](#)
- Block field, Change Part Setup [2 - 78](#)
- Block field, Comment data block [2 - 79](#)
- Block field, Contour Arc [2 - 45](#)
- Block field, Contour Blend Arc [2 - 47](#)
- Block field, Contour End [2 - 51](#)
- Block field, Diamond data block [2 - 31](#)
- Block field, Ellipse data block [2 - 23](#)
- Block field, Face Milling [2 - 20](#)
- Block field, Gun Drill data block [2 - 59](#)
- Block field, HD3 Lettering [2 - 35](#)
- Block field, Helix data block [2 - 48](#)
- Block field, Hexagon data block [2 - 34](#)
- Block field, Line segment [2 - 45](#)
- Block field, Loop Angular data block [2 - 69](#)
- Block field, Loop Linear data block [2 - 68](#)
- Block field, Loop Rectangular data block [2 - 67](#)
- Block field, Loop Rotate data block [2 - 70](#)
- Block field, Mill Circle data block [2 - 21](#)
- Block field, Mill Contour block [2 - 43](#)
- Block field, Mill Frame data block [2 - 24](#)
- Block field, Mill triangle data block [2 - 28](#)
- Block field, Mirror Image [2 - 73](#)
- Block field, Pattern Scale data block [2 - 72](#)
- Block field, Position data block [2 - 74](#)
- Block field, Tap Operations [2 - 60](#)
- Block Numbering Mode softkey, Search and Edit Menu, NC [3 - 11](#)
- Block Renumbering Mode softkey, NC Editor [3 - 15](#)
- Block Skip Enable softkey, NC Editor [3 - 16](#)
- BNC dialect [3 - 1](#)
- Bolt Circle [2 - 63](#)
- BORDER SIZE field [1 - 57](#)
- Bore [2 - 54](#)
- bore
 - back boring cycle [3 - 98](#)
 - bore cycle [3 - 97](#)
 - chip breaker cycle [3 - 98](#)
 - counter, drill with dwell G82 [3 - 79](#)
 - manual feed out and dwell, G88 ISNC [3 - 88](#)
 - manual feed out cycle [3 - 98](#)
 - orient cycle [3 - 97](#), [3 - 98](#)
 - orient G76 [3 - 77](#)
 - rapid out cycle [3 - 98](#)
 - rapid out, G86 ISNC [3 - 85](#)
 - rigid tapping cycle [3 - 98](#)
 - spot drill, G81 [3 - 78](#)
 - with dwell cycle [3 - 98](#)
 - with dwell G89 [3 - 89](#)

- Bore and Ream Operations [2 - 54](#)
- Bore Dwell field, Holes Parameters [1 - 81](#)
- Bore Orient Retract field, Holes Parameters [1 - 81](#)
- Boring and Reaming Operations [2 - 61](#)
- boring, G85 [3 - 84](#)
- BOX LENGTH (X, Y, Z) field [1 - 57](#)
- BPRNT/DPRNT OUTPUT DEVICE, NC Settings [1 - 36](#)
- BPRNT/DPRNT OUTPUT FILE, NC Settings [1 - 36](#)
- brightness control [1 - 4](#)
- Brightness control, location on console [1 - 3](#)
- Build DB softkey [4 - 20](#)
- Bypass TPS in an Automatic Tool Change [4 - 148](#)
- Bytes Transferred field, Serial I/O [1 - 47](#)

- C**
- C Axis [4 - 25](#)
- C axis
 - clamp, M12 [3 - 109](#)
 - negative direction, M81 [3 - 113](#)
 - positive direction, M80 [3 - 113](#)
 - unclamp, M13 [3 - 109](#)
- C console key [1 - 6](#)
- CAL to LS Velocity A [1 - 41](#)
- CAL to LS Velocity Z [1 - 41](#)
- Calculating Unknown Lines and Arcs [4 - 30](#)
- Calculations, automatic [2 - 5](#)
- Calculator [1 - 22](#)
- calculator [1 - 21](#)
- Calibrate Machine softkey, Manual Mode [1 - 92](#)
- Calibrating the Machine [1 - 16](#)
- Calibration [1 - 16](#)
- Cancel [4 - 20](#)
- cancel canned cycle [3 - 97](#), [3 - 101](#)
 - G80 [3 - 78](#)
- canned cycle
 - activate spindle [3 - 101](#)
 - cancel [3 - 97](#), [3 - 101](#)
 - code (parameters) [3 - 99](#)
 - descriptions [3 - 94](#)
 - operations [3 - 97](#)
 - replace [3 - 101](#)
 - tapping [3 - 82](#)
- carriage return/line feed pair [3 - 3](#)
- Center Drill [2 - 53](#), [2 - 56](#)
- Centerline Y field, 3D Mold Paratmeters [4 - 2](#)
- Centerline Z field, 3D Mold Paratmeters [4 - 2](#)
- Chamfer Angle field, Advanced Tool Settings [1 - 64](#)
- Change All Feeds Speeds & Tools softkey [1 - 87](#)
- Change All Feeds, Speeds, and Tools softkey [1 - 85](#)
- Change Editor softkey, Auxiliary screen [3 - 6](#)
- change feeds [1 - 87](#)
- Change Feeds & Speeds By Tool softkey [1 - 87](#)
- Change Feeds and Speeds by Tool softkey [1 - 85](#)
- Change Finish SFQ field [1 - 87](#)
- Change Parameters [2 - 75](#)
 - [2 - 75](#)
- Change Parameters (General) [2 - 76](#)
- Change Parameters (Holes) [2 - 76](#)
- Change Parameters (Milling) [2 - 76](#)
- Change Parameters (Performance) [2 - 77](#)
- Change Parameters (Probing) [2 - 77](#)
- Change Parameters (Program) [2 - 75](#)
- Change Part Setup [2 - 78](#)
- change program blocks [1 - 85](#)
- change programmed feedrate [3 - 35](#)
- Change Rough SFQ field [1 - 87](#)
- change speeds [1 - 87](#)
- Change Surface Finish Quality [1 - 87](#)
- Change Tool field [1 - 87](#)
- CHANGE TOOL NUMBER F5 softkey, Tool Library screen [1 - 74](#)
- Change Tool Number field [1 - 85](#)
- Change Tool Number softkey [1 - 59](#)
- change tools [1 - 87](#)
- Change Z-Start softkey [1 - 86](#)
- Changing Feeds, Speeds, and Tools [1 - 87](#)
- Character Height field, HD3 Lettering [2 - 35](#)
- Character Length field, Serial Port Settings [1 - 44](#)
- Character Width field, HD3 Lettering [2 - 35](#)
- Check for Errors softkey, Auto Mode [1 - 89](#)
- chip breaker, G87 BNC [3 - 86](#)
- chip conveyor M codes [3 - 113](#)
- Chip Conveyor On Delay Time [1 - 42](#)
- Chip Removal field, Auto Mode [1 - 90](#)
- Chip Removal Forward On/Off softkey, Auto Mode [1 - 91](#)
- CHIPLOAD field, Advanced Tool Settings [1 - 65](#)
- Choose as Replacement softkey [1 - 72](#)
- chord error default [3 - 38](#)
- Chord Error field, General Parameters [1 - 76](#)
- Circle Data Block [2 - 21](#)

- Circles [4 - 20](#)
- circular and helical interpolation, CW G02 [3 - 34](#)
- circular interpolation
 - 3D G02.4 and G03.4 [3 - 38](#)
 - multi-quadrant, G75 BNC [3 - 76](#)
 - single-quadrant, G74 BNC [3 - 76](#)
- Clear Range of Blocks softkey, NC Editor [3 - 13](#)
- CLEAR TOOLS F6 softkey, Tool Library screen [1 - 74](#)
- Climb Milling [2 - 13](#)
- Closing Feed field, Back Spotface [2 - 63](#)
- COLOR field, Advanced Tool Settings [1 - 63](#)
- Column [1 - 1](#)
- Comment Block [2 - 79](#)
- Communications Panel [1 - 11](#)
- Complete [4 - 19](#)
- Compute Estimated Run Time softkey, Auto Mode [1 - 89](#)
- Console [1 - 1](#)
- console [1 - 2](#)
- console buttons
 - Feed hold [1 - 10](#)
 - motion control buttons [1 - 10](#)
 - Motion hold [1 - 10](#)
- Console Jog Unit, location on console [1 - 4](#)
- console keys [1 - 19](#)
 - Alt [1 - 6](#)
 - C [1 - 6](#)
 - Delete [1 - 6](#)
 - End [1 - 6](#)
 - Enter [1 - 6](#)
 - F [1 - 6](#)
 - Home [1 - 6, 3 - 4](#)
 - Insert [1 - 6](#)
 - Page Down [1 - 6](#)
 - Page Up [1 - 6](#)
- console knobs
 - Axis Feed Rate [1 - 7](#)
 - Rapid Override [1 - 7](#)
 - Spindle Speed [1 - 7](#)
- consoles [1 - 2](#)
- Constant Z level, in Swept Surface [2 - 38](#)
- Contour
 - [4 - 20](#)
 - Contour Blend Arc [2 - 46](#)
 - Contour Line [2 - 45](#)
 - closed [2 - 13](#)
 - Contour Arc [2 - 45](#)
 - Mill Contour [2 - 43](#)
- Contour Arc [2 - 45](#)
- Contour Blend Arc [2 - 46](#)
- CONTOUR COUNT
 - True-Type Lettering [2 - 37](#)
- CONTOUR COUNT field, True-Type Lettering [2 - 37](#)
- Contour End [2 - 51](#)
- Contour Line [2 - 45](#)
- contrast control [1 - 4](#)
- control panel [1 - 3](#)
- Control Panel Function Groups [1 - 3](#)
- Control Power Off Time [1 - 40](#)
- Control Power Off Timer [1 - 18](#)
- Conventional Milling [2 - 13](#)
- Conversational [4 - 19](#)
- Conversational Components [1 - 83](#)
- Conversational Overview [2 - 1](#)
- Conversational Part Probing Cycles [4 - 49](#)
- Conversational part program [4 - 19](#)
- Conversational Part Program creation [2 - 1](#)
- CONVERSATIONAL PROGRAM F1 softkey, Program Manager [1 - 25](#)
- CONVERSATIONAL SETTINGS, Utilities screen [1 - 35](#)
- CONVERT TO LINEAR F7 softkey, Program Review screen [1 - 89](#)
- CONVERT TO ROTARY F6 softkey, Program Review screen [1 - 88](#)
- coolant
 - both systems off, M09 [3 - 109](#)
 - both systems on, M10 [3 - 109](#)
 - primary on, M08 [3 - 109](#)
 - secondary on, M07 [3 - 109](#)
- Coolant field [1 - 61](#)
- COOLANT field, Advanced Tool Settings [1 - 65](#)
- Coolant Washdown On/Off softkey, Auto Mode [1 - 92](#)
- coordinate system setting [3 - 91](#)
 - local, G52 [3 - 66](#)
- coordinate systems, multiple work G54-59 [3 - 69](#)
- coordinates, machine, G53 [3 - 68](#)
- Copy and Change Blocks [1 - 85](#)
 - Input screen [1 - 51](#)
- Copy Blocks softkey [1 - 85](#)
- COPY DIRECTORY F2 softkey
 - Disk Operations [1 - 29](#)
- COPY F2 softkey
 - Disk Operations [1 - 29](#)
- COPY F2 softkey, Program Review screen [1 - 88](#)
- copy program blocks [1 - 86](#)
- Copy Range of Blocks softkey, NC Editor [3 - 14](#)
- Corner [4 - 20, 4 - 21](#)
- Corner Radius [4 - 20](#)
- Corner Radius field [4 - 20](#)
- Corner Radius field, Mill Frame data block

- 2 - 25
- Counterbore 2 - 53, 2 - 55
- Countersink 2 - 53, 2 - 55
- CREATE DIRECTORY F4 softkey
 - Disk Operations 1 - 29
- Creates milling 4 - 20
- Creating Tool Setup Templates 1 - 68
- Cursor
 - 4 - 21
- cursor control 1 - 6
- Cusp Height, In Swept Surface 2 - 38
- Cut Direction field, 3D Mold Parameters 4 - 4
- CUT DIRECTION field, Swept Surface 2 - 40
- CUT DIRECTORY F1 softkey
 - Disk Operations 1 - 29
- CUT F1 softkey
 - Disk Operations 1 - 29
- CUT F1 softkey, Program Review screen 1 - 88
- Cutter Comp Param field, Milling Parameters 1 - 80
- Cutter Compensation 2 - 10
- cutter compensation 3 - 52
 - exit move 3 - 55
 - left, G41 3 - 54
 - off, G40 3 - 54
 - right, G42 3 - 55
 - steps for programming 3 - 55
 - tool length offset 3 - 53
 - tool radius offset 3 - 53
- Cutter Compensation Lookahead 2 - 14
- Cutter Insert Routines 4 - 24
- Cutting
 - inside a cavity 2 - 76
- Cutting Edges field, Advanced Tool Settings 1 - 64
- Cutting Feed field, Back Spotface 2 - 63
- Cutting Speed field, Back Spotface 2 - 63
- Cutting Time field, Tool Setup screen 1 - 62
- cycle, return to initial point, G98 3 - 94
- Cylinder Cycle 4 - 75
- CYLINDER field 1 - 57
- Cylinder Skew Cycle 4 - 82

- D**
- D code 3 - 103
- Data block 2 - 1
 - 2 - 75, 4 - 20, 4 - 24
- Data Block Creation and Navigation 2 - 3
- Data Blocks 2 - 3
- data smoothing G05.2 3 - 40
- DB SEARCH F6 softkey, graphics screen 1 - 95
- Default 4 - 20
- DEFAULT CUT COMP LOOK AHEAD field, NC Parameters, NC Configuration screen 3 - 56
- Default Cutter Comp Lookahead field, NC Parameters 3 - 18
- Default M and G Codes 3 - 4
- Default Order 4 - 20
- Default Pocket Overlap field, Milling Parameters 1 - 79
- Default Radius 4 - 20
- Default Tool Number field, NC Parameters 3 - 17
- default values, information about 3 - 4
- DEFAULT VIEW field, Graphics Settings 1 - 93
- DEFAULT XML PROGRAM TYPE, Conversational Settings 1 - 35
- Defines 3 - 22, 4 - 20, 4 - 24
- Delete Block / Delete Sub Block softkey 1 - 89
- Delete Block softkey, Basic Programming Menu, NC 3 - 10
- Delete Blocks softkey 1 - 85
- DELETE DIRECTORY F6 softkey
 - Disk Operations 1 - 29
- DELETE F4 softkey, Program Review screen 1 - 88
- DELETE F5 softkey
 - Disk Operations 1 - 30
- Delete key 1 - 6
- Delete Location softkey 2 - 64
- DELETE MATERIAL F3 softkey, Tool and Material Database screen 1 - 75
- Delete Operation softkey 2 - 52
- delete program blocks 1 - 86
- Delete Range of Blocks (F5) softkey, Edit Functions screen 3 - 15
- Delete Range of Blocks softkey, NC Editor 3 - 14
- Delete Tool softkey 1 - 58
- deleting
 - words or characters 3 - 5
- Depletion Retract field, General Parameters 1 - 77
- depth, Z code 3 - 100
- DESCRIPTION field, in Program Properties 1 - 28
- DIAGNOSTICS F3 softkey, Manual Mode 1 - 92
- Diameter field 1 - 60
- Diameter field, Advanced Tool Settings 1 - 64
- DIAMETER TOLERANCE field, Probing Pa-

- Parameters 1 - 82
 - Diameter Wear field, Tool Setup screen 1 - 62
 - Diamond Data Block 2 - 30
 - Direction 4 - 20
 - Direction field, 3D Mold Arc 4 - 8
 - Direction field, 3D Mold Blend Arc 4 - 9
 - DIRECTION field, Advanced Tool Settings 1 - 63
 - Direction field, Contour Arc 2 - 45
 - Direction field, Contour Blend Arc 2 - 47
 - Direction field, Helix data block 2 - 48
 - Disable Aux Out 1 During Interrupt 1 - 42
 - Disable Aux Out 2 During Interrupt 1 - 42
 - Disable Aux Out 3 During Interrupt 1 - 42
 - Disable Tool Picker Option 1 - 40
 - Disable X/Y/Z Scaling field, NC Parameters 3 - 17
 - Disk Operations 1 - 28
 - DISK OPERATIONS F7 softkey, Program Manager 1 - 27
 - Display Machine Specifications softkey, Utilities screen 1 - 33
 - Display Time field, Comment data block 2 - 79
 - DISPLAY UNITS field, in Program Properties 1 - 28
 - Display WinMax Configuration softkey, Utilities screen 1 - 33
 - Distance field, Loop Linear data block 2 - 68
 - DO Loops 4 - 141
 - Draw 4 - 20, 4 - 21
 - DRAW (PAUSE) F1 softkey, graphics screen 1 - 95
 - Draw Along Contour 2 - 39
 - DRAW OPTIONS F1 softkey, graphics screen 1 - 95
 - Draw Profile Contour 2 - 38
 - Drill 2 - 53, 2 - 54, 2 - 56
 - drill
 - deep hole cycle 3 - 97
 - deep hole, G83 3 - 80
 - peck, G73 3 - 75
 - spot boring cycle 3 - 97
 - with dwell, counter boring cycle 3 - 97
 - Drill Angle field, Advanced Tool Settings 1 - 64
 - Drill Dwell field, Holes Parameters 1 - 81
 - Drill Overview 2 - 53
 - drive
 - jump 1 - 13
 - drop-down lists 1 - 20
 - Dry Run softkey, Auto Mode 1 - 90
 - dwell
 - bottom of hole, P code (canned cycle) 3 - 99
 - mode, G04 3 - 39
 - P code 3 - 100
 - Dwell field, Tap Operations 2 - 60
 - DXF
 - 4 - 19, 4 - 20, 4 - 21
 - DXF Build Data Block 4 - 20
 - DXF CAD Compatibility 4 - 19
 - DXF Zoom Window 4 - 21
 - DXF Build 4 - 20
 - DXF CAD Compatibility 4 - 19
 - DXF Data block building 4 - 20
 - DXF Edit Modify - Arc 4 - 23
 - DXF Edit Modify - Line 4 - 23
 - DXF Edit Modify - Point 4 - 23
 - DXF Layers 4 - 23
 - DXF Parameters 4 - 20
 - DXF Units 4 - 20
 - DXF Zoom Window 4 - 21
- ## E
- Edge Cycle 4 - 71
 - Edge Skew Cycle 4 - 81
 - Edit 4 - 20
 - Edit 3D Mold Parameters softkey 4 - 6
 - EDIT ALONG CONTOUR softkey 2 - 39
 - Edit Apt Parameters 1 - 68
 - Edit Drawing 4 - 20
 - Edit Functions 4 - 20
 - Edit Functions softkey, Search and Edit Menu, NC 3 - 11
 - EDIT MATERIAL F2 softkey, Tool and Material Database screen 1 - 75
 - EDIT MODE, User Interface Settings 1 - 34
 - EDIT PROFILE CONTOUR softkey 2 - 38
 - EDIT TOOL F2 softkey, Tool and Material Database screen 1 - 74
 - editing
 - fields 3 - 6
 - groups of blocks 3 - 13
 - editor
 - features 3 - 6
 - menus 3 - 6
 - Editor Status Line field, NC Editor 3 - 7
 - Ellipse Data Block 2 - 23, 4 - 20
 - Ellipses 4 - 20
 - Emergency Stop 1 - 18
 - Emergency Stop button 1 - 5
 - Emergency Stop Button, location on console 1 - 4
 - Emergency stop, location on console 1 - 3

- ENABLE AUTOMATIC SAVE, Autosave Settings [1 - 36](#)
- Enable Blend Moves field, Mill Contour block [2 - 43](#)
- Enable FTP Server field [4 - 157](#)
- Enable FTP Server field, FTP Server Settings [1 - 44](#)
- ENABLE PROJECT RESTORE, User Interface Settings [1 - 35](#)
- Enable Tool SFQ field, Advanced Tool Settings [1 - 67](#)
- Enable User M/G Codes field, NC M and G Code Program Numbers [3 - 18](#)
- Enable User S/B/T Codes field, NC M and G Code Program Numbers [3 - 18](#)
- End
 - [2 - 75](#)
- End Angle field, 3D Mold Paratmeters [4 - 3](#)
- End Block field [1 - 85](#), [1 - 87](#)
- End Block softkey [1 - 86](#)
- End key [1 - 6](#)
- end of program, M02 [3 - 107](#)
- end of tape [3 - 3](#)
- end program, M30 [3 - 110](#)
- Enter key [1 - 6](#)
- Erase Functions [1 - 51](#)
 - Input screen [1 - 51](#)
- ERASE PART SETUP F1 [1 - 51](#)
- ERASE PROGRAM F4 [1 - 52](#)
- ERASE TOOL SETUP F2 [1 - 51](#)
- Error History [1 - 48](#)
- European machines [1 - 1](#)
- Examples [4 - 155](#)
- Exit Editor softkey, Basic Programming Menu, NC [3 - 10](#)
- Exit softkey, Part Programming [2 - 2](#)
- Exit/Cancel [4 - 20](#)
- Expand and Collapse Files [1 - 20](#)
- EXPORT AUTO AND MANUAL TOOLS F1, Import and Export [1 - 39](#)
- Export Log [1 - 50](#)
- EXPORT MANUAL TOOLS F2, Import and Export [1 - 39](#)
- EXPORTED NC DECIMAL PLACES, NC Settings [1 - 36](#)
- Expression Keywords [4 - 138](#)
- Expression Symbols [4 - 134](#)
- F**
- F code [3 - 2](#), [3 - 9](#)
 - feedrate [3 - 99](#)
- F console key [1 - 6](#)
- F words, feedrate [3 - 93](#)
- F(%) field, Auto Mode [1 - 90](#)
- Face Milling [2 - 19](#)
 - feed
 - functions, dwell mode [3 - 39](#)
 - functions, F words [3 - 93](#)
 - per minute feedrate, G94 [3 - 93](#)
- Feed & Speed Optimization softkey, Auto Mode [1 - 89](#)
- Feed and Speed [1 - 65](#)
- Feed and Speed Calculations [1 - 66](#)
- Feed and Speed, Advanced Tool Settings [1 - 65](#)
- Feed field [1 - 62](#)
- Feed field, 3D Arc [2 - 49](#)
- FEED field, Advanced Tool Settings [1 - 65](#)
- Feed field, Auto Mode [1 - 90](#)
- Feed field, Contour Arc [2 - 46](#)
- Feed field, Contour Blend Arc [2 - 47](#)
- Feed field, Helix data block [2 - 48](#)
- Feed field, Line segment [2 - 45](#)
- Feed Hold console button [1 - 10](#)
- Feed/Flute (Tooth) field [1 - 62](#)
- feedrate [3 - 2](#), [3 - 9](#)
 - change programmed [3 - 35](#)
 - F code [3 - 99](#), [3 - 101](#)
 - inverse time G93 [3 - 93](#)
- Feeds and speeds [1 - 66](#)
- Fields [4 - 20](#)
- File
 - [4 - 19](#)
- Finish Diameter field, 3D Mold Paratmeters [4 - 6](#)
- Finish Diameter field, Ellipse data block [2 - 24](#)
- Finish Diameter field, Face Milling [2 - 21](#)
- Finish Diameter field, Mill Circle data block [2 - 22](#)
- Finish Diameter field, Mill Contour block [2 - 45](#)
- Finish Diameter field, Mill Frame data block [2 - 26](#)
- Finish Feed (%) [1 - 78](#)
- Finish SFQ field [1 - 87](#)
- FINISH SFQ field, Swept Surface [2 - 42](#)
- Finish Speed (%) [1 - 78](#)
- Finish Step Size field, 3D Mold Paratmeters [4 - 5](#)
- Finish Tool field, 3D Mold Paratmeters [4 - 1](#)
- Finish Tool field, Ellipse data block [2 - 23](#)
- Finish Tool field, Mill Circle data block [2 - 21](#)
- Finish Tool field, Mill Contour block [2 - 43](#)
- Finish Tool field, Mill Frame data block [2 - 24](#)
- Finish Tool for a Mill Frame, Mill Circle or Mill Contour [2 - 27](#)

Finish Tool Type field, 3D Mold Parameters
4 - 6

Finish Type field, Ellipse data block 2 - 24

Finish Type field, Face Milling 2 - 21

Finish Type field, Mill Circle data block 2 -
22

Finish Type field, Mill Contour block 2 - 45

Finish Type field, Mill Frame data block 2 -
26

Finish XY field, Milling Parameters 1 - 79

Finish Z field, Milling Parameters 1 - 79

First Peck Offset field, General Parameters
1 - 77

Fit 4 - 21

View 4 - 21

FIT TO VIEW F3 softkey, graphics screen
1 - 95

Flat End Mill 4 - 10

Flat End Mill on a Contour 4 - 10

Flutes field 1 - 61

Flutes field, Advanced Tool Settings 1 - 64

Follow

Name 2 - 75

FONT

True-Type Lettering 2 - 37

formula, speed and feed for tap 3 - 82

Frame Data Block 2 - 24

FTP Client 4 - 156

FTP Host 1 - 30

Properties 1 - 31

FTP Manager 1 - 30, 4 - 156

FTP MANAGER F7 softkey

Disk Operations 1 - 29, 1 - 30

FTP Server 4 - 156

FTP Server Port field 4 - 157

FTP Server Port field, FTP Server Settings
1 - 44

FTP Server Settings 4 - 157

FTP SERVER SETTINGS F2 softkey, Utilities
screen 1 - 44

Function 4 - 20

G

G code 3 - 2

alarm O10 3 - 25

cancel canned cycle 3 - 25

functions 3 - 26, 3 - 29

groups 3 - 26, 3 - 29

modal 3 - 26

same block 3 - 25

same group 3 - 25

table 3 - 26

G Code Group 3 - 22

G Codes 3 - 25

3 - 22, 4 - 118

G00 Rapid Traverse 3 - 32

G01 Linear Interpolation 3 - 33

G02 CW circular and helical interpolation
3 - 34

G02.4 and G03.4 3D circular interpolation
3 - 38

G03 CCW circular and helical interpolation
3 - 34

G04 dwell mode 3 - 39

G05.1 surface finish 3 - 40

G05.2 data smoothing 3 - 40

G05.3, Surface Finish Quality 3 - 40

G09 precision cornering 3 - 40

G10 setting tool offsets 3 - 41

with L3 3 - 42

with P, R 3 - 41

with T, H, D 3 - 41

G10 setting work coordinate systems with
L2 3 - 41

G16 polar coordinates 3 - 42

G17 XY plane selection 3 - 43

G18 XZ plane selection 3 - 44

G19 YZ plane selection 3 - 46

G20 ISNC inch 3 - 47

G21 ISNC metric 3 - 47

G28 automatic return to reference point 3 -
48

G29 automatic return from reference point
3 - 48

G31 skip (probing) function 3 - 49

G40 cutter compensation off 3 - 54

G41 cutter compensation left 3 - 54

G42 cutter compensation right 3 - 55

G43 positive tool length compensation 3 -
57

G44 negative tool length compensation 3 -
57

G45 tool radius offset increase 3 - 59

G46 tool radius offset decrease 3 - 59

G47 tool radius offset double increase 3 -
59

G48 tool radius offset double decrease 3 -
59

G49 cancels tool length offset 3 - 57

G5.3P 1 - 67

G50 scaling, cancel 3 - 62

G50.1 mirroring cancel 3 - 64

G51 scaling 3 - 62

G51.1 mirroring 3 - 64

G52 local coordinate system setting 3 - 66

G53 machine coordinates 3 - 68

G54.1, Aux Work Coordinate Systems 3 -
70

G54-59 multiple work coordinate systems

- [3 - 69](#)
 - [G61 precision cornering on 3 - 71](#)
 - [G64 precision cornering off 3 - 71](#)
 - [G65 Subprogram Call 4 - 113](#)
 - [G68 rotation 3 - 72](#)
 - [G69 rotation cancel 3 - 72](#)
 - [G70 BNC units of measure, inch 3 - 74](#)
 - [G70, Unit of Measure, Inch 3 - 74](#)
 - [G71 BNC units of measure, metric 3 - 74](#)
 - [G71, Units of Measure, MM 3 - 74](#)
 - [G73 peck drilling 3 - 75](#)
 - [G74 BNC single-quadrant circular interpolation 3 - 76](#)
 - [G74 ISNC left-handed tapping, 3 - 75](#)
 - [G75 BNC multi-quadrant circular interpolation 3 - 76](#)
 - [G76, bore orient 3 - 77](#)
 - [G80, cancel canned cycle 3 - 78](#)
 - [G81 drill, spot boring 3 - 78](#)
 - [G82 drill with dwell, counter boring 3 - 79](#)
 - [G83 drill, deep hole 3 - 80](#)
 - [G84 tapping 3 - 82](#)
 - [G84.2 ISNC rigid tapping, right-handed 3 - 87](#)
 - [G84.3 ISNC rigid tapping, left-handed 3 - 87](#)
 - [G85 boring 3 - 84](#)
 - [G86 ISNC bore rapid out 3 - 85](#)
 - [G87 BNC chip breaker 3 - 86](#)
 - [G87 ISNC back boring 3 - 86](#)
 - [G88 BNC rigid tapping 3 - 87](#)
 - [G88 ISNC bore
 - \[manual feed out and dwell 3 - 88\]\(#\)](#)
 - [G89 bore with dwell 3 - 89](#)
 - [G90 absolute machining mode 3 - 90](#)
 - [G91 incremental machining mode 3 - 90](#)
 - [G92 part zero setting 3 - 91](#)
 - [G93 inverse time feedrate 3 - 93](#)
 - [G94 feed per minute feedrate 3 - 93](#)
 - [G98 return to initial point in canned cycles 3 - 94](#)
 - [G99 return to R level in cycles 3 - 96](#)
 - [G-code, NC/Conversational Merge 2 - 81](#)
 - [General Parameters 1 1 - 76](#)
 - [General Parameters 2 1 - 77](#)
 - [Geometry, Advanced Tool Settings 1 - 63](#)
 - [Global variables, NC 3 - 19](#)
 - [Global Variances 4 - 127](#)
 - [GOTO Statements 4 - 139](#)
 - [Graphics 1 - 93
 - \[4 - 21\]\(#\)](#)
 - [GRAPHICS CHORD ERROR field, Graphics Settings 1 - 93](#)
 - [Graphics On/Off 2 - 75](#)
 - [Graphics screen, location on console 1 - 3](#)
 - [Graphics Settings 1 - 93](#)
 - [GRAPHICS SETTINGS F8 1 - 93](#)
 - [GRAPHICS SETTINGS F8 softkey, graphics screen 1 - 95](#)
 - [Graphics Settings, for Stock Geometry 1 - 56](#)
 - [Gun Drill 2 - 53, 2 - 57](#)
- ## H
- [H00 3 - 58](#)
 - [hardware options 1 - 2](#)
 - [HD3 Lettering 2 - 35](#)
 - [HD3 SAVE PROGRAM TYPE, Conversational Settings 1 - 35](#)
 - [Helical 4 - 155](#)
 - [helical and circular interpolation, CW G02, CCW G03 3 - 34](#)
 - [Helical Plunge \(Inside/Outside\) for Mill Frames, Mill Circles and Ellipses 4 - 150](#)
 - [Helical Plunge Milling Parameter Fields 4 - 149](#)
 - [Helical Plunge Option 4 - 149](#)
 - [Helical Plunge with UltiPocket 4 - 151](#)
 - [Helical Plunging of Mill Frame Inside with Pecking and Straight Plunge Finish Pass and Blend Offset Example 4 - 155](#)
 - [Helix 2 - 9
 - \[4 - 155\]\(#\)](#)
 - [Helix Data Block 2 - 48](#)
 - [Help
 - \[On-screen Help 1 - 23\]\(#\)](#)
 - [Help key 1 - 6](#)
 - [Hexagon 4 - 24](#)
 - [Hexagon Data Block 2 - 33](#)
 - [Hole or Circle Pocket Cycle 4 - 73](#)
 - [Hole or Circle Pocket Skew Cycle 4 - 81](#)
 - [Holes 4 - 20](#)
 - [Holes Data Block 2 - 52](#)
 - [Holes End Block 2 - 65](#)
 - [Holes Operation
 - \[4 - 20\]\(#\)](#)
 - [Holes Operation softkeys 4 - 20](#)
 - [Holes Parameters 1 - 81](#)
 - [Holes softkey, Part Programming 2 - 2](#)
 - [Home console key 3 - 4](#)
 - [Home key 1 - 6](#)
- ## I
- [I code, X axis incremental distance for canned cycle 3 - 99](#)
 - [icons - xiii](#)
 - [If 3 - 21, 3 - 22](#)
 - [IF Statements 4 - 139](#)

- Import [1 - 26](#)
- Import and Export [1 - 39](#)
- IMPORT AND EXPORT F7 softkey, Tool Utilities and Settings [1 - 37](#)
- Import Functions [1 - 52](#)
 - Input screen [1 - 51](#)
- IMPORT MANUAL TOOLS F3, Import and Export [1 - 39](#)
- INCR Retract, probe part setup [4 - 37](#)
- INCR Retract, touch probe tool setup [4 - 35](#)
- incremental
 - distance, X axis (canned cycle) [3 - 99](#)
 - distance, Y axis (canned cycle) [3 - 99](#)
 - machining mode, G91 [3 - 90](#)
 - peck depth, Q code (canned cycle) [3 - 99](#)
- Index Pulses field, Position data block [2 - 75](#)
- indexer port [1 - 13](#)
- indexer, pulse one increment, M20 [3 - 110](#)
- Indirect Variables [4 - 109](#)
- INDIVIDUAL PROFILES field, Swept Surface [2 - 39](#)
- INIT Retract, probe part setup [4 - 37](#)
- INIT Retract, touch probe tool setup [4 - 35](#)
- Input
 - key [1 - 5](#)
- Input Mode [1 - 51](#)
- Insert [4 - 20](#), [4 - 24](#)
- Insert Arc field, Milling Parameters [1 - 80](#)
- Insert Block [2 - 80](#)
- Insert Block / Sub Block Before softkey [1 - 89](#)
- Insert Block Before softkey, Basic Programming Menu, NC [3 - 10](#)
- Insert key [1 - 6](#)
- Insert Line field, Milling Parameters [1 - 80](#)
- Insert Location Before softkey [2 - 64](#)
- Insert Operation Before softkey [2 - 52](#)
- Insert Segment Before softkey [2 - 51](#)
- INSERT TOOL F3 softkey, Tool Library screen [1 - 74](#)
- Insert/Over Indicator field, NC Editor [3 - 7](#)
- Insert/Overstrike Mode Toggle softkey, Search and Edit Menu, NC [3 - 11](#)
- INTEGRATOR SUPPORT SERVICES F4 softkey, Utilities screen [1 - 45](#)
- Integrator Support Services [1 - 47](#)
- interpolation modes
 - linear interpolation [3 - 33](#)
 - rapid traverse [3 - 32](#)
- Interrupt Cycle Z Retract field, General Parameters [1 - 77](#)
- inverse time feedrate, G93 [3 - 93](#)
- ISNC dialect [3 - 1](#)
- ISNC, in NC/Conversationl Merge [2 - 81](#)
- J**
 - [3 - 21](#)
 - J code, Y axis incremental distance for canned cycle [3 - 99](#)
 - jog
 - control buttons [1 - 8](#)
 - parameters [1 - 10](#)
 - Jog unit [1 - 8](#)
 - jog unit [1 - 8](#)
 - Jump & Search Functions softkey, NC Editor [3 - 13](#), [3 - 15](#)
 - Jump & Search Functions softkey, Search and Edit Menu, NC [3 - 11](#)
 - jump drive [1 - 13](#)
 - Jump Page Backward softkey, Basic Programming Menu, NC [3 - 10](#)
 - Jump Page Backward softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump Page Forward softkey, Basic Programming Menu, NC [3 - 10](#)
 - Jump Page Forward softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump to Beginning softkey, Basic Programming Menu, NC [3 - 10](#)
 - Jump to Beginning softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump to Block Number softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump to End softkey, Basic Programming Menu, NC [3 - 10](#)
 - Jump to End softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump to Sequence Number softkey, Jump and Search Functions Menu, NC [3 - 12](#)
 - Jump to Syntax Error softkey, NC Editor [3 - 16](#)
 - Jump to Tag softkey, NC Editor [3 - 14](#), [3 - 15](#)
 - Jump to Tagged Block softkey, Search and Edit Menu, NC [3 - 11](#)
- K**
 - [3 - 21](#)
 - K code, repeat operations for canned cycle [3 - 99](#)
 - Keep Original field, Mirror Image [2 - 73](#)
 - keyboard [1 - 5](#), [1 - 19](#), [1 - 21](#)
 - optional [1 - 7](#)
- L**
 - L code [3 - 103](#)

- repeat operations for canned cycle 3 - 99
 - Language Registration 1 - 45
 - large tools in the ATC magazine 1 - 15
 - Laser Beam Calibration 4 - 41
 - laser input update, M40 3 - 111
 - Layer 4 - 23
 - Layering of Local Variables Within Subprogram Calls 4 - 115
 - Lead Angle 2 - 16, 2 - 17
 - Lead Angle field, Mill Circle data block 2 - 22
 - Lead Angle field, Mill Contour block 2 - 44
 - Lead Angle field, Mill Frame data block 2 - 26
 - Lead field, Helix data block 2 - 48
 - Lead In/Out Moves 2 - 16
 - Lead Length 2 - 17
 - Lead Length field, Mill Circle data block 2 - 22
 - Lead Length field, Mill Contour block 2 - 44
 - Lead Length field, Mill Frame data block 2 - 25
 - Least Dwell Units field, NC Parameters 3 - 17
 - least dwell units, Program Parameters screen 3 - 39
 - Least Scaling Factor field, NC Parameters 3 - 17
 - left-handed tapping cycle 3 - 97
 - left-handed tapping, G74 ISNC 3 - 75
 - Length of Cut field, Advanced Tool Settings 1 - 64
 - Lettering 2 - 35
 - HD3 2 - 36
 - True-Type 2 - 36
 - Lettering Data Block 2 - 35
 - Line 4 - 20
 - Line Segments 2 - 6
 - linear interpolation, G01 3 - 33
 - Linear Positioning field, NC Parameters 3 - 17
 - Lines/Arcs 4 - 20
 - Lines/Arcs Data Blocks 2 - 43
 - LIST CONTROL ROWS, User Interface Settings 1 - 35
 - LIST ICON SIZE, User Interface Settings 1 - 35
 - Load 1 - 26
 - LOAD F6 softkey
 - Disk Operations 1 - 30
 - loading
 - tool in the spindle 1 - 13
 - tools in ATC magazine 1 - 14
 - local coordinate system setting, G52 3 - 66
 - Local variables, NC 3 - 19
 - Location field 1 - 60
 - Locations 2 - 64
 - Holes Locations 2 - 64
 - Log Files 1 - 46, 1 - 47
 - Loop Angular 2 - 69
 - Loop Linear blocks 2 - 67
 - Loop Rectangular block 2 - 66
 - Loop Rotate 2 - 70
 - Lube Cycle 2 - 79
- ## M
- M 3 - 21
 - M code 3 - 104
 - M Codes 4 - 118
 - M00 program stop 3 - 106
 - M01 planned stop, pause program 3 - 106
 - M02 end of program 3 - 107
 - M03 spindle, start clockwise 3 - 107
 - M04 spindle, start counterclockwise 3 - 107
 - M05 spindle off 3 - 107
 - M06 change tool 3 - 108
 - M07 secondary coolant on 3 - 109
 - M08 primary coolant on 3 - 109
 - M09 coolant off, both systems 3 - 109
 - M10 coolant on, both systems 3 - 109
 - M12 C axis clamp 3 - 109
 - M128, Tool Center Point Management 3 - 114
 - M129, Tool Center Point Management 3 - 114
 - M13 C axis unclamp 3 - 109
 - M19 spindle, oriented stop 3 - 109
 - M20 indexer pulse one increment 3 - 110
 - M25 BNC Z axis, home position 3 - 110
 - M26 part probe, select signal 3 - 110
 - M27 tool probe, select signal 3 - 110
 - M29 ISNC rigid tapping enable 3 - 110
 - M30 end program 3 - 110
 - M32 clamp A axis 3 - 111
 - M33 unclamp A axis 3 - 111
 - M34 clamp B axis 3 - 111
 - M35 unclamp B axis 3 - 111
 - M36 servo off 3 - 111
 - M40 laser input update 3 - 111
 - M41 single-touch probing 3 - 111
 - M42 double-touch probing 3 - 112
 - M43, probe, increase barrier airflow 3 - 112
 - M44, probe, reduce barrier airflow 3 - 112
 - M45 probe, open shutter control 3 - 112
 - M46 probe, close shutter control 3 - 112
 - M47 probe laser emitter on 3 - 112

- M48 probe laser emitter off [3 - 112](#)
- M49 probe laser receiver on [3 - 112](#)
- M50 probe laser receiver off [3 - 112](#)
- M52 through M55, enable auxiliary output [3 - 112](#)
- M56 rotate pallet changer, nonconfirmation [3 - 112](#)
- M57 rotate pallet changer to pallet 1 [3 - 112](#)
- M58 rotate pallet changer to pallet 2 [3 - 112](#)
- M59 Chip Conveyor Forward [3 - 113](#)
- M6 for tool change [3 - 108](#)
- M6 Initiates Tool Change field, NC Parameters [3 - 17](#)
- M60 Chip Conveyor Reverse [3 - 113](#)
- M61 Chip Conveyor Stop [3 - 113](#)
- M62 through M65, disable auxiliary output [3 - 113](#)
- M68 washdown coolant system enable [3 - 113](#)
- M69 washdown coolant system disable [3 - 113](#)
- M80 right handed C axis [3 - 113](#)
- M81 left handed C axis [3 - 113](#)
- M98 subprogram call [3 - 113](#)
- M99 subprogram, jump (return from) [3 - 114](#)
- machine
 - components [1 - 1](#)
 - control [1 - 7](#)
 - control buttons [1 - 10](#)
 - major components [1 - 1](#)
- Machine and Console Basics [1 - 1](#)
- Machine and Part Axes field, Auto Mode [1 - 90](#)
- Machine Components [1 - 1](#)
- machine coordinates, G53 [3 - 68](#)
- Machine Function [2 - 79](#)
- Machine Operation Keys, location on console [1 - 4](#)
- Machine operations, location on console [1 - 3](#)
- Machine Parameters [1 - 40](#)
 - Alt Dwell Left Side [1 - 40](#)
 - Alt Washdown Dwell [1 - 40](#)
 - Alt Washdown Off Time [1 - 40](#)
 - ATC Disable [1 - 41](#)
 - Auto Balance Enable [1 - 41](#)
 - Aux Output 1 Confirmation Enable [1 - 42](#)
 - Aux Output 2 Confirmation Enable [1 - 42](#)
 - Aux Output 3 Confirmation Enable [1 - 42](#)
 - Aux Output 4 Confirmation Enable [1 - 42](#)
 - CAL to LS Velocity A [1 - 41](#)
 - CAL to LS Velocity B [1 - 41](#)
 - CAL to LS Velocity C [1 - 41](#)
 - CAL to LS Velocity X [1 - 41](#)
 - CAL to LS Velocity Y [1 - 41](#)
 - CAL to LS Velocity Z [1 - 41](#)
 - Chip Conveyor Off Delay Time [1 - 42](#)
 - Chip Conveyor On Delay Time [1 - 42](#)
 - Chip Conveyor On/Off Delay Enable [1 - 42](#)
 - Control Power Off Time [1 - 40](#)
 - Coolant Delay Time [1 - 40](#)
 - Disable Aux Out 1 During Interrupt [1 - 42](#)
 - Disable Aux Out 2 During Interrupt [1 - 42](#)
 - Disable Aux Out 3 During Interrupt [1 - 42](#)
 - Disable Aux Out 4 During Interrupt [1 - 42](#)
 - Disable Tool Picker Option [1 - 40](#)
 - Move to Safety Pos Manual Mode ATC [1 - 42](#)
 - Pulsating or Delay Washdown Enable [1 - 40](#)
 - Rapid Override Disable [1 - 41](#)
 - Tilt Axis Safety Position [1 - 41](#)
 - Warm-Up Axis Feed Rate [1 - 43](#)
 - Warm-Up Cycle Time Per Pass [1 - 43](#)
 - Warm-Up Max Spindle Speed [1 - 43](#)
 - Warm-Up Speed Steps [1 - 43](#)
 - Warm-Up Starting Speed [1 - 43](#)
 - Washdown Off Delay Timer [1 - 40](#)
 - Washdown On Delay Timer [1 - 40](#)
 - X-Axis Safety Position [1 - 41](#)
 - Y-Axis Safety Position [1 - 41](#)
- Macro Instruction (G65) [4 - 118](#)
- Macro Mode
 - [3 - 21, 3 - 22](#)
 - Subprogram Variables [3 - 21](#)
- Macro Mode A Arguments [4 - 129](#)
- Macro Mode A G Code Group Status [3 - 22](#)
- Macro Mode A Local Variables [4 - 127](#)
- Macro Mode A Subprogram Variables [3 - 21](#)
- Macro Mode B field, NC M and G Code Program Numbers [3 - 18](#)
- Macro Modes [4 - 91](#)
- MANUAL BORDER SIZING field [1 - 57](#)
- Manual Function Setup softkey, Manual Mode [1 - 92](#)
- manual jog
 - feed keys [1 - 9](#)
 - feed parameter [1 - 10](#)

- hand wheel [1 - 9](#)
- hand wheel multiplier keys [1 - 9](#)
- Manual Mode [1 - 92](#)
 - Tool Library [1 - 73](#)
- Manual Mode Part Setup Probing Cycles [4 - 50](#)
- Manual Mode Part Skew Probing Cycles [4 - 52](#)
- Manual Spindle Speed parameter [1 - 10](#)
- MANUAL STOCK SIZING field [1 - 56](#)
- Manual, Tool Library [1 - 73](#)
- MATCH TOOLS F4 softkey, Unmatched
 - Tools Review [1 - 70](#)
- Match Tools softkey
 - Tool Review screen [1 - 70](#)
- Matching tools [1 - 71](#)
- Material Database [1 - 74](#)
- MATERIAL field, in Program Properties [1 - 28](#)
- MATH ASSIST STYLE, Conversational Settings [1 - 35](#)
- Max console
 - console keys [1 - 4](#)
 - panel group figure [1 - 4](#)
- Max console panel groups [1 - 4](#)
- Max Deflection, probe part setup [4 - 37](#)
- Max Deflection, probe tool setup [4 - 35](#)
- MAX DEPTH field, Advanced Tool Settings [1 - 65](#)
- MAX MEMORY LOAD [1 - 35](#)
- Maximum Idle Time (Mins) field [4 - 157](#)
- Maximum Idle Time (Mins) field, FTP Server Settings [1 - 44](#)
- Maximum Offset [2 - 15](#)
- Maximum Offset field, Mill Contour block [2 - 44](#)
- M-Code field, NC M and G Code Program Numbers [3 - 18](#)
- Mill Circle [4 - 16](#)
- Mill Contour [2 - 43](#)
- Mill Contours [4 - 16](#)
- Mill Diamond Data Block [2 - 30](#)
- Mill Face [2 - 19](#)
- Mill Feed field, 3D Mold Parameters [4 - 6](#)
- Mill Feed field, Diamond data block [2 - 32](#)
- Mill Feed field, Ellipse data block [2 - 23](#)
- Mill Feed field, Face Milling [2 - 21](#)
- Mill Feed field, HD3 Lettering [2 - 36](#)
- Mill Feed field, Hexagon data block [2 - 34](#)
- Mill Feed field, Mill Circle data block [2 - 22](#)
- Mill Feed field, Mill Contour block [2 - 44](#)
- Mill Feed field, Mill Frame data block [2 - 26](#)
- Mill Feed field, Mill triangle data block [2 - 29](#)
- MILL FEED field, Swept Surface [2 - 40](#)
- Mill Feed field, True-Type Lettering [2 - 37](#)
- Mill Frame [4 - 16](#)
- Mill Frame data block [2 - 24](#)
- Mill Hexagon Data Block [2 - 33](#)
- Mill Triangle Data Block [2 - 28](#)
- Mill True-Type Lettering [2 - 36](#)
- Milling
 - [4 - 20](#)
 - 3-D arc
 - calculate centerline [2 - 50](#)
 - fields [2 - 49](#)
 - guidelines [2 - 50](#)
 - Milling data blocks [2 - 18](#)
 - Milling Direction field, Milling Parameters [1 - 79](#)
 - Milling Parameters 1 [1 - 78](#)
 - Milling Parameters 2 [1 - 81](#)
 - Milling softkey [2 - 19](#)
 - Milling softkey, Part Programming [2 - 2](#)
 - Milling Type [2 - 16](#)
 - Milling Type field [2 - 10](#)
 - Milling Type field, Diamond data block [2 - 32](#)
 - Milling Type field, Ellipse data block [2 - 23](#)
 - Milling Type field, Face Milling [2 - 20](#)
 - Milling Type field, Hexagon data block [2 - 34](#)
 - Milling Type field, Mill Circle data block [2 - 21](#)
 - Milling Type field, Mill Contour block [2 - 43](#)
 - Milling Type field, Mill Frame data block [2 - 24](#)
 - Milling Type field, Mill triangle data block [2 - 29](#)
 - MILLING TYPE field, Swept Surface [2 - 42](#)
 - MIN CUSP OVERLAP (%) field, Swept Surface [2 - 39](#)
 - Min Z field, 3D Mold Parameters [4 - 5](#)
 - MIN Z field, Swept Surface [2 - 41](#)
 - Mirror Image [2 - 72](#)
 - mirroring
 - cancel G50.1 [3 - 64](#)
 - G51.1 [3 - 64](#)
 - miscellaneous functions, M codes [3 - 104](#)
 - Miscellaneous softkey, Part Programming [2 - 2](#)
 - Modal Subprograms [4 - 86](#)
 - Modify Dimensions [1 - 86](#)
 - Modify Dimensions softkey [1 - 85](#)
 - Monitor Motion, probe part setup [4 - 37](#)
 - Monitor Motion, touch probe tool setup [4 - 35](#)
 - Motion Hold button [1 - 10](#)
 - motion, axis [3 - 9](#)
 - Move Blocks softkey [1 - 85](#)

- move commands, scaling [3 - 62](#)
 - move program blocks [1 - 86](#)
 - Move Range of Blocks softkey, NC Editor [3 - 14](#)
 - Move to Safe Pos During TC field, General Parameters [1 - 77](#)
 - Move to Safety Pos Manual Mode ATC [1 - 42](#)
 - MOVE TOOL TO SPINDLE F1 softkey, Tool Library screen [1 - 73](#)
 - Move Zero softkey [4 - 20](#)
 - moving
 - the cursor [3 - 4](#)
 - MULTIPLE BLOCK FUNCTIONS F2 softkey, Program Review screen [1 - 88](#)
 - Multiple parts [2 - 78](#)
 - multiple parts [3 - 70](#)
- ## N
- [N 3 - 21](#)
 - N word [3 - 2](#)
 - NAME field, in Program Properties [1 - 28](#)
 - navigation [3 - 4](#)
 - NC
 - [3 - 21](#)
 - NC Configuration screen [3 - 56](#)
 - NC DIALECT, NC Settings [1 - 36](#)
 - NC DISPLAY TYPE, NC Settings [1 - 36](#)
 - NC Editing Region field, NC Editor [3 - 7](#)
 - NC Editor [3 - 6](#)
 - Basic Programming Menu [3 - 10](#)
 - Jump and Search Functions Menu [3 - 12](#)
 - Menus [3 - 10](#)
 - Program Execution and Verification Menu [3 - 16](#)
 - Search and Edit Menu [3 - 11](#)
 - Wireframe Graphics Markers and Syntax Errors Menu [3 - 16](#)
 - NC MONITOR F6 softkey, NC/Conversational Merge [1 - 90](#)
 - NC Monitor softkey, Auto Mode [1 - 92](#)
 - NC Optional Program Stop field, NC Parameters [3 - 17](#)
 - NC Parameters [3 - 17](#)
 - NC part program
 - address characters [3 - 2](#)
 - Block [3 - 4](#)
 - sequence number [3 - 2](#)
 - special characters [3 - 3](#)
 - start [3 - 2](#)
 - starting new [3 - 9](#)
 - Words [3 - 3](#)
 - NC Part Programming [3 - 1](#)
 - Principles [3 - 1](#)
 - NC Part Programming Example [4 - 142](#)
 - NC Program Call softkey, Part Programming [2 - 2](#)
 - NC PROGRAM F2 softkey, Program Manager [1 - 26](#)
 - NC Programming Rules [3 - 9](#)
 - NC SETTINGS softkey, Utilities screen [1 - 36](#)
 - NC SFQ, Advanced Tool Settings [1 - 67](#)
 - NC States [1 - 83](#)
 - NC Variables [3 - 19](#)
 - NC/Conversational Merge [2 - 81](#)
 - NCPP Example - Bolt Hole Circle [4 - 144](#)
 - NCPP Example - Gear Pattern [4 - 144](#)
 - NCPP Option [4 - 84](#)
 - NCPP Variable Summary [4 - 106](#)
 - Neck Diameter field, Advanced Tool Settings [1 - 64](#)
 - network [1 - 11](#)
 - network ports [1 - 13](#)
 - New [4 - 19](#), [4 - 21](#)
 - New Block menu [4 - 24](#)
 - NEW F1 softkey, Program Manager [1 - 25](#)
 - New Feed field [1 - 85](#), [1 - 87](#)
 - New Finish Tool field [1 - 85](#), [1 - 87](#)
 - new NC program [3 - 9](#)
 - New Plunge Feed field [1 - 85](#), [1 - 87](#)
 - New Speed (RPM) field [1 - 85](#), [1 - 87](#)
 - New Tool field [1 - 85](#), [1 - 87](#)
 - Next Hole Operation softkey [2 - 52](#)
 - NEXT TOOL CHANGE F4 softkey, graphics screen [1 - 95](#)
 - NEXT TOOL field, Tool Library screen [1 - 73](#)
 - Notes, Advanced Tool Settings [1 - 68](#)
 - Number field, Loop Angular data block [2 - 69](#)
 - Number field, Loop Linear data block [2 - 68](#)
 - Number field, Loop Rotate data block [2 - 70](#)
 - Number of Holes field, Bolt Circle data block [2 - 64](#)
 - numeric keypad [1 - 6](#)
- ## O
- off
 - servo M36 [3 - 111](#)
 - spindle, M05 [3 - 107](#)
 - Offset
 - maximum [2 - 15](#)
 - Offset Z field [1 - 53](#)
 - Offset Z field, Change Part Setup [2 - 78](#)
 - On-screen Help [1 - 23](#)
 - OPEN [1 - 26](#)

- Operation field, Back Spotface 2 - 62
 - Operation field, Bolt Circle data block 2 - 64
 - Operation field, Bore and Ream Operations 2 - 54
 - Operation field, Boring and Reaming Operations 2 - 61
 - Operation field, Gun Drill data block 2 - 59
 - Operation field, Tap Operations 2 - 60
 - Operation Priorities 4 - 139
 - Opt Stop On (Off) field, Auto Mode 1 - 90
 - optional keyboard 1 - 7
 - Optional Stop On/Off softkey, Auto Mode 1 - 91
 - options
 - hardware and software 1 - 2
 - OPTNUM/AUTONUM field, NC Editor 3 - 7
 - Order 4 - 20
 - Orient Spindle softkey, Manual Mode 1 - 92
 - ORIENTATION
 - True-Type Lettering 2 - 37
 - Orientation field, Diamond data block 2 - 31
 - Orientation field, Hexagon data block 2 - 34
 - Orientation field, Mill triangle data block 2 - 28
 - ORIENTATION field, True-Type Letting 2 - 37
 - orientation hole 1 - 13
 - orientation key 1 - 13
 - override
 - knobs 1 - 7
 - Override Lockout 2 - 75
 - Override Lockout field, General Parameters 1 - 76
- P**
- P 3 - 21
 - P code, dwell at bottom of hole for canned cycle 3 - 99
 - Page Down key 1 - 6
 - Page Up key 1 - 6
 - pallet rotation
 - M56 nonconfirmation 3 - 112
 - to pallet 1, M57 3 - 112
 - to pallet 2, M58 3 - 112
 - PAN F4 softkey, graphics screen 1 - 95
 - Parameter Change 2 - 5
 - Parameters 2 - 75, 3 - 21, 4 - 20
 - retract clearance 2 - 75
 - parameters
 - jog unit 1 - 10
 - manual jog feed 1 - 10
 - manual spindle speed 1 - 10
 - Parity field, Serial Port Settings 1 - 44
 - Park Machine 1 - 18
 - Park Machine softkey, Manual Mode 1 - 92
 - Part 1 - 51, 4 - 19, 4 - 21
 - Part Count field, Auto Mode 1 - 91
 - Part Fixturing and Tool Loading 1 - 55
 - Part Inspection Cycles 4 - 64
 - Part Inspection files 1 - 46
 - Part Probe Calibration 4 - 43
 - Part Probe Deflection 4 - 33
 - part probe, select signal, M26 3 - 110
 - Part Probing Parameters 4 - 37
 - Part Program 4 - 19
 - part program
 - address characters 3 - 2
 - axis motion 3 - 9
 - components 3 - 1
 - deleting 3 - 5
 - editor 3 - 6
 - feedrates 3 - 9
 - sequence number 3 - 2
 - Part Program Printing 1 - 46
 - Part Program Tool Review
 - Review, Tools in Part Program 1 - 70
 - Part Program Tool Review softkey 1 - 59, 1 - 89
 - Part Programming 2 - 1
 - Input screen 1 - 51
 - Part Programming softkey 1 - 58, 1 - 89, 2 - 1, 4 - 19
 - Tool Review screen 1 - 70
 - Part Setup 1 - 52
 - Input screen 1 - 51
 - Part Setup Fields 1 - 53
 - Part Setup softkey 1 - 58, 1 - 89
 - Tool Review screen 1 - 70
 - Part Setup Softkeys 1 - 54
 - Calculate Rotary Offsets 1 - 55
 - Orient Spindle 1 - 55
 - Part Probing 1 - 54
 - Part Programming 1 - 54
 - Program Parameters 1 - 54
 - Stock Geometry 1 - 55
 - Store Machine Position 1 - 54
 - Toggle Units 1 - 55
 - Tool Setup 1 - 54
 - Work Offsets 1 - 54
 - Part Skew Probing Cycles 4 - 69
 - PART SURFACE field, Graphics Settings 1 - 93
 - Part Zero A / B field 1 - 53
 - Part Zero Storage Cycle 4 - 50
 - Part Zero X / Y fields 1 - 53
 - Part Zero X field, Change Part Setup 2 - 78

- Part Zero Y field, Change Part Setup [2 - 78](#)
- part zero, setting, G92 [3 - 91](#)
- Passing Argument Lists to Subprograms in Macro Mode B [4 - 114](#)
- Passing Single Dedicated Parameters to Subprograms [4 - 124](#)
- Password field [4 - 157](#)
- Password field, FTP Server Settings [1 - 44](#)
- PASTE F3 softkey
 - Disk Operations [1 - 30](#)
- PASTE F3 softkey, Program Review screen [1 - 88](#)
- PASTE INTO DIRECTORY F3 softkey
 - Disk Operations [1 - 29](#)
- Path field [4 - 157](#)
- Path field, FTP Server Settings [1 - 44](#)
- PATH field, in Program Properties [1 - 28](#)
- Pattern [4 - 16](#)
- Pattern End [2 - 73](#)
- Pattern Locations [2 - 71](#)
- Pattern Scale [2 - 71](#)
- Patterns Operations [2 - 66](#)
- Patterns softkey, Part Programming [2 - 2](#)
- pause program, M01 [3 - 106](#)
- Peck Clearance Plane field, General Parameters [1 - 76](#)
- Peck Depth field, 3D Mold Paratmeters [4 - 5](#)
- PECK DEPTH field, Advanced Tool Settings [1 - 65](#)
- Peck Depth field, Bore and Ream Operations [2 - 55](#)
- Peck Depth field, Diamond data block [2 - 32](#)
- Peck Depth field, Ellipse data block [2 - 23](#)
- Peck Depth field, Face Milling [2 - 20](#)
- Peck Depth field, Gun Drill data block [2 - 59](#)
- Peck Depth field, HD3 Lettering [2 - 36](#)
- Peck Depth field, Hexagon data block [2 - 35](#)
- Peck Depth field, Mill Circle data block [2 - 22](#)
- Peck Depth field, Mill Contour block [2 - 44](#)
- Peck Depth field, Mill Frame data block [2 - 26](#)
- Peck Depth field, Mill triangle data block [2 - 29](#)
- PECK DEPTH field, Swept Surface [2 - 42](#)
- Peck Depth field, Tap Operations [2 - 60](#)
- Peck Depth field, True-Type Letting [2 - 37](#)
- peck drilling cycle [3 - 97](#)
- Peck Type field, Bore and Ream Operations [2 - 55](#)
- Peck Type field, Gun Drill data block [2 - 59](#)
- percent character [3 - 2](#)
- Performance Parameters [1 - 82](#)
- Pitch field, Tap Operations [2 - 60](#)
- Plane Intersection (Non-Rectangular Corner) Cycle [4 - 80](#)
- plane of interpolation, specify [3 - 35](#)
- plane selection
 - G17 XY [3 - 43](#)
 - G18 XZ [3 - 44](#)
 - G19 YZ [3 - 46](#)
- Plunge [4 - 155](#)
- Plunge Feed field, 3D Mold Paratmeters [4 - 6](#)
- PLUNGE FEED field, Advanced Tool Settings [1 - 65](#)
- Plunge Feed field, Bore and Ream Operations [2 - 55](#)
- Plunge Feed field, Boring and Reaming Operations [2 - 62](#)
- Plunge Feed field, Diamond data block [2 - 32](#)
- Plunge Feed field, Ellipse data block [2 - 23](#)
- Plunge Feed field, Face Milling [2 - 20](#)
- Plunge Feed field, Gun Drill data block [2 - 59](#)
- Plunge Feed field, HD3 Lettering [2 - 36](#)
- Plunge Feed field, Hexagon data block [2 - 35](#)
- Plunge Feed field, Mill Circle data block [2 - 22](#)
- Plunge Feed field, Mill Contour block [2 - 44](#)
- Plunge Feed field, Mill Frame data block [2 - 26](#)
- Plunge Feed field, Mill triangle data block [2 - 29](#)
- PLUNGE FEED field, Swept Surface [2 - 42](#)
- Plunge Feed field, Tap Operations [2 - 60](#)
- Plunge Feed field, True-Type Letting [2 - 37](#)
- Plunge Speed field, Back Spotface [2 - 63](#)
- PLUNGES field, Graphics Settings [1 - 93](#)
- Pocket Boundary [4 - 14](#)
- POCKET FINISH SFQ field, Swept Surface [2 - 42](#)
- POCKET FIRST field, Swept Surface [2 - 39](#)
- POCKET OVERLAP (%) field, Swept Surface [2 - 42](#)
- Pocket Overlap field, Ellipse data block [2 - 24](#)
- Pocket Overlap field, Mill Circle data block [2 - 22](#)
- Pocket Overlap field, Mill Contour block [2 - 44](#)
- Pocket Overlap field, Mill Frame data block [2 - 26](#)
- Pocket Overlap field, True-Type Letting [2 -](#)

- 37
 - POCKET ROUGH SFQ field, Swept Surface
 - 2 - 42
 - Pocket Type field, Ellipse data block 2 - 23
 - Pocket Type field, Mill Circle data block 2 - 21
 - Pocket Type field, Mill Contour block 2 - 43
 - Pocket Type field, Mill Frame data block 2 - 24
 - POCKET TYPE field, Swept Surface 2 - 42
 - Point
 - 4 - 21
 - polar coordinates, G16 3 - 42
 - pop-ups 1 - 21
 - port
 - serial
 - pin descriptions 1 - 12
 - USB 1 - 13
 - Position
 - 2 - 75, 4 - 20, 4 - 21
 - Position block 2 - 76
 - Position data block 2 - 74
 - 4 - 20
 - Position softkey, Part Programming 2 - 2
 - Power Drawbar 1 - 1
 - Power On Button, location on console 1 - 4
 - Power on button, location on console 1 - 3
 - Power On console button 1 - 10
 - precision cornering
 - off G64 3 - 71
 - on G61 3 - 71
 - precision cornering, G09 3 - 40
 - Press
 - 4 - 19
 - Previous 4 - 21
 - Previous Segment softkey 2 - 51
 - principles for programming 3 - 1
 - Printing
 - Part Program 1 - 46
 - Probing Data 1 - 46
 - Printing Help 1 - 24
 - Printing Setup 1 - 46
 - PRINTING SETUP F3 softkey, in Utilities screen 1 - 45
 - probe
 - close shutter control, M46 3 - 112
 - double-touch M42 3 - 112
 - increase barrier airflow, M43 3 - 112
 - laser emitter off, M48 3 - 112
 - laser emitter on, M47 3 - 112
 - laser input update M40 3 - 111
 - laser receiver off, M50 3 - 112
 - laser receiver on, M49 3 - 112
 - open shutter control, M45 3 - 112
 - reduce barrier airflow, M44 3 - 112
 - single-touch M41 3 - 111
 - skip function G31 3 - 49
 - Probe a Single Tool 4 - 66
 - Probe Deflection Offset Calibration 4 - 43, 4 - 45
 - Probe Multiple Tools 4 - 67
 - Probe Part Setup 4 - 48
 - Probing Cycles 4 - 68
 - Probing Data Printing 1 - 46
 - Probing Equipment 4 - 33
 - Probing Parameters 1 - 82
 - Probing Part Setup, NC 3 - 23
 - Profile Contour 2 - 38
 - Profile Left 2 - 13
 - Profile Right 2 - 13
 - program
 - functions, M00, M01, M02, and M30 3 - 106
 - Program Control Statements 4 - 112
 - Program Definition 4 - 26
 - Program Manager 1 - 25
 - Input screen 1 - 51
 - Program Parameters 1 - 75
 - Input screen 1 - 51
 - Program Parameters softkey 1 - 59, 1 - 89
 - Tool Review screen 1 - 70
 - Program Properties 1 - 28
 - Program Protect 2 - 75
 - Program Review screen 1 - 88
 - Program Run Time field, Auto Mode 1 - 90
 - PROGRAM TYPE, in Program Properties 1 - 28
 - Program# 2 - 75, 4 - 19, 4 - 24
 - Programming Islands 4 - 15
 - Programming Keyboard, location on console 1 - 4
 - Programming keyboard, location on console 1 - 3
 - programming mode keys 1 - 5
 - Protocol field, Serial Port Settings 1 - 44
 - Put Block Before field 1 - 85
- ## Q
- Q 3 - 21
 - Q code, incremental peck depth, canned cycle 3 - 99
 - Quit CAD 4 - 19
- ## R
- R 3 - 21, 3 - 22
 - R code
 - BNC canned cycle 3 - 99
 - ISNC canned cycle 3 - 99

- R level, return in cycles, G99 [3 - 96](#)
- R parameter, angle of rotation [3 - 72](#)
- R(%) field, Auto Mode [1 - 91](#)
- R/W [3 - 22](#)
- Radius field, 3D Mold Arc [4 - 8](#)
- Radius field, 3D Mold Blend Arc [4 - 9](#)
- Radius field, Advanced Tool Settings [1 - 64](#)
- Radius field, Bolt Circle data block [2 - 64](#)
- Radius field, Contour Arc [2 - 46](#)
- Radius field, Contour Blend Arc [2 - 47](#)
- Radius field, Diamond data block [2 - 31](#)
- Radius field, Helix data block [2 - 48](#)
- Radius field, Hexagon data block [2 - 34](#)
- Radius field, Mill Circle data block [2 - 21](#)
- Radius field, Mill triangle data block [2 - 28](#)
- Range Checking field, NC Editor [3 - 8](#)
- Rapid Override dial [1 - 7](#)
- Rapid Traverse field, General Parameters [1 - 76](#)
- rapid traverse, G00 [3 - 32](#)
- RAPIDS field, Graphics Settings [1 - 93](#)
- Read/Write Restrictions [4 - 134](#)
- Ream [2 - 54](#)
- Ream Chamfer field, Advanced Tool Settings [1 - 64](#)
- Reaming Operations [2 - 61](#)
- Recovery and Restart [1 - 17](#)
- Recovery Restart softkey, Auto Mode [1 - 90](#)
- Rectangular Pocket Inside Cycle [4 - 76](#)
- Rectangular Pocket Skew Cycle [4 - 83](#)
- Rectangular Solid Outside Cycle [4 - 78](#)
- reference corner [2 - 18](#)
- Reference Point X/Y/Z field, NC Parameters [3 - 17](#)
- Relief 1 field, Diamond data block [2 - 32](#)
- Relief 1 field, Hexagon data block [2 - 34](#)
- Relief 1 field, Mill triangle data block [2 - 28](#)
- Relief 2 field, Diamond data block [2 - 32](#)
- Relief 2 field, Hexagon data block [2 - 34](#)
- Relief 3 field, Hexagon data block [2 - 34](#)
- remote jog unit [1 - 8](#)
- Remote jog, location on console [1 - 3](#)
- REMOVE TOOL F3 softkey, Tool and Material Database screen [1 - 74](#)
- removing tools from the ATC [1 - 15](#)
- RENAME DIRECTORY F5 softkey
 - Disk Operations [1 - 29](#)
- RENAME F4 softkey
 - Disk Operations [1 - 30](#)
- repeat operations, K code (canned cycles) [3 - 99](#)
- repeat operations, L code (canned cycles) [3 - 99](#)
- replace canned cycle [3 - 101](#)
- replacing, search text [3 - 13](#)
- Reset Control [1 - 17](#)
- Reset Part Count softkey, Auto Mode [1 - 91](#)
- RESET PROBE WORK REGION TO MAXIMUM (F4) softkey, Part Setup screen [4 - 36](#)
- RESET PROGRAM PARAMETERS F3 [1 - 52](#)
- Reset Servos and Spindle softkey, Manual Mode [1 - 92](#)
- Reset Start/End Markers softkey, NC Editor [3 - 16](#)
- Reset Wireframe Markers softkey, NC Editor [3 - 16](#)
- restart [1 - 5](#)
- RESTART CONTROL F5 softkey, Utilities screen [1 - 45](#)
- Restore Config & Machine Files [1 - 34](#)
- RESTORE USER DEFAULTS F5 softkey, Program Parameters [1 - 75](#)
- RESTORE WINMAX DEFAULTS F6 softkey, Program Parameters [1 - 75](#)
- Retain Probed Part Setup field, Probing Parameters [1 - 82](#)
- Retract clearance [2 - 75](#)
- Retract Clearance field, General Parameters [1 - 76](#)
- Retrieve Log and Diagnostic Files [1 - 49](#)
- Return
 - [4 - 19](#), [4 - 20](#), [4 - 21](#)
- return to initial point in cycle, G98 [3 - 94](#)
- Reverse Dwell field, Back Spotface [2 - 63](#)
- Reverse Mirrored field, Mill Contour block [2 - 44](#)
- Review key [1 - 5](#)
- Review Mode [1 - 88](#)
- Rigid Tap softkey [2 - 60](#)
- rigid tapping
 - G84.2 ISNC right-handed [3 - 87](#)
 - G84.3 ISNC left-handed [3 - 87](#)
 - G88 BNC [3 - 87](#)
- rigid tapping enable, M29 ISNC [3 - 110](#)
- ROLL END POINT field, Swept Surface [2 - 39](#)
- ROLL START POINT field, Swept Surface [2 - 39](#)
- Rotary A Axis Circle and Frame [4 - 30](#)
- Rotary A Axis Lines and Arcs [4 - 29](#)
- Rotary A Axis Milling Operations [4 - 29](#)
- Rotary A Axis Part Programming [4 - 27](#)
- Rotary A Axis Pattern Locations [4 - 32](#)
- Rotary A Axis Pattern Loop [4 - 31](#)
- Rotary A Axis Patterns [4 - 31](#)
- Rotary and Rotary Tilt Options [4 - 25](#)
- Rotary Parameters [4 - 28](#)
- Rotary Position Block [4 - 29](#)

- Rotary softkey, Part Programming 2 - 2
 - Rotate Angle field, Loop Angular data block 2 - 69
 - Rotate Angle field, Loop Rotate data block 2 - 71
 - ROTATE F5 softkey, graphics screen 1 - 95
 - rotation
 - angle of 3 - 72
 - cancel, G69 3 - 72
 - G68 3 - 72
 - negative R, CW 3 - 72
 - positive R, CCW 3 - 72
 - Rough SFQ field 1 - 87
 - ROUGH SFQ field, Swept Surface 2 - 42
 - Roughing and Finishing Passes 4 - 13
 - Roughing and Finishing Tools 4 - 10
 - RS-232 C
 - serial communications 1 - 11
 - RS-232-C
 - serial port 1 - 11
 - RS-274-D standard 3 - 1
 - Run Program softkey, Auto Mode 1 - 90
- S**
- S 3 - 21
 - S B and T Codes 4 - 119
 - S code 3 - 3
 - spindle speed 3 - 102
 - S Codes 4 - 119
 - S(%) field, Auto Mode 1 - 91
 - Safety Work Region field 1 - 53
 - sample screens - *xiii*
 - SAVE 1 - 27
 - SAVE ACTIVE PROGRAM ONLY, Autosave Settings 1 - 36
 - SAVE AS 1 - 27
 - SAVE AS USER DEFAULTS F4 softkey, Program Parameters 1 - 75
 - SAVE FREQUENCY, Autosave Settings 1 - 36
 - Save to Database softkey 1 - 72
 - Saving Variable Values to a File on the Control 4 - 109
 - Scale 2 - 71, 4 - 21
 - scaling
 - cancel G50 3 - 62
 - circular radius command 3 - 62
 - G51 3 - 62
 - ISNC methods 3 - 62
 - specify center point 3 - 62
 - specify, factor 3 - 62
 - SCREEN REFRESH RATE field, Graphics Settings 1 - 94
 - Screens 2 - 75, 4 - 21
 - screens
 - NC Configuration 3 - 56
 - NC, Tool Setup 3 - 58
 - SCREENSAVER TIMEOUT, User Interface Settings 1 - 35
 - search 3 - 13
 - Search Again (F3) softkey, search functions 3 - 13
 - Search Again softkey, Jump and Search Functions Menu, NC 3 - 13
 - Search Back (F2) softkey, search functions 3 - 13
 - Search Back softkey, Jump and Search Functions Menu, NC 3 - 13
 - Search for Text softkey, Jump and Search Functions Menu, NC 3 - 12
 - Search Forward (F1) softkey, search functions 3 - 13
 - Search Forward softkey, Jump and Search Functions Menu, NC 3 - 13
 - Segment field, 3D Mold Arc 4 - 8
 - Segment field, 3D Mold Blend Arc 4 - 9
 - Segment field, 3D Mold Contour 4 - 7
 - Segment field, 3D Mold Line 4 - 7
 - Segment field, Contour Arc 2 - 45
 - Segment field, Contour Blend Arc 2 - 47
 - Segment field, Contour End 2 - 51
 - Segment field, Helix data block 2 - 48
 - Segment field, Line segment 2 - 45
 - Segment field, Mill Contour block 2 - 43
 - Segments 2 - 3, 4 - 20
 - Segments, arc 2 - 8
 - Segments, line 2 - 6
 - Segments, programming 2 - 3
 - Select
 - 2 - 75, 4 - 20, 4 - 21
 - Select DRO softkey, Auto Mode 1 - 92
 - SELECT LANGUAGE F5 softkey, Utilities screen 1 - 45
 - SELECT MATERIAL FOR PART PROGRAM F5 softkey, Tool and Material Database screen 1 - 75
 - SELECT NEW FONT softkey 2 - 37
 - Select Point 4 - 20, 4 - 21
 - Select Range of Blocks softkey, NC Editor 3 - 13
 - Select Surface 1 - 82
 - Select Tool from List 2 - 5
 - SELECT VIEW F2 softkey, graphics screen 1 - 95
 - SelectSurface Finish Quality 1 - 75, 1 - 82
 - Sequence Number 3 - 2
 - Serial I/O 1 - 45, 1 - 47
 - Serial Port Settings 1 - 44, 4 - 157
 - SERIAL PORT SETTINGS F1 softkey, Utili-

- ties screen [1 - 34](#)
- serial ports (see ports) [1 - 12](#)
- Servo Power [1 - 16](#)
- Set
 - [4 - 20](#)
- Set End Marker softkey, NC Editor [3 - 16](#)
- Set Start Marker softkey, NC Editor [3 - 16](#)
- Set Tool Zero softkey [1 - 59](#)
- Set Wireframe End Marker softkey, NC Editor [3 - 16](#)
- Set Wireframe Start Marker softkey, NC Editor [3 - 16](#)
- SFQ [1 - 82](#)
- Shank Diameter field [1 - 60](#)
- Shank Diameter field, Advanced Tool Settings [1 - 64](#)
- Shape Angle field, Diamond data block [2 - 32](#)
- Shape Angle field, Hexagon data block [2 - 34](#)
- SHOW ALL FILE TYPES, User Interface Settings [1 - 35](#)
- SHOW F-ERROR field, Graphics Settings [1 - 93](#)
- SHOW GRAPHICS field, Graphics Settings [1 - 93](#)
- SHOW PECKS OF 3D SURFACES field, Graphics Settings [1 - 93](#)
- SHOW PECKS OF CONTOURS field, Graphics Settings [1 - 93](#)
- SHOW RUNTIME TOOL field, Graphics Settings [1 - 93](#)
- SHOW SFQ field, Graphics Settings [1 - 93](#)
- SHUTDOWN CONTROL F6 softkey, Utilities screen [1 - 45](#)
- SINGLE STEP F3 softkey, graphics screen [1 - 95](#)
- skip function G31 [3 - 49](#)
- Skip List field, Bolt Circle data block [2 - 64](#)
- SNAPSHOT F7 softkey, graphics screen [1 - 95](#)
- Softkey [4 - 19](#), [4 - 20](#), [4 - 21](#)
- SOFTKEY MENU POSITION, User Interface Settings [1 - 34](#)
- softkeys [1 - 5](#), [1 - 6](#), [1 - 19](#), [1 - 20](#)
- software options [1 - 2](#)
- Special Characters [3 - 3](#)
- special function keys [1 - 6](#)
- Special softkey [4 - 24](#)
- Specify [3 - 21](#), [3 - 22](#)
- Specifying Subprogram Iterations [4 - 115](#)
- Speed (RPM) field [1 - 61](#)
- Speed (RPM) field, 3D Mold Paratmeters [4 - 6](#)
- Speed (RPM) field, Bore and Ream Operations [2 - 55](#)
- Speed (RPM) field, Boring and Reaming Operations [2 - 62](#)
- Speed (RPM) field, Diamond data block [2 - 32](#)
- Speed (RPM) field, Ellipse data block [2 - 23](#)
- Speed (RPM) field, Face Milling [2 - 21](#)
- Speed (RPM) field, Gun Drill data block [2 - 59](#)
- Speed (RPM) field, HD3 Lettering [2 - 36](#)
- Speed (RPM) field, Hexagon data block [2 - 34](#)
- Speed (RPM) field, Mill Circle data block [2 - 22](#)
- Speed (RPM) field, Mill Contour block [2 - 44](#)
- Speed (RPM) field, Mill Frame data block [2 - 26](#)
- Speed (RPM) field, Mill triangle data block [2 - 29](#)
- SPEED (RPM) field, Swept Surface [2 - 40](#)
- Speed (RPM) field, True-Type Letting [2 - 37](#)
- speed and feed formula, tap [3 - 82](#)
- SPEED field, Advanced Tool Settings [1 - 65](#)
- Speed field, Tap Operations [2 - 60](#)
- Spindle [1 - 1](#), [1 - 13](#)
- spindle
 - activate [3 - 101](#)
 - control [1 - 7](#)
 - direction [3 - 101](#)
 - manual speed [1 - 10](#)
 - off, M05 [3 - 107](#)
 - oriented stop M19 [3 - 109](#)
 - speed, S code [3 - 102](#)
 - start clockwise, M03 [3 - 107](#)
 - start counterclockwise, M04 [3 - 107](#)
 - tool removal [1 - 14](#)
- Spindle field, Auto Mode [1 - 90](#)
- Spindle Load Monitor field, Auto Mode [1 - 91](#)
- Spindle Motor [1 - 1](#)
- Spindle Speed dial [1 - 7](#)
- Spindle Stop field, Gun Drill data block [2 - 59](#)
- Spindle Unclamp button [1 - 14](#)
- Spindle, Tool Library [1 - 73](#)
- Spiral, in Swept Surface [2 - 38](#)
- Spotface [2 - 53](#), [2 - 56](#)
- Standard Calculator [1 - 35](#)
- Start Angle field, 3D Mold Paratmeters [4 - 3](#)
- Start Angle field, Bolt Circle data block [2 - 64](#)
- Start Angle field, Loop Angular data block

- [2 - 69](#)
 - Start Angle field, Loop Rotate data block [2 - 70](#)
 - Start Block field [1 - 85](#), [1 - 87](#)
 - Start Block softkey [1 - 86](#)
 - Start Cycle console button [1 - 10](#)
 - starting new part program [3 - 9](#)
 - Status Address [3 - 21](#), [3 - 22](#)
 - Status Bar [1 - 21](#)
 - Status field, Serial I/O [1 - 47](#)
 - Status History [1 - 49](#)
 - STEP CONNECT TYPE field, Swept Surface [2 - 39](#)
 - Step Size field, 3D Mold Parameters [4 - 5](#)
 - STEP SIZE field, Swept Surface [2 - 41](#)
 - Stock Allowance field, 3D Mold Parameters [4 - 6](#)
 - STOCK ALLOWANCE field, Swept Surface [2 - 40](#)
 - Stock Geometry [1 - 56](#)
 - STOCK GEOMETRY F1
 - Part Setup [1 - 56](#)
 - Stock Geometry screen [1 - 56](#)
 - BORDER SIZE [1 - 57](#)
 - BOX LENGTH (X, Y, Z) [1 - 57](#)
 - CYLINDER [1 - 57](#)
 - MANUAL BORDER SIZING [1 - 57](#)
 - MANUAL STOCK SIZING [1 - 56](#)
 - STOCK TYPE [1 - 57](#)
 - X REF POSITION [1 - 57](#)
 - Y REF POSITION [1 - 57](#)
 - Z REF POSITION [1 - 57](#)
 - ZERO REF [1 - 57](#)
 - STOCK OUTLINE field, Graphics Settings [1 - 93](#)
 - STOCK OUTLINE, Graphics Settings [1 - 56](#)
 - STOCK TYPE field [1 - 57](#)
 - Stop Bits field, Serial Port Settings [1 - 44](#)
 - Stop Cycle console button [1 - 10](#)
 - Stop field, Comment data block [2 - 79](#)
 - Stop field, Position data block [2 - 74](#)
 - stop program
 - (planned), M01 [3 - 106](#)
 - M00 [3 - 106](#)
 - Store Calculated Value [2 - 5](#)
 - Store Calculated Value softkey [4 - 7](#), [4 - 8](#)
 - STORE MACHINE POSITION (F7) softkey,
 - Part Setup screen [4 - 36](#)
 - Store Position key [1 - 9](#)
 - Stylus Length field, Advanced Tool Settings [1 - 64](#)
 - subprogram
 - call, M98 [3 - 113](#)
 - commands [3 - 66](#)
 - jump (return from) M99 [3 - 114](#)
 - Subprogram Variables [3 - 21](#)
 - Macro Mode [3 - 21](#)
 - Subprograms [4 - 112](#)
 - Supplier, Advanced Tool Settings [1 - 67](#)
 - surface finish G05.1 [3 - 40](#)
 - Surface Finish Quality [1 - 82](#)
 - Surface Finish Quality, G05.3 [3 - 40](#)
 - Surface Speed (FPM) field [1 - 61](#)
 - SURFACE SPEED field, Advanced Tool Settings [1 - 65](#)
 - Sweep Angle field, Helix data block [2 - 48](#)
 - Swept Surface [2 - 38](#), [2 - 39](#)
 - Syntax Checking field, NC Editor [3 - 7](#)
 - system
 - principles [3 - 1](#)
 - SYSTEM CONFIGURATION F1 softkey, Utilities screen [1 - 32](#)
 - System variables, NC [3 - 19](#)
 - System Variances [4 - 127](#)
- ## T
- [T 3 - 21](#)
 - T code [3 - 103](#)
 - T Codes [4 - 119](#)
 - Table [1 - 1](#)
 - Tag Block softkey, Search and Edit Menu, NC [3 - 11](#)
 - Tap Operations [2 - 60](#)
 - Tap softkey [2 - 60](#)
 - tapping cycle [3 - 97](#)
 - tapping, G84 [3 - 82](#)
 - Templates, Tool Setup [1 - 68](#)
 - Temporary Parameter Change [2 - 5](#)
 - TEXT
 - True-Type Lettering [2 - 37](#)
 - Text field, HD3 Lettering [2 - 36](#)
 - TEXT field, True-Type Lettering [2 - 37](#)
 - Text screen [1 - 5](#)
 - Text screen, location on console [1 - 3](#)
 - Thread Diameter field [1 - 60](#)
 - Thread Diameter field, Advanced Tool Settings [1 - 64](#)
 - Threads per inch field, Advanced Tool Settings [1 - 64](#)
 - time [1 - 21](#)
 - Tip Angle field, Advanced Tool Settings [1 - 64](#)
 - Tip Diameter field, Advanced Tool Settings [1 - 64](#)
 - Tip Length field, Advanced Tool Settings [1 - 64](#)
 - Toggle Rapid Override Enable softkey, Auto Mode [1 - 92](#)
 - Toggle Units softkey [3 - 51](#)

- Tool
 - [2 - 75, 4 - 19](#)
- tool
 - change, M06 [3 - 108](#)
 - functions, D, L, and T codes [3 - 103](#)
 - holder, orientation hole [1 - 13](#)
 - in Spindle [1 - 13](#)
 - initiate change, NC Parameters, M6 [3 - 108](#)
 - loading, machine spindle [1 - 13](#)
 - removal from ATC magazine [1 - 15](#)
 - removal from spindle [1 - 14](#)
- Tool & Material Library [1 - 73](#)
- Tool and Material Database [1 - 74](#)
- Tool and Part Quality Verification [4 - 64](#)
- Tool Center Point Management, M128 & M129 [3 - 114](#)
- tool changer [1 - 13](#)
 - orientation key [1 - 13](#)
- Tool Changes [2 - 75](#)
- Tool Diameter field, 3D Mold Parameters [4 - 6](#)
- Tool Diameter field, Back Spotface [2 - 63](#)
- Tool Diameter field, Bore and Ream Operations [2 - 55](#)
- Tool Diameter field, Boring and Reaming Operations [2 - 62](#)
- Tool Diameter field, Ellipse data block [2 - 24](#)
- Tool Diameter field, Face Milling [2 - 21](#)
- Tool Diameter field, Gun Drill data block [2 - 59](#)
- Tool Diameter field, HD3 Lettering [2 - 36](#)
- Tool Diameter field, Mill Circle data block [2 - 22](#)
- Tool Diameter field, Mill Contour block [2 - 44](#)
- Tool Diameter field, Mill Frame data block [2 - 26](#)
- Tool Diameter field, Tap Operations [2 - 60](#)
- Tool field, 3D Mold Parameters [4 - 1](#)
- Tool field, Back Spotface [2 - 62](#)
- Tool field, Bore and Ream Operations [2 - 54](#)
- Tool field, Boring and Reaming Operations [2 - 61](#)
- Tool field, Diamond data block [2 - 32](#)
- Tool field, Ellipse data block [2 - 23](#)
- Tool field, Face Milling [2 - 20](#)
- Tool field, Gun Drill data block [2 - 59](#)
- Tool field, HD3 Lettering [2 - 35](#)
- Tool field, Hexagon data block [2 - 34](#)
- Tool field, Mill Circle data block [2 - 21](#)
- Tool field, Mill Contour block [2 - 43](#)
- Tool field, Mill Frame data block [2 - 24](#)
- Tool field, Mill triangle data block [2 - 29](#)
- Tool field, Position data block [2 - 74, 2 - 75](#)
- TOOL field, Swept Surface [2 - 40](#)
- Tool field, Tap Operations [2 - 60](#)
- Tool field, True-Type Letting [2 - 37](#)
- Tool Geometry [1 - 63](#)
- Tool Home softkey [1 - 58](#)
- Tool in Spindle field, Auto Mode [1 - 90](#)
- TOOL IN SPINDLE field, Tool Library screen [1 - 73](#)
- Tool Information and Printing [1 - 37](#)
- TOOL INFORMATION PRINTING F6 softkey, Tool Utilities and Settings [1 - 37](#)
- Tool Length field, Advanced Tool Settings [1 - 64](#)
- tool length offset
 - cutter compensation [3 - 53](#)
 - G43, G44, and G49 [3 - 57](#)
 - table [3 - 51](#)
- Tool Length Tolerance field, NC Parameters [3 - 17](#)
- Tool Library [1 - 73](#)
 - Auto [1 - 73](#)
 - Manual [1 - 73](#)
 - Spindle [1 - 73](#)
- Tool Management softkey, Manual Mode [1 - 92](#)
- Tool Matching [1 - 71](#)
- Tool Matching Results [1 - 71](#)
- Tool Number field [1 - 59](#)
- tool offset [3 - 51](#)
 - assigning [3 - 42](#)
 - radius [3 - 59](#)
- tool offsets
 - setting with G10 [3 - 41](#)
 - setting with G10 and L3 [3 - 42](#)
 - setting with G10 and P, R [3 - 41](#)
 - setting with G10 and T, H, D [3 - 41](#)
- Tool Offsets softkey [1 - 58](#)
- TOOL PATH field, Graphics Settings [1 - 93](#)
- tool positioning
 - G00 [3 - 32](#)
 - G01 [3 - 33](#)
 - G02 [3 - 34](#)
 - G02.4 and G03.4 [3 - 38](#)
 - G03 [3 - 34](#)
- Tool Probe Calibration [4 - 37](#)
- Tool Probe Setup Parameters [4 - 35](#)
- tool probe, select signal, M27 [3 - 110](#)
- Tool Probing softkey [1 - 59](#)
- tool radius offset
 - cutter compensation [3 - 53](#)
 - G45, G46, G47, G48 [3 - 59](#)
 - table [3 - 51](#)
- Tool Removal [4 - 146](#)

TOOL REVIEW

- Input Screen *1 - 51*
 - Tool Setup *1 - 58, 4 - 19*
 - Tool Setup Fields *1 - 59, 1 - 62*
 - Coolant *1 - 61*
 - Cutting Time *1 - 62*
 - Diameter *1 - 60*
 - Diameter Wear *1 - 62*
 - Feed *1 - 62*
 - Feed/Flute (Tooth) *1 - 62*
 - Flutes *1 - 61*
 - Location *1 - 60*
 - Shank Diameter *1 - 60*
 - Speed (RPM) *1 - 61*
 - Surface Speed (FPM) *1 - 61*
 - Thread Diameter *1 - 60*
 - Tool Number *1 - 59*
 - Tool Type *1 - 60*
 - TPI (or PITCH) *1 - 61*
 - Zero Calibration *1 - 60*
 - Tool Setup Probing Fields *4 - 47*
 - Tool Setup Probing Softkeys *4 - 46*
 - Tool Setup softkey
 - Tool Review screen *1 - 70*
 - Tool Setup Softkeys *1 - 58, 1 - 59*
 - Advanced Tool Settings *1 - 59*
 - Change Tool Number *1 - 59*
 - Delete Tool *1 - 58*
 - Part Program Tool Review *1 - 59*
 - Part Programming *1 - 58*
 - Part Setup *1 - 58*
 - Program Parameters *1 - 59*
 - Set Tool Zero *1 - 59*
 - Tool Home *1 - 58*
 - Tool Offsets *1 - 58*
 - Tool Probing *1 - 59*
 - Validate Zero Calibration *1 - 59*
 - Tool Setup Templates *1 - 68*
 - Tool Type Checking *2 - 5*
 - Tool Type field *1 - 60*
 - Tool Type field, 3D Mold Parameters *4 - 6*
 - Tool Type field, Back Spotface *2 - 63*
 - Tool Type field, Bore and Ream Operations *2 - 55*
 - Tool Type field, Boring and Reaming Operations *2 - 62*
 - Tool Type field, Ellipse data block *2 - 24*
 - Tool Type field, Face Milling *2 - 21*
 - Tool Type field, Gun Drill data block *2 - 59*
 - Tool Type field, HD3 Lettering *2 - 36*
 - Tool Type field, Mill Circle data block *2 - 22*
 - Tool Type field, Mill Contour block *2 - 44*
 - Tool Type field, Mill Frame data block *2 - 26*
 - Tool Type field, Tap Operations *2 - 60*
 - Tool Type Setup/Advanced Tool Settings
 - 1 - 74*
 - Tool Utilities and Settings *1 - 36*
 - Tool Wear Detection Data Block *4 - 67*
 - Toolbar *4 - 19*
 - Toolpath and Solid Graphics *1 - 94*
 - Toolpath Graphics *1 - 94*
 - Touch Tool and Part Probe Calibration *4 - 39*
 - Touch Tool Probe Calibration *4 - 38*
 - touchscreen *1 - 19*
 - Touchscreen softkeys, location on console *1 - 3*
 - TPI (or PITCH) field *1 - 61*
 - Trackball, location on console *1 - 3*
 - Transfer *1 - 30*
 - transfer files
 - jump drive *1 - 13*
 - Triangle Data Block *2 - 28*
 - Type field, 3D Mold Parameters *4 - 1*
 - TYPE field, Swept Surface *2 - 39*
 - TYPE OF CORNERS field, Swept Surface *2 - 39*
 - Types *3 - 21, 3 - 22*
- ## U
- Ultimax 4 and Max consoles *1 - 2*
 - Ultimax 4 console panel groups *1 - 3*
 - Ultimax 4 panel group *1 - 3*
 - Ultimax classic edit mode *1 - 19*
 - Ultimax Classic Math Assist *1 - 35*
 - UltiNet *4 - 156*
 - UltiNet FTP Client *4 - 156*
 - UltiNet FTP Server *4 - 156*
 - UltiPocket *2 - 18*
 - UltiPockets Option *4 - 14*
 - unit of measure *1 - 21*
 - units of measure
 - G70 BNC, inch *3 - 74*
 - G71 BNC, metric *3 - 74*
 - ISNC G20, inch *3 - 47*
 - ISNC G21, metric *3 - 47*
 - Units of Measure (BNC G70, G71) *3 - 74*
 - UNLOAD PROGRAM F5 *1 - 52*
 - USB port *1 - 13*
 - USE CHORD ERROR FROM PROGRAM? field,
 - Graphics Settings *1 - 93*
 - USE CUSP HEIGHT field, Swept Surface *2 - 39*
 - Use Editing File softkey, Auto Mode *1 - 89*
 - USE TOOL TYPE CHECKING, Tool Utilities and Settings *1 - 37*
 - User Defined Codes *4 - 118*
 - User Defined G and M Code Example *4 - 125*

User Defined S B and T Code Example 4 - 141

User defined value 1 - 66

USER INTERFACE SETTINGS softkey, Utilities screen 1 - 34

User Name field 4 - 157

User Name field, FTP Server Settings 1 - 44

USER PREFERENCES softkey, Utilities screen 1 - 34

using this manual - *xiii*

Utilities 1 - 32

V

Vacant Variables 4 - 109

Validate Zero Calibration softkey 1 - 59

Value Address 3 - 21

Values 3 - 21, 3 - 22, 4 - 20

 Default Radius 4 - 20

Variable Example 4 - 110

Variable Expressions 4 - 109

Variables 3 - 21, 4 - 106

Variables, global 3 - 19

Variables, Local 3 - 19

Variables, NC 3 - 19

Variables, system 3 - 19

View 4 - 20, 4 - 21

 Fit 4 - 21

W

Warm Up Machine softkey, Manual Mode 1 - 92

Warming Up the Machine 1 - 16

Warm-Up Axis Feed Rate 1 - 43

Warm-Up Max Spindle Speed 1 - 43

Warm-Up Speed Steps 1 - 43

WARN BEFORE SAVING IN OLD FORMAT, User Interface Settings 1 - 35

washdown coolant system M codes 3 - 113

Way Cover 1 - 1

WHILE Loops 4 - 140

Window Select 4 - 20

WinMax

 4 - 19

 use 4 - 19

WINMAX UPTIME F3 softkey, Utilities screen 1 - 45

work coordinate systems setting with G10 L2 3 - 41

Work Offsets 1 - 55

Work Offsets F1 softkey, Part Setup screen 3 - 70

Worklight On/Off softkey, Auto Mode 1 - 92

WRITE PROTECTION field, in Program Properties 1 - 28

X

X Axis 4 - 25

X BASE

 True-Type Lettering 2 - 37

X BASE field, True-Type Letting 2 - 37

X Center field, 3D Arc 2 - 49

X Center field, 3D Mold Arc 4 - 8

X Center field, 3D Mold Blend Arc 4 - 9

X Center field, Bolt Circle data block 2 - 64

X Center field, Contour Arc 2 - 46

X Center field, Contour Blend Arc 2 - 47

X Center field, Diamond data block 2 - 31

X Center field, Ellipse data block 2 - 23

X Center field, Helix data block 2 - 48

X Center field, Hexagon data block 2 - 34

X Center field, Loop Angular data block 2 - 69

X Center field, Loop Rotate data block 2 - 70

X Center field, Mill Circle data block 2 - 21

X Center field, Mill triangle data block 2 - 28

X code, X axis hole position 3 - 99

X Corner field, Face Milling 2 - 20

X Corner field, Mill Frame data block 2 - 25

X Distance field, Loop Linear data block 2 - 68

X Distance field, Loop Rectangular data block 2 - 67

X End field, 3D Arc 2 - 49

X End field, 3D Mold Arc 4 - 8

X End field, 3D Mold Blend Arc 4 - 9

X End field, 3D Mold Line 4 - 7

X End field, Contour Arc 2 - 46

X End field, Contour Blend Arc 2 - 47

X End field, Helix data block 2 - 48

X End field, Line segment 2 - 45

X field, Mirror Image 2 - 73

X field, Position data block 2 - 74

X LENGTH

 True-Type Lettering 2 - 37

X Length field, Face Milling 2 - 20

X Length field, Mill Frame data block 2 - 25

X LENGTH field, True-Type Lettering 2 - 37

X Number field, Loop Rectangular data block 2 - 67

X Offset softkey 1 - 86

X Point field, 3D Arc 2 - 49

X Radius field, Ellipse data block 2 - 23

X REF POSITION field 1 - 57

X Reference field, Loop Angular data block 2 - 69

X Reference field, Pattern Scale data block 2 - 72

X Scale field, Pattern Scale data block 2 -

72

X Start field, 3D Mold Arc [4 - 8](#)
X Start field, 3D Mold Blend Arc [4 - 9](#)
X Start field, 3D Mold Contour [4 - 7](#)
X Start field, 3D Mold Line [4 - 8](#)
X Start field, Contour Arc [2 - 46](#)
X Start field, Contour Blend Arc [2 - 47](#)
X Start field, HD3 Lettering [2 - 35](#)
X Start field, Helix data block [2 - 48](#)
X Start field, Line segment [2 - 45](#)
X Start field, Mill Contour block [2 - 43](#)
XY Angle field, 3D Mold Line [4 - 7](#)
XY Angle field, Line segment [2 - 45](#)
XY Length field, 3D Mold Line [4 - 7](#)
XY Length field, Line segment [2 - 45](#)
XY plane selection, G17 [3 - 43](#)
XZ Angle field, 3D Mold Line [4 - 7](#)
XZ Length field, 3D Mold Line [4 - 7](#)
XZ Plane Selection, G18 [3 - 44](#)
XZ plane selection, G18 [3 - 44](#)

Y

Y

[3 - 21](#)Y Axis [4 - 25](#)

Y BASE

True-Type Lettering [2 - 37](#)Y BASE field, True-Type Letting [2 - 37](#)Y Center field, 3D Arc [2 - 49](#)Y Center field, 3D Mold Arc [4 - 8](#)Y Center field, 3D Mold Blend Arc [4 - 9](#)Y Center field, Bolt Circle data block [2 - 64](#)Y Center field, Contour Arc [2 - 46](#)Y Center field, Contour Blend Arc [2 - 47](#)Y Center field, Diamond data block [2 - 31](#)Y Center field, Ellipse data block [2 - 23](#)Y Center field, Helix data block [2 - 48](#)Y Center field, Hexagon data block [2 - 34](#)Y Center field, Loop Angular data block [2 - 69](#)Y Center field, Loop Rotate data block [2 - 70](#)Y Center field, Mill Circle data block [2 - 21](#)Y Center field, Mill triangle data block [2 - 28](#)Y code, Y axis hole position [3 - 99](#)Y Corner field, Face Milling [2 - 20](#)Y Corner field, Mill Frame data block [2 - 25](#)Y Distance field, Loop Linear data block [2 - 68](#)Y Distance field, Loop Rectangular data block [2 - 67](#)Y End field, 3D Arc [2 - 49](#)Y End field, 3D Mold Arc [4 - 8](#)Y End field, 3D Mold Blend Arc [4 - 9](#)Y End field, 3D Mold Line [4 - 7](#)Y End field, 3D Mold Paratmeters [4 - 3](#)Y End field, Contour Arc [2 - 46](#)Y End field, Contour Blend Arc [2 - 47](#)Y End field, Helix data block [2 - 48](#)Y End field, Line segment [2 - 45](#)Y field, Mirror Image [2 - 73](#)Y field, Position data block [2 - 74](#)

Y LENGTH

True-Type Lettering [2 - 37](#)Y Length field, Face Milling [2 - 20](#)Y Length field, Mill Frame data block [2 - 25](#)Y LENGTH field, True-Type Letting [2 - 37](#)

Y MAPPING

True-Type Lettering [2 - 36](#)Y MAPPING field, True-Type Letting [2 - 36](#)Y Number field, Loop Rectangular data block [2 - 67](#)Y Offset softkey [1 - 86](#)Y Point field, 3D Arc [2 - 49](#)Y Radius field, Ellipse data block [2 - 23](#)Y REF POSITION field [1 - 57](#)Y Reference field, Loop Angular data block [2 - 69](#)Y Reference field, Pattern Scale data block [2 - 72](#)Y Scale field, Pattern Scale data block [2 - 72](#)Y Start field, 3D Mold Arc [4 - 8](#)Y Start field, 3D Mold Blend Arc [4 - 9](#)Y Start field, 3D Mold Contour [4 - 7](#)Y Start field, 3D Mold Line [4 - 8](#)Y Start field, 3D Mold Paratmeters [4 - 3](#)Y Start field, Contour Arc [2 - 46](#)Y Start field, Contour Blend Arc [2 - 47](#)Y Start field, HD3 Lettering [2 - 35](#)Y Start field, Helix data block [2 - 48](#)Y Start field, Line segment [2 - 45](#)Y Start field, Mill Contour block [2 - 43](#)Y-Axis Safety Position [1 - 41](#)YZ Plane Selection, G19 [3 - 46](#)YZ plane selection, G19 [3 - 46](#)**Z**

Z

[3 - 21](#)Z Axis [4 - 25](#)Z axis home position, M25 BNC [3 - 110](#)

Z BOTTOM

True-Type Lettering [2 - 37](#)Z Bottom field, Back Spotface [2 - 62](#)Z Bottom field, Bore and Ream Operations [2 - 55](#)

- Z Bottom field, Boring and Reaming Operations [2 - 61](#)
- Z Bottom field, Diamond data block [2 - 32](#)
- Z Bottom field, Ellipse data block [2 - 23](#)
- Z Bottom field, Face Milling [2 - 20](#)
- Z Bottom field, Gun Drill data block [2 - 59](#)
- Z Bottom field, HD3 Lettering [2 - 36](#)
- Z Bottom field, Hexagon data block [2 - 34](#)
- Z Bottom field, Mill Circle data block [2 - 22](#)
- Z Bottom field, Mill Contour block [2 - 44](#)
- Z Bottom field, Mill Frame data block [2 - 26](#)
- Z Bottom field, Mill triangle data block [2 - 28](#)
- Z Bottom field, Tap Operations [2 - 60](#)
- Z BOTTOM field, True-Type Letting [2 - 37](#)
- Z Center field, 3D Arc [2 - 49](#)
- Z Center field, 3D Mold Arc [4 - 8](#)
- Z Center field, 3D Mold Blend Arc [4 - 9](#)
- Z Center field, Contour Arc [2 - 46](#)
- Z Clearance field, Back Spotface [2 - 63](#)
- Z code, Z bottom location [3 - 99](#)
- Z Depth field, Back Spotface [2 - 63](#)
- Z End field, 3D Arc [2 - 49](#)
- Z End field, 3D Mold Arc [4 - 8](#)
- Z End field, 3D Mold Blend Arc [4 - 9](#)
- Z End field, 3D Mold Line [4 - 7](#)
- Z End field, Contour Arc [2 - 46](#)
- Z End field, Helix data block [2 - 48](#)
- Z End field, Line segment [2 - 45](#)
- Z field, Position data block [2 - 74](#)
- Z Offset softkey [1 - 86](#)
- Z Plunge field, Back Spotface [2 - 62](#)
- Z Point field, 3D Arc [2 - 49](#)
- Z REF POSITION field [1 - 57](#)
- Z Reference field, Pattern Scale data block [2 - 72](#)
- Z Retract field, Back Spotface [2 - 63](#)
- Z ROUGHING field, Swept Surface [2 - 42](#)
- Z Scale field, Pattern Scale data block [2 - 72](#)
- Z START
 - True-Type Lettering [2 - 37](#)
- Z Start field, 3D Mold Arc [4 - 8](#)
- Z Start field, 3D Mold Blend Arc [4 - 9](#)
- Z Start field, 3D Mold Contour [4 - 7](#)
- Z Start field, 3D Mold Line [4 - 8](#)
- Z Start field, 3D Mold Parameters [4 - 5](#)
- Z Start field, Back Spotface [2 - 62](#)
- Z Start field, Bore and Ream Operations [2 - 54](#)
- Z Start field, Boring and Reaming Operations [2 - 61](#)
- Z Start field, Contour Arc [2 - 46](#)
- Z Start field, Diamond data block [2 - 32](#)
- Z Start field, Ellipse data block [2 - 23](#)
- Z Start field, Face Milling [2 - 20](#)
- Z Start field, Gun Drill data block [2 - 59](#)
- Z Start field, HD3 Lettering [2 - 36](#)
- Z Start field, Helix data block [2 - 48](#)
- Z Start field, Hexagon data block [2 - 34](#)
- Z Start field, Line segment [2 - 45](#)
- Z Start field, Mill Circle data block [2 - 22](#)
- Z Start field, Mill Contour block [2 - 44](#)
- Z Start field, Mill Frame data block [2 - 26](#)
- Z Start field, Mill triangle data block [2 - 28](#)
- Z START field, Swept Surface [2 - 39](#)
- Z Start field, Tap Operations [2 - 60](#)
- Z START field, True-Type Letting [2 - 37](#)
- Z Start parameter [2 - 75](#)
- Z Top Feed field, Gun Drill data block [2 - 59](#)
- Z Top field, Gun Drill data block [2 - 59](#)
- Z-Axis Servo [1 - 1](#)
- ZERO CAL (LENGTH) TOLERANCE field, Probing Parameters [1 - 82](#)
- Zero Calibration [1 - 69](#)
- zero calibration [3 - 58](#)
- Zero Calibration field [1 - 60](#)
- ZERO REF field [1 - 57](#)
- ZOOM F3 softkey, graphics screen [1 - 95](#)
- ZOOM IN F1 softkey, graphics screen [1 - 95](#)
- Zoom Out [4 - 20](#), [4 - 21](#)
- ZOOM OUT F2 softkey, graphics screen [1 - 95](#)
- Zoom Window [4 - 20](#), [4 - 21](#)
- Zoom Window softkey [4 - 21](#)
 - Use [4 - 21](#)